

SOLIDWORKS Document Manager API (.NET) — Reference (10/19) ISwDMDimXpertGeometricTolerance- ISwDMDimXpertOrientationGeoTol

SOLIDWORKS API Documentation (converted from CHM)

ISwDMDimXpertGeometricTolerance (Type)

ISwDMDimXpertGeometricTolerance Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertGeometricTolerance Interface

Allows you to access general information about DimXpert geometric tolerances such as circularity, orientation, flatness, etc.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertGeometricTolerance

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [ISwDMDimXpertGeometricTolerance](#)

C#

public interface ISwDMDimXpertGeometricTolerance

C++/CLI

public interface class ISwDMDimXpertGeometricTolerance

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertGeometricTolerance](#).

Example

[Get DimXpert Tolerance5 \(VB.NET\)](#)
[Get DimXpert Tolerance5 \(C#\)](#)

Remarks

This interface is the base class for several more specific interfaces (see the **See Also** section). You can access more general information from [ISwDMDimXpertAnnotation](#). Use the [ISwDMDimXpertAnnotation::type](#) property to find out which specific interface is needed to acquire more information for a given tolerance type.

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::!GetAnnotations](#)

See Also

- [ISwDMDimXpertGeometricTolerance Members](#)
- [SolidWorks.Interop.swdocumentmgr.Namespace](#)
- [ISwDMDimXpertAngularityGeoTol Interface](#)
- [ISwDMDimXpertCircularityGeoTol Interface](#)
- [ISwDMDimXpertCircularRunoutGeoTol Interface](#)
- [ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
- [ISwDMDimXpertCompositePositionGeoTol Interface](#)
- [ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
- [ISwDMDimXpertConcentricityGeoTol Interface](#)
- [ISwDMDimXpertCylindricityGeoTol Interface](#)
- [ISwDMDimXpertFlatnessGeoTol Interface](#)
- [ISwDMDimXpertLineProfileGeoTol Interface](#)
- [ISwDMDimXpertOrientationGeoTol Interface](#)
- [ISwDMDimXpertParallelismGeoTol Interface](#)
- [ISwDMDimXpertPerpendicularityGeoTol Interface](#)
- [ISwDMDimXpertPositionGeoTol Interface](#)
- [ISwDMDimXpertStraightnessGeoTol Interface](#)
- [ISwDMDimXpertSurfaceProfileGeoTol Interface](#)
- [ISwDMDimXpertSymmetryGeoTol Interface](#)
- [ISwDMDimXpertTangencyGeoTol Interface](#)
- [ISwDMDimXpertTotalRunoutGeoTol Interface](#)

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertGeometricTolerance Interface

For a list of all members of this type, see [ISwDMDimXpertGeometricTolerance members](#).

 Public Methods

Name	Description
 GetPrimaryDatumCount	Gets the number of primary datums in this DimXpert geometric tolerance.
 GetPrimaryDatumModifiers	Gets all of the material condition modifiers of the primary datum in this DimXpert geometric tolerance.
 GetPrimaryDatums	Gets all of the primary datums in this DimXpert geometric tolerance.
 GetSecondaryDatumCount	Gets the number of secondary datums in this DimXpert geometric tolerance.
 GetSecondaryDatumModifiers	Gets all of the material condition modifiers of the secondary datum in this DimXpert geometric tolerance.
 GetSecondaryDatums	Gets all of the secondary datums in this DimXpert geometric tolerance.
 GetTertiaryDatumCount	Gets the number of tertiary datums in this DimXpert geometric tolerance.
 GetTertiaryDatumModifiers	Gets all of the material condition modifiers of the tertiary datum in this DimXpert geometric tolerance.
 GetTertiaryDatums	Gets all of the tertiary datums in this DimXpert geometric tolerance.
 IGetPrimaryDatumModifiers	Gets all of the material condition modifiers of the primary datum in this DimXpert geometric tolerance.
 IGetPrimaryDatums	Gets all of the primary datums in this DimXpert geometric tolerance.
 IGetSecondaryDatumModifiers	Gets all of the material condition modifiers of the secondary datum in this DimXpert geometric tolerance.
 IGetSecondaryDatums	Gets all of the secondary datums in this DimXpert geometric tolerance.
 IGetTertiaryDatumModifiers	Gets all of the material condition modifiers of the tertiary datum in this DimXpert geometric tolerance.
 IGetTertiaryDatums	Gets all of the tertiary datums in this DimXpert geometric tolerance.

[Top](#)

 See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDimXpertAngularityGeoTol Interface](#)
[ISwDMDimXpertCircularityGeoTol Interface](#)
[ISwDMDimXpertCircularRunoutGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertConcentricityGeoTol Interface](#)
[ISwDMDimXpertCylindricityGeoTol Interface](#)
[ISwDMDimXpertFlatnessGeoTol Interface](#)
[ISwDMDimXpertLineProfileGeoTol Interface](#)
[ISwDMDimXpertOrientationGeoTol Interface](#)
[ISwDMDimXpertParallelismGeoTol Interface](#)
[ISwDMDimXpertPerpendicularityGeoTol Interface](#)
[ISwDMDimXpertPositionGeoTol Interface](#)
[ISwDMDimXpertStraightnessGeoTol Interface](#)
[ISwDMDimXpertSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertSymmetryGeoTol Interface](#)
[ISwDMDimXpertTangencyGeoTol Interface](#)
[ISwDMDimXpertTotalRunoutGeoTol Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertGeometricTolerance Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertGeometricTolerance Interface

The following tables list the members exposed by [ISwDMDimXpertGeometricTolerance](#).

 Public Properties

Name	Description
 Tolerance	Gets the value of this DimXpert geometric tolerance.

[Top](#)

 Public Methods

Name	Description
 GetPrimaryDatumCount	Gets the number of primary datums in this DimXpert geometric tolerance.
 GetPrimaryDatumModifiers	Gets all of the material condition modifiers of the primary datum in this DimXpert geometric tolerance.
 GetPrimaryDatums	Gets all of the primary datums in this DimXpert geometric tolerance.
 GetSecondaryDatumCount	Gets the number of secondary datums in this DimXpert geometric tolerance.
 GetSecondaryDatumModifiers	Gets all of the material condition modifiers of the secondary datum in this DimXpert geometric tolerance.
 GetSecondaryDatums	Gets all of the secondary datums in this DimXpert geometric tolerance.
 GetTertiaryDatumCount	Gets the number of tertiary datums in this DimXpert geometric tolerance.
 GetTertiaryDatumModifiers	Gets all of the material condition modifiers of the tertiary datum in this DimXpert geometric tolerance.
 GetTertiaryDatums	Gets all of the tertiary datums in this DimXpert geometric tolerance.
 IGetPrimaryDatumModifiers	Gets all of the material condition modifiers of the primary datum in this DimXpert geometric tolerance.
 IGetPrimaryDatums	Gets all of the primary datums in this DimXpert geometric tolerance.
 IGetSecondaryDatumModifiers	Gets all of the material condition modifiers of the secondary datum in this DimXpert geometric tolerance.
 IGetSecondaryDatums	Gets all of the secondary datums in this DimXpert geometric tolerance.
 IGetTertiaryDatumModifiers	Gets all of the material condition modifiers of the tertiary datum in this DimXpert geometric tolerance.
 IGetTertiaryDatums	Gets all of the tertiary datums in this DimXpert geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDimXpertAngularityGeoTol Interface](#)
[ISwDMDimXpertCircularityGeoTol Interface](#)
[ISwDMDimXpertCircularRunoutGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertConcentricityGeoTol Interface](#)
[ISwDMDimXpertCylindricityGeoTol Interface](#)
[ISwDMDimXpertFlatnessGeoTol Interface](#)
[ISwDMDimXpertLineProfileGeoTol Interface](#)
[ISwDMDimXpertOrientationGeoTol Interface](#)
[ISwDMDimXpertParallelismGeoTol Interface](#)
[ISwDMDimXpertPerpendicularityGeoTol Interface](#)
[ISwDMDimXpertPositionGeoTol Interface](#)
[ISwDMDimXpertStraightnessGeoTol Interface](#)
[ISwDMDimXpertSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertSymmetryGeoTol Interface](#)
[ISwDMDimXpertTangencyGeoTol Interface](#)
[ISwDMDimXpertTotalRunoutGeoTol Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDimXpertGeometricTolerance Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertGeometricTolerance Interface

For a list of all members of this type, see [ISwDMDimXpertGeometricTolerance members](#).

Public Properties

Name	Description
 Tolerance	Gets the value of this DimXpert geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDimXpertAngularityGeoTol Interface](#)
[ISwDMDimXpertCircularityGeoTol Interface](#)
[ISwDMDimXpertCircularRunoutGeoTol Interface](#)
[ISwDMDimXpertCompositeLineProfileGeoTol Interface](#)
[ISwDMDimXpertCompositePositionGeoTol Interface](#)
[ISwDMDimXpertCompositeSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertConcentricityGeoTol Interface](#)
[ISwDMDimXpertCylindricityGeoTol Interface](#)
[ISwDMDimXpertFlatnessGeoTol Interface](#)
[ISwDMDimXpertLineProfileGeoTol Interface](#)

[ISwDMDimXpertOrientationGeoTol Interface](#)
[ISwDMDimXpertParallelismGeoTol Interface](#)
[ISwDMDimXpertPerpendicularityGeoTol Interface](#)
[ISwDMDimXpertPositionGeoTol Interface](#)
[ISwDMDimXpertStraightnessGeoTol Interface](#)
[ISwDMDimXpertSurfaceProfileGeoTol Interface](#)
[ISwDMDimXpertSymmetryGeoTol Interface](#)
[ISwDMDimXpertTangencyGeoTol Interface](#)
[ISwDMDimXpertTotalRunoutGeoTol Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPrimaryDatumCount Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : GetPrimaryDatumCount Method (ISwDMDimXpertGeometricTolerance)

Gets the number of primary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrimaryDatumCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim value As System.Integer
```

```
value = instance.GetPrimaryDatumCount()
```

C#

```
System.int GetPrimaryDatumCount()
```

C++/CLI

```
System.int GetPrimaryDatumCount();
```

Return Value

Number of primary datums

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertGeometricTolerance::GetPrimaryDatumCount](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPrimaryDatumModifiers Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : GetPrimaryDatumModifiers Method (ISwDMDimXpertGeometricTolerance)

Gets all of the material condition modifiers of the primary datum in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrimaryDatumModifiers() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim value As System.Object
```

```
value = instance.GetPrimaryDatumModifiers()
```

C#

```
System.Object GetPrimaryDatumModifiers()
```

C++/CLI

```
System.Object^ GetPrimaryDatumModifiers();
```

Return Value

Array of material condition modifiers as defined in [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertGeometricTolerance::GetPrimaryDatumModifiers](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)
[ISwDMDimXpertGeometricTolerance::GetPrimaryDatumModifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPrimaryDatums Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : GetPrimaryDatums Method (ISwDMDimXpertGeometricTolerance)

Gets all of the primary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPrimaryDatums() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim value As System.Object
```

```
value = instance.GetPrimaryDatums()
```

C#

```
System.Object GetPrimaryDatums()
```

C++/CLI

```
System.Object^ GetPrimaryDatums();
```

Return Value

Array of [ISwMDimXpertDatum](#)s

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertGeometricTolerance::GetPrimaryDatums](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertGeometricTolerance Interface](#)
[ISwMDimXpertGeometricTolerance Members](#)
[ISwMDimXpertGeometricTolerance::IGetPrimaryDatums Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSecondaryDatumCount Method (ISwMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertGeometricTolerance Interface](#) : GetSecondaryDatumCount Method (ISwMDimXpertGeometricTolerance)

Gets the number of secondary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSecondaryDatumCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertGeometricTolerance  
Dim value As System.Integer
```

```
value = instance.GetSecondaryDatumCount()
```

C#

```
System.int GetSecondaryDatumCount()
```

C++/CLI

```
System.int GetSecondaryDatumCount();
```

Return Value

Number of secondary datums

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertGeometricTolerance::GetSecondaryDatumCount](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertGeometricTolerance Interface](#)
[ISwMDimXpertGeometricTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSecondaryDatumModifiers Method (ISwMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertGeometricTolerance Interface](#) : GetSecondaryDatumModifiers Method (ISwMDimXpertGeometricTolerance)

Gets all of the material condition modifiers of the secondary datum in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSecondaryDatumModifiers() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertGeometricTolerance
Dim value As System.Object

value = instance.GetSecondaryDatumModifiers()
```

C#

```
System.Object GetSecondaryDatumModifiers()
```

C++/CLI

```
System.Object^ GetSecondaryDatumModifiers();
```

Return Value

Array of material condition modifiers as defined in [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertGeometricTolerance::GetSecondaryDatumModifiers](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertGeometricTolerance Interface](#)
[ISwMDimXpertGeometricTolerance Members](#)
[ISwMDimXpertGeometricTolerance::IGetSecondaryDatumModifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetSecondaryDatums Method (ISwMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertGeometricTolerance Interface](#) : GetSecondaryDatums Method (ISwMDimXpertGeometricTolerance)

Gets all of the secondary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)


```
Function GetSecondaryDatums() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertGeometricTolerance  
Dim value As System.Object
```

```
value = instance.GetSecondaryDatums()
```

C#

```
System.object GetSecondaryDatums()
```

C++/CLI

```
System.Object^ GetSecondaryDatums();
```

Return Value

Array of [ISwMDimXpertDatums](#)

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertGeometricTolerance::GetSecondaryDatums](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertGeometricTolerance Interface](#)
[ISwMDimXpertGeometricTolerance Members](#)
[ISwMDimXpertGeometricTolerance::GetSecondaryDatums Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetTertiaryDatumCount Method (ISwMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertGeometricTolerance Interface](#) : GetTertiaryDatumCount Method (ISwMDimXpertGeometricTolerance)

Gets the number of tertiary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTertiaryDatumCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertGeometricTolerance  
Dim value As System.Integer
```

```
value = instance.GetTertiaryDatumCount()
```

C#

```
System.int GetTertiaryDatumCount()
```

C++/CLI

```
System.int GetTertiaryDatumCount();
```

Return Value

Number of tertiary datums

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertGeometricTolerance::GetTertiaryDatumCount](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetTertiaryDatumModifiers Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : GetTertiaryDatumModifiers Method (ISwDMDimXpertGeometricTolerance)

Gets all of the material condition modifiers of the tertiary datum in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTertiaryDatumModifiers() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim value As System.Object
```

```
value = instance.GetTertiaryDatumModifiers()
```

C#

```
System.object GetTertiaryDatumModifiers()
```

C++/CLI

```
System.Object^ GetTertiaryDatumModifiers();
```

Return Value

Array of material condition modifiers as defined in [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertGeometricTolerance::GetTertiaryDatumModifiers](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)
[ISwDMDimXpertGeometricTolerance::IGetTertiaryDatumModifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetTertiaryDatums Method (ISwMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertGeometricTolerance Interface](#) : GetTertiaryDatums Method (ISwMDimXpertGeometricTolerance)

Gets all of the tertiary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTertiaryDatums() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertGeometricTolerance  
Dim value As System.Object
```

```
value = instance.GetTertiaryDatums()
```

C#

```
System.Object GetTertiaryDatums()
```

C++/CLI

```
System.Object^ GetTertiaryDatums();
```

Return Value

Array of [ISwMDimXpertDatum](#)s

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertGeometricTolerance::GetTertiaryDatums](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertGeometricTolerance Interface](#)
[ISwMDimXpertGeometricTolerance Members](#)
[ISwMDimXpertGeometricTolerance::IGetTertiaryDatums Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IGetPrimaryDatumModifiers Method (ISwMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertGeometricTolerance Interface](#) : IGetPrimaryDatumModifiers Method (ISwMDimXpertGeometricTolerance)

Gets all of the material condition modifiers of the primary datum in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPrimaryDatumModifiers( _  
    ByVal Count As System.Integer _  
) As swDmDimXpertMaterialConditionModifier\_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim Count As System.Integer  
Dim value As swDmDimXpertMaterialConditionModifier\_e  
  
value = instance.IGetPrimaryDatumModifiers(Count)
```

C#

```
swDmDimXpertMaterialConditionModifier\_e IGetPrimaryDatumModifiers(  
    System.int Count  
)
```

C++/CLI

```
swDmDimXpertMaterialConditionModifier\_e IGetPrimaryDatumModifiers(  
&    System.int Count  
)
```

Parameters

Count
Number of primary datum modifiers

Return Value

- in-process, unmanaged C++: Pointer to an array of [SwDMDimXpertMaterialConditionModifier_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwDMDimXpertGeometricTolerance::GetPrimaryDatumCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)
[ISwDMDimXpertGeometricTolerance::GetPrimaryDatumModifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IGetPrimaryDatums Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : IGetPrimaryDatums Method (ISwDMDimXpertGeometricTolerance)

Gets all of the primary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPrimaryDatums( _  
    ByVal Count As System.Integer _  
) As swDmDimXpertDatum
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim Count As System.Integer  
Dim value As swDmDimXpertDatum
```

```
value = instance.IGetPrimaryDatums(Count)
```

C#

```
swDmDimXpertDatum IGetPrimaryDatums(  
    System.int Count  
)
```

C++/CLI

```
swDmDimXpertDatum^ IGetPrimaryDatums(  
& System.int Count  
)
```

Parameters

Count

Number of primary datums

Return Value

- in-process, unmanaged C++: Pointer to an array of [ISwDMDimXpertDatum](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwDMDimXpertGeometricTolerance::GetPrimaryDatumCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)

[ISwDMDimXpertGeometricTolerance Members](#)

[ISwDMDimXpertGeometricTolerance::GetPrimaryDatums Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

IGetSecondaryDatumModifiers Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : IGetSecondaryDatumModifiers Method (ISwDMDimXpertGeometricTolerance)

Gets all of the material condition modifiers of the secondary datum in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSecondaryDatumModifiers( _  
    ByVal Count As System.Integer _  
) As swDmDimXpertMaterialConditionModifier\_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim Count As System.Integer  
Dim value As swDmDimXpertMaterialConditionModifier\_e
```

```
value = instance.IGetSecondaryDatumModifiers(Count)
```

C#

```
swDmDimXpertMaterialConditionModifier\_e IGetSecondaryDatumModifiers(  
    System.int Count  
)
```

C++/CLI

```
swDmDimXpertMaterialConditionModifier_e IGetSecondaryDatumModifiers(  
& System.int Count  
)
```

Parameters

Count
Number of secondary datum modifiers

Return Value

- in-process, unmanaged C++: Pointer to an array of [SwDMDimXpertMaterialConditionModifier_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwDMDimXpertGeometricTolerance::GetSecondaryDatumCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)
[ISwDMDimXpertGeometricTolerance::GetSecondaryDatumModifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IGetSecondaryDatums Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : IGetSecondaryDatums Method (ISwDMDimXpertGeometricTolerance)

Gets all of the secondary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSecondaryDatums( _  
    ByVal Count As System.Integer _  
) As swDmDimXpertDatum
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim Count As System.Integer  
Dim value As swDmDimXpertDatum  
  
value = instance.IGetSecondaryDatums(Count)
```

C#

```
swDmDimXpertDatum IGetSecondaryDatums(  
    System.int Count  
)
```

C++/CLI

```
swDmDimXpertDatum^ IGetSecondaryDatums(  
& System.int Count  
)
```

Parameters

Count
Number of secondary datums

Return Value

- in-process, unmanaged C++: Pointer to an array of [ISwMDimXpertDatum](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwMDimXpertGeometricTolerance::GetSecondaryDatumCount](#) to populate the Count argument.

See Also

[ISwMDimXpertGeometricTolerance Interface](#)
[ISwMDimXpertGeometricTolerance Members](#)
[ISwMDimXpertGeometricTolerance::GetSecondaryDatums Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IGetTertiaryDatumModifiers Method (ISwMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertGeometricTolerance Interface](#) : IGetTertiaryDatumModifiers Method (ISwMDimXpertGeometricTolerance)

Gets all of the material condition modifiers of the tertiary datum in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTertiaryDatumModifiers( _
    ByVal Count As System.Integer _
) As swDmDimXpertMaterialConditionModifier\_e
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertGeometricTolerance
Dim Count As System.Integer
Dim value As swDmDimXpertMaterialConditionModifier\_e

value = instance.IGetTertiaryDatumModifiers(Count)
```

C#

```
swDmDimXpertMaterialConditionModifier\_e IGetTertiaryDatumModifiers(
    System.int Count
)
```

C++/CLI

```
swDmDimXpertMaterialConditionModifier\_e IGetTertiaryDatumModifiers(
    & System.int Count
)
```

Parameters

Count
 Number of tertiary datum modifiers

Return Value

- in-process, unmanaged C++: Pointer to an array of [SwDMDimXpertMaterialConditionModifier_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwMDimXpertGeometricTolerance::GetTertiaryDatumCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)
[ISwDMDimXpertGeometricTolerance::GetTertiaryDatumModifiers Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IGetTertiaryDatums Method (ISwDMDimXpertGeometricTolerance)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertGeometricTolerance Interface](#) : IGetTertiaryDatums Method (ISwDMDimXpertGeometricTolerance)

Gets all of the tertiary datums in this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTertiaryDatums( _  
    ByVal Count As System.Integer _  
) As swDmDimXpertDatum
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertGeometricTolerance  
Dim Count As System.Integer  
Dim value As swDmDimXpertDatum  
  
value = instance.IGetTertiaryDatums(Count)
```

C#

```
swDmDimXpertDatum IGetTertiaryDatums(  
    System.int Count  
)
```

C++/CLI

```
swDmDimXpertDatum^ IGetTertiaryDatums(  
& System.int Count  
)
```

Parameters

Count
Number of tertiary datums

Return Value

- in-process, unmanaged C++: Pointer to an array of [ISwDMDimXpertDatum](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

Remarks

Use [ISwDMDimXpertGeometricTolerance::GetTertiaryDatumCount](#) to populate the Count argument.

See Also

[ISwDMDimXpertGeometricTolerance Interface](#)
[ISwDMDimXpertGeometricTolerance Members](#)
[ISwDMDimXpertGeometricTolerance::GetTertiaryDatums Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Tolerance Property (ISwDMDimXpertGeometricTolerance)

[See Also](#)



Gets the value of this DimXpert geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Tolerance As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertGeometricTolerance  
Dim value As System.Double  
  
value = instance.Tolerance
```

C#

```
System.double Tolerance {get;}
```

C++/CLI

```
property System.double Tolerance {  
    System.double get();  
}
```

Property Value

Tolerance value

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertGeometricTolerance::Tolerance](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertGeometricTolerance Interface](#)
[ISwMDimXpertGeometricTolerance Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertIntersectCircleFeature (Type)

ISwDMDimXpertIntersectCircleFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertIntersectCircleFeature Interface

Allows you to access specific information about DimXpert intersect circles.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertIntersectCircleFeature

Visual Basic (Usage)

Dim instance As [ISwDMDimXpertIntersectCircleFeature](#)

C#

public interface ISwDMDimXpertIntersectCircleFeature

C++/CLI

public interface class ISwDMDimXpertIntersectCircleFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectCircleFeature](#).

Example

[Get DimXpert Intersect Features \(VB.NET\)](#)
[Get DimXpert Intersect Features \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertIntersectCircleFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertIntersectCircleFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertIntersectCircleFeature Interface

The following tables list the members exposed by [ISwDMDimXpertIntersectCircleFeature](#).

Public Methods

Name	Description
 GetIntersectFeature	Gets the DimXpert feature that intersects this DimXpert intersect circle.
 GetNominalCircle	Gets the origin coordinates, radius, and vector for this DimXpert intersect circle.
GetPlaneFeature	Gets the DimXpert plane feature used to dimension this DimXpert intersect circle.



[Top](#)

See Also

[ISwDMDimXpertIntersectCircleFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertIntersectCircleFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertIntersectCircleFeature Interface

For a list of all members of this type, see [ISwDMDimXpertIntersectCircleFeature members](#).

Public Methods

Name	Description
 GetIntersectFeature	Gets the DimXpert feature that intersects this DimXpert intersect circle.
 GetNominalCircle	Gets the origin coordinates, radius, and vector for this DimXpert intersect circle.
 GetPlaneFeature	Gets the DimXpert plane feature used to dimension this DimXpert intersect circle.

[Top](#)

See Also

[ISwDMDimXpertIntersectCircleFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetIntersectFeature Method (ISwDMDimXpertIntersectCircleFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertIntersectCircleFeature Interface](#) : GetIntersectFeature Method (ISwDMDimXpertIntersectCircleFeature)

Gets the DimXpert feature that intersects this DimXpert intersect circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIntersectFeature() As SwDMDimXpertFeature
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertIntersectCircleFeature  
Dim value As SwDMDimXpertFeature  
  
value = instance.GetIntersectFeature()
```

C#

```
SwDMDimXpertFeature GetIntersectFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetIntersectFeature();
```

Return Value

[ISwDMDimXpertFeature](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectCircleFeature::GetIntersectFeature](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertIntersectCircleFeature Interface](#)
[ISwMDimXpertIntersectCircleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalCircle Method (ISwMDimXpertIntersectCircleFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertIntersectCircleFeature Interface](#) : GetNominalCircle Method (ISwMDimXpertIntersectCircleFeature)

Gets the origin coordinates, radius, and vector for this DimXpert intersect circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalCircle( _  
    ByRef R As System.Double, _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertIntersectCircleFeature  
Dim R As System.Double  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalCircle(R, X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalCircle(  
    out System.double R,  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalCircle(  
& [Out] System.double R,  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,
```

```

& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)

```

Parameters

R
 Radius of the intersect circle
X
 x coordinate of the origin of the intersect circle
Y
 y coordinate of the origin of the intersect circle
Z
 z coordinate of the origin of the intersect circle
I
 i component of the direction vector of the intersect circle
J
 j component of the direction vector of the intersect circle
K
 k component of the direction vector of the intersect circle

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectCircleFeature::GetNominalCircle](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectCircleFeature Interface](#)
[ISwDMDimXpertIntersectCircleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPlaneFeature Method (ISwDMDimXpertIntersectCircleFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertIntersectCircleFeature Interface](#) : GetPlaneFeature Method (ISwDMDimXpertIntersectCircleFeature)

Gets the DimXpert plane feature used to dimension this DimXpert intersect circle.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeature() As SwDMDimXpertFeature
```

Visual Basic (Usage)



```

Dim instance As ISwDMDimXpertIntersectCircleFeature
Dim value As SwDMDimXpertFeature

value = instance.GetPlaneFeature()

```

C#

```
SwDMDimXpertFeature GetPlaneFeature()
```

C++/CLI

```
SwDMDimXpertFeature^ GetPlaneFeature();
```

Return Value

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectCircleFeature::GetPlaneFeature](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectCircleFeature Interface](#)
[ISwDMDimXpertIntersectCircleFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertIntersectLineFeature (Type)

ISwDMDimXpertIntersectLineFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertIntersectLineFeature Interface

Allows you to access specific information about DimXpert intersect lines.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertIntersectLineFeature
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertIntersectLineFeature
```

C#

```
public interface ISwDMDimXpertIntersectLineFeature
```

C++/CLI

```
public interface class ISwDMDimXpertIntersectLineFeature
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectLineFeature](#).

Example

[Get DimXpert Intersect Features \(VB.NET\)](#)
[Get DimXpert Intersect Features \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertIntersectLineFeature Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)

ISwDMDimXpertIntersectLineFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertIntersectLineFeature Interface

For a list of all members of this type, see [ISwDMDimXpertIntersectLineFeature members](#).

Public Methods

Name	Description
 GetNominalLine	Gets the coordinates and vector for this DimXpert intersect line.
 GetPlaneFeatures	Gets the DimXpert plane features that intersect to form this DimXpert intersect line.

[Top](#)

See Also

[ISwDMDimXpertIntersectLineFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertIntersectLineFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertIntersectLineFeature Interface

The following tables list the members exposed by [ISwDMDimXpertIntersectLineFeature](#).

Public Methods

Name	Description
 GetNominalLine	Gets the coordinates and vector for this DimXpert intersect line.
 GetPlaneFeatures	Gets the DimXpert plane features that intersect to form this DimXpert intersect line.

[Top](#)

See Also

[ISwDMDimXpertIntersectLineFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetNominalLine Method (ISwDMDimXpertIntersectLineFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertIntersectLineFeature Interface](#) : GetNominalLine Method (ISwDMDimXpertIntersectLineFeature)

Gets the coordinates and vector for this DimXpert intersect line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalLine( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertIntersectLineFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalLine(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalLine(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,
```



```
        out System.double K
    )
```

C++/CLI

```
System.bool GetNominalLine(
& [Out] System.double X,
& [Out] System.double Y,
& [Out] System.double Z,
& [Out] System.double I,
& [Out] System.double J,
& [Out] System.double K
)
```

Parameters

X
x coordinate of the intersect line
Y
y coordinate of the intersect line
Z
z coordinate of the intersect line
I
i component of the direction vector of the intersect line
J
j component of the direction vector of the intersect line
K
k component of the direction vector of the intersect line

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertIntersectLineFeature::GetNominalLine](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertIntersectLineFeature Interface](#)
[ISwMDimXpertIntersectLineFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetPlaneFeatures Method (ISwMDimXpertIntersectLineFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertIntersectLineFeature Interface](#) : GetPlaneFeatures Method (ISwMDimXpertIntersectLineFeature)

Gets the DimXpert plane features that intersect to form this DimXpert intersect line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlaneFeatures( _
    ByRef Feature1 As SwMDimXpertFeature, _
    ByRef Feature2 As SwMDimXpertFeature _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertIntersectLineFeature
Dim Feature1 As SwMDimXpertFeature
Dim Feature2 As SwMDimXpertFeature
```

```
Dim value As System.Boolean
```

```
value = instance.GetPlaneFeatures(Feature1, Feature2)
```

C#

```
System.bool GetPlaneFeatures(  
    out SwDMDimXpertFeature Feature1,  
    out SwDMDimXpertFeature Feature2  
)
```

C++/CLI

```
System.bool GetPlaneFeatures(  
& [Out] SwDMDimXpertFeature^ Feature1,  
& [Out] SwDMDimXpertFeature^ Feature2  
)
```

Parameters

Feature1

[ISwDMDimXpertFeature](#)

Feature2

[ISwDMDimXpertFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectLineFeature::GetPlaneFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectLineFeature Interface](#)

[ISwDMDimXpertIntersectLineFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertIntersectPlaneFeature (Type)

ISwDMDimXpertIntersectPlaneFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertIntersectPlaneFeature Interface

Allows you to access specific information about DimXpert intersect planes.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertIntersectPlaneFeature

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertIntersectPlaneFeature](#)

C#

public interface ISwDMDimXpertIntersectPlaneFeature

C++/CLI

public interface class ISwDMDimXpertIntersectPlaneFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectPlaneFeature](#).

Example

[Get DimXpert Intersect Features \(VB.NET\)](#)
[Get DimXpert Intersect Features \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertIntersectPlaneFeature Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)

ISwDMDimXpertIntersectPlaneFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertIntersectPlaneFeature Interface

For a list of all members of this type, see [ISwDMDimXpertIntersectPlaneFeature members](#).

Public Methods

Name	Description
 GetFeatures	Gets the DimXpert features that intersect to form this DimXpert intersect plane.
 GetNominalPlane	Gets the coordinates and vector for this DimXpert intersect plane.

[Top](#)

See Also

[ISwMDimXpertIntersectPlaneFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwMDimXpertIntersectPlaneFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDimXpertIntersectPlaneFeature Interface

The following tables list the members exposed by [ISwMDimXpertIntersectPlaneFeature](#).

Public Methods

Name	Description
 GetFeatures	Gets the DimXpert features that intersect to form this DimXpert intersect plane.
 GetNominalPlane	Gets the coordinates and vector for this DimXpert intersect plane.

[Top](#)

See Also

[ISwMDimXpertIntersectPlaneFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetFeatures Method (ISwMDimXpertIntersectPlaneFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertIntersectPlaneFeature Interface](#) : GetFeatures Method (ISwMDimXpertIntersectPlaneFeature)

Gets the DimXpert features that intersect to form this DimXpert intersect plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatures( _  
    ByRef Feature1 As SwMDimXpertFeature, _  
    ByRef Feature2 As SwMDimXpertFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertIntersectPlaneFeature  
Dim Feature1 As SwMDimXpertFeature  
Dim Feature2 As SwMDimXpertFeature  
Dim value As System.Boolean  
  
value = instance.GetFeatures(Feature1, Feature2)
```

C#

```
System.bool GetFeatures(  
    out SwMDimXpertFeature Feature1,  
    out SwMDimXpertFeature Feature2  
)
```

C++/CLI

```
System.bool GetFeatures(  
& [Out] SwMDimXpertFeature^ Feature1,  
& [Out] SwMDimXpertFeature^ Feature2  
)
```

Parameters

Feature1
[ISwMDimXpertFeature](#)
Feature2

[ISwDMDimXpertFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectPlaneFeature::GetFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectPlaneFeature Interface](#)
[ISwDMDimXpertIntersectPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalPlane Method (ISwDMDimXpertIntersectPlaneFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertIntersectPlaneFeature Interface](#) : GetNominalPlane Method (ISwDMDimXpertIntersectPlaneFeature)

Gets the coordinates and vector for this DimXpert intersect plane.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalPlane( _  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double, _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertIntersectPlaneFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalPlane(X, Y, Z, I, J, K)
```

C#

```
System.bool GetNominalPlane(  
    out System.double X,  
    out System.double Y,  
    out System.double Z,  
    out System.double I,  
    out System.double J,  
    out System.double K  
)
```

C++/CLI

```
System.bool GetNominalPlane(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z,  
& [Out] System.double I,  
& [Out] System.double J,  
& [Out] System.double K  
)
```

Parameters

X
x coordinate of the intersect plane
Y
y coordinate of the intersect plane
Z
z coordinate of the intersect plane
I
i component of the direction vector of the intersect plane
J
j component of the direction vector of the intersect plane
K
k component of the direction vector of the intersect plane

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectPlaneFeature::GetNominalPlane](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectPlaneFeature Interface](#)
[ISwDMDimXpertIntersectPlaneFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertIntersectPointFeature (Type)

ISwDMDimXpertIntersectPointFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertIntersectPointFeature Interface

Allows you to access specific information about DimXpert intersect points.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertIntersectPointFeature

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertIntersectPointFeature](#)

C#

public interface ISwDMDimXpertIntersectPointFeature

C++/CLI

public interface class ISwDMDimXpertIntersectPointFeature

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectPointFeature](#).

Example

[Get DimXpert Intersect Features \(VB.NET\)](#)
[Get DimXpert Intersect Features \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertFeature](#).

Accessors

[ISwDMDimXpertPart::GetFeatures](#) and [ISwDMDimXpertPart::IGetFeatures](#)

See Also

[ISwDMDimXpertIntersectPointFeature Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertIntersectPointFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertIntersectPointFeature Interface

For a list of all members of this type, see [ISwDMDimXpertIntersectPointFeature members](#).

Public Methods

Name	Description
 GetFeatures	Gets the DimXpert features that intersect to form this DimXpert intersect point.
 GetNominalPoint	Gets the coordinates of this DimXpert intersect point.
GetNominalVector	Gets the direction vector of this DimXpert intersect point.



[Top](#)

See Also

[ISwDMDimXpertIntersectPointFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertIntersectPointFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertIntersectPointFeature Interface

The following tables list the members exposed by [ISwDMDimXpertIntersectPointFeature](#).

Public Methods

Name	Description
 GetFeatures	Gets the DimXpert features that intersect to form this DimXpert intersect point.
 GetNominalPoint	Gets the coordinates of this DimXpert intersect point.
 GetNominalVector	Gets the direction vector of this DimXpert intersect point.

[Top](#)

See Also

[ISwDMDimXpertIntersectPointFeature Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetFeatures Method (ISwDMDimXpertIntersectPointFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertIntersectPointFeature Interface](#) : GetFeatures Method (ISwDMDimXpertIntersectPointFeature)

Gets the DimXpert features that intersect to form this DimXpert intersect point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatures( _  
    ByRef Feature1 As SwDMDimXpertFeature, _  
    ByRef Feature2 As SwDMDimXpertFeature _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertIntersectPointFeature  
Dim Feature1 As SwDMDimXpertFeature  
Dim Feature2 As SwDMDimXpertFeature  
Dim value As System.Boolean
```

```
value = instance.GetFeatures(Feature1, Feature2)
```

C#

```
System.bool GetFeatures(  
    out SwDMDimXpertFeature Feature1,  
    out SwDMDimXpertFeature Feature2  
)
```

C++/CLI

```
System.bool GetFeatures(  
    & [Out] SwDMDimXpertFeature^ Feature1,
```



```
& [Out] SwDMDimXpertFeature^ Feature2  
)
```

Parameters

Feature1
[ISwDMDimXpertFeature](#)
Feature2
[ISwDMDimXpertFeature](#)

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectPointFeature::GetFeatures](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectPointFeature Interface](#)
[ISwDMDimXpertIntersectPointFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalPoint Method (ISwDMDimXpertIntersectPointFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertIntersectPointFeature Interface](#) : GetNominalPoint Method (ISwDMDimXpertIntersectPointFeature)

Gets the coordinates of this DimXpert intersect point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalPoint(  
    ByRef X As System.Double, _  
    ByRef Y As System.Double, _  
    ByRef Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertIntersectPointFeature  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.GetNominalPoint(X, Y, Z)
```

C#

```
System.bool GetNominalPoint(  
    out System.double X,  
    out System.double Y,  
    out System.double Z  
)
```

C++/CLI

```
System.bool GetNominalPoint(  
& [Out] System.double X,  
& [Out] System.double Y,  
& [Out] System.double Z  
)
```

Parameters

X
x coordinate of the intersect point
Y
y coordinate of the intersect point
Z
z coordinate of the intersect point

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectPointFeature::GetNominalPoint](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectPointFeature Interface](#)
[ISwDMDimXpertIntersectPointFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetNominalVector Method (ISwDMDimXpertIntersectPointFeature)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertIntersectPointFeature Interface](#) : GetNominalVector Method (ISwDMDimXpertIntersectPointFeature)

Gets the direction vector of this DimXpert intersect point.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNominalVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertIntersectPointFeature  
Dim I As System.Double  
Dim J As System.Double  
Dim K As System.Double  
Dim value As System.Boolean
```

```
value = instance.GetNominalVector(I, J, K)
```

C#

```
System.bool GetNominalVector(  
    out System.double I,  
    out System.double J,
```

```
        out System.double K  
    )
```

C++/CLI

```
System.bool GetNominalVector(  
    & [Out] System.double I,  
    & [Out] System.double J,  
    & [Out] System.double K  
)
```

Parameters

I
i component of the direction vector of the intersect point
J
j component of the direction vector of the intersect point
K
k component of the direction vector of the intersect point

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertIntersectPointFeature::GetNominalVector](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertIntersectPointFeature Interface](#)
[ISwDMDimXpertIntersectPointFeature Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertLengthDimTol (Type)

ISwDMDimXpertLengthDimTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertLengthDimTol Interface

Allows you to access tolerance information for DimXpert length dimensions.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDimXpertLengthDimTol

Visual Basic (Usage)



Dim instance As [ISwDMDimXpertLengthDimTol](#)

C#

public interface ISwDMDimXpertLengthDimTol

C++/CLI

public interface class ISwDMDimXpertLengthDimTol

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertLengthDimTol](#).

Example

[Get DimXpert Tolerance1 \(VB.NET\)](#)
[Get DimXpert Tolerance1 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertDimensionTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertLengthDimTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertLengthDimTol Interface Members

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertLengthDimTol Interface

The following tables list the members exposed by [ISwDMDimXpertLengthDimTol](#).

See Also

[ISwDMDimXpertLengthDimTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertLineProfileGeoTol (Type)

ISwDMDimXpertLineProfileGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertLineProfileGeoTol Interface

Allows you to access DimXpert line profile geometric tolerance information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertLineProfileGeoTol
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertLineProfileGeoTol
```

C#

```
public interface ISwDMDimXpertLineProfileGeoTol
```

C++/CLI

```
public interface class ISwDMDimXpertLineProfileGeoTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertLineProfileGeoTol](#).

Example

[Get DimXpert Tolerance4 \(VB.NET\)](#)
[Get DimXpert Tolerance4 \(C#\)](#)

Remarks

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertLineProfileGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)

ISwDMDimXpertLineProfileGeoTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDimXpertLineProfileGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertLineProfileGeoTol members](#).

Public Methods

Name	Description
 GetPlanarZoneVector	Gets the planar zone vector that is used to compute this DimXpert line profile geometric tolerance.

[Top](#)

See Also

[ISwMDimXpertLineProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDimXpertLineProfileGeoTol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDimXpertLineProfileGeoTol Interface

The following tables list the members exposed by [ISwMDimXpertLineProfileGeoTol](#).

Public Properties

Name	Description
 OuterToleranceValue	Gets the outer tolerance value for this DimXpert line profile geometric tolerance.

[Top](#)

Public Methods

Name	Description
 GetPlanarZoneVector	Gets the planar zone vector that is used to compute this DimXpert line profile geometric tolerance.

[Top](#)

See Also

[ISwMDimXpertLineProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDimXpertLineProfileGeoTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDimXpertLineProfileGeoTol Interface

For a list of all members of this type, see [ISwMDimXpertLineProfileGeoTol members](#).

Public Properties

Name	Description
 OuterToleranceValue	Gets the outer tolerance value for this DimXpert line profile geometric tolerance.

[Top](#)

See Also

[ISwMDimXpertLineProfileGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetPlanarZoneVector Method (ISwMDimXpertLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertLineProfileGeoTol Interface](#) : GetPlanarZoneVector Method (ISwMDimXpertLineProfileGeoTol)

Gets the planar zone vector that is used to compute this DimXpert line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlanarZoneVector( _  
    ByRef I As System.Double, _  
    ByRef J As System.Double, _  
    ByRef K As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertLineProfileGeoTol
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean

value = instance.GetPlanarZoneVector(I, J, K)
```

C#

```
System.bool GetPlanarZoneVector(
    out System.double I,
    out System.double J,
    out System.double K
)
```

C++/CLI

```
System.bool GetPlanarZoneVector(
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)
```

Parameters

I
i component of the planar zone vector
J
j component of the planar zone vector
K
k component of the planar zone vector

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertLineProfileGeoTol::GetPlanarZoneVector](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertLineProfileGeoTol Interface](#)
[ISwDMDimXpertLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

OuterToleranceValue Property (ISwDMDimXpertLineProfileGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertLineProfileGeoTol Interface](#) : OuterToleranceValue Property (ISwDMDimXpertLineProfileGeoTol)

Gets the outer tolerance value for this DimXpert line profile geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property OuterToleranceValue As System.Double
```

Visual Basic (Usage)

```
Dim instance As ISwDMDimXpertLineProfileGeoTol  
Dim value As System.Double  
  
value = instance.OuterToleranceValue
```

C#

```
System.double OuterToleranceValue {get;}
```

C++/CLI

```
property System.double OuterToleranceValue {  
    System.double get();  
}
```

Property Value

Outer tolerance value

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertLineProfileGeoTol.OuterToleranceValue](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertLineProfileGeoTol Interface](#)
[ISwDMDimXpertLineProfileGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

ISwDMDimXpertOrientationGeoTol (Type)

ISwDMDimXpertOrientationGeoTol Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertOrientationGeoTol Interface

Allows you to access DimXpert information for the orientation geometric tolerances: angularity, parallelism, and perpendicularity.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDimXpertOrientationGeoTol
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertOrientationGeoTol
```

C#

```
public interface ISwDMDimXpertOrientationGeoTol
```

C++/CLI

```
public interface class ISwDMDimXpertOrientationGeoTol
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertOrientationGeoTol](#).

Example

[Get DimXpert Tolerance3 \(VB.NET\)](#)
[Get DimXpert Tolerance3 \(C#\)](#)

Remarks

This interface contains information common to all of the orientation geometric interfaces: [ISwDMDimXpertAngularityGeoTol](#), [ISwDMDimXpertParallelismGeoTol](#), and [ISwDMDimXpertPerpendicularityGeoTol](#).

You can access more general information from [ISwDMDimXpertGeometricTolerance](#).

Accessors

[ISwDMDimXpertPart::GetAnnotations](#) and [ISwDMDimXpertPart::IGetAnnotations](#)

See Also

[ISwDMDimXpertOrientationGeoTol Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

ISwDMDimXpertOrientationGeoTol Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertOrientationGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertOrientationGeoTol members](#).

Public Methods

Name	Description
 GetMaxTolerance	Gets the maximum tolerance for this DimXpert orientation geometric tolerance.

 GetPlanarZoneVector	Gets the planar zone vector that is used to compute this DimXpert orientation geometric tolerance.
 GetProjectedZone	Gets the projected zone value of this DimXpert orientation geometric tolerance.
 IsTangentPlane	Gets whether the tangent plane is specified for this DimXpert orientation geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertOrientationGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertOrientationGeoTol Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertOrientationGeoTol Interface

The following tables list the members exposed by [ISwDMDimXpertOrientationGeoTol](#).

Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert orientation geometric tolerance.
 ZoneType	Gets the zone type of this DimXpert orientation geometric tolerance.

[Top](#)

Public Methods

Name	Description
 GetMaxTolerance	Gets the maximum tolerance for this DimXpert orientation geometric tolerance.
 GetPlanarZoneVector	Gets the planar zone vector that is used to compute this DimXpert orientation geometric tolerance.
 GetProjectedZone	Gets the projected zone value of this DimXpert orientation geometric tolerance.
 IsTangentPlane	Gets whether the tangent plane is specified for this DimXpert orientation geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertOrientationGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDimXpertOrientationGeoTol Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDimXpertOrientationGeoTol Interface

For a list of all members of this type, see [ISwDMDimXpertOrientationGeoTol members](#).

Public Properties

Name	Description
 Modifier	Gets the material condition modifier for this DimXpert orientation geometric tolerance.
 ZoneType	Gets the zone type of this DimXpert orientation geometric tolerance.

[Top](#)

See Also

[ISwDMDimXpertOrientationGeoTol Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetMaxTolerance Method (ISwDMDimXpertOrientationGeoTol)

[See Also](#)



Gets the maximum tolerance for this DimXpert orientation geometric tolerance.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetMaxTolerance( _  
    ByRef IsMax As System.Boolean, _  
    ByRef Tolerance As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertOrientationGeoTol  
Dim IsMax As System.Boolean  
Dim Tolerance As System.Double  
Dim value As System.Boolean  
  
value = instance.GetMaxTolerance(IsMax, Tolerance)
```

C#

```
System.bool GetMaxTolerance(  
    out System.bool IsMax,  
    out System.double Tolerance  
)
```

C++/CLI

```
System.bool GetMaxTolerance(  
& [Out] System.bool IsMax,  
& [Out] System.double Tolerance  
)
```

Parameters

IsMax
True, if maximum tolerance is set; false, otherwise
Tolerance
Maximum tolerance

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertOrientationGeoTol::GetMaxTolerance](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertOrientationGeoTol Interface](#)
[ISwDMDimXpertOrientationGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0



Gets the planar zone vector that is used to compute this DimXpert orientation geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlanarZoneVector( _
    ByRef I As System.Double, _
    ByRef J As System.Double, _
    ByRef K As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertOrientationGeoTol
Dim I As System.Double
Dim J As System.Double
Dim K As System.Double
Dim value As System.Boolean
```

```
value = instance.GetPlanarZoneVector(I, J, K)
```

C#

```
System.bool GetPlanarZoneVector(
    out System.double I,
    out System.double J,
    out System.double K
)
```

C++/CLI

```
System.bool GetPlanarZoneVector(
    & [Out] System.double I,
    & [Out] System.double J,
    & [Out] System.double K
)
```

Parameters

I
i component of the planar zone vector
J
j component of the planar zone vector
K
k component of the planar zone vector

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertOrientationGeoTol::GetPlanarZoneVector](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertOrientationGeoTol Interface](#)
[ISwMDimXpertOrientationGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

GetProjectedZone Method (ISwMDimXpertOrientationGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertOrientationGeoTol Interface](#) : GetProjectedZone Method (ISwMDimXpertOrientationGeoTol)

Gets the projected zone value of this DimXpert orientation geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetProjectedZone( _  
    ByRef Enabled As System.Boolean, _  
    ByRef Value As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertOrientationGeoTol  
Dim Enabled As System.Boolean  
Dim Value As System.Double  
Dim value As System.Boolean  
  
value = instance.GetProjectedZone(Enabled, Value)
```

C#

```
System.bool GetProjectedZone(  
    out System.bool Enabled,  
    out System.double Value  
)
```

C++/CLI

```
System.bool GetProjectedZone(  
& [Out] System.bool Enabled,  
& [Out] System.double Value  
)
```

Parameters

Enabled

True if the projected zone is in effect; false otherwise

Value

Orientation projected zone value

Return Value

True if method call is successful; false otherwise

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertOrientationGeoTol::GetProjectedZone](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertOrientationGeoTol Interface](#)

[ISwMDimXpertOrientationGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertOrientationGeoTol Interface](#) : IsTangentPlane Method (ISwMDimXpertOrientationGeoTol)

Gets whether the tangent plane is specified for this DimXpert orientation geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
Function IsTangentPlane() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertOrientationGeoTol  
Dim value As System.Boolean
```

```
value = instance.IsTangentPlane()
```

C#

```
System.bool IsTangentPlane()
```

C++/CLI

```
System.bool IsTangentPlane();
```

Return Value

True if tangent plane is specified; false if not

Visual Basic for Applications (VBA) Syntax

See [SwMDimXpertOrientationGeoTol::IsTangentPlane](#).

Example

See the examples on the interface page.

See Also

[ISwMDimXpertOrientationGeoTol Interface](#)
[ISwMDimXpertOrientationGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Modifier Property (ISwMDimXpertOrientationGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDimXpertOrientationGeoTol Interface](#) : Modifier Property (ISwMDimXpertOrientationGeoTol)

Gets the material condition modifier for this DimXpert orientation geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Modifier As swDmDimXpertMaterialConditionModifier\_e
```

Visual Basic (Usage)



```
Dim instance As ISwMDimXpertOrientationGeoTol  
Dim value As swDmDimXpertMaterialConditionModifier\_e
```

```
value = instance.Modifier
```

C#

```
swDmDimXpertMaterialConditionModifier_e Modifier {get;}
```

C++/CLI

```
property swDmDimXpertMaterialConditionModifier_e Modifier {  
    swDmDimXpertMaterialConditionModifier_e get();  
}
```

Property Value

Material condition modifier as defined in [swDmDimXpertMaterialConditionModifier_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertOrientationGeoTol::Modifier](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertOrientationGeoTol Interface](#)
[ISwDMDimXpertOrientationGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ZoneType Property (ISwDMDimXpertOrientationGeoTol)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDimXpertOrientationGeoTol Interface](#) : ZoneType Property (ISwDMDimXpertOrientationGeoTol)

Gets the zone type of this DimXpert orientation geometric tolerance.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ZoneType As swDmDimXpertOrientationZoneType_e
```

Visual Basic (Usage)



```
Dim instance As ISwDMDimXpertOrientationGeoTol  
Dim value As swDmDimXpertOrientationZoneType_e  
  
value = instance.ZoneType
```

C#

```
swDmDimXpertOrientationZoneType_e ZoneType {get;}
```

C++/CLI

```
property swDmDimXpertOrientationZoneType_e ZoneType {  
    swDmDimXpertOrientationZoneType_e get();  
}
```

Property Value

Zone type for the orientation tolerance as defined in [swDmDimXpertOrientationZoneType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDimXpertOrientationGeoTol::ZoneType](#).

Example

See the examples on the interface page.

See Also

[ISwDMDimXpertOrientationGeoTol Interface](#)
[ISwDMDimXpertOrientationGeoTol Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0