

SOLIDWORKS Document Manager API (.NET) — Reference (14/19) ISwDMDocument18- ISwDMDocument26

SOLIDWORKS API Documentation (converted from CHM)

ISwDMDocument18 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument18 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument18 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument18
    Inherits
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15,
    ISwDMDocument16, ISwDMDocument17, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6,
    ISwDMDocument7, ISwDMDocument8
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument18
```

C#

```
public interface ISwDMDocument18 :
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15,
    ISwDMDocument16, ISwDMDocument17, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6,
    ISwDMDocument7, ISwDMDocument8
```

C++/CLI

```
public interface class ISwDMDocument18 : public
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15,
    ISwDMDocument16, ISwDMDocument17, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6,
    ISwDMDocument7, ISwDMDocument8
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument18](#).

Example

[Get External References for Part \(C#\)](#)
[Get External References for Part \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument18 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument18 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument18 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument18 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument18 Interface

The following tables list the members exposed by [ISwDMDocument18](#).

Public Methods

Name	Description
GetExternalFeatureReferences2	Obsolete. Superseded by ISwDMDocument27.GetExternalFeatureReferences3

[Top](#)

See Also

[ISwDMDocument18 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument18 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument18 Interface

For a list of all members of this type, see [ISwDMDocument18 members](#).

Public Methods

Name	Description
GetExternalFeatureReferences2	Obsolete. Superseded by ISwDMDocument27.GetExternalFeatureReferences3

[Top](#)

See Also

[ISwDMDocument18 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetExternalFeatureReferences2 Method (ISwDMDocument18)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument18 Interface](#) : GetExternalFeatureReferences2 Method (ISwDMDocument18)

Obsolete. Superseded by [ISwDMDocument27::GetExternalFeatureReferences3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetExternalFeatureReferences2( _  
    ByVal ExtRefOption As SwDMExternalReferenceOption2 _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument18  
Dim ExtRefOption As SwDMExternalReferenceOption2  
Dim value As System.Integer  
  
value = instance.GetExternalFeatureReferences2(ExtRefOption)
```

C#

```
System.int GetExternalFeatureReferences2(  
    SwDMExternalReferenceOption2 ExtRefOption  
)
```

C++/CLI

```
System.int GetExternalFeatureReferences2(  
& SwDMExternalReferenceOption2^ ExtRefOption  
)
```

Parameters

ExtRefOption

An [ISwDMExternalReferenceOption2](#) object (see **Remarks**)

Return Value

Number of external references in this document

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument18::GetExternalFeatureReferences2](#).

Remarks

Files must be saved in SOLIDWORKS 2020 or later for this method to report imported feature references in parts and assemblies.

Use [ISwDMDocument13::GetAllExternalReferences4](#) for drawings.

Before calling this method:

1. Call [ISwDMAApplication4::GetExternalReferenceOptionObject2](#) to obtain an [ISwDMExternalReferenceOption2](#) object.
2. Set [ISwDMExternalReferenceOption::Configuration](#).
3. Set [ISwDMExternalReferenceOption::NeedSuppress](#).
4. Set [ISwDMExternalReferenceOption::SearchOption](#).
5. Assign this method's ExtRefOption parameter to the ISwDMExternalReferenceOption2 object.

After calling this method, call [ISwDMExternalReferenceOption::ExternalReferences](#) and [ISwDMExternalReferenceOption::ReferencedConfigurations](#) to obtain the external feature references and their configurations.

To find out if an external feature reference is suppressed:

1. Call [ISwDMComponent6::PathName](#) to set one of the external components returned by ISwDMDocument18::GetExternalFeatureReferences2.
2. Call [ISwDMComponent::IsSuppressed](#).

The suppression states and other information of all of the external references are also embedded in the parent document. To obtain this information in XML format, call [ISwDMDocument::GetXMLStream](#).

Call this method before calling [ISwDMDocument::ReplaceReference](#).

The SOLIDWORKS Document Manager API applies the same rules when searching for a reference as described in the SOLIDWORKS Help. The mix-and-match of subfolder combinations is applied to the current document, which for the SOLIDWORKS Document Manager API is the document attached using [ISwDMAApplication::GetDocument](#) and the reference for which is being searched. You can set up the list of folders to be searched using [ISwDMSearchOption::AddSearchPath](#), which is equivalent to using the SOLIDWORKS user-interface commands **Tools > Options > System Options > File Locations > Referenced Documents**.

Two differences between SOLIDWORKS and the SOLIDWORKS Document Manager API searches are:

- the path of the last opened visible top-level document (drawing or assembly) is not tried directly.
- the last user path is not tried directly.

These concepts have little meaning when SOLIDWORKS is not running.

Because the search routine is shared between SOLIDWORKS and the SOLIDWORKS Document Manager API, most of the same changes applying from SOLIDWORKS 2006 to SOLIDWORKS 2007 and later. However, one significant change related to caching of resolved paths for references being searched for in SOLIDWORKS does not apply to the SOLIDWORKS Document Manager API. In SOLIDWORKS 2007 and later, the next time these references are needed, a simple lookup suffices instead of a potentially lengthy search. However, because this caching mechanism was not applied to the SOLIDWORKS Document Manager API, the SOLIDWORKS Document Manager API in 2006 and 2007, and later, exhibit similar behavior.

See Also

[ISwDMDocument18 Interface](#)
[ISwDMDocument18 Members](#)

Availability

SOLIDWORKS Document Manager API 2014 SP0

ISwDMDocument19 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument19 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument19 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument19
    Inherits
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15,
    ISwDMDocument16, ISwDMDocument17, ISwDMDocument18, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5,
    ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19
```

C#

```
public interface ISwDMDocument19 :
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15,
    ISwDMDocument16, ISwDMDocument17, ISwDMDocument18, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5,
    ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

C++/CLI

```
public interface class ISwDMDocument19 : public
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15,
    ISwDMDocument16, ISwDMDocument17, ISwDMDocument18, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5,
    ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19](#).

Example

[Get Document Settings \(VB.NET\)](#)
[Get Document Settings \(C#\)](#)

Remarks

Before you can access this object, you must call [ISwDMApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument19 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument19 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMApplication::GetDocument](#)
[ISwDMConfiguration::Document](#)
[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument19 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument19 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument19 Interface

For a list of all members of this type, see [ISwDMDocument19 members](#).

Public Methods

Name	Description
 Get3rdPartyStorage	Gets an IStream interface to the specified third-party storage of this model document.
 Get3rdPartyStorageStore	Gets the IStorage interface to the specified third-party storage store of this model document.
 GetSwDmSettingInteger	Gets the specified document setting.
 GetSwDmSettingToggle	Gets the specified document setting.
 Release3rdPartyStorage	Closes the specified third-party storage.
 Release3rdPartyStorageStore	Closes the specified third-party storage store.

[Top](#)

See Also

[ISwDMDocument19 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument19 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument19 Interface

The following tables list the members exposed by [ISwDMDocument19](#).

Public Properties

Name	Description
 CreationDate2	Gets the date in numeric format that this document was created.
 LastSavedDate2	Gets the date in numeric format that this document was last saved.

[Top](#)

Public Methods

Name	Description
 Get3rdPartyStorage	Gets an IStream interface to the specified third-party storage of this model document.
 Get3rdPartyStorageStore	Gets the IStorage interface to the specified third-party storage store of this model document.
 GetSwDmSettingInteger	Gets the specified document setting.
 GetSwDmSettingToggle	Gets the specified document setting.
 Release3rdPartyStorage	Closes the specified third-party storage.
 Release3rdPartyStorageStore	Closes the specified third-party storage store.

[Top](#)

See Also

[ISwDMDocument19 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument19 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument19 Interface

For a list of all members of this type, see [ISwDMDocument19 members](#).

Public Properties

Name	Description
 CreationDate2	Gets the date in numeric format that this document was created.
 LastSavedDate2	Gets the date in numeric format that this document was last saved.

[Top](#)

See Also

[ISwDMDocument19 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)

[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

CreationDate2 Property (ISwDMDocument19)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument19 Interface](#) : CreationDate2 Property (ISwDMDocument19)

Gets the date in numeric format that this document was created.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CreationDate2 As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim value As System.Integer
```

```
value = instance.CreationDate2
```

C#

```
System.int CreationDate2 {get;}
```

C++/CLI

```
property System.int CreationDate2 {  
    System.int get();  
}
```

Property Value

Date in numeric format that this document was created

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::CreationDate2](#).

Example

[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

Remarks

To get the creation date in string format that this document was created, use [ISwDMDocument::CreationDate](#).

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument::Author Property\(\)](#)
[ISwDMDocument::Comments Property\(\)](#)
[ISwDMDocument::Keywords Property\(\)](#)
[ISwDMDocument::LastSavedBy Property\(\)](#)
[ISwDMDocument::LastSavedDate Property\(\)](#)
[ISwDMDocument19::LastSavedDate2 Property\(\)](#)

[ISwDMDocument::Subject Property\(\)](#)
[ISwDMDocument::Title Property\(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 FCS

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

Get3rdPartyStorage Method (ISwDMDocument19)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument19 Interface](#) : Get3rdPartyStorage Method (ISwDMDocument19)

Gets an IStream interface to the specified third-party storage of this model document.

.NET Syntax

Visual Basic (Declaration)

```
Function Get3rdPartyStorage( _  
    ByVal StringIn As System.String, _  
    ByVal IsStoring As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim StringIn As System.String  
Dim IsStoring As System.Boolean  
Dim value As System.Object  
  
value = instance.Get3rdPartyStorage(StringIn, IsStoring)
```

C#

```
System.object Get3rdPartyStorage(  
    System.string StringIn,  
    System.bool IsStoring  
)
```

C++/CLI

```
System.Object^ Get3rdPartyStorage(  
& System.String^ StringIn,  
& System.bool IsStoring  
)
```

Parameters

StringIn

Name of the stream; the name should be less than 30 characters and must be unique and qualified among all of the software parties storing within the current session

IsStoring

True if writing data, false if reading data

Return Value

Pointer to Unknown (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::Get3rdPartyStorage](#).

Example

[Read and Write to Third-party Storage \(VB.NET\)](#)
[Read and Write to Third-party Storage \(C#\)](#)

Remarks

After calling this method, you must call [ISwDMDocument19::Release3rdPartyStorage](#). Otherwise, the third-party node might remain locked and prevent future access.

NOTE: The name given to the storage stream should be registered so that no conflicts occur. Once registered, the stream name is reserved exclusively for your application.

Passing the unique ID string and a flag to determine if data is being stored or loaded returns an IUnknown pointer. You must then use QueryInterface() to get the **Microsoft.VisualStudio.OLE.Interop.IStream** interface. The stream object is used for serialization and then release in the third-party code.

```
SwRootStorage --|  
  
|-- ThirdPty --|  
  
    |-- <SW Assigned IStream name 1>  
  
    |-- <SW Assigned IStream name 2>  
  
    |-- <SW Assigned IStream name 3>  
  
    ...  
  
    |-- <SW Assigned IStream name n>
```

The IStream object used by the third party is written under an IStorage object called ThirdPty in the SOLIDWORKS compound document. Each third party writes to a single IStream object whose name is assigned by SOLIDWORKS.

NOTE: If you are using serialization, then be careful with the standard MFC macros. Otherwise, you may get a message like **Unexpected File Format** after your application is unloaded. One way of using IMPLEMENT_SERIAL:

```
IMPLEMENT_SERIAL( CCustomAttr, COject, VERSIONABLE_SCHEMA|0 )
```

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument19::Get3rdPartyStorageStore Method \(\)](#)
[ISwDMDocument20::Delete3rdPartyStorage Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Get3rdPartyStorageStore Method (ISwDMDocument19)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument19 Interface](#) : Get3rdPartyStorageStore Method (ISwDMDocument19)

Gets the IStorage interface to the specified third-party storage store of this model document.

.NET Syntax

Visual Basic (Declaration)

```
Function Get3rdPartyStorageStore( _  
    ByVal SubStorageName As System.String, _  
    ByVal IsStoring As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim SubStorageName As System.String  
Dim IsStoring As System.Boolean  
Dim value As System.Object  
  
value = instance.Get3rdPartyStorageStore(SubStorageName, IsStoring)
```

C#

```
System.object Get3rdPartyStorageStore(  
    System.string SubStorageName,  
    System.bool IsStoring  
)
```

C++/CLI

```
System.Object^ Get3rdPartyStorageStore(
& System.String^ SubStorageName,
& System.bool IsStoring
)
```

Parameters

SubStorageName
Name of the storage
IsStoring
True if writing data, false if reading data

Return Value

Pointer to Unknown (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::Get3rdPartyStorageStore](#).

Example

[Read and Write to Third-party Storage \(VB.NET\)](#)
[Read and Write to Third-party Storage \(C#\)](#)

Remarks

After calling this method, you must call [ISwDMDocument19::Release3rdPartyStorageStore](#). Otherwise, the third-party node might remain locked and prevent future access.

NOTE: The name given to the storage should be registered so that no conflicts occur. Once registered, the storage name is reserved exclusively for your application.

Passing the unique ID string and a flag to determine if data is being stored or loaded returns an IUnknown pointer. You must then use QueryInterface() to get the **Microsoft.VisualStudio.OLE.Interop.IStorage** interface. The storage object is used for serialization and then released in the third-party code.

The IStorage object used by the third party is written under an IStorage object called ThirdPtyStore in the SOLIDWORKS compound document. Each third party writes to a single IStorage whose name is assigned by SOLIDWORKS.

SwRootStorage --|

|-- ThirdPtyStore --|

|-- <SW Assigned IStorage name 1> --|

|-- <Application 1 IStream name 1>

|-- <Application 1 IStream name 2>

|-- <SW Assigned IStorage name 2> --|

|-- <Application 2 IStream name 1>

|-- <Application 2 IStream name 2>

|-- <Application 2 IStorage name 2> --|

|-- <Application 2 IStream name 3>

NOTE: If you are using serialization, then be careful with the standard MFC macros. Otherwise, you may get a message like **Unexpected File Format** after your application is unloaded. One way of using IMPLEMENT_SERIAL:

IMPLEMENT_SERIAL(CCustomAttr, CObject, VERSIONABLE_SCHEMA|0)

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument19::Get3rdPartyStorageStore Method \(\)](#)
[ISwDMDocument20::Delete3rdPartyStorageStore Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 SP0

GetSwDmSettingInteger Method (ISwDMDocument19)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument19 Interface](#) : GetSwDmSettingInteger Method (ISwDMDocument19)

Gets the specified document setting.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSwDmSettingInteger( _  
    ByVal DmSetting As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim DmSetting As System.Integer  
Dim value As System.Integer  
  
value = instance.GetSwDmSettingInteger(DmSetting)
```

C#

```
System.int GetSwDmSettingInteger(  
    System.int DmSetting  
)
```

C++/CLI

```
System.int GetSwDmSettingInteger(  
& System.int DmSetting  
)
```

Parameters

DmSetting
Setting as defined by [swDmDocumentUnitsIntegerValue_e](#)

Return Value

Value for DmSetting

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::GetSwDmSettingInteger](#).

Example

See the [ISwDMDocument19](#) examples.

Remarks

This method works only with documents saved in SOLIDWORKS 2015 or later.

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument19::GetSwDmSettingToggle Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 SP0



Gets the specified document setting.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSwDmSettingToggle( _  
    ByVal DmSetting As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim DmSetting As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetSwDmSettingToggle(DmSetting)
```

C#

```
System.bool GetSwDmSettingToggle(  
    System.int DmSetting  
)
```

C++/CLI

```
System.bool GetSwDmSettingToggle(  
    & System.int DmSetting  
)
```

Parameters

DmSetting
Setting as defined by [swDmDocumentUnitsToggle_e](#)

Return Value

Value for DmSetting

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::GetSwDmSettingToggle](#).

Example

See the [ISwDMDocument19](#) examples.

Remarks

This method works only with documents saved in SOLIDWORKS 2015 or later.

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument19::GetSwDmSettingInteger Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 SP0



Gets the date in numeric format that this document was last saved.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LastSavedDate2 As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim value As System.Integer
```

```
value = instance.LastSavedDate2
```

C#

```
System.int LastSavedDate2 {get;}
```

C++/CLI

```
property System.int LastSavedDate2 {  
    System.int get();  
}
```

Property Value

Date in numeric format that this document was last saved

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::LastSavedDate2](#).

Example

[Get Configuration Information \(C#\)](#)
[Get Configuration Information \(VB.NET\)](#)

Remarks

To get the date in string format that this document was last saved, use [ISwDMDocument::LastSavedDate](#).

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument::Author Property \(\)](#)
[ISwDMDocument::Comments Property \(\)](#)
[ISwDMDocument::CreationDate Property \(\)](#)
[ISwDMDocument19::CreationDate2 Property \(\)](#)
[ISwDMDocument::LastSavedBy Property \(\)](#)
[ISwDMDocument::Subject Property \(\)](#)
[ISwDMDocument::Title Property \(\)](#)
[ISwDMDocument::Keywords Property \(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Release3rdPartyStorage Method (ISwDMDocument19)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument19 Interface](#) : Release3rdPartyStorage Method (ISwDMDocument19)

Closes the specified third-party storage.

.NET Syntax

Visual Basic (Declaration)

```
Function Release3rdPartyStorage( _  
    ByVal StringIn As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim StringIn As System.String  
Dim value As System.Boolean  
  
value = instance.Release3rdPartyStorage(StringIn)
```

C#

```
System.bool Release3rdPartyStorage(  
    System.string StringIn  
)
```

C++/CLI

```
System.bool Release3rdPartyStorage(  
& System.String^ StringIn  
)
```

Parameters

StringIn
Name of the stream to close

Return Value

True if stream is closed, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::Release3rdPartyStorage](#).

Example

[Read and Write to Third-party Storage \(VB.NET\)](#)
[Read and Write to Third-party Storage \(C#\)](#)

Remarks

You must call this method after calling [ISwDMDocument19::Get3rdPartyStorage](#).

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument20::Delete3rdPartyStorage Method \(\)](#)
[ISwDMDocument19::Release3rdPartyStorageStore Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Release3rdPartyStorageStore Method (ISwDMDocument19)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument19 Interface](#) : Release3rdPartyStorageStore Method (ISwDMDocument19)

Closes the specified third-party storage store.

.NET Syntax

Visual Basic (Declaration)

```
Function Release3rdPartyStorageStore( _  
    ByVal SubStorageName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument19  
Dim SubStorageName As System.String  
Dim value As System.Boolean  
  
value = instance.Release3rdPartyStorageStore(SubStorageName)
```

C#

```
System.bool Release3rdPartyStorageStore(  
    System.string SubStorageName  
)
```

C++/CLI

```
System.bool Release3rdPartyStorageStore(  
& System.String^ SubStorageName  
)
```

Parameters

SubStorageName
Name of the storage to close

Return Value

True if the storage is closed, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument19::Release3rdPartyStorageStore](#).

Example

[Read and Write to Third-party Storage \(VB.NET\)](#)
[Read and Write to Third-party Storage \(C#\)](#)

Remarks

You must call this method after calling [ISwDMDocument19::Get3rdPartyStorageStore](#).

See Also

[ISwDMDocument19 Interface](#)
[ISwDMDocument19 Members](#)
[ISwDMDocument19::Release3rdPartyStorageStore Method \(\)](#)
[ISwDocument20::Delete3rdPartyStorageStore Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2015 SP0

ISwDMDocument20 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument20 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument20 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument20

Inherits

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic (Usage)



Dim instance As [ISwDMDocument20](#)

C#

public interface ISwDMDocument20 :

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

C++/CLI

public interface class ISwDMDocument20 : public

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument20](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument20 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument20 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument20 Members](#)

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

[ISwDMDocument3 Interface](#)

[ISwDMDocument4 Interface](#)

[ISwDMDocument5 Interface](#)

[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument20 Interface Members

[See Also](#) [Methods](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument20 Interface

The following tables list the members exposed by [ISwDMDocument20](#).

Public Methods

Name	Description
 Delete3rdPartyStorage	Deletes the specified third-party storage.
 Delete3rdPartyStorageStore	Deletes the specified third-party storage store.

[Top](#)

See Also

[ISwDMDocument20 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument20 Interface Methods

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument20 Interface

For a list of all members of this type, see [ISwDMDocument20 members](#).

Public Methods

Name	Description
 Delete3rdPartyStorage	Deletes the specified third-party storage.
 Delete3rdPartyStorageStore	Deletes the specified third-party storage store.

[Top](#)

See Also

[ISwDMDocument20 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Delete3rdPartyStorage Method (ISwDMDocument20)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument20 Interface](#) : Delete3rdPartyStorage Method (ISwDMDocument20)

Deletes the specified third-party storage.

.NET Syntax

Visual Basic (Declaration)

```
Function Delete3rdPartyStorage( _  
    ByVal StringIn As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument20  
Dim StringIn As System.String  
Dim value As System.Boolean  
  
value = instance.Delete3rdPartyStorage(StringIn)
```

C#

```
System.bool Delete3rdPartyStorage(  
    System.string StringIn  
)
```

C++/CLI

```
System.bool Delete3rdPartyStorage(  
& System.String^ StringIn  
)
```

Parameters

StringIn
Name of the stream to delete

Return Value

True if the stream is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument20::Delete3rdPartyStorage](#).

See Also

[ISwDMDocument20 Interface](#)
[ISwDMDocument20 Members](#)
[ISwDMDocument19::Get3rdPartyStorage Method \(\)](#)
[ISwDMDocument19::Release3rdPartyStorage Method \(\)](#)
[ISwDMDocument20::Delete3rdPartyStorageStore Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2016 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Delete3rdPartyStorageStore Method (ISwDMDocument20)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument20 Interface](#) : Delete3rdPartyStorageStore Method (ISwDMDocument20)

Deletes the specified third-party storage store.

.NET Syntax

Visual Basic (Declaration)

```
Function Delete3rdPartyStorageStore( _  
    ByVal SubStorageName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument20  
Dim SubStorageName As System.String  
Dim value As System.Boolean  
  
value = instance.Delete3rdPartyStorageStore(SubStorageName)
```

C#

```
System.bool Delete3rdPartyStorageStore(  
    System.string SubStorageName  
)
```

C++/CLI

```
System.bool Delete3rdPartyStorageStore(  
& System.String^ SubStorageName  
)
```

Parameters

SubStorageName
Name of the storage to delete

Return Value

True if the storage is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument20::Delete3rdPartyStorageStore](#).

See Also

[ISwDMDocument20 Interface](#)
[ISwDMDocument20 Members](#)
[ISwDMDocument19::Get3rdPartyStorageStore Method \(\)](#)
[ISwDMDocument19::Release3rdPartyStorageStore Method \(\)](#)
[ISwDMDocument20::Delete3rdPartyStorage Method \(\)](#)

Availability

ISwDMDocument21 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument21 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument21 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument21

Inherits

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument26](#), [ISwDMDocument27](#), [ISwDMDocument28](#)

Visual Basic (Usage)



Dim instance As [ISwDMDocument21](#)

C#

public interface ISwDMDocument21 :

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument26](#), [ISwDMDocument27](#), [ISwDMDocument28](#)

C++/CLI

public interface class ISwDMDocument21 : public

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument26](#), [ISwDMDocument27](#), [ISwDMDocument28](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument21](#).

Example

[Get All External References for Drawing \(VB.NET\)](#)

[Get All External References for Drawing \(C#\)](#)

Remarks

Before you can access this object, you must call [ISwDMApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument21 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument21 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument21 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument21 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument21 Interface

The following tables list the members exposed by [ISwDMDocument21](#).

Public Methods

Name	Description
 GetAllExternalReferences5	Gets all of the external references used in a drawing document, including the statuses of any broken external references.

[Top](#)

See Also

[ISwDMDocument21 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument21 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument21 Interface

For a list of all members of this type, see [ISwDMDocument21 members](#).

Public Methods

Name	Description
 GetAllExternalReferences5	Gets all of the external references used in a drawing document, including the statuses of any broken external references.

See Also

[ISwDMDocument21 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetAllExternalReferences5 Method (ISwDMDocument21)

[See Also](#)SolidWorks.Interop.swdocumentmgr Namespace > [ISwDMDocument21 Interface](#) : GetAllExternalReferences5 Method (ISwDMDocument21)

Gets all of the external references used in a drawing document, including the statuses of any broken external references.

.NET Syntax

Visual Basic (Declaration)

```

Function GetAllExternalReferences5( _
    ByVal pSrcOption As SwDMSearchOption, _
    ByRef brokenRefVar As System.Object, _
    ByRef IsVirtual As System.Object, _
    ByRef TimeStamp As System.Object, _
    ByRef ImportedPaths As System.Object _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As ISwDMDocument21
Dim pSrcOption As SwDMSearchOption
Dim brokenRefVar As System.Object
Dim IsVirtual As System.Object
Dim TimeStamp As System.Object
Dim ImportedPaths As System.Object
Dim value As System.Object

```

```

value = instance.GetAllExternalReferences5(pSrcOption, brokenRefVar, IsVirtual, TimeStamp,
ImportedPaths)

```

C#

```

System.object GetAllExternalReferences5(
    SwDMSearchOption pSrcOption,
    out System.object brokenRefVar,
    out System.object IsVirtual,
    out System.object TimeStamp,
    out System.object ImportedPaths
)

```

C++/CLI

```

System.Object^ GetAllExternalReferences5(
    & SwDMSearchOption^ pSrcOption,

```

```

& [Out] System.Object^ brokenRefVar,
& [Out] System.Object^ IsVirtual,
& [Out] System.Object^ TimeStamp,
& [Out] System.Object^ ImportedPaths
)

```

Parameters

pSrcOption

Pointer to the [ISwDMSearchOption](#) object

brokenRefVar

Array of the statuses of any broken external references as defined in [swDmReferenceStatus](#) (see **Remarks**)

IsVirtual

Array of Booleans that indicate whether each reference corresponds to a virtual component

TimeStamp

Array of time stamps in time_t format

ImportedPaths

Array of strings containing the full path names of imported components; empty string if component is not imported (see **Remarks**)

Return Value

Array of the full path names of the external references used in this document

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument21::GetAllExternalReferences5](#).

Example

See the [ISwDMDocument21](#) examples.

Remarks

Use this method for drawings; use [ISwDMDocument15::GetExternalFeatureReferences](#) for parts and assemblies.

This method only supports model documents saved in SOLIDWORKS 2009 and later.

Although this method returns valid data for files created in SOLIDWORKS 2005 and earlier, this method only returns valid data in brokenRefVar for files created in SOLIDWORKS 2005 files and later. For files created in versions of SOLIDWORKS earlier than SOLIDWORKS 2005, it returns swDmReferenceStatusUnknown in brokenRefVar.

Call this method before calling [ISwDMDocument::ReplaceReference](#).

The SOLIDWORKS Document Manager API applies the same rules when searching for a reference as described in the SOLIDWORKS Help. The mix-and-match of sub-folder combinations is applied to the current document, which for the SOLIDWORKS Document Manager is the document attached using [ISwDMApplication::GetDocument](#) and the reference being searched for. You can set up the list of folders to be searched using [ISwDMSearchOption::AddSearchPath](#), which is equivalent to using the SOLIDWORKS user-interface commands **Tools, Option > System Options > File Locations > Referenced Documents**.

Two differences between SOLIDWORKS and the SOLIDWORKS Document Manager API searches are:

- the path of the last opened visible top-level document (drawing or assembly) is not tried directly.
- the last user path is not tried directly.

as these concepts have little meaning when SOLIDWORKS is not running.

Because the search routine is shared between SOLIDWORKS and the SOLIDWORKS Document Manager API, most of the changes to the search routine apply to the SOLIDWORKS Document Manager API from SOLIDWORKS 2006, onward. However, one significant change related to caching of resolved paths for references being searched for in SOLIDWORKS does not apply to the SOLIDWORKS Document Manager API. In SOLIDWORKS 2007, the next time these cached references are needed, a simple lookup can be performed. This caching mechanism was not applied to the SOLIDWORKS Document Manager API in 2007. The search routines for SOLIDWORKS Document Manager API 2007, onward, are the same as that of SOLIDWORKS Document Manager API 2006.

SOLIDWORKS does not open suppressed components of assemblies in memory. Thus, information, such as a suppressed component's time stamp, is not updated when the assembly is rebuilt. You can compare [ISwDMComponent6::PathName](#) to the path returned by this method and then call [ISwDMComponent::IsSuppressed](#) to find out if the component is suppressed.

The array of time stamps are in time_t format, which Microsoft defines as "seconds elapsed since midnight, January 1, 1970 or -1 in the case of error". You must either have built-in functions to convert these values to something more accessible or write your own functions.

ImportedPaths contains full path names of imported references in the following supported import formats:

Format	Extension
Autodesk Inventor	IPT, IAM
CATIA V5	CATPART, CATPRODUCT
PTC Creo	PRT, XPR, ASM, XAS
Siemens NX	PRT
Solid Edge	PAR, PSM, ASM

See Also

[ISwDMDocument21 Interface](#)

[ISwDMDocument21 Members](#)

[ISwDMDocument13::GetLastUpdateTimeStamp Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2017 SP02

ISwDMDocument22 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument22 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument22 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument22

Inherits

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic (Usage)



Dim instance As [ISwDMDocument22](#)

C#

public interface ISwDMDocument22 :

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

C++/CLI

public interface class ISwDMDocument22 : public

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument22](#).

Example

[Get All External References for Drawing \(VB.NET\)](#)

[Get All External References for Drawing \(C#\)](#)

Remarks

Before you can access this object, you must call [ISwDMApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument22 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument22 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

See Also

- ISwDMDocument22 Members
- SolidWorks.Interop.swdocumentmgr Namespace
- ISwDMDocument Interface
- ISwDMDocument3 Interface
- ISwDMDocument4 Interface
- ISwDMDocument5 Interface
- ISwDMDocument6 Interface
- ISwDMDocument7 Interface
- ISwDMDocument8 Interface
- ISwDMDocument10 Interface
- ISwDMDocument13 Interface
- ISwDMDocument14 Interface
- ISwDMDocument15 Interface
- ISwDMDocument16 Interface
- ISwDMDocument17 Interface
- ISwDMDocument18 Interface
- ISwDMDocument19 Interface
- ISwDMDocument20 Interface
- ISwDMDocument21 Interface
- ISwDMDocument23 Interface
- ISwDMDocument24 Interface
- ISwDMDocument25 Interface
- ISwDMDocument26 Interface
- ISwDMDocument27 Interface
- ISwDMDocument28 Interface
- ISwDMDocument29 Interface
- ISwDMDocument30 Interface

ISwDMDocument22 Interface Methods

[See Also](#)



SolidWorks.Interop.swdocumentmgr Namespace : ISwDMDocument22 Interface

For a list of all members of this type, see [ISwDMDocument22 members](#).

Public Methods

Name	Description
 GetFileAvgTime	Gets the amount of time it took to open this document the last time.
 IsCustomPropertyEditable	Gets whether the specified custom property is editable.

[Top](#)

See Also

- ISwDMDocument22 Interface
- SolidWorks.Interop.swdocumentmgr Namespace
- ISwDMDocument Interface
- ISwDMDocument3 Interface
- ISwDMDocument4 Interface
- ISwDMDocument5 Interface
- ISwDMDocument6 Interface
- ISwDMDocument7 Interface
- ISwDMDocument8 Interface
- ISwDMDocument10 Interface
- ISwDMDocument13 Interface
- ISwDMDocument14 Interface
- ISwDMDocument15 Interface
- ISwDMDocument16 Interface
- ISwDMDocument17 Interface
- ISwDMDocument18 Interface
- ISwDMDocument19 Interface
- ISwDMDocument20 Interface
- ISwDMDocument21 Interface
- ISwDMDocument23 Interface
- ISwDMDocument24 Interface
- ISwDMDocument25 Interface
- ISwDMDocument26 Interface
- ISwDMDocument27 Interface
- ISwDMDocument28 Interface
- ISwDMDocument29 Interface
- ISwDMDocument30 Interface

ISwDMDocument22 Interface Members

[See Also](#) [Methods](#)



SolidWorks.Interop.swdocumentmgr Namespace : ISwDMDocument22 Interface

The following tables list the members exposed by [ISwDMDocument22](#).

Public Methods

Name	Description
 GetFileAvgTime	Gets the amount of time it took to open this document the last time.
 IsCustomPropertyEditable	Gets whether the specified custom property is editable.

[Top](#)

See Also

[ISwDMDocument22 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetFileAvgTime Method (ISwDMDocument22)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument22 Interface](#) : GetFileAvgTime Method (ISwDMDocument22)

Gets the amount of time it took to open this document the last time.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetFileAvgTime( _
    ByRef bsFileTime As System.String, _
    ByRef bsLWFileTime As System.String _
)
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument22
Dim bsFileTime As System.String
Dim bsLWFileTime As System.String

instance.GetFileAvgTime(bsFileTime, bsLWFileTime)
```

C#

```
void GetFileAvgTime(
    out System.string bsFileTime,
    out System.string bsLWFileTime
)
```

C++/CLI

```
void GetFileAvgTime(
    & [Out] System.String^ bsFileTime,
    & [Out] System.String^ bsLWFileTime
)
```

Parameters

bsFileTime

Last open time; "mm mins ss secs" or "unknown"

bsLWFileTime
Last lightweight open time; "mm mins ss secs" or "unknown LW"

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument22::GetFileAvgTime](#).

Example

See the [ISwDMDocument22](#) examples.

See Also

[ISwDMDocument22 Interface](#)
[ISwDMDocument22 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsCustomPropertyEditable Method (ISwDMDocument22)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument22 Interface](#) : IsCustomPropertyEditable Method (ISwDMDocument22)

Gets whether the specified custom property is editable.

.NET Syntax

Visual Basic (Declaration)

```
Sub IsCustomPropertyEditable(  
    ByVal FieldName As System.String, _  
    ByRef IsEditable As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument22  
Dim FieldName As System.String  
Dim IsEditable As System.Boolean
```

```
instance.IsCustomPropertyEditable(FieldName, IsEditable)
```

C#

```
void IsCustomPropertyEditable(  
    System.string FieldName,  
    out System.bool IsEditable  
)
```

C++/CLI

```
void IsCustomPropertyEditable(  
& System.String^ FieldName,  
& [Out] System.bool IsEditable  
)
```

Parameters

FieldName
Name of the custom property in this document
IsEditable
True if editable, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument22::IsCustomPropertyEditable](#).

Example

See the [ISwDMDocument22](#) examples.

Remarks

To populate FieldName, use [ISwDMDocument::GetCustomPropertyNames](#) to get the names of all of the custom properties in this document.

See Also

[ISwDMDocument22 Interface](#)
[ISwDMDocument22 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

ISwDMDocument23 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument23 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument23 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument23

Inherits

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic (Usage)



Dim instance As [ISwDMDocument23](#)

C#

public interface ISwDMDocument23 :

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

C++/CLI

public interface class ISwDMDocument23 : public

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument23](#).

Example

[Get All External References for Drawing \(VB.NET\)](#)

[Get All External References for Drawing \(C#\)](#)

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument23 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument23 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

See Also

- [ISwDMDocument23 Members](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMDocument Interface](#)
- [ISwDMDocument3 Interface](#)
- [ISwDMDocument4 Interface](#)
- [ISwDMDocument5 Interface](#)
- [ISwDMDocument6 Interface](#)
- [ISwDMDocument7 Interface](#)
- [ISwDMDocument8 Interface](#)
- [ISwDMDocument10 Interface](#)
- [ISwDMDocument13 Interface](#)
- [ISwDMDocument14 Interface](#)
- [ISwDMDocument15 Interface](#)
- [ISwDMDocument16 Interface](#)
- [ISwDMDocument17 Interface](#)
- [ISwDMDocument18 Interface](#)
- [ISwDMDocument19 Interface](#)
- [ISwDMDocument20 Interface](#)
- [ISwDMDocument21 Interface](#)
- [ISwDMDocument22 Interface](#)
- [ISwDMDocument24 Interface](#)
- [ISwDMDocument25 Interface](#)
- [ISwDMDocument26 Interface](#)
- [ISwDMDocument27 Interface](#)
- [ISwDMDocument28 Interface](#)
- [ISwDMDocument29 Interface](#)
- [ISwDMDocument30 Interface](#)

ISwDMDocument23 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument23 Interface

For a list of all members of this type, see [ISwDMDocument23 members](#).

Public Methods

Name	Description
 GetLicenseType	Gets the license type of this document.

[Top](#)

See Also

- [ISwDMDocument23 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMDocument Interface](#)
- [ISwDMDocument3 Interface](#)
- [ISwDMDocument4 Interface](#)
- [ISwDMDocument5 Interface](#)
- [ISwDMDocument6 Interface](#)
- [ISwDMDocument7 Interface](#)
- [ISwDMDocument8 Interface](#)
- [ISwDMDocument10 Interface](#)
- [ISwDMDocument13 Interface](#)
- [ISwDMDocument14 Interface](#)
- [ISwDMDocument15 Interface](#)
- [ISwDMDocument16 Interface](#)
- [ISwDMDocument17 Interface](#)
- [ISwDMDocument18 Interface](#)
- [ISwDMDocument19 Interface](#)
- [ISwDMDocument20 Interface](#)
- [ISwDMDocument21 Interface](#)
- [ISwDMDocument22 Interface](#)
- [ISwDMDocument24 Interface](#)
- [ISwDMDocument25 Interface](#)
- [ISwDMDocument26 Interface](#)
- [ISwDMDocument27 Interface](#)
- [ISwDMDocument28 Interface](#)
- [ISwDMDocument29 Interface](#)
- [ISwDMDocument30 Interface](#)

ISwDMDocument23 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument23 Interface

The following tables list the members exposed by [ISwDMDocument23](#).

Public Methods

Name	Description
------	-------------

[Top](#)

See Also

[ISwDMDocument23 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetLicenseType Method (ISwDMDocument23)

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument23 Interface](#) : GetLicenseType Method (ISwDMDocument23)

Gets the license type of this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLicenseType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument23
Dim value As System.Integer

value = instance.GetLicenseType()
```

C#

```
System.int GetLicenseType()
```

C++/CLI

```
System.int GetLicenseType();
```

Return Value

 Document Manager license type as defined in [swDMDocumentLicenseType_e](#)

Visual Basic for Applications (VBA) Syntax

 See [SwDMDocument23::GetLicenseType](#).

Example

 See the [ISwDMDocument23](#) examples.

See Also

Availability

SOLIDWORKS Document Manager API 2019 SP0

ISwDMDocument24 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument24 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument24 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument24

Inherits

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic (Usage)



Dim instance As [ISwDMDocument24](#)

C#

public interface ISwDMDocument24 :

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

C++/CLI

public interface class ISwDMDocument24 : public

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument24](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument24 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument24 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument24 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument24 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument24 Interface

For a list of all members of this type, see [ISwDMDocument24 members](#).

Public Methods

Name	Description
 IsSavedInDetailingMode	Gets whether this document is saved in detailing mode.

[Top](#)

See Also

[ISwDMDocument24 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument24 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument24 Interface

The following tables list the members exposed by [ISwDMDocument24](#).

Public Methods

Name	Description
 IsSavedInDetailingMode	Gets whether this document is saved in detailing mode.

[Top](#)

See Also

[ISwDMDocument24 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

IsSavedInDetailingMode Method (ISwDMDocument24)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument24 Interface](#) : IsSavedInDetailingMode Method (ISwDMDocument24)

Gets whether this document is saved in detailing mode.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSavedInDetailingMode() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument24  
Dim value As System.Boolean  
  
value = instance.IsSavedInDetailingMode()
```

C#

```
System.bool IsSavedInDetailingMode()
```

C++/CLI

```
System.bool IsSavedInDetailingMode();
```

Return Value

True if saved in detailing mode, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument24::IsSavedInDetailingMode](#).

See Also

[ISwDMDocument24 Interface](#)
[ISwDMDocument24 Members](#)

Availability

SOLIDWORKS Document Manager API 2020 SP0

ISwDMDocument25 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument25 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument25 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument25

Inherits

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic (Usage)



Dim instance As [ISwDMDocument25](#)

C#

public interface ISwDMDocument25 :

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

C++/CLI

public interface class ISwDMDocument25 : public

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument25](#).

Example

See the [ISwDMDocument25::GetDisplayTitleName](#) examples.

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument25 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument25 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

See Also

- ISwDMDocument25 Members
- SolidWorks.Interop.swdocumentmgr Namespace
- ISwDMDocument Interface
- ISwDMDocument3 Interface
- ISwDMDocument4 Interface
- ISwDMDocument5 Interface
- ISwDMDocument6 Interface
- ISwDMDocument7 Interface
- ISwDMDocument8 Interface
- ISwDMDocument10 Interface
- ISwDMDocument13 Interface
- ISwDMDocument14 Interface
- ISwDMDocument15 Interface
- ISwDMDocument16 Interface
- ISwDMDocument17 Interface
- ISwDMDocument18 Interface
- ISwDMDocument19 Interface
- ISwDMDocument20 Interface
- ISwDMDocument21 Interface
- ISwDMDocument22 Interface
- ISwDMDocument23 Interface
- ISwDMDocument24 Interface
- ISwDMDocument26 Interface
- ISwDMDocument27 Interface
- ISwDMDocument28 Interface
- ISwDMDocument29 Interface
- ISwDMDocument30 Interface

ISwDMDocument25 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument25 Interface

The following tables list the members exposed by [ISwDMDocument25](#).

Public Methods

Name	Description
 GetDisplayTitleName	Gets the display title name of this document.

[Top](#)

See Also

- ISwDMDocument25 Interface
- SolidWorks.Interop.swdocumentmgr Namespace
- ISwDMDocument Interface
- ISwDMDocument3 Interface
- ISwDMDocument4 Interface
- ISwDMDocument5 Interface
- ISwDMDocument6 Interface
- ISwDMDocument7 Interface
- ISwDMDocument8 Interface
- ISwDMDocument10 Interface
- ISwDMDocument13 Interface
- ISwDMDocument14 Interface
- ISwDMDocument15 Interface
- ISwDMDocument16 Interface
- ISwDMDocument17 Interface
- ISwDMDocument18 Interface
- ISwDMDocument19 Interface
- ISwDMDocument20 Interface
- ISwDMDocument21 Interface
- ISwDMDocument22 Interface
- ISwDMDocument23 Interface
- ISwDMDocument24 Interface
- ISwDMDocument26 Interface
- ISwDMDocument27 Interface
- ISwDMDocument28 Interface
- ISwDMDocument29 Interface
- ISwDMDocument30 Interface

ISwDMDocument25 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument25 Interface

For a list of all members of this type, see [ISwDMDocument25 members](#).

Public Methods

Name	Description
------	-------------

 GetDisplayName	Gets the display title name of this document.
---	---

[Top](#)

See Also

[ISwDMDocument25 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetDisplayName Method (ISwDMDocument25)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument25 Interface](#) : GetDisplayName Method (ISwDMDocument25)

Gets the display title name of this document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayName() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument25
Dim value As System.String

value = instance.GetDisplayName()
```

C#

```
System.string GetDisplayName()
```

C++/CLI

```
System.String^ GetDisplayName();
```

Return Value

Display title name

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument25::GetDisplayName](#).

Example

'VB.NET

'-----
' Preconditions:

1. Read the SOLIDWORKS Document Manager API **Getting Started** topic and ensure that the required DLLs are registered.
 2. Copy and paste this code into a VB.NET console application in Microsoft Visual Studio.
 3. Add the **SolidWorks.Interop.swdocumentmgr.dll** reference to the project:
 - a. Right-click the solution in Solution Explorer.
 - b. Click **Add Reference**.
 - c. Click **Browse**.
 - d. Click:


```
install_dir\api\redist\SolidWorks.Interop.swdocumentmgr.dll
```
 - e. Click **Add**.
 - f. Click **Close**.
 4. Substitute *model_path_and_filename* with the path and filename of the model to open.
 5. Substitute *your_license_key* with your SOLIDWORKS Document Manager license key.
 6. Open the Immediate window.
- Postconditions: Inspect the Immediate window.
- NOTE:** If the model is used elsewhere, do not save changes.

```
Imports SolidWorks.Interop.sldworks
Imports SolidWorks.Interop.swdocumentmgr
Imports SolidWorks.Interop.swconst
Imports System.Runtime.InteropServices
Imports System
Partial Class SolidWorksMacro
    Sub main()
        Dim swClassFact As SwDMClassFactory
        Dim swDocMgr As SwDMApplication
        Dim swDoc As SwDMDocument25
        Dim sLicenseKey As String
        sLicenseKey = "your_license_key"
        Dim sDocFileName As String
        sDocFileName = "model_path_and_filename"
        Dim nDocType As Integer
        nDocType = SwDmDocumentType.swDmDocumentPart
        swClassFact = New SwDMClassFactory
        swDocMgr = swClassFact.GetApplication(sLicenseKey)
        Dim retval As SwDmDocumentOpenError
        swDoc = swDocMgr.GetDocument(sDocFileName, nDocType, False, retval)
        Debug.Print("File = " + swDoc.FullName)
        Debug.Print("DisplayTitleName = " + swDoc.GetDisplayTitleName)
        swDoc.CloseDoc
    End Sub
    ''' <summary>
    ''' The SldWorks swApp variable is pre-assigned for you.
    ''' </summary>
    Public swApp As SldWorks
End Class
```

Example

[Get Display Title Name \(C#\)](#)

See Also

Availability

SOLIDWORKS Document Manager API 2020 SP04

ISwDMDocument26 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument26 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument26 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument26

Inherits

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic (Usage)



Dim instance As [ISwDMDocument26](#)

C#

public interface ISwDMDocument26 :

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

C++/CLI

public interface class ISwDMDocument26 : public

[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument26](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument26 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument26 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument26 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument26 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument26 Interface

The following tables list the members exposed by [ISwDMDocument26](#).

Public Methods

Name	Description
Get3DExperienceType	Gets the type of 3DEXPERIENCE application that created this document.

[Top](#)

See Also

[ISwDMDocument26 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument26 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument26 Interface

For a list of all members of this type, see [ISwDMDocument26 members](#).

Public Methods

Name	Description
Get3DExperienceType	Gets the type of 3DEXPERIENCE application that created this document.

[Top](#)

See Also

[ISwDMDocument26 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Get3DExperienceType Method (ISwDMDocument26)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument26 Interface](#) : Get3DExperienceType Method (ISwDMDocument26)

Gets the type of 3DEXPERIENCE application that created this document.

.NET Syntax

Visual Basic (Declaration)

```
Function Get3DExperienceType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument26  
Dim value As System.Integer  
  
value = instance.Get3DExperienceType()
```

C#

```
System.int Get3DExperienceType()
```

C++/CLI

```
System.int Get3DExperienceType();
```

Return Value

3DEXPERIENCE model type as defined by [swDm3DExperienceModelType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument26::Get3DExperienceType](#).

See Also

[ISwDMDocument26 Interface](#)
[ISwDMDocument26 Members](#)

Availability

SOLIDWORKS Document Manager API 2021 SP0