

ISwDMDocument27 (Type)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument27 Interface

[See Also](#) [Members](#)

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ISwDMDocument27

[ISwMDocument](#), [ISwMDocument10](#), [ISwMDocument12](#), [ISwMDocument13](#), [ISwMDocument14](#), [ISwMDocument15](#), [ISwMDocument16](#), [ISwMDocument17](#), [ISwMDocument18](#), [ISwMDocument19](#), [ISwMDocument20](#), [ISwMDocument21](#), [ISwMDocument22](#), [ISwMDocument23](#), [ISwMDocument24](#), [ISwMDocument25](#), [ISwMDocument26](#), [ISwMDocument27](#), [ISwMDocument28](#), [ISwMDocument29](#), [ISwMDocument30](#), [ISwMDocument31](#), [ISwMDocument32](#), [ISwMDocument33](#), [ISwMDocument34](#), [ISwMDocument35](#), [ISwMDocument36](#), [ISwMDocument37](#), [ISwMDocument38](#), [ISwMDocument39](#), [ISwMDocument40](#), [ISwMDocument41](#), [ISwMDocument42](#), [ISwMDocument43](#), [ISwMDocument44](#), [ISwMDocument45](#), [ISwMDocument46](#), [ISwMDocument47](#), [ISwMDocument48](#), [ISwMDocument49](#), [ISwMDocument50](#), [ISwMDocument51](#), [ISwMDocument52](#), [ISwMDocument53](#), [ISwMDocument54](#), [ISwMDocument55](#), [ISwMDocument56](#), [ISwMDocument57](#), [ISwMDocument58](#), [ISwMDocument59](#), [ISwMDocument60](#), [ISwMDocument61](#), [ISwMDocument62](#), [ISwMDocument63](#), [ISwMDocument64](#), [ISwMDocument65](#), [ISwMDocument66](#), [ISwMDocument67](#), [ISwMDocument68](#), [ISwMDocument69](#), [ISwMDocument70](#), [ISwMDocument71](#), [ISwMDocument72](#), [ISwMDocument73](#), [ISwMDocument74](#), [ISwMDocument75](#), [ISwMDocument76](#), [ISwMDocument77](#), [ISwMDocument78](#), [ISwMDocument79](#), [ISwMDocument80](#), [ISwMDocument81](#), [ISwMDocument82](#), [ISwMDocument83](#), [ISwMDocument84](#), [ISwMDocument85](#), [ISwMDocument86](#), [ISwMDocument87](#), [ISwMDocument88](#), [ISwMDocument89](#), [ISwMDocument90](#), [ISwMDocument91](#), [ISwMDocument92](#), [ISwMDocument93](#), [ISwMDocument94](#), [ISwMDocument95](#), [ISwMDocument96](#), [ISwMDocument97](#), [ISwMDocument98](#), [ISwMDocument99](#)

Visual Basic (Usage)

Dim instance As ISwDMDocument27

CN

```
public interface ISwMDMDocument27 :  
ISwMDMDocument, ISwMDMDocument10, ISwMDMDocument12, ISwMDMDocument13, ISwMDMDocument14, ISwMDMDocument15, ISwMDMDocument16, ISwMDMDocument17, ISwMDMDocument18  
    , ISwMDMDocument19, ISwMDMDocument20, ISwMDMDocument21, ISwMDMDocument22, ISwMDMDocument23, ISwMDMDocument24, ISwMDMDocument25, ISwMDMDocument26, ISwMDMDocume  
nt3, ISwMDMDocument4, ISwMDMDocument5, ISwMDMDocument6, ISwMDMDocument7, ISwMDMDocument8
```

C++/CLI

```
public interface class ISwDMDocument27 : public
ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
ISwDMDocument19, ISwDMDocument20, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocume
nt3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument27](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument27 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument27 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

ISwDMApplication::GetDocument

ISwDMConfiguration::Document

[ISwDMConfigurationMgr::Document](#)

 See Also

- [IswoMfDocument27.Members](#)
- [SolidWorks.Interop.sldworksmtgtr.Namespace](#)
- [IswoMfDocumentInterface](#)
- [IswoMfDocument12.Interface](#)
- [IswoMfDocument1.Interface](#)
- [IswoMfDocument5.Interface](#)
- [IswoMfDocument6.Interface](#)
- [IswoMfDocument7.Interface](#)
- [IswoMfDocument8.Interface](#)
- [IswoMfDocument10.Interface](#)
- [IswoMfDocument13.Interface](#)
- [IswoMfDocument14.Interface](#)
- [IswoMfDocument15.Interface](#)
- [IswoMfDocument16.Interface](#)
- [IswoMfDocument17.Interface](#)
- [IswoMfDocument18.Interface](#)
- [IswoMfDocument19.Interface](#)
- [IswoMfDocument20.Interface](#)
- [IswoMfDocument21.Interface](#)
- [IswoMfDocument22.Interface](#)
- [IswoMfDocument23.Interface](#)
- [IswoMfDocument24.Interface](#)
- [IswoMfDocument25.Interface](#)
- [IswoMfDocument26.Interface](#)
- [IswoMfDocument28.Interface](#)
- [IswoMfDocument29.Interface](#)
- [IswoMfDocument30.Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMDocument27 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument27 Interface

For a list of all members of this type, see [ISwDMDocument27 members](#).

Public Methods

Name	Description
Cefixime	Gets all of the external references, such as inserted or mirrored parts, related to features in this document.

[Top](#)

 See Also

[ISwDMDocument27 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument Interface](#)

[ISwMDocument3 Interface](#)
[ISwMDocument4 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument28 Interface](#)
[ISwMDocument29 Interface](#)
[ISwMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDocument27 Interface Members

[See Also](#) [Methods](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDocument27 Interface

The following tables list the members exposed by [ISwMDocument27](#).

 Public Methods

Name	Description
 GetExternalFeatureReferences3	Gets all of the external references, such as inserted or mirrored parts, related to features in parts in this document.

[Top](#)

 See Also

[ISwMDocument27 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwMDocument Interface](#)
[ISwMDocument3 Interface](#)
[ISwMDocument4 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument28 Interface](#)
[ISwMDocument29 Interface](#)
[ISwMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetExternalFeatureReferences3 Method (ISwMDocument27)

[See Also](#) [Example](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDocument27 Interface](#) : GetExternalFeatureReferences3 Method (ISwMDocument27)

Gets all of the external references, such as inserted or mirrored parts, related to features in parts in this document.

 .NET Syntax

Visual Basic (Declaration)
<pre>Function GetExternalFeatureReferences3(_ ByVal ExtRefOption As SwDMExternalReferenceOption2 _) As System.Integer</pre>
Visual Basic (Usage)
<pre>Dim instance As ISwMDocument27 Dim ExtRefOption As SwDMExternalReferenceOption2 Dim value As System.Integer value = instance.GetExternalFeatureReferences3(ExtRefOption)</pre>
C#
<pre>System.int GetExternalFeatureReferences3(SwDMExternalReferenceOption2 ExtRefOption)</pre>
C++/CLI
<pre>System.int GetExternalFeatureReferences3(& SwDMExternalReferenceOption2^ ExtRefOption)</pre>

Parameters

ExtRefOption
An [ISwDMExternalReferenceOption2](#) object (see [Remarks](#))

Return Value

Number of external references in this document

 Visual Basic for Applications (VBA) Syntax

See [SwDMDocument27.GetExternalFeatureReferences3](#)

 Example

[Get External References for Part \(VB.NET\)](#)
[Get External References for Part \(C#\)](#)
[Get Current Name of Configuration of Suppressed Component \(VB.NET\)](#)
[Get Current Name of Configuration of Suppressed Component \(C#\)](#)

Remarks

This method retrieves data faster than the now obsolete `ISwMDocument18::GetExternalFeatureReferences2`.

Files must be saved in SOLIDWORKS 2020 or later for this method to report imported feature references in parts and assemblies.

Use [ISwMDocument13::GetAllExternalReferences4](#) for drawings.

Before calling this method:

1. Call [ISwDApplication4::GetExternalReferenceOptionObject2](#) to obtain an [ISwDExternalReferenceOption2](#) object.
2. Set [ISwDExternalReferenceOption::Configuration](#).
3. Set [ISwDExternalReferenceOption::NeedSuppress](#).
4. Set [ISwDExternalReferenceOption::SearchOption](#).
5. Assign this method's `ExtRefOption` parameter to an [ISwDExternalReferenceOption2](#) object.

After calling this method, call [ISwDExternalReferenceOption::ExternalReferences](#) and [ISwDExternalReferenceOption::ReferencedConfigurations](#) to obtain the external feature references and their configurations.

To find out if an external feature reference is suppressed:

1. Call [ISwDComponent16::PathName](#) to set one of the external components returned by this method.
2. Call [ISwDComponent::IsSuppressed](#).

The suppression states and other information of all of the external references are also embedded in the parent document. To obtain this information in XML format, call [ISwMDocument::GetXMLStream](#).

Call this method before calling [ISwMDocument::ReplaceReference](#).

The SOLIDWORKS Document Manager API applies the same rules when searching for a reference as described in the SOLIDWORKS Help. The mix-and-match of subfolder combinations is applied to the current document, which for the SOLIDWORKS Document Manager API is the document attached using [ISwDApplication::GetDocument](#) and the reference for which is being searched. You can set up the list of folders to be searched using [ISwDSearchOption::AddSearchPath](#), which is equivalent to using the SOLIDWORKS user-interface commands **Tools > Options > System Options > File Locations > Referenced Documents**.

Two differences between SOLIDWORKS and the SOLIDWORKS Document Manager API searches are:

- the path of the last opened visible top-level document (drawing or assembly) is not tried directly.
- the last user path is not tried directly.

These concepts have little meaning when SOLIDWORKS is not running.

Because the search routine is shared between SOLIDWORKS and the SOLIDWORKS Document Manager API, most of the same changes apply going from SOLIDWORKS 2006 to SOLIDWORKS 2007 and later. However, one significant change related to caching of resolved paths for references being searched for in SOLIDWORKS does not apply to the SOLIDWORKS Document Manager API. In SOLIDWORKS 2007 and later the next time these references are needed, a simple lookup suffices instead of a potentially lengthy search. However, because this caching mechanism was not applied to the SOLIDWORKS Document Manager API, the SOLIDWORKS Document Manager API in 2006 and 2007, and later, exhibit similar behavior.

See Also

[ISwMDocument27 Interface](#)
[ISwMDocument27 Members](#)

Availability

SOLIDWORKS Document Manager API 2021 SP02

ISwDMDocument28 (Type)

ISwDMDocument28 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument28 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (.NET) Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument28
    Inherits
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument28
```

C#

```
public interface ISwDMDocument28 :
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

C++/CLI

```
public interface class ISwDMDocument28 : public
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument28](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument28 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument28 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument28 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument28 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument28 Interface

For a list of all members of this type, see [ISwDMDocument28 members](#).

Public Methods

Name	Description
 GetSplitFeatureReferences	Gets the split parts in this document.
 GetSplitFeatureReferences	Sets the specified split parts in this document.
 SetStockFeatureReferences	Sets the specified split parts in this stock part document.

[Top](#)

See Also

[ISwDMDocument28 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument28 Interface Members

[See Also](#) [Methods](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument28 Interface

The following tables list the members exposed by [ISwDMDocument28](#).

 Public Methods

Name	Description
 GetSplitFeatureReferences	Gets the split parts in this document.
 SetSplitFeatureReferences	Sets the specified split parts in this document.
 SetStockFeatureReferences	Sets the specified split parts in this stock part document.

[Top](#)

 See Also

[ISwDMDocument28 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetSplitFeatureReferences Method (ISwDMDocument28)

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument28 Interface](#) : GetSplitFeatureReferences Method (ISwDMDocument28)

Gets the split parts in this document.

 .NET Syntax

Visual Basic (Declaration)
<pre>Function GetSplitFeatureReferences(_ ByVal SrcOption As SwDMSearchOption _) As System.Object</pre>
Visual Basic (Usage)
<pre>Dim instance As ISwDMDocument28 Dim SrcOption As SwDMSearchOption Dim value As System.Object value = instance.GetSplitFeatureReferences(SrcOption)</pre>
C#
<pre>System.object GetSplitFeatureReferences(SwDMSearchOption SrcOption)</pre>
C++/CLI
<pre>System.Object^ GetSplitFeatureReferences(& SwDMSearchOption^ SrcOption)</pre>

Parameters

SrcOption
[ISwDMSearchOption](#)

Return Value

Array of paths of split parts

 Visual Basic for Applications (VBA) Syntax

See [SwDMDocument28.SetSplitFeatureReferences](#).

Remarks

SOLIDWORKS 2022 allows you to Pack and Go parts created by the Save Bodies and Split features. The split parts created are listed as references of the parent part.

See Also

[ISwDMDocument28 Interface](#)
[ISwDMDocument28 Members](#)

Availability

SOLIDWORKS Document Manager API 2022 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

SetSplitFeatureReferences Method (ISwDMDocument28)

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument28 Interface](#) : SetSplitFeatureReferences Method (ISwDMDocument28)

Sets the specified split parts in this document.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSplitFeatureReferences( _  
    ByVal ListOfSplitPartPaths As System.Object, _  
    ByVal ListOfModifiedSplitPartPaths As System.Object, _  
    ByVal NewPathName As System.String _  
)
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument28  
Dim ListOfSplitPartPaths As System.Object  
Dim ListOfModifiedSplitPartPaths As System.Object  
Dim NewPathName As System.String  
  
instance.SetSplitFeatureReferences(ListOfSplitPartPaths, ListOfModifiedSplitPartPaths, NewPathName)
```

C#

```
void SetSplitFeatureReferences(  
    System.object ListOfSplitPartPaths,  
    System.object ListOfModifiedSplitPartPaths,  
    System.string NewPathName  
)
```

C++/CLI

```
void SetSplitFeatureReferences(  
& System.Object^ ListOfSplitPartPaths,  
& System.Object^ ListOfModifiedSplitPartPaths,  
& System.String^ NewPathName  
)
```

Parameters

ListOfSplitPartPaths
Array of paths of split parts
ListOfModifiedSplitPartPaths
Array of renamed paths of split parts
NewPathName
New path name

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument28.SetSplitFeatureReferences](#).

Remarks

SOLIDWORKS 2022 allows you to Pack and Go parts created by the Save Bodies and Split features. The split parts created are listed as references of the parent part.

See Also

[ISwDMDocument28 Interface](#)
[ISwDMDocument28 Members](#)

Availability

SOLIDWORKS Document Manager API 2022 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

SetStockFeatureReferences Method (ISwDMDocument28)

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument28 Interface](#) : SetStockFeatureReferences Method (ISwDMDocument28)

Sets the specified split parts in this stock part document.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetStockFeatureReferences( _  
    ByVal ListOfSplitPartPaths As System.Object, _  
    ByVal ListOfModifiedSplitPartPaths As System.Object, _
```

```
) ByVal NewPathName As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument28  
Dim ListOfSplitPartPaths As System.Object  
Dim ListOfModifiedSplitPartPaths As System.Object  
Dim NewPathName As System.String  
  
instance.SetStockFeatureReferences(ListOfSplitPartPaths, ListOfModifiedSplitPartPaths, NewPathName)
```

C#

```
void SetStockFeatureReferences(  
    System.object ListOfSplitPartPaths,  
    System.object ListOfModifiedSplitPartPaths,  
    System.string NewPathName  
)
```

C++/CLI

```
void SetStockFeatureReferences(  
    & System.Object^ ListOfSplitPartPaths,  
    & System.Object^ ListOfModifiedSplitPartPaths,  
    & System.String^ NewPathName  
)
```

Parameters

ListOfSplitPartPaths
Array of paths of split parts
ListOfModifiedSplitPartPaths
Array of renamed paths of split parts
NewPathName
New path name

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument28.SetStockFeatureReferences](#).

Remarks

SOLIDWORKS 2022 allows you to Pack and Go parts created by the Save Bodies and Split features. The split parts created are listed as references of the parent part.

See Also

[ISwDMDocument28 Interface](#)
[ISwDMDocument28 Members](#)

Availability

SOLIDWORKS Document Manager API 2022 SP0

ISwDMDocument29 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument29 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument29 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (Declaration)

Public Interface ISwDMDocument29
Inherits
[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument26](#), [ISwDMDocument27](#), [ISwDMDocument28](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic (Usage)

Dim instance As [ISwDMDocument29](#)

C#

public interface ISwDMDocument29 :
[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument26](#), [ISwDMDocument27](#), [ISwDMDocument28](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

C++/CLI

public interface class ISwDMDocument29 : public
[ISwDMDocument](#), [ISwDMDocument10](#), [ISwDMDocument12](#), [ISwDMDocument13](#), [ISwDMDocument14](#), [ISwDMDocument15](#), [ISwDMDocument16](#), [ISwDMDocument17](#), [ISwDMDocument18](#), [ISwDMDocument19](#), [ISwDMDocument20](#), [ISwDMDocument21](#), [ISwDMDocument22](#), [ISwDMDocument23](#), [ISwDMDocument24](#), [ISwDMDocument25](#), [ISwDMDocument26](#), [ISwDMDocument27](#), [ISwDMDocument28](#), [ISwDMDocument3](#), [ISwDMDocument4](#), [ISwDMDocument5](#), [ISwDMDocument6](#), [ISwDMDocument7](#), [ISwDMDocument8](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument29](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument29 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument29 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument29 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument29 Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument29 Interface

The following tables list the members exposed by [ISwDMDocument29](#).


Public Properties

Name	Description
 IsLegacyCustomProperties	Gets whether this document has legacy custom properties.

[Top](#)

Public Methods

Name	Description
------	-------------



[SetCustomProperty2](#)

Sets a custom property for this document.

[Top](#)

See Also

[ISwMDocument29 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwMDocument28 Interface](#)
[ISwMDocument27 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument4 Interface](#)
[ISwMDocument3 Interface](#)
[ISwMDocument Interface](#)
[ISwMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDocument29 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDocument29 Interface

For a list of all members of this type, see [ISwMDocument29 members](#).

Public Methods



[SetCustomProperty2](#)

Description

Sets a custom property for this document.

[Top](#)

See Also

[ISwMDocument29 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwMDocument28 Interface](#)
[ISwMDocument27 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument4 Interface](#)
[ISwMDocument3 Interface](#)
[ISwMDocument Interface](#)
[ISwMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDocument29 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDocument29 Interface

For a list of all members of this type, see [ISwMDocument29 members](#).

Public Properties



[HasLegacyCustomProperties](#)

Description

Gets whether this document has legacy custom properties.

[Top](#)

See Also

[ISwMDocument29 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwMDocument28 Interface](#)
[ISwMDocument27 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument4 Interface](#)
[ISwMDocument3 Interface](#)
[ISwMDocument Interface](#)
[ISwMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

HasLegacyCustomProperties Property (ISwMDocument29)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDocument29 Interface](#) : HasLegacyCustomProperties Property (ISwMDocument29)

Gets whether this document has legacy custom properties.

Visual Basic (Declaration)

ReadOnly Property HasLegacyCustomProperties As System.Boolean

Visual Basic (Usage)

```
Dim instance As ISwDMDocument29
Dim value As System.Boolean

value = instance.HasLegacyCustomProperties
```

C#

```
System.bool HasLegacyCustomProperties {get;}
```

C++/CLI

```
property System.bool HasLegacyCustomProperties {
    System.bool get();
}
```

Property Value

True if document has legacy custom properties, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument29.HasLegacyCustomProperties](#).

See Also

[ISwDMDocument29 Interface](#)
[ISwDMDocument29 Members](#)

Availability

SOLIDWORKS Document Manager API 2023 FCS

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SetCustomProperty2 Method (ISwDMDocument29)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument29 Interface](#) : SetCustomProperty2 Method (ISwDMDocument29)

Sets a custom property for this document.

Visual Basic (Declaration)

```
Function SetCustomProperty2( _
    ByVal FieldName As System.String, _
    ByVal newValue As System.String _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument29
Dim fieldName As System.String
Dim newValue As System.String
Dim value As System.Boolean

value = instance.SetCustomProperty2(fieldName, newValue)
```

C#

```
System.bool SetCustomProperty2(
    System.string FieldName,
    System.string newValue
)
```

C++/CLI

```
System.bool SetCustomProperty2(
    & System.String^ FieldName,
    & System.String^ newValue
)
```

Parameters

FieldName
Name of custom property
newValue
Value for custom property

Return Value

True if custom property successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument29.SetCustomProperty2](#).

Remarks

This method sets an existing custom property.

Before calling this method, call [ISwDMDocument::GetCustomPropertyNames](#) to populate FieldName.

If you call this method to set a linked custom property with an expression value, then you need to open and save the file in SOLIDWORKS before calling [ISwDMDocument::GetCustomProperty](#), [ISwDMDocument17::GetCustomProperty2](#), [ISwDMDocument3::GetAllCustomPropertyNamesAndValues](#), or [ISwDMDocument5::GetCustomPropertyValues](#). SOLIDWORKS

needs to process the linked custom property before your DocumentMgr application attempts to get its evaluated value.

See Also

[ISwDMDocument29 Interface](#)
[ISwDMDocument29 Members](#)
[ISwDMDocument.AddCustomProperty Method \(\)](#)
[ISwDMDocument.DeleteCustomProperty Method \(\)](#)
[ISwDMDocument.GetCustomProperty Method \(\)](#)
[ISwDMConfiguration18.SetCustomProperty2 Method \(\)](#)

Availability

SOLIDWORKS Document Manager API 2023 FCS

ISwDMDocument3 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument3 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument3 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (Declaration)

Public Interface ISwDMDocument3
Inherits [ISwDMDocument](#)

Visual Basic (Usage)

Dim instance As [ISwDMDocument3](#)

C#

public interface ISwDMDocument3 : [ISwDMDocument](#)

C++/CLI

public interface class ISwDMDocument3 : public [ISwDMDocument](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument3](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument3 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument3 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [JPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument3 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument9 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument3 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument3 Interface

The following tables list the members exposed by [ISwDMDocument3](#).

Public Methods

Name	Description
 GetAllCustomPropertyNamesAndValues	Gets all of the custom properties for this document.

[Top](#)

See Also

[ISwDMDocument3 Interface](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument9 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)

[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument3 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument3 Interface

For a list of all members of this type, see [ISwDMDocument3 members](#).

Public Methods

Name	Description
 GetAllCustomPropertyNamesAndValues	Gets all of the custom properties for this document.

[Top](#)

See Also

[ISwDMDocument3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetAllCustomPropertyNamesAndValues Method (ISwDMDocument3)

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument3 Interface](#) : GetAllCustomPropertyNamesAndValues Method (ISwDMDocument3)

Gets all of the custom properties for this document.

.NET Syntax

Visual Basic (Declaration)
<pre>Sub GetAllCustomPropertyNamesAndValues(_ ByRef names As System.Object, _ ByRef types As System.Object, _ ByRef linkedTo As System.Object, _ ByRef values As System.Object _)</pre>
Visual Basic (Usage)
<pre>Dim instance As ISwDMDocument3 Dim names As System.Object Dim types As System.Object Dim linkedTo As System.Object Dim values As System.Object instance.GetAllCustomPropertyNamesAndValues(names, types, linkedTo, values)</pre>
C#
<pre>void GetAllCustomPropertyNamesAndValues(out System.object names, out System.object types, out System.object linkedTo, out System.object values)</pre>
C++/CLI
<pre>void GetAllCustomPropertyNamesAndValues(& [Out] System.Object^ names, & [Out] System.Object^ types, & [Out] System.Object^ linkedTo, & [Out] System.Object^ values)</pre>

Parameters

names
Array of Property Names
types
Array of Types
linkedTo
Array of linked to Values/Text Expressions (see **Remarks**)
values
Array of Evaluated Values

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument3.GetAllCustomPropertyNamesAndValues](#).

Remarks

If the properties are...	Then this method returns...
Linked	The evaluated results of linkedTo
Not linked	Empty strings.
	This method returns the same values as returned by ISwMDocument::GetCustomProperty .

This method returns evaluated values from when the document was last saved in SOLIDWORKS.

If you called [ISwMDocument::SetCustomProperty](#) to set a linked custom property, then you must open and save the file in SOLIDWORKS before calling this method. SOLIDWORKS must process the linked custom property before your DocumentMgr application can retrieve its evaluated value.

See Also

[ISwMDocument3 Interface](#)
[ISwMDocument3 Members](#)
[ISwMDocument::DeleteCustomProperty Method](#)
[ISwMDocument::GetCustomPropertyCount Method](#)
[ISwMDocument::GetCustomPropertyNames Method](#)
[ISwMDocument4::GetAllCustomPropertyNamesAndValues Method](#)
[ISwMDocument5::GetCustomPropertyValues Method \(1\)](#)
[ISwMDocument17::GetCustomProperty2 Method \(1\)](#)

Availability

SOLIDWORKS Document Manager API 2004 SP4

ISwDMDocument30 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument30 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument30 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (.NET) Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument30
    Inherits
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument28, ISwDMDocument29, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument30
```

C#

```
public interface ISwDMDocument30 :
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument28, ISwDMDocument29, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

C++/CLI

```
public interface class ISwDMDocument30 : public
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument28, ISwDMDocument29, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument30](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument30 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument30 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument30 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument01 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument30 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument30 Interface

For a list of all members of this type, see [ISwDMDocument30 members](#).

Public Methods

Name	Description
 IsSavedInCREDMMode	Gets whether this document was saved in LDR Edit mode.

[Top](#)

See Also

[ISwDMDocument30 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument9 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument31 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument30 Interface Members

[See Also](#) [Methods](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument30 Interface

The following tables list the members exposed by [ISwDMDocument30](#).

 Public Methods

Name	Description
 SavedInLDREditMode	Gets whether this document was saved in LDR Edit mode.

[Top](#)

 See Also

[ISwDMDocument30 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument9 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument Interface](#)
[ISwDMDocument31 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

SavedInLDREditMode Method (ISwDMDocument30)

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument30 Interface](#) : SavedInLDREditMode Method (ISwDMDocument30)

Gets whether this document was saved in LDR Edit mode.

 .NET Syntax

Visual Basic (Declaration)
Function SavedInLDREditMode() As SwDMDocumentSavedInLDREditMode_e
Visual Basic (Usage)
<pre>Dim instance As ISwDMDocument30 Dim value As SwDMDocumentSavedInLDREditMode_e value = instance.SavedInLDREditMode()</pre>
C#
<pre>SwDMDocumentSavedInLDREditMode_e SavedInLDREditMode()</pre>
C++/CLI
<pre>SwDMDocumentSavedInLDREditMode_e SavedInLDREditMode();</pre>

Return Value

Status as defined by [swDMDocumentSavedInLDREditMode_e](#)

 Visual Basic for Applications (VBA) Syntax

See [SwDMDocument30::SavedInLDREditMode](#).

 See Also

[ISwDMDocument30 Interface](#)
[ISwDMDocument30 Members](#)

 Availability

ISwDMDocument31 (Type)

ISwDMDocument31 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument31 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument31
    Inherits
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument28, ISwDMDocument29, ISwDMDocument3, ISwDMDocument30, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument31
```

C#

```
public interface ISwDMDocument31 :
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument28, ISwDMDocument29, ISwDMDocument3, ISwDMDocument30, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

C++/CLI

```
public interface class ISwDMDocument31 : public
    ISwDMDocument, ISwDMDocument10, ISwDMDocument12, ISwDMDocument13, ISwDMDocument14, ISwDMDocument15, ISwDMDocument16, ISwDMDocument17, ISwDMDocument18,
    ISwDMDocument19, ISwDMDocument20, ISwDMDocument21, ISwDMDocument22, ISwDMDocument23, ISwDMDocument24, ISwDMDocument25, ISwDMDocument26, ISwDMDocument27,
    ISwDMDocument28, ISwDMDocument29, ISwDMDocument3, ISwDMDocument30, ISwDMDocument4, ISwDMDocument5, ISwDMDocument6, ISwDMDocument7, ISwDMDocument8
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument31](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument31 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument31 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument31 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument30 Interface](#)
[ISwDMDocument9 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument1 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument Interface](#)

ISwDMDocument31 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument31 Interface

The following tables list the members exposed by [ISwDMDocument31](#).

Public Methods

Name	Description
 GetSheetFormatPath(Int32)	Gets the path and filename of the sheet format used for the specified sheet without removing leading or trailing whitespace characters.
 GetSheetNames(Int32)	Gets the names of the sheets in the drawing document without removing leading or trailing whitespace characters.



[GetSheetPropertiesUntrimmed](#)

Gets the specified sheet's properties.

[Top](#)

See Also

[ISwMDocument31 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwMDocument30 Interface](#)
[ISwMDocument29 Interface](#)
[ISwMDocument28 Interface](#)
[ISwMDocument27 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument12 Interface](#)
[ISwMDocument11 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument4 Interface](#)
[ISwMDocument3 Interface](#)
[ISwMDocument Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDocument31 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDocument31 Interface

For a list of all members of this type, see [ISwMDocument31 members](#).

Public Methods

Name	Description
 GetSheetFormatPathUntrimmed	Gets the path and filename of the sheet format used for the specified sheet without removing leading or trailing whitespace characters.
 GetSheetNamesUntrimmed	Gets the names of the sheets in the drawing document without removing leading or trailing whitespace characters.
 GetSheetPropertiesUntrimmed	Gets the specified sheet's properties.

[Top](#)

See Also

[ISwMDocument31 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwMDocument30 Interface](#)
[ISwMDocument29 Interface](#)
[ISwMDocument28 Interface](#)
[ISwMDocument27 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument12 Interface](#)
[ISwMDocument11 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument4 Interface](#)
[ISwMDocument3 Interface](#)
[ISwMDocument Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetSheetFormatPathUntrimmed Method (ISwMDocument31)

[See Also](#) [Example](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDocument31 Interface](#) : GetSheetFormatPathUntrimmed Method (ISwMDocument31)

Gets the path and filename of the sheet format used for the specified sheet without removing leading or trailing whitespace characters.

.NET Syntax

Visual Basic (Declaration)
<pre>Function GetSheetFormatPathUntrimmed(_ ByVal SheetName As System.String, _ ByRef FormatPath As System.String _) As System.Integer</pre>
Visual Basic (Usage)
<pre>Dim instance As ISwMDocument31 Dim SheetName As System.String Dim FormatPath As System.String Dim value As System.Integer value = instance.GetSheetFormatPathUntrimmed(SheetName, FormatPath)</pre>
C#
<pre>System.int GetSheetFormatPathUntrimmed(System.string SheetName, out System.string FormatPath)</pre>
C++/CLI

```
System.int GetSheetFormatPathUntrimmed(
& System.String^ SheetName,
& [Out] System.String^ FormatPath
)
```

Parameters

SheetName
Untrimmed sheet name, complete with leading and trailing whitespace characters.
FormatPath
Path and filename of the sheet format.

Return Value

Result as defined in [swSheetFormatPathResult](#).

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument31::GetSheetFormatPathUntrimmed](#).

Example

Get Drawing Sheets' Properties (Untrimmed) (C#)
Get Drawing Sheets' Properties (Untrimmed) (VB.NET)

Remarks

This method only supports drawing documents saved in SOLIDWORKS 2005 SP02 and later. An empty string is returned for documents saved in earlier versions of SOLIDWORKS. Before calling this method, call [ISwDMDocument4::GetActiveSheetName](#) or [ISwDMDocument31::GetSheetNamesUntrimmed](#).

See Also

[ISwDMDocument31 Interface](#)
[ISwDMDocument31 Members](#)
[GetSheetFormatPath Method \(ISwDMDocument31\)](#)
[GetSheetProperties Method \(ISwDMDocument31\)](#)
[GetSheetPropertiesUntrimmed Method \(ISwDMDocument31\)](#)
[getSheetNames](#)
[GetSheetNamesUntrimmed Method \(ISwDMDocument31\)](#)

Availability

SOLIDWORKS Document Manager API 2026 SP2.

SOLIDWORKS Document Manager API Help

GetSheetNamesUntrimmed Method (ISwDMDocument31)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument31 Interface](#) > [GetSheetNamesUntrimmed Method \(ISwDMDocument31\)](#)

Gets the names of the sheets in the drawing document without removing leading or trailing whitespace characters.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSheetNamesUntrimmed() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument31
Dim value As System.Object

value = instance.GetSheetNamesUntrimmed()
```

C#

```
System.object GetSheetNamesUntrimmed()
```

C++/CLI

```
System.Object^ GetSheetNamesUntrimmed();
```

Return Value

Array of sheet name strings.

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument31::GetSheetNamesUntrimmed](#).

Remarks

This method only supports drawing documents saved in SOLIDWORKS 2005 SP02 and later. An empty array is returned if the names of the sheets are not found.

See Also

[ISwDMDocument31 Interface](#)
[ISwDMDocument31 Members](#)
[SwDMDocument4::GetActiveSheetName Method](#)
[ISwDMDocument4::GetSheetCount Method](#)
[ISwDMDocument6::GetSheetNames Method](#)
[ISwDMDocument13::GetSheetFormatPath Method](#)
[GetSheetFormatPathUntrimmed Method \(ISwDMDocument31\)](#)
[GetSheetProperties Method \(ISwDMDocument31\)](#)
[GetSheetPropertiesUntrimmed Method \(ISwDMDocument31\)](#)

Availability

SOLIDWORKS Document Manager API 2026 SP2

[Send comments](#) on this topic.

GetSheetPropertiesUntrimmed Method (ISwDMDocument31)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespaces](#) > [ISwDMDocument31 Interface](#) : GetSheetPropertiesUntrimmed Method (ISwDMDocument31)

Gets the specified sheet's properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSheetPropertiesUntrimmed( _  
    ByVal SheetName As System.String, _  
    ByRef Properties As System.Object _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument31  
Dim SheetName As System.String  
Dim Properties As System.Object  
Dim value As System.Integer  
  
value = instance.GetSheetPropertiesUntrimmed(SheetName, Properties)
```

C#

```
System.int GetSheetPropertiesUntrimmed(  
    System.string SheetName,  
    out System.object Properties  
)
```

C++/CLI

```
System.int GetSheetPropertiesUntrimmed(  
& System.String^ SheetName,  
& [Out] System.Object^ Properties  
)
```

Parameters

SheetName
Untrimmed sheet name, complete with leading and trailing whitespace characters.

Properties
Array of 8 doubles (see [Remarks](#))

Return Value

Result as defined in [swSheetPropertiesResult](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument31.GetSheetPropertiesUntrimmed](#).

Example

Get Drawing Sheets' Properties (Untrimmed) (C#)
Get Drawing Sheets' Properties (Untrimmed) (VB.NET)

Remarks

This method only supports drawing documents saved in SOLIDWORKS 2005 SP02 and later. An empty string is returned for documents saved in earlier versions of SOLIDWORKS.

Before calling this method, call [ISwDMDocument4.GetActiveSheetName](#) or [ISwDMDocument31.GetSheetNamesUntrimmed](#).

The output value is an array of 8 doubles:

[*sheetPaperSize*, *sheetWidth*, *sheetHeight*, *sheetScale1*, *sheetScale2*, *firstAngle*, *templateSize*, *templateVisible*]

where:

- sheetPaperSize*: long packed into a double represented by [swDwgPaperSizes_e](#)
- sheetWidth*: sheet width
- sheetHeight*: sheet height
- sheetScale1*: sheet scale1
- sheetScale2*: sheet scale2
- firstAngle*: Boolean packed into a double; true if sheet is using first angle project, false if not
- templateSize*: long packed into a double represented by [swDwgTemplates_e](#)
- templateVisible*: Boolean packed into a double; true if template is visible, false if not

See Also

[ISwDMDocument31 Interface](#)
[ISwDMDocument31 Members](#)
[GetSheetProperties Method \(ISwDMDocument31\)](#)
[GetSheetNames Method \(ISwDMDocument31\)](#)
[GetSheetNamesUntrimmed Method \(ISwDMDocument31\)](#)
[GetSheetFormatPath Method \(ISwDMDocument31\)](#)
[GetSheetFormatPathUntrimmed Method \(ISwDMDocument31\)](#)

Availability

SOLIDWORKS Document Manager API 2026 SP2

ISwDMDocument4 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument4 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument4 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (.NET) Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument4
    Inherits ISwDMDocument, ISwDMDocument3
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument4
```

C#

```
public interface ISwDMDocument4 : ISwDMDocument, ISwDMDocument3
```

C++/CLI

```
public interface class ISwDMDocument4 : public ISwDMDocument, ISwDMDocument3
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument4](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument4 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument4 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [JPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument4 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument9 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument4 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument4 Interface

For a list of all members of this type, see [ISwDMDocument4 members](#).

Public Methods

Name	Description
 GetActiveSheetName	Gets the name of the active sheet in a SOLIDWORKS drawing document.
 GetSheetCount	Gets the number of sheets in the SOLIDWORKS drawing document.

[Top](#)

See Also

[ISwDMDocument4 Interface](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument9 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument11 Interface](#)
[ISwDMDocument12 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)

[ISwMDocument21 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument27 Interface](#)
[ISwMDocument28 Interface](#)
[ISwMDocument29 Interface](#)
[ISwMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwMDocument4 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwMDocument4 Interface

The following tables list the members exposed by [ISwMDocument4](#).

Public Methods

Name	Description
 GetActiveSheetName	Gets the name of the active sheet in a SOLIDWORKS drawing document.
 GetSheetCount	Gets the number of sheets in the SOLIDWORKS drawing document.

[Top](#)

See Also

[ISwMDocument4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwMDocument3 Interface](#)
[ISwMDocument5 Interface](#)
[ISwMDocument6 Interface](#)
[ISwMDocument7 Interface](#)
[ISwMDocument8 Interface](#)
[ISwMDocument10 Interface](#)
[ISwMDocument13 Interface](#)
[ISwMDocument14 Interface](#)
[ISwMDocument15 Interface](#)
[ISwMDocument16 Interface](#)
[ISwMDocument17 Interface](#)
[ISwMDocument18 Interface](#)
[ISwMDocument19 Interface](#)
[ISwMDocument20 Interface](#)
[ISwMDocument21 Interface](#)
[ISwMDocument22 Interface](#)
[ISwMDocument23 Interface](#)
[ISwMDocument24 Interface](#)
[ISwMDocument25 Interface](#)
[ISwMDocument26 Interface](#)
[ISwMDocument27 Interface](#)
[ISwMDocument28 Interface](#)
[ISwMDocument29 Interface](#)
[ISwMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetActiveSheetName Method (ISwMDocument4)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDocument4 Interface](#) : GetActiveSheetName Method (ISwMDocument4)

Gets the name of the active sheet in a SOLIDWORKS drawing document.

.NET Syntax

Visual Basic (Declaration)

```
Function GetActiveSheetName() As System.String
```

Visual Basic (Usage)

```
Dim instance As ISwMDocument4  
Dim value As System.String  
  
value = instance.GetActiveSheetName()
```

C#

```
System.string GetActiveSheetName()
```

C++/CLI

```
System.String^ GetActiveSheetName();
```

Return Value

Name of the active sheet

Visual Basic for Applications (VBA) Syntax

See [SwMDocument4::GetActiveSheetName](#).

Remarks

This method supports SOLIDWORKS drawing documents only. A -1 or NULL is returned for all other types of SOLIDWORKS documents.

See Also

[ISwMDocument4 Interface](#)
[ISwMDocument4 Members](#)
[ISwMDocument4::GetSheetCount Method](#)
[ISwMDocument6::GetSheetNames Method](#)
[ISwMDocument13::GetSheetFormatPath Method](#)
[ISwMDocument13::GetSheetProperties Method](#)

Availability

SOLIDWORKS Document Manager API 2005 FCS

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetSheetCount Method (ISwMDocument4)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument4 Interface](#) : GetSheetCount Method (ISwDMDocument4)
Gets the number of sheets in the SOLIDWORKS drawing document.

■ .NET Syntax

Visual Basic (Declaration)

```
Function GetSheetCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument4  
Dim value As System.Integer  
  
value = instance.GetSheetCount()
```

C#

```
System.int GetSheetCount()
```

C++/CLI

```
System.int GetSheetCount();
```

Return Value

Number of sheets

■ Visual Basic for Applications (VBA) Syntax

See [SwDMDocument4::GetSheetCount](#).

■ Example

[Get Drawing Sheets' Properties \(C#\)](#)
[Get Drawing Sheets' Properties \(VB.NET\)](#)

■ Remarks

This method supports SOLIDWORKS drawing documents only. A -1 or NULL is returned for all other types of SOLIDWORKS documents.

■ See Also

[ISwDMDocument4 Interface](#)
[ISwDMDocument4 Members](#)
[SwDMDocument4::GetSheetNames Method](#)
[ISwDMDocument4::GetActiveSheetName Method](#)

■ Availability

SOLIDWORKS Document Manager API 2005 FCS

ISwDMDocument5 (Type)

ISwDMDocument5 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument5 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (.NET) Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument5
    Inherits ISwDMDocument, ISwDMDocument3, ISwDMDocument4
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument5
```

C#

```
public interface ISwDMDocument5 : ISwDMDocument, ISwDMDocument3, ISwDMDocument4
```

C++/CLI

```
public interface class ISwDMDocument5 : public ISwDMDocument, ISwDMDocument3, ISwDMDocument4
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument5](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument5 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument5 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [JPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument5 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument4a Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument5 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#): ISwDMDocument5 Interface

For a list of all members of this type, see [ISwDMDocument5 members](#).

Public Methods

Name	Description
 GetAllExternalReferences2	Obsolete. Superseded by ISwDMDocument12::GetAllExternalReferences3
 GetCustomPropertyValues	Gets the specified custom property value for this document.
 GetLinkedDocuments	Gets the names of the linked documents.

[Top](#)

See Also

[ISwDMDocument5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)

[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument5 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument5 Interface

The following tables list the members exposed by [ISwDMDocument5](#).

Public Methods

Name	Description
GetAllExternalReferences2	<i>Obsolete. Superseded by ISwDMDocument12::GetAllExternalReferences3</i>
GetCustomPropertyValue	Gets the specified custom property value for this document.
GetLinkedMechanisms	Gets the names of the linked documents.

[Top](#)

See Also

[ISwDMDocument5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument6 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetAllExternalReferences2 Method (ISwDMDocument5)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument5 Interface](#) : GetAllExternalReferences2 Method (ISwDMDocument5)

Obsolete. Superseded by [ISwDMDocument12::GetAllExternalReferences3](#)

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllExternalReferences2( _  
    ByVal pSrcOption As SwDMSearchOption, _  
    ByRef brokenRefVar As System.Object _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISwDMDocument5  
Dim pSrcOption As SwDMSearchOption  
Dim brokenRefVar As System.Object  
Dim value As System.Object  
  
value = instance.GetAllExternalReferences2(pSrcOption, brokenRefVar)
```

C#

```
System.Object GetAllExternalReferences2(  
    SwDMSearchOption pSrcOption,  
    out System.Object brokenRefVar  
)
```

C++/CLI

```
System.Object^ GetAllExternalReferences2(  
    & SwDMSearchOption^ pSrcOption,  
    [Out] System.Object^ brokenRefVar  
)
```

Parameters

pSrcOption

Pointer to the [ISwDMSearchOption](#) object

brokenRefVar

Array of the statuses of the any broken external references as defined in [swDmReferenceStatus](#) (see [Remarks](#))

Return Value

Array of the names of the external references used in this document

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument5::GetAllExternalReferences2](#)

Remarks

Although this method returns valid data for files created in SOLIDWORKS 2005 and earlier, this method only returns valid data for the brokenRefVar argument for files created in SOLIDWORKS 2005 files and later. For files created in versions of SOLIDWORKS earlier than SOLIDWORKS 2005, it returns swDmReferenceStatusUnknown for brokenRefVar.

Call this method before calling [ISwDMDocument.ReplaceReference](#).

The SOLIDWORKS Document Manager API applies the same rules when searching for a reference as described in the SOLIDWORKS Help topic "Search Routine for Referenced Documents". The mix-and-match of sub-folder combinations is applied to the current document, which for the SOLIDWORKS Document Manager is the document attached using [ISwDMApplication.GetDocument](#) and the reference being searched for. You can set up the list of folders to be searched using [ISwDMSearchOption.AddSearchPath](#), which is equivalent to using the SOLIDWORKS user-interface commands **Tools, Options, System Options, File Locations, Referenced Documents**.

Two differences between SOLIDWORKS and the SOLIDWORKS Document Manager API searches are:

- the path of the last opened visible top-level document (drawing or assembly) is not tried directly.
- the last user path is not tried directly.

as these concepts have little meaning when SOLIDWORKS is not running.

Because the search routine is shared between SOLIDWORKS and the SOLIDWORKS Document Manager API, most of the same changes apply going from SOLIDWORKS 2006 to SOLIDWORKS 2007 and later. However, one significant change related to caching of resolved paths for references being searched for in SOLIDWORKS does not apply to the SOLIDWORKS Document Manager API. In SOLIDWORKS 2007 and later the next time these references are needed, a simple lookup suffices instead of a potentially lengthy search. However, because this caching mechanism was not applied to the SOLIDWORKS Document Manager API, the SOLIDWORKS Document Manager API in 2006 and 2007, and later, exhibit similar behavior.

See Also

[ISwDMDocument5 Interface](#)
[ISwDMDocument5 Members](#)
[ISwDMDocument5.GetChangedReferences Method](#)

Availability

SOLIDWORKS Document Manager API 2005 FCS

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetCustomPropertyValues Method (ISwDMDocument5)

[See Also](#)



SolidWorks.Interop.swdocumentmgr Namespace > [ISwDMDocument5 Interface](#) : GetCustomPropertyValues Method (ISwDMDocument5)

Gets the specified custom property value for this document.

NET Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertyValues( _  
    ByVal FieldName As System.String, _  
    ByRef type As SwDmCustomInfoType, _  
    ByRef linkedTo As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument5  
Dim fieldName As System.String  
Dim type As SwDmCustomInfoType  
Dim linkedTo As System.String  
Dim value As System.String
```

```
value = instance.GetCustomPropertyValues(fieldName, type, linkedTo)
```

C#

```
System.string GetCustomPropertyValues(  
    System.string FieldName,  
    out SwDmCustomInfoType type,  
    out System.string linkedTo  
)
```

C++/CLI

```
System.String^ GetCustomPropertyValues(  
& System.String^ FieldName,  
& [Out] SwDmCustomInfoType type,  
& [Out] System.String^ linkedTo  
)
```

Parameters

FieldName
Property Name
type
Type of custom property as defined in [SwDmCustomInfoType](#)
linkedTo
Linked to Value/Text Expression (see [Remarks](#))

Return Value

Evaluated Value

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument5.GetCustomPropertyValues](#).

Remarks

This property only supports documents saved in SOLIDWORKS 2005 and later.

If the property is...

Linked

Not linked

Then this method returns...

The evaluated result of linkedTo.

An empty string.

This method returns the same value as returned by [ISwDMDocument.GetCustomProperty](#)

This method returns evaluated values from when the document was last saved in SOLIDWORKS.

If you called [ISwDMDocument.SetCustomProperty](#) to set a linked custom property, then you must open and save the file in SOLIDWORKS before calling this method. SOLIDWORKS must process the linked custom property before your DocumentMgr application can retrieve its evaluated value.

See Also

[ISwMDocument5 Interface](#)
[ISwMDocument5 Members](#)
[ISwDocument.AddCustomProperty Method](#)
[ISwDocument.DeleteCustomProperty Method](#)
[ISwDocument.GetCustomPropertyCount Method](#)
[ISwDocument.GetCustomPropertyNames Method](#)
[ISwMDocument3.GetAllCustomPropertyNamesAndValues Method](#)
[ISwConfiguration.AddCustomProperty Method](#)
[ISwConfiguration.DeleteCustomProperty Method](#)
[ISwConfiguration.GetCustomProperty Method](#)
[ISwConfiguration.GetCustomPropertyCount Method](#)
[ISwConfiguration.GetCustomPropertyNames Method](#)
[ISwConfiguration.GetCustomPropertyNamesAndValues Method](#)
[ISwConfiguration4.GetAllCustomPropertyNamesAndValues Method](#)
[ISwConfiguration5.GetCustomPropertyValues Method](#)

Availability

SOLIDWORKS Document Manager API 2005 FCS

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

GetLinkedAttachments Method (ISwMDocument5)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwMDocument5 Interface](#) : GetLinkedAttachments Method (ISwMDocument5)

Gets the names of the linked documents.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLinkedAttachments() As System.Object
```

Visual Basic (Usage)

```
Dim instance As ISwMDocument5  
Dim value As System.Object
```

```
value = instance.GetLinkedAttachments()
```

C#

```
System.Object GetLinkedAttachments()
```

C++/CLI

```
System.Object^ GetLinkedAttachments();
```

Return Value

Array of the names of the linked documents

Visual Basic for Applications (VBA) Syntax

See [SwMDocument5.GetLinkedAttachments](#).

Remarks

This method is supported by SOLIDWORKS Document Manager 2005 and later.

See Also

[ISwMDocument5 Interface](#)
[ISwMDocument5 Members](#)

Availability

SOLIDWORKS Document Manager API 2005 FCS

ISwDMDocument6 (Type)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument6 Interface

[See Also](#) [Members](#)

[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument6 Interface

Accesses the document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic (.NET) Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMDocument6
    Inherits ISwDMDocument, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5
```

Visual Basic (Usage)



```
Dim instance As ISwDMDocument6
```

C#

```
public interface ISwDMDocument6 : ISwDMDocument, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5
```

C++/CLI

```
public interface class ISwDMDocument6 : public ISwDMDocument, ISwDMDocument3, ISwDMDocument4, ISwDMDocument5
```

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument6](#).

Remarks

Before you can access this object, you must call [ISwDMAApplication::GetDocument](#).

NOTES:

- You can access an ISwDMDocument6 object by calling QueryInterface on an [ISwDMDocument](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMDocument object can be assigned to an ISwDMDocument6 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [JPartDoc](#) variable.

Accessors

[ISwDMAApplication::GetDocument](#)

[ISwDMConfiguration::Document](#)

[ISwDMConfigurationMgr::Document](#)

See Also

[ISwDMDocument6.Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMDocument4.Interface](#)
[ISwDMDocument4.Interface](#)
[ISwDMDocument5.Interface](#)
[ISwDMDocument7.Interface](#)
[ISwDMDocument10.Interface](#)
[ISwDMDocument13.Interface](#)
[ISwDMDocument8.Interface](#)
[ISwDMDocument14.Interface](#)
[ISwDMDocument15.Interface](#)
[ISwDMDocument16.Interface](#)
[ISwDMDocument17.Interface](#)
[ISwDMDocument18.Interface](#)
[ISwDMDocument19.Interface](#)
[ISwDMDocument20.Interface](#)
[ISwDMDocument21.Interface](#)
[ISwDMDocument22.Interface](#)
[ISwDMDocument23.Interface](#)
[ISwDMDocument24.Interface](#)
[ISwDMDocument25.Interface](#)
[ISwDMDocument26.Interface](#)
[ISwDMDocument27.Interface](#)
[ISwDMDocument28.Interface](#)
[ISwDMDocument29.Interface](#)
[ISwDMDocument30.Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMDocument6 Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMDocument6 Interface

The following tables list the members exposed by [ISwDMDocument6](#).

Public Methods

Name	Description
 GetSheetNames	Gets the names of the sheets in the drawing document.

[Top](#)

See Also

[ISwDMDocument6.Interface](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMDocument3.Interface](#)
[ISwDMDocument4.Interface](#)
[ISwDMDocument5.Interface](#)
[ISwDMDocument7.Interface](#)
[ISwDMDocument10.Interface](#)
[ISwDMDocument13.Interface](#)
[ISwDMDocument8.Interface](#)
[ISwDMDocument14.Interface](#)
[ISwDMDocument15.Interface](#)
[ISwDMDocument16.Interface](#)
[ISwDMDocument17.Interface](#)
[ISwDMDocument18.Interface](#)
[ISwDMDocument19.Interface](#)
[ISwDMDocument20.Interface](#)
[ISwDMDocument21.Interface](#)
[ISwDMDocument22.Interface](#)

[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

ISwDMDocument6 Interface Methods

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMDocument6 Interface

For a list of all members of this type, see [ISwDMDocument6 members](#).

Public Methods

Name	Description
 GetSheetNames	Gets the names of the sheets in the drawing document.

[Top](#)

See Also

[ISwDMDocument6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMDocument3 Interface](#)
[ISwDMDocument4 Interface](#)
[ISwDMDocument5 Interface](#)
[ISwDMDocument7 Interface](#)
[ISwDMDocument10 Interface](#)
[ISwDMDocument13 Interface](#)
[ISwDMDocument8 Interface](#)
[ISwDMDocument14 Interface](#)
[ISwDMDocument15 Interface](#)
[ISwDMDocument16 Interface](#)
[ISwDMDocument17 Interface](#)
[ISwDMDocument18 Interface](#)
[ISwDMDocument19 Interface](#)
[ISwDMDocument20 Interface](#)
[ISwDMDocument21 Interface](#)
[ISwDMDocument22 Interface](#)
[ISwDMDocument23 Interface](#)
[ISwDMDocument24 Interface](#)
[ISwDMDocument25 Interface](#)
[ISwDMDocument26 Interface](#)
[ISwDMDocument27 Interface](#)
[ISwDMDocument28 Interface](#)
[ISwDMDocument29 Interface](#)
[ISwDMDocument30 Interface](#)

GetSheetNames Method (ISwDMDocument6)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMDocument6 Interface](#) : GetSheetNames Method (ISwDMDocument6)

Gets the names of the sheets in the drawing document.

.NET Syntax

Visual Basic (Declaration)
<pre>Function GetSheetNames() As System.Object</pre>
Visual Basic (Usage)
<pre>Dim instance As ISwDMDocument6 Dim value As System.Object value = instance.GetSheetNames()</pre>
C#
<pre>System.Object GetSheetNames()</pre>
C++/CLI
<pre>System.Object^ GetSheetNames();</pre>

Return Value

Array of sheet name strings.

Visual Basic for Applications (VBA) Syntax

See [SwDMDocument6.GetSheetNames](#).

Example

[Get Drawing Sheets' Properties \(C#\)](#)
[Get Drawing Sheets' Properties \(VB.NET\)](#)

Remarks

This method only supports drawing documents saved in SOLIDWORKS 2005 SP02 and later. An empty array is returned if the names of the sheets are not found.

See Also

[ISwDMDocument6 Interface](#)
[ISwDMDocument6 Members](#)
[ISwDMDocument4.GetActiveSheetName Method](#)
[ISwDMDocument4.GetSheetCount Method](#)
[ISwDMDocument13.GetSheetFormatPath Method](#)

Availability

SOLIDWORKS Document Manager API 2005 SP2