

SOLIDWORKS Document Manager API (.NET) — Reference (17/19): ISwDMTable-ISwDMTable6

SOLIDWORKS API Documentation (converted from CHM)

ISwDMTable (Type)

ISwDMTable Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable Interface

Accesses revision and bill of materials (BOM) tables.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMTable
```

Visual Basic (Usage)

```
Dim instance As ISwDMTable
```

C#

```
public interface ISwDMTable
```

C++/CLI

```
public interface class ISwDMTable
```

Visual Basic for Applications (VBA) Syntax

See [SwDMTable](#).

Remarks

Only revision and bill of materials (BOM) tables are supported.

Accessors

[ISwDMDocument10::GetTable](#)

See Also

- [ISwDMTable Members](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMTable2 Interface](#)
- [ISwDMDocument10::GetTableNames Method](#)
- [ISwDMTable3 Interface](#)
- [ISwDMTable4 Interface](#)
- [ISwDMTable5 Interface](#)
- [ISwDMTable6 Interface](#)

ISwDMTable Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable Interface

For a list of all members of this type, see [ISwDMTable members](#).

Public Methods

Name	Description
AddColumnLeft	Adds a column to the left of the table's current leftmost column.
AddColumnRight	Adds a column to the right of the table's current rightmost column.
AddRowHead	Adds a row to the top of the table.

	AddRowTail	Adds a row to the end of the table.
	DeleteColumn	Deletes the specified column.
	DeleteRow	Deletes the specified row.
	GetCellText	Gets the text in the specified cell.
	GetColumnCount	Gets the number of columns in the table.
	GetColumnType	Gets the type of the specified column
	GetComponentRep	Gets the component representation.
	GetHeaderStyle	Gets the header style for the table.
	GetRowCount	Gets the number of rows in the table.
	IsTitleVisible	Gets whether the table title is visible.
	SetCellText	Sets the specified text in the specified cell.

[Top](#)

 See Also

- [ISwDMTable Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMTable2 Interface](#)
- [ISwDMDocument10::GetTableNames Method](#)
- [ISwDMTable3 Interface](#)
- [ISwDMTable4 Interface](#)
- [ISwDMTable5 Interface](#)
- [ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMTable Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable Interface

The following tables list the members exposed by [ISwDMTable](#).

 Public Properties

Name	Description
 Name	Gets the name of the table.

[Top](#)

 Public Methods

Name	Description
 AddColumnLeft	Adds a column to the left of the table's current leftmost column.
 AddColumnRight	Adds a column to the right of the table's current rightmost column.
 AddRowHead	Adds a row to the top of the table.
 AddRowTail	Adds a row to the end of the table.
 DeleteColumn	Deletes the specified column.
 DeleteRow	Deletes the specified row.
 GetCellText	Gets the text in the specified cell.
 GetColumnCount	Gets the number of columns in the table.
 GetColumnType	Gets the type of the specified column
 GetComponentRep	Gets the component representation.
 GetHeaderStyle	Gets the header style for the table.
 GetRowCount	Gets the number of rows in the table.
 IsTitleVisible	Gets whether the table title is visible.

 **SetCellText**

Sets the specified text in the specified cell.

[Top](#)

 See Also

[ISwDMTable Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable2 Interface](#)
[ISwDMDocument10::GetTableNames Method](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

ISwDMTable Interface Properties

[See Also](#)

 **SolidWorks.Interop.swdocumentmgr Namespace** : ISwDMTable Interface

For a list of all members of this type, see [ISwDMTable members](#).

 Public Properties

Name	Description
 Name	Gets the name of the table.

[Top](#)

 See Also

[ISwDMTable Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable2 Interface](#)
[ISwDMDocument10::GetTableNames Method](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

AddColumnLeft Method (ISwDMTable)

[See Also](#)

 **SolidWorks.Interop.swdocumentmgr Namespace** > [ISwDMTable Interface](#) : AddColumnLeft Method (ISwDMTable)

Adds a column to the left of the table's current leftmost column.

 Visual Basic Syntax

Visual Basic (Declaration)

```
Function AddColumnLeft( _  
    ByRef ColumnDataIn As System.Object _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim ColumnDataIn As System.Object  
Dim value As SwDmTableError  
  
value = instance.AddColumnLeft(ColumnDataIn)
```

C#

```
SwDmTableError AddColumnLeft(  
    ref System.object ColumnDataIn  
)
```

C++/CLI

```
SwDmTableError AddColumnLeft(  
& System.Object^% ColumnDataIn
```

)

Parameters

ColumnDataIn
Array of text data for the new column

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::AddColumnLeft](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddColumnRight Method](#)
[ISwDMTable::DeleteColumn Method](#)
[ISwDMTable::GetColumnCount Method](#)
[ISwDMTable::GetColumnType Method](#)
[ISwDMTable2::GetColumnWidth Method](#)
[ISwDMTable2::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

AddColumnRight Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : AddColumnRight Method (ISwDMTable)

Adds a column to the right of the table's current rightmost column.

.NET Syntax

Visual Basic (Declaration)

```
Function AddColumnRight( _  
    ByRef ColumnDataIn As System.Object _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim ColumnDataIn As System.Object  
Dim value As SwDmTableError  
  
value = instance.AddColumnRight(ColumnDataIn)
```

C#

```
SwDmTableError AddColumnRight(  
    ref System.object ColumnDataIn  
)
```

C++/CLI

```
SwDmTableError AddColumnRight(  
& System.Object^% ColumnDataIn  
)
```

Parameters

ColumnDataIn
Array of text data for the new column

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::AddColumnRight](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddColumnLeft Method](#)
[ISwDMTable::DeleteColumn Method](#)
[ISwDMTable::GetColumnCount Method](#)
[ISwDMTable::GetColumnType Method](#)
[ISwDMTable2::GetColumnCustomProperty Method](#)
[ISwDMTable2::GetColumnWidth Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

AddRowHead Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : AddRowHead Method (ISwDMTable)

Adds a row to the top of the table.

.NET Syntax

Visual Basic (Declaration)

```
Function AddRowHead(  
    ByRef RowDataIn As System.Object _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim RowDataIn As System.Object  
Dim value As SwDmTableError  
  
value = instance.AddRowHead(RowDataIn)
```

C#

```
SwDmTableError AddRowHead(  
    ref System.object RowDataIn  
)
```

C++/CLI

```
SwDmTableError AddRowHead(  
& System.Object^% RowDataIn  
)
```

Parameters

RowDataIn
Array of data for the row

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::AddRowHead](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddRowTail Method](#)
[ISwDMTable::DeleteRow Method](#)
[ISwDMTable::GetRowCount Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

AddRowTail Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : AddRowTail Method (ISwDMTable)

Adds a row to the end of the table.

.NET Syntax

Visual Basic (Declaration)

```
Function AddRowTail( _  
    ByRef RowDataIn As System.Object _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim RowDataIn As System.Object  
Dim value As SwDmTableError  
  
value = instance.AddRowTail(RowDataIn)
```

C#

```
SwDmTableError AddRowTail(  
    ref System.object RowDataIn  
)
```

C++/CLI

```
SwDmTableError AddRowTail(  
    & System.Object^% RowDataIn  
)
```

Parameters

RowDataIn
Array of data for the row

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::AddRowTail](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddRowHead Method](#)
[ISwDMTable::DeleteRow Method](#)
[ISwDMTable::GetRowCount Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

DeleteColumn Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : DeleteColumn Method (ISwDMTable)

Deletes the specified column.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteColumn( _  
    ByVal ColumnIndex As System.Integer _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim ColumnIndex As System.Integer  
Dim value As SwDmTableError  
  
value = instance.DeleteColumn(ColumnIndex)
```

C#

```
SwDmTableError DeleteColumn(  
    System.int ColumnIndex  
)
```

C++/CLI

```
SwDmTableError DeleteColumn(  
&    System.int ColumnIndex  
)
```

Parameters

ColumnIndex
Index of the column

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::DeleteColumn](#).

Remarks

Before calling this method, call [ISwDMTable::GetColumnCount](#) to determine the index of the column to delete.

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddColumnLeft Method](#)
[ISwDMTable::AddColumnRight Method](#)
[ISwDMTable::GetColumnType Method](#)
[ISwDMTable2::GetColumnCustomProperty Method](#)
[ISwDMTable2::GetColumnWidth Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

DeleteRow Method (ISwDMTable)

[See Also](#)



Deletes the specified row.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteRow( _  
    ByVal RowIndex As System.Integer _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim RowIndex As System.Integer  
Dim value As SwDmTableError  
  
value = instance.DeleteRow(RowIndex)
```

C#

```
SwDmTableError DeleteRow(  
    System.int RowIndex  
)
```

C++/CLI

```
SwDmTableError DeleteRow(  
& System.int RowIndex  
)
```

Parameters

RowIndex
Index of the row

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::DeleteRow](#).

Remarks

Before calling this method, call [ISwDMTable::GetRowCount](#) to determine the index of the row to delete.

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddRowHead Method](#)
[ISwDMTable::AddRowTail Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

GetCellText Method (ISwDMTable)

[See Also](#)



Gets the text in the specified cell.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCellText( _
    ByVal RowIndex As System.Integer, _
    ByVal ColumnIndex As System.Integer, _
    ByRef CellTextOut As System.String _
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable
Dim RowIndex As System.Integer
Dim ColumnIndex As System.Integer
Dim CellTextOut As System.String
Dim value As SwDmTableError

value = instance.GetCellText(RowIndex, ColumnIndex, CellTextOut)
```

C#

```
SwDmTableError GetCellText(
    System.int RowIndex,
    System.int ColumnIndex,
    out System.string CellTextOut
)
```

C++/CLI

```
SwDmTableError GetCellText(
    & System.int RowIndex,
    & System.int ColumnIndex,
    & [Out] System.String^ CellTextOut
)
```

Parameters

RowIndex
Index of row where cell is located
ColumnIndex
Index of column where cell is located
CellTextOut
String containing the text in cell

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::GetCellText](#).

Remarks

Before calling this method, call:

- [ISwDMTable::GetRowCount](#) to determine the index of the row where the cell is located.
- [ISwDMTable::GetColumnCount](#) to determine the index of the column where the cell is located.

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::SetCellText Method](#)
[ISwDMTable2::GetCellTextHorizontalJustification Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetColumnCount Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : GetColumnCount Method (ISwDMTable)

Gets the number of columns in the table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable
Dim value As System.Integer

value = instance.GetColumnCount()
```

C#

```
System.int GetColumnCount()
```

C++/CLI

```
System.int GetColumnCount();
```

Return Value

Number of columns

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::GetColumnCount](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddColumnLeft Method](#)
[ISwDMTable::AddColumnRight Method](#)
[ISwDMTable::DeleteColumn Method](#)
[ISwDMTable::GetColumnType Method](#)
[ISwDMTable2::GetColumnCustomProperty Method](#)
[ISwDMTable2::GetColumnWidth Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetColumnType Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : GetColumnType Method (ISwDMTable)

Gets the type of the specified column

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnType(  
    ByVal ColumnIndex As System.Integer _  
) As SwDmColumnType
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable
Dim ColumnIndex As System.Integer
Dim value As SwDmColumnType
```

```
value = instance.GetColumnType(ColumnIndex)
```

C#

```
SwDmColumnType GetColumnType(  
    System.int ColumnIndex  
)
```

C++/CLI

```
SwDmColumnType GetColumnType(  
& System.int ColumnIndex  
)
```

Parameters

ColumnIndex
Index of column

Return Value

Type of column as defined by [swDmColumnType](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::GetColumnType](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

Before calling this method, call [ISwDMTable::GetColumnCount](#) to determine the index of the column.

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddColumnLeft Method](#)
[ISwDMTable::AddColumnRight Method](#)
[ISwDMTable::DeleteColumn Method](#)
[ISwDMTable2::GetColumnCustomProperty Method](#)
[ISwDMTable2::GetColumnWidth Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetComponentRep Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : GetComponentRep Method (ISwDMTable)

Gets the component representation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentRep( _  
    ByVal RowIndex As System.Integer, _  
    ByRef ComponentRep As System.String _  
) As SwDmTableError
```

Visual Basic (Usage)

```
Dim instance As ISwDMTable  
Dim RowIndex As System.Integer  
Dim ComponentRep As System.String  
Dim value As SwDmTableError
```



```
value = instance.GetComponentRep(RowIndex, ComponentRep)
```

C#

```
SwDmTableError GetComponentRep(  
    System.int RowIndex,  
    out System.string ComponentRep  
)
```

C++/CLI

```
SwDmTableError GetComponentRep(  
& System.int RowIndex,  
[Out] System.String^ ComponentRep  
)
```

Parameters

RowIndex
Row number for the component representation
ComponentRep
Component representation

Return Value

Error as defined in [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::GetComponentRep](#).

Remarks

Before calling this method, call [ISwDMTable::GetRowCount](#) to determine the index of the row for the component representation.

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetHeaderStyle Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : GetHeaderStyle Method (ISwDMTable)

Gets the header style for the table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHeaderStyle() As SwDmTableHeaderStyle
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim value As SwDmTableHeaderStyle  
  
value = instance.GetHeaderStyle()
```

C#

```
SwDmTableHeaderStyle GetHeaderStyle()
```

C++/CLI

[SwDmTableHeaderStyle](#) GetHeaderStyle();

Return Value

Header style as defined by [SwDmTableHeaderStyle](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::GetHeaderStyle](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetRowCount Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : GetRowCount Method (ISwDMTable)

Gets the number of rows in the table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRowCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim value As System.Integer  
  
value = instance.GetRowCount()
```

C#

```
System.int GetRowCount()
```

C++/CLI

```
System.int GetRowCount();
```

Return Value

Number of rows

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::GetRowCount](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)
[ISwDMTable::AddRowHead Method](#)
[ISwDMTable::AddRowTail Method](#)
[ISwDMTable::DeleteRow Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

IsTitleVisible Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : IsTitleVisible Method (ISwDMTable)

Gets whether the table title is visible.

.NET Syntax

Visual Basic (Declaration)

```
Function IsTitleVisible() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim value As System.Boolean  
  
value = instance.IsTitleVisible()
```

C#

```
System.bool IsTitleVisible()
```

C++/CLI

```
System.bool IsTitleVisible();
```

Return Value

True if the table title is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMTable.IsTitleVisible](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

Name Property (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : Name Property (ISwDMTable)

Gets the name of the table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim value As System.String  
  
value = instance.Name
```

C#

```
System.string Name {get;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
}
```

Property Value

Name of the table

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::Name](#).

See Also

[ISwDMTable Interface](#)
[ISwDMTable Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SetCellText Method (ISwDMTable)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable Interface](#) : SetCellText Method (ISwDMTable)

Sets the specified text in the specified cell.

.NET Syntax

Visual Basic (Declaration)

```
Function SetCellText( _  
    ByVal RowIndex As System.Integer, _  
    ByVal ColumnIndex As System.Integer, _  
    ByVal CellTextIn As System.String _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable  
Dim RowIndex As System.Integer  
Dim ColumnIndex As System.Integer  
Dim CellTextIn As System.String  
Dim value As SwDmTableError
```

```
value = instance.SetCellText(RowIndex, ColumnIndex, CellTextIn)
```

C#

```
SwDmTableError SetCellText(  
    System.int RowIndex,  
    System.int ColumnIndex,  
    System.string CellTextIn  
)
```

C++/CLI

```
SwDmTableError SetCellText(  
& System.int RowIndex,  
& System.int ColumnIndex,  
& System.String^ CellTextIn  
)
```

Parameters

RowIndex

Index of row where cell is located

ColumnIndex

Index of column where cell is located

CellTextIn

Text for cell

Return Value

Error as defined by [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable::SetCellText](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

Before calling this method, call:

- [ISwDMTable::GetRowCount](#) to determine the index of the row where the cell is located.
- [ISwDMTable::GetColumnCount](#) to determine the index of the column where the cell is located.

See Also

[ISwDMTable Interface](#)

[ISwDMTable Members](#)

[ISwDMTable::GetCellText Method](#)

[ISwDMTable2::GetCellTextHorizontalJustification Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

ISwDMTable2 (Type)

ISwDMTable2 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable2 Interface

Accesses revision and bill of materials (BOM) tables.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMTable2
    Inherits ISwDMTable
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2
```

C#

```
public interface ISwDMTable2 : ISwDMTable
```

C++/CLI

```
public interface class ISwDMTable2 : public ISwDMTable
```

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2](#).

Remarks

Only revision and bill of materials (BOM) tables are supported.

NOTES:

- You can access an SwDMTable2 object by calling QueryInterface on an [ISwDMTable](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMTable object can be assigned to a SwDMTable2 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMDocument10::GetTable](#)

See Also

- [ISwDMTable2 Members](#)
- [SolidWorks.Interop.swdocumentmgr.Namespace](#)
- [ISwDMTable Interface](#)
- [ISwDMTable3 Interface](#)
- [ISwDMDocument10::GetTableNames Method](#)
- [ISwDMTable4 Interface](#)
- [ISwDMTable5 Interface](#)
- [ISwDMTable6 Interface](#)

ISwDMTable2 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable2 Interface

For a list of all members of this type, see [ISwDMTable2 members](#).

Public Methods

Name	Description
GetBOMNumberIncrement	Gets the increment value by which the item numbers are increased in the bill of materials (BOM) table.

		
	GetBOMStartNumber	Gets the starting item number for this bill of materials (BOM) table.
	GetBOMTableType	Gets the type of bill of materials (BOM) table.
	GetCellTextHorizontalJustification	Gets the type of text horizontal alignment for the specified cell in this table.
	GetColumnCustomProperty	Gets the custom property for the specified column in this table.
	GetColumnWidth	Gets the width of the specified column in this table.
	GetFeatureName	Gets the name of the bill of materials (BOM) feature.
	ReferencedConfigurationNames	Gets the configuration names used by the bill of materials (BOM) table.
	ReferencedDocumentName	Gets the document name used by this bill of materials (BOM) table.

[Top](#)

See Also

[ISwDMTable2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMDocument10::GetTableNames Method](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMTable2 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable2 Interface

The following tables list the members exposed by [ISwDMTable2](#).

Public Methods

Name	Description
	GetBOMNumberIncrement
	GetBOMStartNumber
	GetBOMTableType
	GetCellTextHorizontalJustification
	GetColumnCustomProperty
	GetColumnWidth
	GetFeatureName
	ReferencedConfigurationNames
	ReferencedDocumentName

[Top](#)

See Also

[ISwDMTable2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMDocument10::GetTableNames Method](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetBOMNumberIncrement Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : GetBOMNumberIncrement Method (ISwDMTable2)

Gets the increment value by which the item numbers are increased in the bill of materials (BOM) table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBOMNumberIncrement( _  
    ByRef Error As SwDmTableError _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2  
Dim Error As SwDmTableError  
Dim value As System.Integer  
  
value = instance.GetBOMNumberIncrement(Error)
```

C#

```
System.int GetBOMNumberIncrement(  
    out SwDmTableError Error  
)
```

C++/CLI

```
System.int GetBOMNumberIncrement(  
& [Out] SwDmTableError Error  
)
```

Parameters

Error

Error as defined by [SwDmTableError](#)

Return Value

Increment value by which the item numbers are increased in the bill of materials (BOM) table

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::GetBOMNumberIncrement](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable2::GetBOMStartNumber Method](#)
[ISwDMTable2::GetBOMTableType Method](#)
[ISwDMComponent5::ExcludeFromBOM Property](#)
[ISwDMConfiguration11::BOMPartNoSource Property](#)
[ISwDMConfiguration11::ShowChildComponentsInBOM Property](#)
[ISwDMTable2::GetFeatureName Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetBOMStartNumber Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : GetBOMStartNumber Method (ISwDMTable2)

Gets the starting item number for this bill of materials (BOM) table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBOMStartNumber( _  
    ByRef Error As SwDmTableError _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2  
Dim Error As SwDmTableError  
Dim value As System.Integer  
  
value = instance.GetBOMStartNumber(Error)
```

C#

```
System.int GetBOMStartNumber(  
    out SwDmTableError Error  
)
```

C++/CLI

```
System.int GetBOMStartNumber(  
& [Out] SwDmTableError Error  
)
```

Parameters

Error

Error as defined by [SwDmTableError](#)

Return Value

Starting item number for this bill of materials (BOM) table

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::GetBOMStartNumber](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable2::GetBOMNumberIncrement Method](#)
[ISwDMTable2::GetBOMTableType Method](#)
[ISwDMConfiguration11::BOMPartNoSource Property](#)
[ISwDMConfiguration11::ShowChildComponentsInBOM Property](#)
[ISwDMComponent5::ExcludeFromBOM Property](#)
[ISwDMTable2::GetFeatureName Method](#)
[ISwDMTable2::ReferencedConfigurationNames Method](#)
[ISwDMTable2::ReferencedDocumentName Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetBOMTableType Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : GetBOMTableType Method (ISwDMTable2)

Gets the type of bill of materials (BOM) table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBOMTableType( _  
    ByRef Error As SwDmTableError _  
) As swDmBOMTableType
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2  
Dim Error As SwDmTableError  
Dim value As swDmBOMTableType  
  
value = instance.GetBOMTableType(Error)
```

C#

```
swDmBOMTableType GetBOMTableType(  
    out SwDmTableError Error  
)
```

C++/CLI

```
swDmBOMTableType GetBOMTableType(  
& [Out] SwDmTableError Error  
)
```

Parameters

Error

Error as defined by [SwDmTableError](#)

Return Value

Type of BOM table as defined in [swDmBOMTableType](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::GetBOMTableType](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable2::GetBOMNumberIncrement Method](#)
[ISwDMTable2::GetBOMStartNumber Method](#)
[ISwDMConfiguration11::BOMPartNoSource Property](#)
[ISwDMConfiguration11::ShowChildComponentsInBOM Property](#)
[ISwDMComponent5::ExcludeFromBOM Property](#)
[ISwDMTable2::GetFeatureName Method](#)
[ISwDMTable2::ReferencedConfigurationNames Method](#)
[ISwDMTable2::ReferencedDocumentName Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetCellTextHorizontalJustification Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : GetCellTextHorizontalJustification Method (ISwDMTable2)

Gets the type of text horizontal alignment for the specified cell in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCellTextHorizontalJustification( _
    ByVal RowIndex As System.Integer, _
    ByVal ColumnIndex As System.Integer, _
    ByRef Error As SwDmTableError _
) As swDmTableCellHorzAlignType
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2
Dim RowIndex As System.Integer
Dim ColumnIndex As System.Integer
Dim Error As SwDmTableError
Dim value As swDmTableCellHorzAlignType

value = instance.GetCellTextHorizontalJustification(RowIndex, ColumnIndex, Error)
```

C#

```
swDmTableCellHorzAlignType GetCellTextHorizontalJustification(
    System.int RowIndex,
    System.int ColumnIndex,
    out SwDmTableError Error
)
```

C++/CLI

```
swDmTableCellHorzAlignType GetCellTextHorizontalJustification(
    & System.int RowIndex,
    & System.int ColumnIndex,
    & [Out] SwDmTableError Error
)
```

Parameters

RowIndex

Index of row where the cell is located

ColumnIndex

Index of the column where the cell is located

Error

Error as defined by [swDmTableError](#)

Return Value

Type of horizontal alignment for this cell as defined by [swDmTableCellHorzAlignType](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::GetCellTextHorizontalJustification](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

Before calling this method, call:

- [ISwDMTable::GetRowCount](#) to determine the index of the row where the cell is located.
- [ISwDMTable::GetColumnCount](#) to determine the index of the column where the cell is located.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable::GetCellText Method](#)
[ISwDMTable::SetCellText Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : GetColumnCustomProperty Method (ISwDMTable2)

Gets the custom property for the specified column in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnCustomProperty( _  
    ByVal ColumnIndex As System.Integer, _  
    ByRef Error As SwDmTableError _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2  
Dim ColumnIndex As System.Integer  
Dim Error As SwDmTableError  
Dim value As System.String  
  
value = instance.GetColumnCustomProperty(ColumnIndex, Error)
```

C#

```
System.string GetColumnCustomProperty(  
    System.int ColumnIndex,  
    out SwDmTableError Error  
)
```

C++/CLI

```
System.String^ GetColumnCustomProperty(  
& System.int ColumnIndex,  
& [Out] SwDmTableError Error  
)
```

Parameters

ColumnIndex
Index of the column
Error
Error as defined by [swDmTableError](#)

Return Value

Column custom property, which is in the form of "\$PRP:..."

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::GetColumnCustomProperty](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

Before calling this method, call [ISwDMTable::GetColumnCount](#) to determine the index of the column to whose custom property you want.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable::AddColumnLeft Method](#)
[ISwDMTable::AddColumnRight Method](#)
[ISwDMTable::DeleteColumn Method](#)
[ISwDMTable::GetColumnCount Method](#)
[ISwDMTable::GetColumnType Method](#)
[ISwDMTable2::GetColumnWidth Method](#)

Availability

GetColumnWidth Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : GetColumnWidth Method (ISwDMTable2)

Gets the width of the specified column in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnWidth( _
    ByVal ColumnIndex As System.Integer, _
    ByRef Error As SwDmTableError _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2
Dim ColumnIndex As System.Integer
Dim Error As SwDmTableError
Dim value As System.Object

value = instance.GetColumnWidth(ColumnIndex, Error)
```

C#

```
System.object GetColumnWidth(
    System.int ColumnIndex,
    out SwDmTableError Error
)
```

C++/CLI

```
System.Object^ GetColumnWidth(
    & System.int ColumnIndex,
    & [Out] SwDmTableError Error
)
```

Parameters

ColumnIndex
Index of the column

Error
Error as defined by [swDmTableError](#)

Return Value

Width

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::GetColumnWidth](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

Before calling this method, call [ISwDMTable::GetColumnCount](#) to determine the index of the column whose width you want.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable::AddColumnLeft Method](#)
[ISwDMTable::AddColumnRight Method](#)
[ISwDMTable::DeleteColumn Method](#)
[ISwDMTable::GetColumnCount Method](#)
[ISwDMTable::GetColumnType Method](#)
[ISwDMTable2::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetFeatureName Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : GetFeatureName Method (ISwDMTable2)

Gets the name of the bill of materials (BOM) feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetFeatureName( _  
    ByRef Error As SwDmTableError _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2  
Dim Error As SwDmTableError  
Dim value As System.String  
  
value = instance.GetFeatureName(Error)
```

C#

```
System.string GetFeatureName(  
    out SwDmTableError Error  
)
```

C++/CLI

```
System.String^ GetFeatureName(  
& [Out] SwDmTableError Error  
)
```

Parameters

Error

Error as described by [SwDmTableError](#)

Return Value

BOM feature name

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::GetFeatureName](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable2::GetBOMNumberIncrement Method](#)
[ISwDMTable2::GetBOMStartNumber Method](#)
[ISwDMTable2::GetBOMTableType Method](#)
[ISwDMComponent5::ExcludeFromBOM Property](#)
[ISwDMConfiguration11::BOMPartNoSource Property](#)
[ISwDMConfiguration11::ShowChildComponentsInBOM Property](#)
[ISwDMTable2::ReferencedConfigurationNames Method](#)
[ISwDMTable2::ReferencedDocumentName Method](#)

Availability

ReferencedConfigurationNames Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : ReferencedConfigurationNames Method (ISwDMTable2)

Gets the configuration names used by the bill of materials (BOM) table.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ReferencedConfigurationNames( _
    ByRef Error As SwDmTableError _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2
Dim Error As SwDmTableError
Dim value As System.Object

value = instance.ReferencedConfigurationNames(Error)
```

C#

```
System.Object ReferencedConfigurationNames(
    out SwDmTableError Error
)
```

C++/CLI

```
System.Object^ ReferencedConfigurationNames(
    & [Out] SwDmTableError Error
)
```

Parameters

Error
Error as defined by [swDmTableError](#)

Return Value

Array of configuration names

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::ReferencedConfigurationNames](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable2::ReferencedConfigurationNames Method](#)
[ISwDMTable2::GetFeatureName Method](#)
[ISwDMTable2::GetBOMTableType Method](#)
[ISwDMTable2::GetBOMStartNumber Method](#)
[ISwDMTable2::GetBOMNumberIncrement Method](#)
[ISwDMConfiguration11::BOMPartNoSource Property](#)
[ISwDMConfiguration11::ShowChildComponentsInBOM Property](#)
[ISwDMComponent5::ExcludeFromBOM Property](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

ReferencedDocumentName Method (ISwDMTable2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable2 Interface](#) : ReferencedDocumentName Method (ISwDMTable2)

Gets the document name used by this bill of materials (BOM) table.

.NET Syntax

Visual Basic (Declaration)

```
Function ReferencedDocumentName( _  
    ByRef Error As SwDmTableError _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable2  
Dim Error As SwDmTableError  
Dim value As System.String
```

```
value = instance.ReferencedDocumentName(Error)
```

C#

```
System.string ReferencedDocumentName(  
    out SwDmTableError Error  
)
```

C++/CLI

```
System.String^ ReferencedDocumentName(  
& [Out] SwDmTableError Error  
)
```

Parameters

Error

Error as defined by [SwDmTableError](#)

Return Value

Document name

Visual Basic for Applications (VBA) Syntax

See [SwDMTable2::ReferencedDocumentName](#).

Remarks

This method only supports documents saved in SOLIDWORKS 2009 and later.

See Also

[ISwDMTable2 Interface](#)
[ISwDMTable2 Members](#)
[ISwDMTable2::ReferencedConfigurationNames Method](#)
[ISwDMTable2::GetFeatureName Method](#)
[ISwDMTable2::GetBOMTableType Method](#)
[ISwDMTable2::GetBOMStartNumber Method](#)
[ISwDMTable2::GetBOMNumberIncrement Method](#)
[ISwDMConfiguration11::ShowChildComponentsInBOM Property](#)
[ISwDMConfiguration11::BOMPartNoSource Property](#)
[ISwDMComponent5::ExcludeFromBOM Property](#)

Availability

SOLIDWORKS Document Manager 2009 SP0

ISwDMTable3 (Type)

ISwDMTable3 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable3 Interface

Accesses revision and bill of materials (BOM) tables.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMTable3
    Inherits ISwDMTable, ISwDMTable2
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable3
```

C#

```
public interface ISwDMTable3 : ISwDMTable, ISwDMTable2
```

C++/CLI

```
public interface class ISwDMTable3 : public ISwDMTable, ISwDMTable2
```

Visual Basic for Applications (VBA) Syntax

See [SwDMTable3](#).

Example

[Get Table Cell Text \(C#\)](#)
[Get Table Cell Text \(VB.NET\)](#)

Remarks

Only revision and bill of materials (BOM) tables are supported.

NOTES:

- You can access an SwDMTable3 object by calling QueryInterface on na [ISwDMTable](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMTable object can be assigned to a SwDMTable3 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMDocument10::GetTable](#)

See Also

[ISwDMTable3 Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMDocument10::GetTableNames Method](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

ISwDMTable3 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable3 Interface

The following tables list the members exposed by [ISwDMTable3](#).

Public Methods

Name	Description
 GetTableCellText	Gets all of the cell text and the number of rows and columns in this table.

[Top](#)

See Also

[ISwDMTable3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMDocument10::GetTableNames Method](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMTable3 Interface Methods

[See Also](#)

 [SolidWorks.Interop.swdocumentmgr Namespace](#) : [ISwDMTable3 Interface](#)

For a list of all members of this type, see [ISwDMTable3 members](#).

Public Methods

Name	Description
 GetTableCellText	Gets all of the cell text and the number of rows and columns in this table.

[Top](#)

See Also

[ISwDMTable3 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMDocument10::GetTableNames Method](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetTableCellText Method (ISwDMTable3)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable3 Interface](#) : [GetTableCellText Method \(ISwDMTable3\)](#)

Gets all of the cell text and the number of rows and columns in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableCellText( _  
    ByRef Error As SwDmTableError, _  
    ByRef RowCount As System.Integer, _  
    ByRef ColCount As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable3  
Dim Error As SwDmTableError  
Dim RowCount As System.Integer  
Dim ColCount As System.Integer  
Dim value As System.Object  
  
value = instance.GetTableCellText(Error, RowCount, ColCount)
```

C#

```
System.Object GetTableCellText(  
    out SwDmTableError Error,  
    out System.Int RowCount,  
    out System.Int ColCount  
)
```

C++/CLI

```
System.Object^ GetTableCellText(  
& [Out] SwDmTableError Error,  
& [Out] System.Int RowCount,  
& [Out] System.Int ColCount  
)
```

Parameters

Error

Error as defined by [SwDmTableError](#)

RowCount

Number of rows in the table

ColCount

Number of columns in the table

Return Value

A 1-dimensional array of strings containing all of the cell text in the table

Visual Basic for Applications (VBA) Syntax

See [SwDMTable3::GetTableCellText](#).

Example

[Get Table Cell Text \(C#\)](#)

[Get Table Cell Text \(VB.NET\)](#)

Remarks

The returned array is indexed by row count.

See Also

[ISwDMTable3 Interface](#)

[ISwDMTable3 Members](#)

[ISwDMTable::GetCellText Method](#)

Availability

SOLIDWORKS 2009 SP4, Revision Number 17.4

ISwDMTable4 (Type)

ISwDMTable4 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable4 Interface

Accesses revision and bill of materials (BOM) tables.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMTable4
    Inherits ISwDMTable, ISwDMTable2, ISwDMTable3
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable4
```

C#

```
public interface ISwDMTable4 : ISwDMTable, ISwDMTable2, ISwDMTable3
```

C++/CLI

```
public interface class ISwDMTable4 : public ISwDMTable, ISwDMTable2, ISwDMTable3
```

Visual Basic for Applications (VBA) Syntax

See [SwDMTable4](#).

Example

[Get BOM Tables \(C#\)](#)
[Get BOM Tables \(VB.NET\)](#)

Remarks

Only revision and bill of materials (BOM) tables are supported.

NOTES:

- You can access an SwDMTable4 object by calling QueryInterface on an [ISwDMTable](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMTable object can be assigned to a SwDMTable4 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMDocument10::GetTable](#)

See Also

[ISwDMTable4 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

ISwDMTable4 Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable4 Interface

The following tables list the members exposed by [ISwDMTable4](#).

Public Properties

Name	Description
 DisplayAsOneItem	Gets whether different configurations have the same item number when the bill of materials (BOM) table contains components with multiple configurations.
 Hidden	Gets whether the bill of materials (BOM) table is hidden.
 PartConfigurationGrouping	Gets the part configuration grouping for the bill of materials (BOM) table.

[Top](#)

See Also

[ISwDMTable4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMTable4 Interface Properties

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable4 Interface

For a list of all members of this type, see [ISwDMTable4 members](#).

Public Properties

Name	Description
 DisplayAsOneItem	Gets whether different configurations have the same item number when the bill of materials (BOM) table contains components with multiple configurations.
 Hidden	Gets whether the bill of materials (BOM) table is hidden.
 PartConfigurationGrouping	Gets the part configuration grouping for the bill of materials (BOM) table.

[Top](#)

See Also

[ISwDMTable4 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable5 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

DisplayAsOneItem Property (ISwDMTable4)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable4 Interface](#) : DisplayAsOneItem Property (ISwDMTable4)

Gets whether different configurations have the same item number when the bill of materials (BOM) table contains components with multiple configurations.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property DisplayAsOneItem As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISwDMTable4
Dim value As System.Boolean

value = instance.DisplayAsOneItem
```

C#

```
System.bool DisplayAsOneItem {get;}
```

C++/CLI

```
property System.bool DisplayAsOneItem {  
    System.bool get();  
}
```

Property Value

True if different configurations have the same item number when the BOM table contains components with multiple configurations, false if different configurations have different item numbers when the BOM table contains components with multiple configurations

Visual Basic for Applications (VBA) Syntax

See [SwDMTable4::DisplayAsOneItem](#).

Example

[Get BOM Tables \(C#\)](#)
[Get BOM Tables \(VB.NET\)](#)

Remarks

This property only supports model documents saved in SOLIDWORKS 2012 and later.

See Also

[ISwDMTable4 Interface](#)
[ISwDMTable4 Members](#)

Availability

SOLIDWORKS Document Manager API 2012 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Hidden Property (ISwDMTable4)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable4 Interface](#) : Hidden Property (ISwDMTable4)

Gets whether the bill of materials (BOM) table is hidden.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Hidden As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable4  
Dim value As System.Boolean
```

```
value = instance.Hidden
```

C#

```
System.bool Hidden {get;}
```

C++/CLI

```
property System.bool Hidden {  
    System.bool get();  
}
```

Property Value

True if the BOM table is hidden, false if the BOM table is shown

Visual Basic for Applications (VBA) Syntax

See [SwDMTable4::Hidden](#).

Example

[Get BOM Tables \(C#\)](#)
[Get BOM Tables \(VB.NET\)](#)

Remarks

This property only supports model documents saved in SOLIDWORKS 2012 and later.

See Also

[ISwDMTable4 Interface](#)
[ISwDMTable4 Members](#)

Availability

SOLIDWORKS Document Manager API 2012 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

PartConfigurationGrouping Property (ISwDMTable4)

[See Also](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable4 Interface](#) : PartConfigurationGrouping Property (ISwDMTable4)

Gets the part configuration grouping for the bill of materials (BOM) table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PartConfigurationGrouping As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable4  
Dim value As System.Integer  
  
value = instance.PartConfigurationGrouping
```

C#

```
System.int PartConfigurationGrouping {get;}
```

C++/CLI

```
property System.int PartConfigurationGrouping {  
    System.int get();  
}
```

Property Value

Part configuration grouping as defined in [swDMPartConfigurationGrouping](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable4::PartConfigurationGrouping](#).

Example

[Get BOM Tables \(C#\)](#)
[Get BOM Tables \(VB.NET\)](#)

Requirements

This property only supports model documents saved in SOLIDWORKS 2012 and later.

See Also

[ISwDMTable4 Interface](#)
[ISwDMTable4 Members](#)

Availability

SOLIDWORKS Document Manager API 2012 SP0

ISwDMTable5 (Type)

ISwDMTable5 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable5 Interface

Accesses revision and bill of materials (BOM) tables.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMTable5
    Inherits ISwDMTable, ISwDMTable2, ISwDMTable3, ISwDMTable4
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable5
```

C#

```
public interface ISwDMTable5 : ISwDMTable, ISwDMTable2, ISwDMTable3, ISwDMTable4
```

C++/CLI

```
public interface class ISwDMTable5 : public ISwDMTable, ISwDMTable2, ISwDMTable3, ISwDMTable4
```

Visual Basic for Applications (VBA) Syntax

See [SwDMTable5](#).

Example

[Get BOM Tables \(VB.NET\)](#)
[Get BOM Tables \(C#\)](#)

Remarks

Only revision and bill of materials (BOM) tables are supported.

NOTES:

- You can access an SwDMTable5 object by calling QueryInterface on an [ISwDMTable](#) object in C++ or by direct assignment in Visual Basic.
- The SwDMTable object can be assigned to a SwDMTable5 variable, just like the SOLIDWORKS [IModelDoc2](#) object can be assigned to a SOLIDWORKS [IPartDoc](#) variable.

Accessors

[ISwDMDocument10::GetTable](#)

See Also

[ISwDMTable5 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable6 Interface](#)

ISwDMTable5 Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable5 Interface

The following tables list the members exposed by [ISwDMTable5](#).

Public Properties

Name	Description
 Sheet	Gets the drawing sheet for this table.

[Top](#)

See Also

[ISwDMTable5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMTable5 Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable5 Interface

For a list of all members of this type, see [ISwDMTable5 members](#).

Public Properties

Name	Description
 Sheet	Gets the drawing sheet for this table.

[Top](#)

See Also

[ISwDMTable5 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable6 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Sheet Property (ISwDMTable5)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable5 Interface](#) : Sheet Property (ISwDMTable5)

Gets the drawing sheet for this table.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Sheet As SwDMSheet
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable5  
Dim value As SwDMSheet  
  
value = instance.Sheet
```

C#

```
SwDMSheet Sheet {get;}
```

C++/CLI

```
property SwDMSheet^ Sheet {  
    SwDMSheet^ get();  
}
```

Property Value

[ISwDMSheet](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable5::Sheet](#).

Example

See the [ISwDMTable5](#) examples.

Remarks

This property works only with documents saved in SOLIDWORKS 2017 or later.

See Also

[ISwDMTable5 Interface](#)
[ISwDMTable5 Members](#)

Availability

SOLIDWORKS Document Manager API 2017 FCS

ISwDMTable6 (Type)

ISwDMTable6 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable6 Interface

Accesses revision and bill of materials (BOM) tables.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMTable6
    Inherits ISwDMTable, ISwDMTable2, ISwDMTable3, ISwDMTable4, ISwDMTable5
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable6
```

C#

```
public interface ISwDMTable6 : ISwDMTable, ISwDMTable2, ISwDMTable3, ISwDMTable4, ISwDMTable5
```

C++/CLI

```
public interface class ISwDMTable6 : public
ISwDMTable, ISwDMTable2, ISwDMTable3, ISwDMTable4, ISwDMTable5
```

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6](#).

Example

[Get Revision Tables \(VB.NET\)](#)
[Get Revision Tables \(C#\)](#)

Accessors

[ISwDMDocument10::GetTable](#)

See Also

[ISwDMTable6 Members](#)
[SolidWorks.Interop.swdocumentmgr.Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)

ISwDMTable6 Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : ISwDMTable6 Interface

The following tables list the members exposed by [ISwDMTable6](#).

Public Methods

Name	Description
 AddRevisionRow	Adds a row with the specified revision to this table.
 GetLatestRevision	Gets the latest revision in this table.

	GetRevisionInfo	Gets information for the specified revision.
	GetRevTableStyle	Gets the style of this revision table.
	HasPlaceholderRow	Gets whether this table has a placeholder row.
	UpdateRevisionColumn	Updates the specified revision column in this table.
	UpdateRevisionRow	Updates the specified revision row in this table.

[Top](#)

 See Also

[ISwDMTable6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ISwDMTable6 Interface Methods

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMTable6 Interface

For a list of all members of this type, see [ISwDMTable6 members](#).

 Public Methods

Name	Description
	AddRevisionRow Adds a row with the specified revision to this table.
	GetLatestRevision Gets the latest revision in this table.
	GetRevisionInfo Gets information for the specified revision.
	GetRevTableStyle Gets the style of this revision table.
	HasPlaceholderRow Gets whether this table has a placeholder row.
	UpdateRevisionColumn Updates the specified revision column in this table.
	UpdateRevisionRow Updates the specified revision row in this table.

[Top](#)

 See Also

[ISwDMTable6 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMTable Interface](#)
[ISwDMTable2 Interface](#)
[ISwDMTable3 Interface](#)
[ISwDMTable4 Interface](#)
[ISwDMTable5 Interface](#)

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

AddRevisionRow Method (ISwDMTable6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable6 Interface](#) : AddRevisionRow Method (ISwDMTable6)

Adds a row with the specified revision to this table.

 .NET Syntax

Visual Basic (Declaration)

```
Function AddRevisionRow( _  
    ByVal Revision As System.String _  
    ) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable6
Dim Revision As System.String
Dim value As SwDmTableError

value = instance.AddRevisionRow(Revision)
```

C#

```
SwDmTableError AddRevisionRow(
    System.string Revision
)
```

C++/CLI

```
SwDmTableError AddRevisionRow(
    & System.String^ Revision
)
```

Parameters

Revision
Revision

Return Value

Return code as defined in [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6::AddRevisionRow](#).

See Also

[ISwDMTable6 Interface](#)
[ISwDMTable6 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetLatestRevision Method (ISwDMTable6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable6 Interface](#) : GetLatestRevision Method (ISwDMTable6)

Gets the latest revision in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLatestRevision() As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable6
Dim value As System.String

value = instance.GetLatestRevision()
```

C#

```
System.string GetLatestRevision()
```

C++/CLI

```
System.String^ GetLatestRevision();
```

Return Value

Latest revision

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6::GetLatestRevision](#).

See Also

[ISwDMTable6 Interface](#)
[ISwDMTable6 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetRevisionInfo Method (ISwDMTable6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable6 Interface](#) : GetRevisionInfo Method (ISwDMTable6)

Gets information for the specified revision.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRevisionInfo( _  
    ByVal Revision As System.String, _  
    ByRef RowData As System.Object _  
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable6  
Dim Revision As System.String  
Dim RowData As System.Object  
Dim value As SwDmTableError
```

```
value = instance.GetRevisionInfo(Revision, RowData)
```

C#

```
SwDmTableError GetRevisionInfo(  
    System.string Revision,  
    out System.object RowData  
)
```

C++/CLI

```
SwDmTableError GetRevisionInfo(  
& System.String^ Revision,  
& [Out] System.Object^ RowData  
)
```

Parameters

Revision
Revision for which to get data
RowData
Array of revision information

Return Value

Return code as defined in [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6::GetRevisionInfo](#).

See Also

[ISwDMTable6 Interface](#)
[ISwDMTable6 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

GetRevTableStyle Method (ISwDMTable6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable6 Interface](#) : GetRevTableStyle Method (ISwDMTable6)

Gets the style of this revision table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRevTableStyle() As swDmRevTableStyle
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable6  
Dim value As swDmRevTableStyle  
  
value = instance.GetRevTableStyle()
```

C#

```
swDmRevTableStyle GetRevTableStyle()
```

C++/CLI

```
swDmRevTableStyle GetRevTableStyle();
```

Return Value

Revision table style as defined in [SwDmRevTableStyle](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6::GetRevTableStyle](#).

See Also

[ISwDMTable6 Interface](#)
[ISwDMTable6 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

HasPlaceholderRow Method (ISwDMTable6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable6 Interface](#) : HasPlaceholderRow Method (ISwDMTable6)

Gets whether this table has a placeholder row.

.NET Syntax

Visual Basic (Declaration)

```
Function HasPlaceholderRow() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable6
Dim value As System.Boolean

value = instance.HasPlaceholderRow()
```

C#

```
System.bool HasPlaceholderRow()
```

C++/CLI

```
System.bool HasPlaceholderRow();
```

Return Value

True if this table has a placeholder row, false if not

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6::HasPlaceholderRow](#).

See Also

[ISwDMTable6 Interface](#)
[ISwDMTable6 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

UpdateRevisionColumn Method (ISwDMTable6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable6 Interface](#) : UpdateRevisionColumn Method (ISwDMTable6)

Updates the specified revision column in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function UpdateRevisionColumn( _
    ByVal Revision As System.String, _
    ByVal ColType As SwDmColumnType, _
    ByVal Data As System.String _
) As SwDmTableError
```

Visual Basic (Usage)



```
Dim instance As ISwDMTable6
Dim Revision As System.String
Dim ColType As SwDmColumnType
Dim Data As System.String
Dim value As SwDmTableError

value = instance.UpdateRevisionColumn(Revision, ColType, Data)
```

C#

```
SwDmTableError UpdateRevisionColumn(
    System.string Revision,
    SwDmColumnType ColType,
```

```
System.string Data
)
```

C++/CLI

```
SwDmTableError UpdateRevisionColumn(
& System.String^ Revision,
& SwDmColumnType ColType,
& System.String^ Data
)
```

Parameters

Revision

Revision; if empty, the column in the latest revision row is updated

ColType

Type of column as defined in [SwDmColumnType](#)

Data

Column data

Return Value

Return code as defined in [swDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6::UpdateRevisionColumn](#).

See Also

[ISwDMTable6 Interface](#)

[ISwDMTable6 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0

SOLIDWORKS Document Manager API Help

[Send comments](#) on this topic.

UpdateRevisionRow Method (ISwDMTable6)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMTable6 Interface](#) : UpdateRevisionRow Method (ISwDMTable6)

Updates the specified revision row in this table.

.NET Syntax

Visual Basic (Declaration)

```
Function UpdateRevisionRow( _
    ByVal Revision As System.String, _
    ByRef RowDataIn As System.Object _
) As SwDmTableError
```

Visual Basic (Usage)

```
Dim instance As ISwDMTable6
Dim Revision As System.String
Dim RowDataIn As System.Object
Dim value As SwDmTableError
```

```
value = instance.UpdateRevisionRow(Revision, RowDataIn)
```

C#

```
SwDmTableError UpdateRevisionRow(
    System.string Revision,
    ref System.object RowDataIn
)
```

C++/CLI



```
SwDmTableError UpdateRevisionRow(  
& System.String^ Revision,  
& System.Object^% RowDataIn  
)
```

Parameters

Revision

Revision; if empty, the latest revision row is updated

RowDataIn

Row data

Return Value

Return code as defined in [SwDmTableError](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMTable6::UpdateRevisionRow](#).

See Also

[ISwDMTable6 Interface](#)

[ISwDMTable6 Members](#)

Availability

SOLIDWORKS Document Manager API 2018 SP0