

SOLIDWORKS Document Manager API (.NET) — Reference (18/19): ISwDMView. swDmShowChildComponentsInBOMResult

SOLIDWORKS API Documentation (converted from CHM)

ISwDMView (Type)

ISwDMView Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMView Interface

Access the the drawing views in this drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMView
```

Visual Basic (Usage)



```
Dim instance As ISwDMView
```

C#

```
public interface ISwDMView
```

C++/CLI

```
public interface class ISwDMView
```

Visual Basic for Applications (VBA) Syntax

See [SwDMView](#).

Example

[Get BOM Tables \(VB.NET\)](#)
[Get BOM Tables \(C#\)](#)

Accessors

[ISwDMDocument10::GetViews](#)
[ISwDMSheet4::CustomPropertyView](#)
[ISwDMSheet4::GetViews](#)

See Also

[ISwDMView Members](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMView2 Interface](#)

ISwDMView Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMView Interface

The following tables list the members exposed by [ISwDMView](#).

Public Properties

Name	Description
 Name	Gets or sets the name of this drawing view.

 ReferencedConfiguration	Gets the name of the configuration for this drawing view. NOTE: This property is a get-only property. Set is not implemented.
 ReferencedDocument	Gets or sets the name of the document for this drawing view. NOTE: This property is a get-only property. Set is not implemented.
 Sheet	Gets or sets the sheet for this drawing view.
 SheetName	Gets or sets the name of the sheet for this drawing view.

[Top](#)

 See Also

[ISwDMView Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMView2 Interface](#)

ISwDMView Interface Properties

[See Also](#)

	SolidWorks.Interop.swdocumentmgr Namespace : ISwDMView Interface
---	--

For a list of all members of this type, see [ISwDMView members](#).

 Public Properties

Name	Description
 Name	Gets or sets the name of this drawing view.
 ReferencedConfiguration	Gets the name of the configuration for this drawing view. NOTE: This property is a get-only property. Set is not implemented.
 ReferencedDocument	Gets or sets the name of the document for this drawing view. NOTE: This property is a get-only property. Set is not implemented.
 Sheet	Gets or sets the sheet for this drawing view.
 SheetName	Gets or sets the name of the sheet for this drawing view.

[Top](#)

 See Also

[ISwDMView Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMView2 Interface](#)

Name Property (ISwDMView)

[See Also](#)

	
SolidWorks.Interop.swdocumentmgr Namespace > ISwDMView Interface : Name Property (ISwDMView)	
Gets or sets the name of this drawing view.	

 .NET Syntax

Visual Basic (Declaration)

Property Name As System.String

Visual Basic (Usage)

```
Dim instance As ISwDMView
Dim value As System.String
```



```
instance.Name = value  
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

Property Value

Name of this drawing view

Visual Basic for Applications (VBA) Syntax

See [SwDMView::Name](#).

Example

See the [ISwDMView](#) examples.

See Also

[ISwDMView Interface](#)
[ISwDMView Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ReferencedConfiguration Property (ISwDMView)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMView Interface](#) : ReferencedConfiguration Property (ISwDMView)

Gets the name of the configuration for this drawing view.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property ReferencedConfiguration As System.String
```

Visual Basic (Usage)



```
Dim instance As ISwDMView  
Dim value As System.String
```

```
instance.ReferencedConfiguration = value  
value = instance.ReferencedConfiguration
```

C#

```
System.string ReferencedConfiguration {get; set;}
```

C++/CLI

```
property System.String^ ReferencedConfiguration {  
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

Property Value

Name of configuration

Visual Basic for Applications (VBA) Syntax

See [SwDMView::ReferencedConfiguration](#).

See Also

[ISwDMView Interface](#)
[ISwDMView Members](#)
[ISwDMView2::ReferencedConfigurationID Property \(\)](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

ReferencedDocument Property (ISwDMView)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMView Interface](#) : ReferencedDocument Property (ISwDMView)

Gets or sets the name of the document for this drawing view.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

Property ReferencedDocument As System.String

Visual Basic (Usage)



```
Dim instance As ISwDMView  
Dim value As System.String  
  
instance.ReferencedDocument = value  
  
value = instance.ReferencedDocument
```

C#

```
System.string ReferencedDocument {get; set;}
```

C++/CLI

```
property System.String^ ReferencedDocument {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

Property Value

Name of document

Visual Basic for Applications (VBA) Syntax

See [SwDMView::ReferencedDocument](#).

See Also

[ISwDMView Interface](#)
[ISwDMView Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

Sheet Property (ISwDMView)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMView Interface](#) : Sheet Property (ISwDMView)

Gets or sets the sheet for this drawing view.

.NET Syntax

Visual Basic (Declaration)

Property Sheet As SwDMSheet

Visual Basic (Usage)



```
Dim instance As ISwDMView
Dim value As SwDMSheet
```

```
instance.Sheet = value
```

```
value = instance.Sheet
```

C#

```
SwDMSheet Sheet {get; set;}
```

C++/CLI

```
property SwDMSheet^ Sheet {
    SwDMSheet^ get();
    void set ( & SwDMSheet^ value);
}
```

Property Value

[Sheet](#)

Visual Basic for Applications (VBA) Syntax

See [SwDMView::Sheet](#).

See Also

[ISwDMView Interface](#)
[ISwDMView Members](#)

Availability

SOLIDWORKS Document Manager API 2009 SP0

SOLIDWORKS Document Manager API Help

[Send comments on this topic.](#)

SheetName Property (ISwDMView)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMView Interface](#) : SheetName Property (ISwDMView)

Gets or sets the name of the sheet for this drawing view.

.NET Syntax

Visual Basic (Declaration)

Property SheetName As System.String

```
Dim instance As ISwDMView  
Dim value As System.String  
  
instance.SheetName = value  
  
value = instance.SheetName
```

C#

```
System.string SheetName {get; set;}
```

C++/CLI

```
property System.String^ SheetName {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

Property Value

Name of sheet

 Visual Basic for Applications (VBA) SyntaxSee [SwDMView::SheetName](#). **See Also**[ISwDMView Interface](#)
[ISwDMView Members](#) **Availability**

SOLIDWORKS Document Manager API 2009 SP0

ISwDMView2 (Type)

ISwDMView2 Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMView2 Interface

Access the the drawing views in this drawing document.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISwDMView2
    Inherits ISwDMView
```

Visual Basic (Usage)



```
Dim instance As ISwDMView2
```

C#

```
public interface ISwDMView2 : ISwDMView
```

C++/CLI

```
public interface class ISwDMView2 : public ISwDMView
```

Visual Basic for Applications (VBA) Syntax

See [SwDMView2](#).

Accessors

- [ISwDMDocument10::GetViews](#)
- [ISwDMSheet4::CustomPropertyView](#)
- [ISwDMSheet4::GetViews](#)

See Also

- [ISwDMView2 Members](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMView Interface](#)

ISwDMView2 Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMView2 Interface

The following tables list the members exposed by [ISwDMView2](#).

Public Properties

Name	Description
ReferencedConfigurationID	Gets the ID of the configuration for this drawing view.

[Top](#)

See Also

- [ISwDMView2 Interface](#)
- [SolidWorks.Interop.swdocumentmgr Namespace](#)
- [ISwDMView Interface](#)

ISwDMView2 Interface Properties

[See Also](#)

[SolidWorks.Interop.swdocumentmgr Namespace](#) : ISwDMView2 Interface

For a list of all members of this type, see [ISwDMView2 members](#).

Public Properties

Name	Description
 ReferencedConfigurationID	Gets the ID of the configuration for this drawing view.

[Top](#)

See Also

[ISwDMView2 Interface](#)
[SolidWorks.Interop.swdocumentmgr Namespace](#)
[ISwDMView Interface](#)

ReferencedConfigurationID Property (ISwDMView2)

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) > [ISwDMView2 Interface](#) : ReferencedConfigurationID Property (ISwDMView2)

Gets the ID of the configuration for this drawing view.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReferencedConfigurationID As System.Integer

Visual Basic (Usage)



```
Dim instance As ISwDMView2
Dim value As System.Integer

value = instance.ReferencedConfigurationID
```

C#

```
System.int ReferencedConfigurationID {get;}
```

C++/CLI

```
property System.int ReferencedConfigurationID {
    System.int get();
}
```

Property Value

ID of configuration or -1 for legacy files (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SwDMView2::ReferencedConfigurationID](#).

Remarks

This property works only with documents saved in SOLIDWORKS 2017 or later.

See Also

[ISwDMView2 Interface](#)
[ISwDMView2 Members](#)
[ISwDMView::ReferencedConfiguration Property \(\)](#)

SolidWorks.Interop.swdocumentmgr (Namespace Overview)

SolidWorks.Interop.swdocumentmgr Namespace

See Also [Inheritance Hierarchy](#).

 SOLIDWORKS Document Manager API

Interfaces

Interface	Description
ISwDMApplication	Manages part, assembly, or drawing documents.
ISwDMApplication2	Manages part, assembly, or drawing documents.
ISwDMApplication3	Manages part, assembly, or drawing documents.
ISwDMApplication4	Manages part, assembly, or drawing documents.
ISwDMApplication5	Manages part, assembly, or drawing documents.
ISwDMClassFactory	Allows you to use the SOLIDWORKS Document Manager API, which requires a valid license key .
ISwDMComponent	Accesses a component's data.
ISwDMComponent10	Accesses a component's data.
ISwDMComponent11	Accesses a component's data.
ISwDMComponent12	Accesses a component's data.
ISwDMComponent2	Accesses a component's data.
ISwDMComponent3	Accesses a component's data.
ISwDMComponent4	Accesses a component's data.
ISwDMComponent5	Accesses a component's data.
ISwDMComponent6	Accesses a component's data.
ISwDMComponent7	Accesses a component's data.
ISwDMComponent8	Accesses a component's data.
ISwDMComponent9	Accesses a component's data.
ISwDMConfiguration	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration10	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration11	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration12	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration13	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration14	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration15	Accesses configuration-specific information for the part, assembly, or drawing document.

ISwDMConfiguration16	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration17	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration18	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration2	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration3	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration4	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration5	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration6	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration7	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration8	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfiguration9	Accesses configuration-specific information for the part, assembly, or drawing document.
ISwDMConfigurationMgr	Accesses the ConfigurationMgr for the document, which lets you get different configurations in the document.
ISwDMConfigurationMgr2	Accesses the ConfigurationMgr for the document, which lets you get different configurations of the document.
ISwDMCutListItem	Accesses cut-list items.
ISwDMCutListItem2	Accesses cut-list items.
ISwDMCutListItem3	Accesses cut-list items.
ISwDMCutListItem4	Accesses cut-list items.
ISwMDimXpertAngleBetweenDimTol	Allows you to access tolerance information for DimXpert angle-between dimensions.
ISwMDimXpertAngularityGeoTol	Allows you to access DimXpert angularity geometric tolerance information.
ISwMDimXpertAnnotation	Allows you to access general information about DimXpert geometric tolerance, dimension tolerance, and datum annotations.
ISwMDimXpertBestFitPlaneFeature	Allows you to access specific information about DimXpert best fit planes.
ISwMDimXpertBlockTolerances	Allows you to access DimXpert block tolerance information.
ISwMDimXpertChamferDimTol	Allows you to access tolerance information for DimXpert chamfer dimensions.
ISwMDimXpertChamferFeature	Allows you to access specific information about DimXpert chamfers.
ISwMDimXpertCircularityGeoTol	Allows you to access DimXpert circularity geometric tolerance information.
ISwMDimXpertCircularRunoutGeoTol	Allows you to access DimXpert circular runout geometric tolerance information.

<u>ISwMDimXpertCompositeDistanceBetweenDimTol</u>	Allows you to access tolerance information for DimXpert composite distance-between dimensions.
<u>ISwMDimXpertCompositeLineProfileGeoTol</u>	Allows you to access DimXpert composite line profile geometric tolerance information.
<u>ISwMDimXpertCompositePositionGeoTol</u>	Allows you to access DimXpert composite position geometric tolerance information.
<u>ISwMDimXpertCompositeSurfaceProfileGeoTol</u>	Allows you to access DimXpert composite surface profile geometric tolerance information.
<u>ISwMDimXpertCompoundClosedSlot3dFeature</u>	Allows you to access specific information about DimXpert 3D compound closed slots.
<u>ISwMDimXpertCompoundHoleFeature</u>	Allows you to access specific information about DimXpert compound holes.
<u>ISwMDimXpertCompoundNotchFeature</u>	Allows you to access specific information about DimXpert compound notches.
<u>ISwMDimXpertCompoundWidthFeature</u>	Allows you to access specific information about DimXpert compound widths.
<u>ISwMDimXpertConcentricityGeoTol</u>	Allows you to access DimXpert concentricity geometric tolerance information.
<u>ISwMDimXpertConeAngleDimTol</u>	Allows you to access tolerance information for DimXpert cone angle dimensions.
<u>ISwMDimXpertConeFeature</u>	Allows you to access specific information about DimXpert cones.
<u>ISwMDimXpertCounterBoreDimTol</u>	Allows you to access tolerance information for DimXpert counterbore dimensions.
<u>ISwMDimXpertCounterSinkAngleDimTol</u>	Allows you to access tolerance information for DimXpert countersink angle dimensions.
<u>ISwMDimXpertCounterSinkDiameterDimTol</u>	Allows you to access tolerance information for DimXpert countersink diameter dimensions.
<u>ISwMDimXpertCylinderFeature</u>	Allows you to access specific information about DimXpert cylinders.
<u>ISwMDimXpertCylindricityGeoTol</u>	Allows you to access DimXpert cylindricity geometric tolerance information.
<u>ISwMDimXpertDatum</u>	Allows you to access information about DimXpert datums.
<u>ISwMDimXpertDepthDimTol</u>	Allows you to access tolerance information for DimXpert depth dimensions.
<u>ISwMDimXpertDiameterDimTol</u>	Allows you to access tolerance information for DimXpert diameter dimensions.
<u>ISwMDimXpertDimensionTolerance</u>	Allows you to access general information about DimXpert dimension tolerances.
<u>ISwMDimXpertDistanceBetweenDimTol</u>	Allows you to access tolerance information for DimXpert distance-between dimensions.
<u>ISwMDimXpertExtrudeFeature</u>	Allows you to access specific information about DimXpert extrudes.
<u>ISwMDimXpertFeature</u>	Allows you to access general information about DimXpert features and sub-features.
<u>ISwMDimXpertFilletFeature</u>	Allows you to access specific information about DimXpert fillets.
<u>ISwMDimXpertFlatnessGeoTol</u>	Allows you to access DimXpert flatness geometric tolerance information.
<u>ISwMDimXpertGeometricTolerance</u>	Allows you to access general information about DimXpert geometric tolerances such as circularity, orientation, flatness, etc.

ISwDMDimXpertIntersectCircleFeature	Allows you to access specific information about DimXpert intersect circles.
ISwDMDimXpertIntersectLineFeature	Allows you to access specific information about DimXpert intersect lines.
ISwDMDimXpertIntersectPlaneFeature	Allows you to access specific information about DimXpert intersect planes.
ISwDMDimXpertIntersectPointFeature	Allows you to access specific information about DimXpert intersect points.
ISwDMDimXpertLengthDimTol	Allows you to access tolerance information for DimXpert length dimensions.
ISwDMDimXpertLineProfileGeoTol	Allows you to access DimXpert line profile geometric tolerance information.
ISwDMDimXpertOrientationGeoTol	Allows you to access DimXpert information for the orientation geometric tolerances: angularity, parallelism, and perpendicularity.
ISwDMDimXpertParallelismGeoTol	Allows you to access DimXpert parallelism geometric tolerance information.
ISwDMDimXpertPart	Allows you to access the geometric and dimension tolerance information that underpins the DimXpert functionality, features, and annotations of a given model.
ISwDMDimXpertPatternAngleBetweenDimTol	Allows you to access DimXpert a pattern angle dimension tolerances.
ISwDMDimXpertPatternFeature	Allows you to access specific information about DimXpert patterns.
ISwDMDimXpertPerpendicularityGeoTol	Allows you to access DimXpert perpendicularity geometric tolerance information.
ISwDMDimXpertPlaneFeature	Allows you to access specific information about DimXpert planes.
ISwDMDimXpertPositionGeoTol	Allows you to access DimXpert position geometric tolerance information.
ISwDMDimXpertRadiusDimTol	Allows you to access tolerance information for DimXpert radius dimensions.
ISwDMDimXpertSphereFeature	Allows you to access specific information about DimXpert spheres.
ISwDMDimXpertStraightnessGeoTol	Allows you to access DimXpert straightness geometric tolerance information.
ISwDMDimXpertSurfaceFeature	Allows you to access specific information about DimXpert surfaces.
ISwDMDimXpertSurfaceProfileGeoTol	Allows you to access DimXpert surface profile geometric tolerance information.
ISwDMDimXpertSymmetryGeoTol	Allows you to access DimXpert symmetry geometric tolerance information.
ISwDMDimXpertTangencyGeoTol	Allows you to access DimXpert tangency geometric tolerance information.
ISwDMDimXpertTotalRunoutGeoTol	Allows you to access DimXpert total runout geometric tolerance information.
ISwDMDimXpertWidthDimTol	Allows you to access tolerance information for DimXpert width dimensions.
ISwDMDocument	Accesses the document.
ISwDMDocument10	Accesses the document.
ISwDMDocument11	Obsolete.
ISwDMDocument12	Obsolete.

ISwDMDocument13	Accesses the document.
ISwDMDocument14	Accesses the document.
ISwDMDocument15	Accesses the document.
ISwDMDocument16	Accesses the document.
ISwDMDocument17	Accesses the document.
ISwDMDocument18	Accesses the document.
ISwDMDocument19	Accesses the document.
ISwDMDocument20	Accesses the document.
ISwDMDocument21	Accesses the document.
ISwDMDocument22	Accesses the document.
ISwDMDocument23	Accesses the document.
ISwDMDocument24	Accesses the document.
ISwDMDocument25	Accesses the document.
ISwDMDocument26	Accesses the document.
ISwDMDocument27	Accesses the document.
ISwDMDocument28	Accesses the document.
ISwDMDocument29	Accesses the document.
ISwDMDocument3	Accesses the document.
ISwDMDocument30	Accesses the document.
ISwDMDocument31	Accesses the document.
ISwDMDocument4	Accesses the document.
ISwDMDocument5	Accesses the document.
ISwDMDocument6	Accesses the document.
ISwDMDocument7	Accesses the document.
ISwDMDocument8	Accesses the document.
ISwDMExternalReferenceOption	Allows you to access information about external references from a document.
ISwDMExternalReferenceOption2	Allows you to access information about external references from a document.
ISwDMSearchOption	Allows you to specify the types of references and paths to search.
ISwDMSheet	Accesses the drawing sheet.
ISwDMSheet2	Accesses the drawing sheet.
ISwDMSheet3	Accesses the drawing sheet.
ISwDMSheet4	Accesses the drawing sheet.
ISwDMTable	Accesses revision and bill of materials (BOM) tables.
ISwDMTable2	Accesses revision and bill of materials (BOM) tables.
ISwDMTable3	Accesses revision and bill of materials (BOM) tables.

ISwDMTable4	Accesses revision and bill of materials (BOM) tables.
ISwDMTable5	Accesses revision and bill of materials (BOM) tables.
ISwDMTable6	Accesses revision and bill of materials (BOM) tables.
ISwDMView	Access the the drawing views in this drawing document.
ISwDMView2	Access the the drawing views in this drawing document.

Enumerations

Enumeration	Description
swDm3DExperienceCfgType_e	Types of 3DEXPERIENCE configurations.
swDm3DExperienceModelType_e	Types of 3DEXPERIENCE models.
swDmAngleUnit_e	Units of angle.
SwDmAnnotationFileOpenError	Result codes when opening the preview bitmap of an annotation file.
SwDmBodyError	Body errors.
swDmBOMPartNumberSource	Sources of bill of materials (BOM) part numbers.
swDmBOMTableType	Bill of materials (BOM) table types.
SwDMConfigurationError	Return codes for methods of ISwDMConfigurationMgr2 .
swDmConfigurationType	Configuration types.
SwDmCopyOptions	Copy options. Bitmask.
SwDmCustomInfoType	Custom property types.
swDMCutListExclusionStatus_e	Exclusion statuses of a cut list item.
swDMCutListType_e	Cut list types.
SwDmDesignTableDataError	Design table data errors.
swDmDimXpertAnnotationType_e	DimXpert annotation types.
swDmDimXpertBlockToleranceType_e	DimXpert block tolerance types.
swDmDimXpertChamferAngleType_e	DimXpert chamfer angle types.
swDmDimXpertChamferDimensionType_e	DimXpert chamfer dimension types.
swDmDimXpertChamferType_e	DimXpert chamfer types.
swDmDimXpertDimensionToleranceType_e	DimXpert dimension tolerance types.
swDmDimXpertDistanceFosUsage_e	DimXpert distance feature of size usages.
swDmDimXpertFeatureType_e	DimXpert feature types.
swDmDimXpertISO2768PartType_e	DimXpert ISO 2768 part types.
swDmDimXpertMaterialConditionModifier_e	DimXpert material condition modifiers.
swDmDimXpertOrientationZoneType_e	DimXpert orientation zone types.
swDmDimXpertPatternTreatmentType_e	DimXpert pattern treatment types.
swDmDimXpertPositionZoneType_e	DimXpert position zone types.
swDmDimXpertStraightnessZoneType_e	DimXpert straightness zone types.
SwDMDocumentLicenseType_e	Document Manager license types.
SwDmDocumentOpenError	Document open errors.
SwDMDocumentSavedInLDREditMode_e	Return values for ISwDMDocument30::SavedInLDREditMode .
SwDmDocumentSaveError	Document save errors.
SwDmDocumentType	Document types.
swDmDocumentUnitsIntegerValue_e	Return options for document values.
swDmDocumentUnitsToggle_e	Document switches for the linear feet and inches format.
SwDmEDwgDataError	eDrawings data errors.
swDmExcludeFromBOMResult	Bill of materials (BOM) components exclusion options.
swDmFractionDisplay_e	Fraction display options.
swDmLengthUnit_e	Units of length.
SwDmMassPropError	Mass property errors.
SwDmMoveCopyError	Move/copy errors.
swDMPartConfigurationGrouping	Options for part configuration groupings.
SwDmPreviewError	Preview errors.
SwDmReferenceStatus	Reference status.
swDmRevTableStyle	Multiple drawing sheet styles for revision tables.
SwDmSearchFilters	Search filters. Bitmask.
swDmShowChildComponentsInBOMResult	How components are displayed in the bill of materials (BOM).
swDmTableCellHorzAlignType	Table cell alignment.
SwDmTableError	Table errors.
SwDmTableHeaderStyle	Table header styles.
SwDmTableType	Table types.
SwDmToolboxPartType	Toolbox part types. Bitmask.
swDmUnitsDecimalRounding_e	Rounding options for decimal units.
swDmUnitsEnergyUnit_e	Units of energy.
swDmUnitsForce_e	Units of force.
swDmUnitsMassPropMass_e	Units of mass.
swDmUnitsMassPropVolume_e	Units of volume.
swDmUnitsPowerUnit_e	Units of power.
swDmUnitsTimeUnit_e	Units of time.

swDmUnitSystem_e	Unit systems.
SwDmXmiDataError	XML errors.
swSheetFormatPathResult	Sheet format path results.
swSheetPropertiesResult	Sheet properties results.

See Also

[SolidWorks.Interop.swdocumentmgr.Assembly](#)

swDm3DExperienceCfgType_e (Type)

swDm3DExperienceCfgType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDm3DExperienceCfgType_e Enumeration

Types of 3DEXPERIENCE configurations.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDm3DExperienceCfgType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDm3DExperienceCfgType\_e
```

C#

```
public enum swDm3DExperienceCfgType_e : System.Enum
```

C++/CLI

```
public enum class swDm3DExperienceCfgType_e : public System.Enum
```

Members

Member	Description
swDmNot3DExperienceType	0 = Default configuration used by SOLIDWORKS Desktop
swDmPhysicalProduct	1 = Family member of 3DEXPERIENCE
swDmRepresentation	2 = Break view, section view, or other representation of the Physical Product in 3DEXPERIENCE

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDm3DExperienceModelType_e (Type)

swDm3DExperienceModelType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDm3DExperienceModelType_e Enumeration

Types of 3DEXPERIENCE models.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDm3DExperienceModelType_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDm3DExperienceModelType\_e
```

C#

```
public enum swDm3DExperienceModelType_e : System.Enum
```

C++/CLI

```
public enum class swDm3DExperienceModelType_e : public System.Enum
```

Members

Member	Description
swDm3DExperienceModelType_3DExperience	2
swDm3DExperienceModelType_PartSupply	1
swDm3DExperienceModelType_Standard	0 = From a non-specific source; denoted by a SOLIDWORKS Desktop component icon
swDm3DExperienceModelType_xCad	3

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmAngleUnit_e (Type)

swDmAngleUnit_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmAngleUnit_e Enumeration

Units of angle.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmAngleUnit_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmAngleUnit\_e
```

C#

```
public enum swDmAngleUnit_e : System.Enum
```

C++/CLI

```
public enum class swDmAngleUnit_e : public System.Enum
```

Members

Member	Description
swDmAngleUnit_swDmDegrees	0
swDmAngleUnit_swDmDegreesMinutes	1
swDmAngleUnit_swDmDegreesMinutesSeconds	2
swDmAngleUnit_swDmRadians	3

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmAnnotationFileOpenError (Type)

SwDmAnnotationFileOpenError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmAnnotationFileOpenError Enumeration

Result codes when opening the preview bitmap of an annotation file.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmAnnotationFileOpenError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmAnnotationFileOpenError
```

C#

```
public enum SwDmAnnotationFileOpenError : System.Enum
```

C++/CLI

```
public enum class SwDmAnnotationFileOpenError : public System.Enum
```

Members

Member	Description
swDmAnnotationFileOpenErrorFail	1
swDmAnnotationFileOpenErrorFileNotFound	2
swDmAnnotationFileOpenErrorNonAnnotationFile	3
swDmAnnotationFileOpenErrorNone	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmBodyError (Type)

SwDmBodyError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmBodyError Enumeration

Body errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmBodyError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmBodyError
```

C#

```
public enum SwDmBodyError : System.Enum
```

C++/CLI

```
public enum class SwDmBodyError : public System.Enum
```

Members

Member	Description
swBodyErrorDecompression	16 = Decompression error
swBodyErrorFileCreation	8 = Failed to create output/intermediate files
swBodyErrorNoData	4 = Body data not present
swDmBodyErrorGetCountNotCalled	1 = Before calling ISwDMConfiguration::GetBody , call ISwDMConfiguration::GetBodiesCount
swDmBodyErrorInvalidStorage	2 = Invalid storage
swDmBodyErrorNone	0 = Success

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmBOMPartNumberSource (Type)

swDmBOMPartNumberSource Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmBOMPartNumberSource Enumeration

Sources of bill of materials (BOM) part numbers.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmBOMPartNumberSource
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmBOMPartNumberSource
```

C#

```
public enum swDmBOMPartNumberSource : System.Enum
```

C++/CLI

```
public enum class swDmBOMPartNumberSource : public System.Enum
```

Members

Member	Description
swDmBOMPartNumber_ConfigurationName	1
swDmBOMPartNumber_DocumentName	0
swDmBOMPartNumber_NotDefined	-1 = Document was saved in older version of SOLIDWORKS; you must save the document in SOLIDWORKS 2009 or later
swDmBOMPartNumber_ParentName	2
swDmBOMPartNumber_UserSpecified	3

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmBOMTableType (Type)

swDmBOMTableType Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmBOMTableType Enumeration

Bill of materials (BOM) table types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmBOMTableType
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmBOMTableType
```

C#

```
public enum swDmBOMTableType : System.Enum
```

C++/CLI

```
public enum class swDmBOMTableType : public System.Enum
```

Members

Member	Description
swDmBOMTableTypeFlattened	3
swDmBOMTableTypeIndented	2
swDmBOMTableTypePartsOnly	0
swDmBOMTableTypeTopLevelOnly	1

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDMConfigurationError (Type)

SwDMConfigurationError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDMConfigurationError Enumeration

Return codes for methods of [ISwDMConfigurationMgr2](#).

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDMConfigurationError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDMConfigurationError
```

C#

```
public enum SwDMConfigurationError : System.Enum
```

C++/CLI

```
public enum class SwDMConfigurationError : public System.Enum
```

Members

Member	Description
SwDMConfigurationError_ComObjectDisconnected	3
SwDMConfigurationError_DataMissing	5
SwDMConfigurationError_NameNotFound	4
SwDMConfigurationError_None	0
SwDMConfigurationError_RequiredArgumentNull	2
SwDMConfigurationError_Unknown	1

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmConfigurationType (Type)

swDmConfigurationType Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmConfigurationType Enumeration

Configuration types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmConfigurationType
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmConfigurationType
```

C#

```
public enum swDmConfigurationType : System.Enum
```

C++/CLI

```
public enum class swDmConfigurationType : public System.Enum
```

Members

Member	Description
swDmConfiguration_AsMachined	1
swDmConfiguration_AsWelded	2
swDmConfiguration_Defeature	5
swDmConfiguration_SheetMetal	3
swDmConfiguration_SpeedPak	4
swDmConfiguration_Standard	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmCopyOptions (Type)

SwDmCopyOptions Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmCopyOptions Enumeration

Copy options. Bitmask.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmCopyOptions
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmCopyOptions
```

C#

```
public enum SwDmCopyOptions : System.Enum
```

C++/CLI

```
public enum class SwDmCopyOptions : public System.Enum
```

Members

Member	Description
swDmCopyOptionsCreateNewFolder	0x2
swDmCopyOptionsOverwriteExistingDocs	0x1

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmCustomInfoType (Type)

SwDmCustomInfoType Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : SwDmCustomInfoType Enumeration

Custom property types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmCustomInfoType
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmCustomInfoType
```

C#

```
public enum SwDmCustomInfoType : System.Enum
```

C++/CLI

```
public enum class SwDmCustomInfoType : public System.Enum
```

Members

Member	Description
swDmCustomInfoDate	64
swDmCustomInfoEquation	105
swDmCustomInfoNumber	3
swDmCustomInfoText	30
swDmCustomInfoUnknown	0
swDmCustomInfoYesOrNo	11

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDMCutListExclusionStatus_e (Type)

swDMCutListExclusionStatus_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDMCutListExclusionStatus_e Enumeration

Exclusion statuses of a cut list item.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDMCutListExclusionStatus_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDMCutListExclusionStatus\_e
```

C#

```
public enum swDMCutListExclusionStatus_e : System.Enum
```

C++/CLI

```
public enum class swDMCutListExclusionStatus_e : public System.Enum
```

Members

Member	Description
swDMCutListStatus_Excluded	1
swDMCutListStatus_Included	0
swDMCutListStatus_Unknown	-1 = Data is missing or document was saved in a SOLIDWORKS version earlier than 2021

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDMCutListType_e (Type)

swDMCutListType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDMCutListType_e Enumeration

Cut list types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDMCutListType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDMCutListType\_e
```

C#

```
public enum swDMCutListType_e : System.Enum
```

C++/CLI

```
public enum class swDMCutListType_e : public System.Enum
```

Members

Member	Description
swDMCutListType_Sheetmetal	2
swDMCutListType_SolidBody	1
swDMCutListType_Unknown	-1
swDMCutListType_Weldment	3

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmDesignTableDataError (Type)

SwDmDesignTableDataError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmDesignTableDataError Enumeration

Design table data errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmDesignTableDataError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmDesignTableDataError
```

C#

```
public enum SwDmDesignTableDataError : System.Enum
```

C++/CLI

```
public enum class SwDmDesignTableDataError : public System.Enum
```

Members

Member	Description
swDmDesignTableDataError_ExternalTableFound	0 = The SOLIDWORKS document has an external design table, which is linked to and has been found on disk
swDmDesignTableDataError_Fail	5 = Unknown failure
swDmDesignTableDataError_InternalTable	1 = The SOLIDWORKS document has an internal design table, so there is no external filename
swDmDesignTableDataError_NoData	4 = The SOLIDWORKS document was saved before in a version of SOLIDWORKS earlier than SOLIDWORKS 2009 SP0, so no data is available
swDmDesignTableDataError_NoTable	2 = The SOLIDWORKS document does not have a design table
swDmDesignTableDataError_ExternalTableNotFound	3 = The SOLIDWORKS document has an external design table, but it cannot be found on disk

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDimXpertAnnotationType_e (Type)

swDmDimXpertAnnotationType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertAnnotationType_e Enumeration
DimXpert annotation types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertAnnotationType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertAnnotationType\_e
```

C#

```
public enum swDmDimXpertAnnotationType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertAnnotationType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertAnnotationType_unknown	0
swDmDimXpertDatum	150
swDmDimXpertDimTol_AngleBetween	106
swDmDimXpertDimTol_ChamferDimension	105
swDmDimXpertDimTol_CompositeDistanceBetween	113
swDmDimXpertDimTol_ConeAngle	108
swDmDimXpertDimTol_CounterBore	102
swDmDimXpertDimTol_CounterSinkAngle	107
swDmDimXpertDimTol_CounterSinkDiameter	104
swDmDimXpertDimTol_Depth	103
swDmDimXpertDimTol_Diameter	109
swDmDimXpertDimTol_DistanceBetween	101
swDmDimXpertDimTol_Length	110
swDmDimXpertDimTol_PatternAngleBetween	114
swDmDimXpertDimTol_Radius	111
swDmDimXpertDimTol_Width	112
swDmDimXpertGeoTol_Angularity	210
swDmDimXpertGeoTol_Circularity	216
swDmDimXpertGeoTol_CircularRunout	214
swDmDimXpertGeoTol_CompositeLineProfile	206
swDmDimXpertGeoTol_CompositePosition	202
swDmDimXpertGeoTol_CompositeSurfaceProfile	208
swDmDimXpertGeoTol_Concentricity	204
swDmDimXpertGeoTol_Cylindricity	217
swDmDimXpertGeoTol_Flatness	215
swDmDimXpertGeoTol_LineProfile	205
swDmDimXpertGeoTol_Parallelism	211
swDmDimXpertGeoTol_Perpendicularity	212
swDmDimXpertGeoTol_Position	201
swDmDimXpertGeoTol_Straightness	218
swDmDimXpertGeoTol_SurfaceProfile	207
swDmDimXpertGeoTol_Symmetry	203
swDmDimXpertGeoTol_Tangency	221
swDmDimXpertGeoTol_TotalRunout	213

See Also

swDmDimXpertBlockToleranceType_e (Type)

swDmDimXpertBlockToleranceType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmDimXpertBlockToleranceType_e Enumeration

DimXpert block tolerance types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertBlockToleranceType_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertBlockToleranceType\_e
```

C#

```
public enum swDmDimXpertBlockToleranceType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertBlockToleranceType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertBlockToleranceType_ASMEinch	1
swDmDimXpertBlockToleranceType_ISO2768	2
swDmDimXpertBlockToleranceType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmDimXpertChamferAngleType_e (Type)

swDmDimXpertChamferAngleType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmDimXpertChamferAngleType_e Enumeration

DimXpert chamfer angle types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertChamferAngleType_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertChamferAngleType\_e
```

C#

```
public enum swDmDimXpertChamferAngleType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertChamferAngleType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertChamferAngleType_Concave	1
swDmDimXpertChamferAngleType_Convex	2
swDmDimXpertChamferAngleType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmDimXpertChamferDimensionType_e (Type)

swDmDimXpertChamferDimensionType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertChamferDimensionType_e Enumeration

DimXpert chamfer dimension types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertChamferDimensionType_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertChamferDimensionType\_e
```

C#

```
public enum swDmDimXpertChamferDimensionType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertChamferDimensionType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertChamferDimensionType_Angle	1
swDmDimXpertChamferDimensionType_LinearDistance1	2
swDmDimXpertChamferDimensionType_LinearDistance2	3
swDmDimXpertChamferDimensionType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDimXpertChamferType_e (Type)

swDmDimXpertChamferType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertChamferType_e Enumeration

DimXpert chamfer types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertChamferType_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertChamferType\_e
```

C#

```
public enum swDmDimXpertChamferType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertChamferType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertChamferType_DistanceAngle	1
swDmDimXpertChamferType_DistanceDistance	2
swDmDimXpertChamferType_unknown	0
swDmDimXpertChamferType_Vertex	3

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDimXpertDimensionToleranceType_e (Type)

swDmDimXpertDimensionToleranceType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmDimXpertDimensionToleranceType_e Enumeration

DimXpert dimension tolerance types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertDimensionToleranceType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertDimensionToleranceType\_e
```

C#

```
public enum swDmDimXpertDimensionToleranceType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertDimensionToleranceType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertDimensionToleranceType_unknown	0
swDmDimXpertDimToType_BlockTolerance	1
swDmDimXpertDimToType_BlockToleranceNoNominal	2
swDmDimXpertDimToType_ISOLimitsAndFits	3
swDmDimXpertDimToType_ISOLimitsAndFitsNoNominal	4
swDmDimXpertDimToType_LimitDimension	5
swDmDimXpertDimToType_MAXTolerance	6
swDmDimXpertDimToType_MINTolerance	7
swDmDimXpertDimToType_NoTolerance	8
swDmDimXpertDimToType_PlusMinusDimension	9
swDmDimXpertDimToType_PlusMinusNoNominal	10

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmDimXpertDistanceFosUsage_e (Type)

swDmDimXpertDistanceFosUsage_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertDistanceFosUsage_e Enumeration

DimXpert distance feature of size usages.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertDistanceFosUsage_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertDistanceFosUsage\_e
```

C#

```
public enum swDmDimXpertDistanceFosUsage_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertDistanceFosUsage_e : public System.Enum
```

Members

Member	Description
swDmDimXpertDistanceFosUsage_Center	1
swDmDimXpertDistanceFosUsage_MaximumSide	2
swDmDimXpertDistanceFosUsage_MinimumSide	3
swDmDimXpertDistanceFosUsage_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDimXpertFeatureType_e (Type)

swDmDimXpertFeatureType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertFeatureType_e Enumeration
DimXpert feature types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertFeatureType_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertFeatureType\_e
```

C#

```
public enum swDmDimXpertFeatureType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertFeatureType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertFeature_BestfitPlane	17
swDmDimXpertFeature_Chamfer	6
swDmDimXpertFeature_CompoundClosedSlot3D	10
swDmDimXpertFeature_CompoundHole	7
swDmDimXpertFeature_CompoundNotch	9
swDmDimXpertFeature_CompoundWidth	8
swDmDimXpertFeature_Cone	3
swDmDimXpertFeature_Cylinder	2
swDmDimXpertFeature_Extrude	4
swDmDimXpertFeature_Fillet	5
swDmDimXpertFeature_IntersectCircle	13
swDmDimXpertFeature_IntersectLine	12
swDmDimXpertFeature_IntersectPlane	14
swDmDimXpertFeature_IntersectPoint	11
swDmDimXpertFeature_Pattern	15
swDmDimXpertFeature_Plane	1
swDmDimXpertFeature_Sphere	16
swDmDimXpertFeature_Surface	18
swDmDimXpertFeatureType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDimXpertISO2768PartType_e (Type)

swDmDimXpertISO2768PartType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertISO2768PartType_e Enumeration

DimXpert ISO 2768 part types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertISO2768PartType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertISO2768PartType\_e
```

C#

```
public enum swDmDimXpertISO2768PartType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertISO2768PartType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertISO2768PartType_Coarse	3
swDmDimXpertISO2768PartType_Fine	1
swDmDimXpertISO2768PartType_Medium	2
swDmDimXpertISO2768PartType_unknown	0
swDmDimXpertISO2768PartType_VeryCoarse	4

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDimXpertMaterialConditionModifier_e (Type)

swDmDimXpertMaterialConditionModifier_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmDimXpertMaterialConditionModifier_e Enumeration
DimXpert material condition modifiers.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertMaterialConditionModifier_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertMaterialConditionModifier\_e
```

C#

```
public enum swDmDimXpertMaterialConditionModifier_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertMaterialConditionModifier_e : public System.Enum
```

Members

Member	Description
swDmDimXpertMaterialConditionModifier_unknown	0 = Unknown material condition modifier
swDmDimXpertMCM_LMC	1 = Least material condition
swDmDimXpertMCM_MMC	2 = Maximum material condition
swDmDimXpertMCM_NoMCM	3 = No material condition modifier
swDmDimXpertMCM_RFS	4 = Regardless of feature size

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmDimXpertOrientationZoneType_e (Type)

swDmDimXpertOrientationZoneType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmDimXpertOrientationZoneType_e Enumeration

DimXpert orientation zone types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertOrientationZoneType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertOrientationZoneType\_e
```

C#

```
public enum swDmDimXpertOrientationZoneType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertOrientationZoneType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertOrientationZoneType_Cylindrical	1
swDmDimXpertOrientationZoneType_Planar	2
swDmDimXpertOrientationZoneType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmDimXpertPatternTreatmentType_e (Type)

swDmDimXpertPatternTreatmentType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmDimXpertPatternTreatmentType_e Enumeration

DimXpert pattern treatment types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertPatternTreatmentType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertPatternTreatmentType\_e
```

C#

```
public enum swDmDimXpertPatternTreatmentType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertPatternTreatmentType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertPatternTreatmentType_CircularPattern	1
swDmDimXpertPatternTreatmentType_IndividualFeatures	2
swDmDimXpertPatternTreatmentType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmDimXpertPositionZoneType_e (Type)

swDmDimXpertPositionZoneType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertPositionZoneType_e Enumeration

DimXpert position zone types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertPositionZoneType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertPositionZoneType\_e
```

C#

```
public enum swDmDimXpertPositionZoneType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertPositionZoneType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertPositionZoneType_Boundary	1
swDmDimXpertPositionZoneType_CylindricalPosition	2
swDmDimXpertPositionZoneType_PlanarPosition	3
swDmDimXpertPositionZoneType_RadialPositionArc	4
swDmDimXpertPositionZoneType_RadialPositionPlanar	5
swDmDimXpertPositionZoneType_SphericalPosition	6
swDmDimXpertPositionZoneType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDimXpertStraightnessZoneType_e (Type)

swDmDimXpertStraightnessZoneType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDimXpertStraightnessZoneType_e Enumeration

DimXpert straightness zone types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDimXpertStraightnessZoneType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDimXpertStraightnessZoneType\_e
```

C#

```
public enum swDmDimXpertStraightnessZoneType_e : System.Enum
```

C++/CLI

```
public enum class swDmDimXpertStraightnessZoneType_e : public System.Enum
```

Members

Member	Description
swDmDimXpertStraightnessZoneType_Cylindrical	1
swDmDimXpertStraightnessZoneType_PlanarMedian	2
swDmDimXpertStraightnessZoneType_Surface	3
swDmDimXpertStraightnessZoneType_unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDMDocumentLicenseType_e (Type)

SwDMDocumentLicenseType_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : SwDMDocumentLicenseType_e Enumeration

Document Manager license types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDMDocumentLicenseType_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDMDocumentLicenseType\_e
```

C#

```
public enum SwDMDocumentLicenseType_e : System.Enum
```

C++/CLI

```
public enum class SwDMDocumentLicenseType_e : public System.Enum
```

Members

Member	Description
swDMDocLicenseType_Commerical	1
swDMDocLicenseType_NonCommercial	2
swDMDocLicenseType_Unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

SwDmDocumentOpenError (Type)

SwDmDocumentOpenError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : SwDmDocumentOpenError Enumeration

Document open errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmDocumentOpenError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmDocumentOpenError
```

C#

```
public enum SwDmDocumentOpenError : System.Enum
```

C++/CLI

```
public enum class SwDmDocumentOpenError : public System.Enum
```

Members

Member	Description
swDmDocumentOpenErrorFail	1 = File failed to open; reasons could be related to permissions or the file is in use by some other application or the file does not exist
swDmDocumentOpenErrorFileNotFound	3 = File not found
swDmDocumentOpenErrorFileReadOnly	4 = File is read only
swDmDocumentOpenErrorFutureVersion	6 = File was created in a version of SOLIDWORKS more recent than the SOLIDWORKS Document Manager version attempting to open the file; you need to install a later version of SOLIDWORKS Document Manager; see ISwDMAApplication::GetLatestSupportedFileVersion
swDmDocumentOpenErrorNoLicense	5 = No valid SOLIDWORKS Document Manager API license; the file may have been saved in a later version of SOLIDWORKS to which your license key does not allow access; see License Key section of Getting Started
swDmDocumentOpenErrorNone	0 = File successfully opened
swDmDocumentOpenErrorNonSW	2 = Non-SOLIDWORKS file was opened

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

SwDMDocumentSavedInLDREditMode_e (Type)

SwDMDocumentSavedInLDREditMode_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : SwDMDocumentSavedInLDREditMode_e Enumeration

Return values for [ISwDMDocument30::SavedInLDREditMode](#).

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDMDocumentSavedInLDREditMode_e  
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDMDocumentSavedInLDREditMode\_e
```

C#

```
public enum SwDMDocumentSavedInLDREditMode_e : System.Enum
```

C++/CLI

```
public enum class SwDMDocumentSavedInLDREditMode_e : public System.Enum
```

Members

Member	Description
SwDMDocumentSavedInLDREditMode_FALSE	2
SwDMDocumentSavedInLDREditMode_TRUE	1
SwDMDocumentSavedInLDREditMode_Unknown	0

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

SwDmDocumentSaveError (Type)

SwDmDocumentSaveError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : SwDmDocumentSaveError Enumeration

Document save errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmDocumentSaveError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmDocumentSaveError
```

C#

```
public enum SwDmDocumentSaveError : System.Enum
```

C++/CLI

```
public enum class SwDmDocumentSaveError : public System.Enum
```

Members

Member	Description
swDmDocumentSaveErrorFail	2 = Failed; reason could be related to permissions
swDmDocumentSaveErrorNone	0 = Saved successfully
swDmDocumentSaveErrorReadOnly	1 = Failed; file was opened as read-only

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

SwDmDocumentType (Type)

SwDmDocumentType Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmDocumentType Enumeration

Document types.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmDocumentType
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmDocumentType
```

C#

```
public enum SwDmDocumentType : System.Enum
```

C++/CLI

```
public enum class SwDmDocumentType : public System.Enum
```

Members

Member	Description
swDmDocumentAssembly	2 = Assembly document
swDmDocumentDrawing	3 = Drawing document
swDmDocumentPart	1 = Part document
swDmDocumentUnknown	0 = Unknown file type

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmDocumentUnitsIntegerValue_e (Type)

swDmDocumentUnitsIntegerValue_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmDocumentUnitsIntegerValue_e Enumeration

Return options for document values.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDocumentUnitsIntegerValue_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDocumentUnitsIntegerValue\_e
```

C#

```
public enum swDmDocumentUnitsIntegerValue_e : System.Enum
```

C++/CLI

```
public enum class swDmDocumentUnitsIntegerValue_e : public System.Enum
```

Members

Member	Description
swDmUnitsAngular	9
swDmUnitsAngularDecimalPlaces	10
swDmUnitsDecimalRounding	24
swDmUnitsDualLinear	5
swDmUnitsDualLinearDecimalDisplay	6
swDmUnitsDualLinearDecimalPlaces	7
swDmUnitsDualLinearFractionDenominator	8
swDmUnitsEnergyDecimalPlaces	22
swDmUnitsEnergyUnits	21
swDmUnitsForce	17
swDmUnitsForceDecimalPlaces	18
swDmUnitsLinear	1
swDmUnitsLinearDecimalDisplay	2
swDmUnitsLinearDecimalPlaces	3
swDmUnitsLinearFractionDenominator	4
swDmUnitsMassPropDecimalPlaces	12
swDmUnitsMassPropLength	11
swDmUnitsMassPropMass	13
swDmUnitsMassPropVolume	14
swDmUnitsPowerDecimalPlaces	20
swDmUnitsPowerUnits	19
swDmUnitsTimeDecimalPlaces	16
swDmUnitsTimeUnits	15
swDmUnitSystem	0

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmDocumentUnitsToggle_e (Type)

swDmDocumentUnitsToggle_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmDocumentUnitsToggle_e Enumeration

Document switches for the linear feet and inches format.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmDocumentUnitsToggle_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmDocumentUnitsToggle\_e
```

C#

```
public enum swDmDocumentUnitsToggle_e : System.Enum
```

C++/CLI

```
public enum class swDmDocumentUnitsToggle_e : public System.Enum
```

Members

Member	Description
swDmUnitsDualLinearFeetAndInchesFormat	3
swDmUnitsDualLinearRoundToNearestFraction	2
swDmUnitsLinearFeetAndInchesFormat	0
swDmUnitsLinearRoundToNearestFraction	1

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmEDwgDataError (Type)

SwDmEDwgDataError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmEDwgDataError Enumeration

eDrawings data errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmEDwgDataError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmEDwgDataError
```

C#

```
public enum SwDmEDwgDataError : System.Enum
```

C++/CLI

```
public enum class SwDmEDwgDataError : public System.Enum
```

Members

Member	Description
swDmEDwgDataErrorFileCreation	2 = Failed to create eDrawings file, possibly because of permissions
swDmEDwgDataErrorInvalidStorage	4 = Invalid storage
swDmEDwgDataErrorNoData	1 = File was not saved with eDrawings data
swDmEDwgDataErrorNone	0 = Success

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmExcludeFromBOMResult (Type)

swDmExcludeFromBOMResult Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDmExcludeFromBOMResult Enumeration

Bill of materials (BOM) components exclusion options.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmExcludeFromBOMResult
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmExcludeFromBOMResult
```

C#

```
public enum swDmExcludeFromBOMResult : System.Enum
```

C++/CLI

```
public enum class swDmExcludeFromBOMResult : public System.Enum
```

Members

Member	Description
swDmExcludeFromBOM_FALSE	0 = Do not exclude components from BOM.
swDmExcludeFromBOM_NotDefined	- 1 = Indicates that the document was created or saved in SOLIDWORKS 2008 SP01 or earlier. Open and save the document in SOLIDWORKS 2008 SP02 or later.
swDmExcludeFromBOM_TRUE	1 = Exclude components from BOM.

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmFractionDisplay_e (Type)

swDmFractionDisplay_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmFractionDisplay_e Enumeration

Fraction display options.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmFractionDisplay_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmFractionDisplay\_e
```

C#

```
public enum swDmFractionDisplay_e : System.Enum
```

C++/CLI

```
public enum class swDmFractionDisplay_e : public System.Enum
```

Members

Member	Description
swDmFractionDisplay_swDmDecimal	1
swDmFractionDisplay_swDmFraction	2
swDmFractionDisplay_swDmNone	0

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDmLengthUnit_e (Type)

swDmLengthUnit_e Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmLengthUnit_e Enumeration

Units of length.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmLengthUnit_e
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmLengthUnit\_e
```

C#

```
public enum swDmLengthUnit_e : System.Enum
```

C++/CLI

```
public enum class swDmLengthUnit_e : public System.Enum
```

Members

Member	Description
swDmLengthUnit_swDmAngstroms	6
swDmLengthUnit_swDmCentimeters	1
swDmLengthUnit_swDmFeet	4
swDmLengthUnit_swDmFeetInches	5
swDmLengthUnit_swDminches	3
swDmLengthUnit_swDmMeters	2
swDmLengthUnit_swDmMicrolnches	10
swDmLengthUnit_swDmMicrons	8
swDmLengthUnit_swDmMillimeters	0
swDmLengthUnit_swDmMils	9
swDmLengthUnit_swDmNanometers	7

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmMassPropError (Type)

SwDmMassPropError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmMassPropError Enumeration

Mass property errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmMassPropError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmMassPropError
```

C#

```
public enum SwDmMassPropError : System.Enum
```

C++/CLI

```
public enum class SwDmMassPropError : public System.Enum
```

Members

Member	Description
swDmMassPropErrorEarlierVersion	1 = Mass properties are stored as document properties in version 2500 and later
swDmMassPropErrorNoData	2 = Reason for error could be that mass properties were not calculated before the part was saved
swDmMassPropErrorNone	0 = Success
swDmMassPropErrorUnknown	3 = Unknown error

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmMoveCopyError (Type)

SwDmMoveCopyError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmMoveCopyError Enumeration

Move/copy errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmMoveCopyError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmMoveCopyError
```

C#

```
public enum SwDmMoveCopyError : System.Enum
```

C++/CLI

```
public enum class SwDmMoveCopyError : public System.Enum
```

Members

Member	Description
swDmMoveCopyErrorFail	2 = Failed to create destination directories or copy operation failed due to problems possibly related to permissions
swDmMoveCopyErrorNone	0 =Success
swDmMoveCopyErrorSourceDoesNotExist	1 = Source file does not exist

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

swDMPartConfigurationGrouping (Type)

swDMPartConfigurationGrouping Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : swDMPartConfigurationGrouping Enumeration

Options for part configuration groupings.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDMPartConfigurationGrouping
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDMPartConfigurationGrouping
```

C#

```
public enum swDMPartConfigurationGrouping : System.Enum
```

C++/CLI

```
public enum class swDMPartConfigurationGrouping : public System.Enum
```

Members

Member	Description
swDMPartConfigurationGrouping_OneItemForAllConfigurationsOfPart	2
swDMPartConfigurationGrouping_OneItemForPartsWithSameConfigurationName	3
swDMPartConfigurationGrouping_SeparateItemsForEachConfigurationOfPart	1

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

SwDmPreviewError (Type)

SwDmPreviewError Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : SwDmPreviewError Enumeration

Preview errors.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmPreviewError
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmPreviewError
```

C#

```
public enum SwDmPreviewError : System.Enum
```

C++/CLI

```
public enum class SwDmPreviewError : public System.Enum
```

Members

Member	Description
swDmPreviewErrorFileOpen	1 = Failed to open the document
swDmPreviewErrorMakeBmpFail	4 = Failed to make the bitmap
swDmPreviewErrorNone	0 = Success
swDmPreviewErrorNoPreview	2 = No preview data stored in document

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmReferenceStatus (Type)

SwDmReferenceStatus Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : SwDmReferenceStatus Enumeration

Reference status.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmReferenceStatus
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmReferenceStatus
```

C#

```
public enum SwDmReferenceStatus : System.Enum
```

C++/CLI

```
public enum class SwDmReferenceStatus : public System.Enum
```

Members

Member	Description
swDmReferenceStatusBroken	1
swDmReferenceStatusNotBroken	2
swDmReferenceStatusUnknown	0 = Either an older version or not applicable

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmRevTableStyle (Type)

swDmRevTableStyle Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmRevTableStyle Enumeration

Multiple drawing sheet styles for revision tables.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmRevTableStyle
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmRevTableStyle
```

C#

```
public enum swDmRevTableStyle : System.Enum
```

C++/CLI

```
public enum class swDmRevTableStyle : public System.Enum
```

Members

Member	Description
swDmRevCopyOfSheet1	1 = Linked; copies the revision table on sheet 1 to all sheets, updating all revision tables when revisions are made
swDmRevIndependent	2 = Independent; makes the revision table on each sheet independent of the other revision tables in the drawing; updates to one revision table do not affect other revision tables
swDmRevSeeSheet1	0 = See Sheet 1; makes the revision table on the first sheet the active table, labeling the revision tables on all other drawing sheets, See Sheet 1
swDmRevStyleUnknown	-1

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)

SwDmSearchFilters (Type)

SwDmSearchFilters Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr Namespace](#) : SwDmSearchFilters Enumeration

Search filters. Bitmask.

.NET Syntax

Visual Basic (Declaration)

```
Public Enum SwDmSearchFilters
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As SwDmSearchFilters
```

C#

```
public enum SwDmSearchFilters : System.Enum
```

C++/CLI

```
public enum class SwDmSearchFilters : public System.Enum
```

Members

Member	Description
SwDmSearchExternalReference	16 = Search for simple assembly references to parts and subassemblies
SwDmSearchForAssembly	8 = Search for assemblies
SwDmSearchForDrawing	4 = Search for drawings
SwDmSearchForPart	2 = Search for parts
SwDmSearchInContextReference	32 = Search for references to base parts for derived parts, mirrored parts, derived component parts, and parts designed in the context of assemblies
SwDmSearchPartToBaseAssemblyReference	128 = Search for references to assemblies that have been inserted into parts using the Insert Assembly feature
SwDmSearchRootAssemblyFolder	64 = Search all the way to the assembly's root folder
SwDmSearchSubfolders	1 = Recursively search all of the subfolders. This is only applicable when used with ISwDMDocument::WhereUsed and ISwDMComponent4::GetDocument2

See Also

[SolidWorks.Interop.swdocumentmgr Namespace](#)

swDmShowChildComponentsInBOMResult (Type)

swDmShowChildComponentsInBOMResult Enumeration

[See Also](#)



[SolidWorks.Interop.swdocumentmgr.Namespace](#) : swDmShowChildComponentsInBOMResult Enumeration

How components are displayed in the bill of materials (BOM).

.NET Syntax

Visual Basic (Declaration)

```
Public Enum swDmShowChildComponentsInBOMResult
    Inherits System.Enum
```

Visual Basic (Usage)



```
Dim instance As swDmShowChildComponentsInBOMResult
```

C#

```
public enum swDmShowChildComponentsInBOMResult : System.Enum
```

C++/CLI

```
public enum class swDmShowChildComponentsInBOMResult : public System.Enum
```

Members

Member	Description
swDmShowChildComponentsInBOM_FALSE	0 = Do not display child components in the BOM; the subassembly appears as a single item
swDmShowChildComponentsInBOM_NotDefined	-1 = Document was saved in an older version of SOLIDWORKS; you must save document in SOLIDWORKS 2009 or later
swDmShowChildComponentsInBOM_Promote	2 = All of the child components are promoted one level; the configuration dissolves when it appears in a BOM
swDmShowChildComponentsInBOM_TRUE	1 = List child components individually in the BOM

See Also

[SolidWorks.Interop.swdocumentmgr.Namespace](#)