

Reconfiguring Attocube IDS3010 Interferometer Network Settings

Biswajit Jana

April 2025

Objective

This document provides a step-by-step guide for reconfiguring the Attocube IDS3010 interferometer network settings in case the device is moved to a different building or network environment.

Scenario

When moving the interferometer to a new network, its previously assigned static IP may no longer be compatible. This guide helps restore access and assign a new static IP address suitable for the new network.

1 Direct Ethernet Connection and Network Discovery

1. **Connect the IDS3010 directly to a PC or laptop via Ethernet.**
2. **Temporarily set a static IP on the PC:**
 - Open Control Panel > Network and Sharing Center > Change adapter settings.
 - Right-click the Ethernet adapter and choose Properties.
 - Select Internet Protocol Version 4 (TCP/IPv4) and click Properties.
 - Choose Use the following IP address, then enter:
 - IP address: 147.197.221.10
 - Subnet mask: 255.255.255.0
 - Default gateway: 147.197.221.252
3. **Access the IDS3010 web interface:**
 - Open a browser and enter: `http://147.197.221.6` or `http://IDS3010-A02-0191.local`
 - Login using the appropriate credentials.

2 Determine New Network Settings

1. **Connect the PC to the new building's network.**
2. Open Command Prompt and type:

```
ipconfig /all
```

3. Note the following information from the Ethernet adapter section:
 - IPv4 Address
 - Subnet Mask
 - Default Gateway
4. Choose a new static IP address within the same subnet but not currently in use (e.g., 147.197.166.191). Note: Use "Advanced IP Scanner" software to check for what are the IP address already in use, therefore use the alternatives.

3 Set New Static IP for IDS3010

1. Reconnect the PC to the IDS3010 directly via Ethernet.
2. Access the web interface as in Section 1.
3. Navigate to **System > Network Settings**.
4. Change the mode from **DHCP (Dynamic)** to **Static**, and enter:
 - IP Address: 147.197.166.191
 - Subnet Mask: 255.255.255.0
 - Gateway: 147.197.166.1
 - DNS Server (optional): 147.197.200.2
5. Click **Apply** and reboot the device.

4 Verify and Use on Building Network

1. Connect the IDS3010 to the building network via Ethernet.
2. From a lab PC on the same network:
 - Open a terminal and run: `ping 147.197.166.191`
 - Open a browser and go to: `http://147.197.166.191`
 - Open Wave software and connect using the static IP.

Note

If the network changes again in the future, repeat this process with a new IP from the current subnet. It's recommended to request a dedicated static IP from the IT department to avoid repeated manual configuration.