

- Barre I 1.
- Barrel sleeve 2.
- 3. Barre | sleeve lock
- Barrel sleeve lock spring 4.
- 5. Front sight
- 6. Barrel bushing
- Receiver tube 7.
- Receiver cap 8.
- Trigger housing
- 10. Butt stock assembly: stock tubing butt plate stock grip stock ring
- 11. Magazine housing
- 12. Magazine housing spacer
- 13. Magazine housing spacer screw
- 14. Magazine latch
- 15. Magazine latch spring
- 16. Trigger
- 17. Trigger spring
- 18. Trigger pin
- 19. Disconnector
- 20. Disconnector pin
- 21. Selector
- 22. Selector spring
- 23. Selector plunger (2)

- 24. Sear
- 25. Sear spring
- 26. Sear pin
- 27. Bolt

- 28. Firing pin29. Extractor30. Extractor spring
- 31. Extractor pin
- 32. Bolt!+ andle
- 33. Closing spring
- 34. Closing spring cup
- 35. Trigger housing cover
- 36. Trigger housing cover screw (2)
- 37. Magazine housing
- 38. Magazine follower
- 39. Magazine spring
- 40. Magazine spring latch
- 41. Magazine bottom
- 42. Rear sight

NOTES:

- Bolt stopping surface on barrel is Imm forward of magazine well slot.
- 2. Bolt stroke is