◆ 拨号界面

1)坐标调整 wgui.h

设置断点,跟踪

IdleScreenDigitHandler()--→ShowCategory16Screen()--→set up_dialing_keypad(&dialing_keypad)

Wgui_inputs.c中setup_dialing_keypad()函数将wgui.h中各个赋的值赋给结构变量dialing_keypad的各个成员变量

附: (调试、跟踪过程)

1. Dialing inputbox(如何画拨号数字框及显示拨号数字图片)

在 dm_redraw_category_screen 处下一个断点, 跟踪, 画控件 DM_DIALER_INPUT_BOX1(拨号输入框)

```
case DM_DIALER_INPUT_BOX1:
{
    dm_setup_and_draw_dialer_inputbox(&UICtrlAccessPtr_p);
    break;
}
```

跟进函数 dm_setup_and_draw_dialer_inputbox() 里去,看到函数 show_dialer_inputbox()

跟进去,看到如下 代码:

gui_show_dialer_input_box(&MMI_dialer_inputbox);
再跟进去:

gui_show_dialer_input_box_ext(b, (-1), (-1));

1. Dialing inputbox(如何在拨号框画拨号数字图片)

进入 ShowCategory16Screen()

1) wgui_setup_dialer_inputbox() 画拨号界面输入框

- 2) 产生触摸屏事件后,拨号界面显示(例:触摸屏按下按钮 8 后,产生一个 MMI_PEN_EVENT_DOWN 事件,显示数字键 8 的拨号图片在拨号框)
- ◆注册触摸屏事件(当触摸屏产生 MMI_PEN_EVENT_DOWN、MMI_PEN_EVENT_UP、MMI_PEN_EVENT_MOVE、MMI_PEN_EVENT_REPEAT、MMI_PEN_EVENT_LONG_TAP、MMI_PEN_EVENT_ABORT等动作时,执行的函数)

```
#ifdef __MMI_TOUCH_DIAL_SCREEN__
wgui_register_category_screen_control_area_pen_handlers(
        Cate16CategoryControlAreaPenDownHandler,
        MMI_PEN_EVENT_DOWN);
     wgui_register_category_screen_control_area_pen_handlers(
       Cate16CategoryControlAreaPenUpHandler, MMI_PEN_EVENT_UP);
     wgui_register_category_screen_control_area_pen_handlers(
        Cate16CategoryControlAreaPenMoveHandler,
        MMI_PEN_EVENT_MOVE);
     wgui_register_category_screen_control_area_pen_handlers(
        Cate16CategoryControlAreaPenRepeatHandler,
        MMI PEN EVENT REPEAT);
     wgui_register_category_screen_control_area_pen_handlers(
        Cate16CategoryControlAreaPenLongTapHandler,
        MMI_PEN_EVENT_LONG_TAP);
     wgui_register_category_screen_control_area_pen_handlers(
        Cate16CategoryControlAreaPenAbortHandler,
        MMI_PEN_EVENT_ABORT);
   #endif / * __MMI_TOUCH_DIAL_SCREEN__ */
    ◆以 MMI_PEN_EVENT_DOWN 事件为例:
进入 Cate16CategoryControlAreaPenDownHandler()函数
          if (ret)
          {
              qdi lcd_repaint_all();
   4
              ExecuteDialKeyPadKeyHandler(KEY_EVENT_DOWN);
   此处,产生了一个 KEY_EVENT_DOWN 事件(此处 key_type 常用的分为
   KEY_EVENT_DOWN, KEY_EVENT_UP, KEY_EVENT_LONG_PRESS,值分别为 ♡,1,2)
   S32 key_id = dialing_keypad.key_type;
   此处赋值后,dialing_keypad.key_type 为选定的按键值,此处值为8
   typedef struct dialing keypad struct
     S32 keypad_x, keypad_y;
     S32 keypad_width, keypad_height;
     S32 key_width, key_height;
     S32 horizontal_gap, vertical_gap;
     S32 selected_key_x, selected_key_y;
     S32 n_rows, n_column;
   #ifdef __MMI_TOUCH_DIAL_SCREEN_WITH_FUNCTION__
     S32 keypad_func_x, keypad_func_y;
     S32 func_key_width, func_key_height;
     $32 func_horizontal_gap, func_vertical_gap;
     S32 func_n_rows, func_n_column;
   #endif /* __MMI_TOUCH_DIAL_SCREEN_WITH_FUNCTION__ */
S32 key_type; /* selected key index */
   #ifndef __GDI_MEMORY_PROFILE_2
     gdi_image_cache_bmp_struct selected_key_bitmap;
   } dialing_keypad_struct;
   跟进去 ExecuteDialKeyPadKeyHandler(),此函数执行拨号界面的按键事件
         /* 1-9 */
         if (key_id >= MMI_DIALING_KEY_START && key_id < MMI_DIALING_KEY_STAR)</pre>
         {
             PlayDialKeyPadTone(key_type);
             ExecuteCurrKeyHandler((S16) (KEY_0 + key_id), key_type);
         }
```

```
ExecuteCurrKeyHandler(), 开始单步跟踪。
此时 currFuncPtr 值如下:
currFuncPtr
                 Oxccccccc
初始化后,赋值
FuncPtr currFuncPtr = NULL;
currFuncPtr
                0x00000000
再给把当前按键值与类型赋给 currKeyCode 和 currKeyType, 赋值前:
currKeyCode
              12
currKeyType
                1
currKeyCode = keyCode;//keyCode=Key_Q+key_id
currKeyType = keyType;//key_type
赋值后:
currKeyCode
                 8
currKeyType
接下来一个判断语句
if (LgEmerencyNoDialed)
  if (mmi_kbd_get_concurrent_mode() ==
    /* special handling for single-key mode */
    switch (keyType)
      case KEY_HALF_PRESS_DOWN:
        pressKey = HALF_DOWN_STATUS;
      case KEY_EVENT_DOWN:
        * The application may call ExecuteCu
        * MMI framework use KEY HALF PRE
        pressKey = FULL_DOWN_STATUS;
        processUpRepeatKey = MMI_TRUE;
pressKey 与processUpRepeatKey 赋值前值为
presskey
processUpRepeatKe 0
赋值后值为(2- full down, 所以此处赋值为2):
presskey
processUpRepeatKe 1
此时,给currFuncPtr 赋值,赋值前地址:
                 0x00000000
currFuncPtr
cuncPtr = currKeyFuncPtrs[keyCode][keyType];
赋值后地址:
currFuncPtr 0x0098df54 MMI key 8 down(void)
至此,得到 cuncPtr 按键地址,指向8
(*currFuncPtr)();
*currFuncPtr
                0x0098df54 MMI key 8 down(void)
此时 currFuncPtr 指针指向 MMI_key_8_down(void), 按键 8 按下后的执行事件
```

判断如果按键在数字键区[1,*)之内,播放按键音,执行当前按键事件句柄

```
MMI_key_input_handler(KEY_8, KEY_EVENT_DOWN);
  跟进去,MMI_key_input_handler
   switch (key event)
       case KEY EVENT DOWN:
           if (MMI_key_down_handler_function != NULL)
               MMI key down handler function(key code);
           }
           break:
     MMI_key_down_handler_function 0x009845a6 dialer_inputbox_handle_key_down(int)
跟进去,进入 dialer_inputbox_handle_key_down()函数,此函数执行按键按
下后, 拨号输入框执行的函数
      dialer_inputbox_direct_input((UI_character_type) ('0' + k));
跟进去, dialer_inputbox_direct_input()
gui_dialer_input_box_insert_character(&MMI_dialer_inputbox, c);
gui_dialer_input_box_insert_character(),在当前光标处插入字符
跟进去,
b->change_callback();
b->change_callback
                     0x00984344 dialer_input_box_change_callback(void)
dialer_input_box_change_callback()
qui_show_dialer_input_box(&MMI_dialer_inputbox)
跟进去,显示拨号数字框
gui_show_dialer_input_box_ext(b, (-1), (-1));
在 gui_show_dialer_input_box_ext()函数里设置显示的数字的坐标,颜色等属性,原
来显示字符的地方,用定义的图片替换。图片显示函数 qui_show_image,获取显示的
字符图的函数 dialer_input_get_image(),通过获取 current_character
的值,来得到图片 ID
#ifdef __DIALFONT_BY_IMAGE_
 gui_show_image(text_x, text_y, dialer_input_get_image(current_character));
 gui_print_character(current_character);
#endif
2. DIALING_SCREEN (如何画拨号界面)
  进入 ShowCategory16Screen()
   3) wgui_setup_dialer_inputbox() 画拨号界面输入框
   #elif defined (__MMI_MAINLCD_176X220__)
     wgui_setup_dialer_inputbox(
       MMI_status_bar_height,
       UI_device_width,
       (UI_buffer_type) Buffer,
       BufferLength.
       MMI_CATEGORY16_ID,
       get string(right softkey),
       get_image(right_softkey_icon),
       history_buffer,
       0);
```

- 4) 产生触摸屏事件后,拨号界面显示(例:触摸屏按下按钮 8 后,产生一个 MMI_PEN_EVENT_DOWN 事件,显示数字键 8 的高亮图片)
- ◆注册触摸屏事件(当触摸屏产生 MMI_PEN_EVENT_DOWN、MMI_PEN_EVENT_UP、MMI_PEN_EVENT_MOVE、MMI_PEN_EVENT_REPEAT、MMI_PEN_EVENT_LONG_TAP、MMI_PEN_EVENT_ABORT等动作时,执行的函数)

```
#ifdef __MMI_TOUCH_DIAL_SCREEN_
  wgui_register_category_screen_control_area_pen_handlers(
    Cate16CategoryControlAreaPenDownHandler,
    MMI_PEN_EVENT_DOWN);
  wgui_register_category_screen_control_area_pen_handlers(
   Cate16CategoryControlAreaPenUpHandler, MMI_PEN_EVENT_UP);
  wgui_register_category_screen_control_area_pen_handlers(
    Cate16CategoryControlAreaPenMoveHandler,
    MMI_PEN_EVENT_MOVE);
  wgui_register_category_screen_control_area_pen_handlers(
    Cate16CategoryControlAreaPenRepeatHandler,
    MMI_PEN_EVENT_REPEAT);
  wgui_register_category_screen_control_area_pen_handlers(
    Cate16CategoryControlAreaPenLongTapHandler,
    MMI_PEN_EVENT_LONG_TAP);
  wgui_register_category_screen_control_area_pen_handlers(
    Cate16CategoryControlAreaPenAbortHandler,
    MMI_PEN_EVENT_ABORT);
#endif / * __MMI_TOUCH_DIAL_SCREEN _ */
```

◆以 MMI_PEN_EVENT_DOWN 事件为例:

进入 Cate16CategoryControlAreaPenDownHandler()函数

```
/* Get dialing screen event type according to current state of dialing screen */
ret = gui_dialing_screen_translate_pen_event(
    &dialing_keypad,
    point.x,
    point.y,
    MMI_PEN_EVENT_DOWN,
    &dialing_key_menu_event,
    &dialing_key_param);
```

通过 point.x 和 point.y 获得刚刚点击的触摸屏的 $X \times Y$ 坐标(此处在点击前,先记住触摸屏点击时的坐标,此处点击坐标为 82,159)。

gui_dialing_screen_translate_pen_event() 拨 号 界 面 的 五 个 触 摸 事 件 MMI_PEN_EVENT_DOWN 、 MMI_PEN_EVENT_UP 、 MMI_PEN_EVENT_MOVE 、 MMI_PEN_EVENT_LONG_TAP、MMI_PEN_EVENT_REPEAT, 当按键按下的事件产生后,确定是哪个按钮被按下,按钮显示位置多少

gui_dialing_screen_translate_pen_event()流程如下:

1> 首先用 gui_dialing_screen_translate_pen_position()函数得到按键的序号还有按键图片 X, Y 坐标

现在以按下数字键8,触摸坐标为(89,129)为例,理解如何将数字键8的高亮图画出来

```
total_height += dialing_keypad->keypad_y;
total_width += dialing_keypad->keypad_x;
*item_index = -1; /* 053005 Calvin added for function key */
```

开始进入 for 循环,此时 total_height=62,total_width=3 为 wgui.h 里设置的拨号键起始坐标。

此时开始第一次判断

total_height	62
у	129

此时,total_heigh</br>
(y,表明不是在第一行的按钮,所以给total_height加一个按钮的height
(25),此时total_height值为87

total_height	87
У	129

total height

接着再往下走,total_height 再加了VERTICAL_GAP(2),此时total_height 值为89

```
publication

else
{
   total_height += dialing_keypad->vertical_gap;
   if (total_height > y)
   {
      *item_index = -1;
      break;
   }
}
```

89

再进行判断 $total_height < y$,跳出,返回到顶上的 FOR 循环,再给 $total_height$ 加上一个按钮 的高度(25),再进行判断,还是小于 y (114 < 129),再跳出,再加上 $VERTICAL_GAP$ (2),再判 断,再加一个图片的高度。

```
total_height 114
y 129
```

此时, $total_height$ 值为 116+25=141,判断成立,跳入,执行下一句(此时 i 值为 2)。开始 $total_width$ 判断是第三行的第几列的图片被选中

```
for (j = 0; j < dialing_keypad->n_column; j++)
{
   total_width += dialing_keypad->key_width;
   if (total_width > x)
   {
     *item index = i * dialing keypad->n column + j + 1;
```

此时,total_widht 即为拨号按键起始坐标,值为 3,开始循环后,加了一个图片的宽度 55,total_width 值为 58

判断不成立,跳转出来,加一个 horizontal_gap(3), total_width 值变为 61, 再判断, 不成立, 再跳转出来。

```
else
     total width += dialing keypad->horizontal qap;
    if (total width > x)
     {
         *item index = -1;
         break:
     }
}
再加一个图片的宽度(55),此时 total\_width 值为 116,判断成立(此时 j 值为 1),执行下面语句
 total width
                     116
                     89
 х
下面的语句获取按键的序号和画按键的 x, y 值
  *item_index = i * dialing_keypad->n_column + j + 1;
dialing_keypad->selected_key_x =
    dialing_keypad->keypad_x + (dialing_keypad->key_width) * j +
    (dialing_keypad->horizontal_gap) * j;
  dialing_keypad->selected_key_y =
    dialing_keypad->keypad_y + (dialing_keypad->key_height) * i +
    (dialing_keypad->vertical_gap) * i;
  dialing keypad->key type = *item_index;
  break;
*item_index = i * dialing_keypad->n_column + j + 1; \frac{1}{2*3+1+1=8}
dialing_keypad->selected_key_x =3+55*1+3*1=61
dialing_keypad->selected_key_y=62+25*2+2*2=116
2> gui_dialing_screen_translate_pen_position 的函数流程:
switch (pen_event)
  case MMI_PEN_EVENT_DOWN:
   if (PEN_CHECK_BOUND(x, y, x1, y1, dialing_keypad->keypad_width, dialing_keypad->keypad_height))
     gui_dialing_screen_translate_pen_position(dialing_keypad, x, γ, &item_index);
if (item_index == -1) /* No key is selected 没有按键被选中*/
       ret = FALSE:
  #ifdef __MMI_TOUCH_DIAL_SCREEN_WITH_FUNCTION__
     if (item_index == MMI_DIALING_KEY_PHB
       && fun_key_phb == 0)
.....
        //当排除了上述情况后,画按下的按钮
  else
     gui_dialing_key_select(dialing_keypad, item_index);
} ? end if PEN_CHECK_BOUND(x,y,x...
else //如 果 按 触 摸 按 键 不 在 有 效 范 围 内 时
  ret = FALSE;
break;
当 触 摸 屏 产 生 一 个 MMI_PEN_EVENT_DOWN 事 件 后 , 获 取 按 键 的 序 号 与 坐 标
(gui_dialing_screen_translate_pen_position), 先判断触摸范围是不是在有效的范围
之内(是否在拨号按键的长宽范围之内),然后判断按键是否被选中,电话簿、SIM1、SIM2 卡是不是在
```

处在Disable 状态,排除以上状态后,获取按键序号,然后,画出来(gui_dialing_key_select)

```
3>在gui_dialing_key_select 中开始画高亮数字键
 x1 = dialing keypad->selected key x;
 y1 = dialing keypad->selected key y;
 /* 053005 Calvin added for function key */
 x2 = x1 + key_width - 1;
 u2 = u1 + kev height - 1;
给 x1, y1 分给赋值为 61, 116, x2, y2 赋值为 85, 170
gai_layer_pusn_clip();
gdi_layer_set_clip(x1, y1, x2, y2);
if (0<= (item_index-1) && (item_index-1) < sizeof(dialing_key_image) / sizeof(dialing_key_image[0]))
 image_id = dialing_key_image[item_index - 1];
 gui_measure_image(get_image(image_id), &width, &height);
/* 053005 Calvin added for function key */
 x1 = x1 + ((key_width - width) >> 1);
y1 = y1 + ((key_height - height) >> 1);
/* Calvin end */
 gui_show_image(x1, y1, get_image(image_id));
再判断按键序号在范围之内,然后取其对应的图片赋给 image_id, 然后将图片 show 出来, 至此, 拨号
键8显示完成
补记:
将 wgui.h 中的设置的各个坐标的值赋值给结构变量 dialing_keypad 的各个成员变量
结构申明如下: (结构_dialing_keypad_struct 别名为 dialing_keypad_struct)
typedef struct _dialing_keypad_struct
   S32 keypad_x, keypad_y;
   S32 keypad_width, keypad_height;
   S32 key_width, key_height;
   S32 horizontal_gap, vertical_gap;
   S32 selected_key_x, selected_key_y;
   S32 n_rows, n_column;
#ifdef __MMI_TOUCH_DIAL_SCREEN_WITH_FUNCTION__
   S32 keypad_func_x, keypad_func_y;
   S32 func_key_width, func_key_height;
   S32 func_horizontal_gap, func_vertical_gap;
   S32 func_n_rows, func_n_column;
#endif / * __MMI_TOUCH_DIAL_SCREEN_WITH_FUNCTION__ */
   S32 key_type; /* selected key index */
#ifndef __GDI_MEMORY_PROFILE_2
   gdi_image_cache_bmp_struct selected_key_bitmap;
#endif
} dialing_keypad_struct;
定义结构变量 dialing_keypad
#ifdef __MMI_TOUCH_DIAL_SCREEN_
dialing_keypad_struct dialing_keypad;
#endif / * _ MMI_TOUCH_DIAL_SCREEN_ */
```

show_dialing_screen() 画拨号界面背景图 IMG_DIALING_SCREEN