AVR350: Xmodem CRC Receive Utility for AVR®

AMEL

8-bit **AVR**® Microcontrollers

Application Note

Features

- Programmable Baud Rate
- Half Duplex
- 128-byte Data Packets
- CRC Data Verification
- Framing Error Detection
- OverRun Detection
- · Less than 1K Bytes of Code Space
- C High-level Language Code

1 Introduction

The Xmodem protocol was created years ago as a simple means of having two computers talk to each other. With its half-duplex mode of operation, 128-byte packets, ACK/NACK responses and CRC data checking, the Xmodem protocol has found its way into many applications. In fact most communication packages found in the PC today have a Xmodem protocol available to the user.



Rev. 1472D-AVR-01/08



2 Theory of Operation

Xmodem is a half-duplex communication protocol. The Receiver, after receiving a packet, will either acknowledge (ACK) or not acknowledge (NACK) the packet. The original Xmodem protocol used a standard checksum method to verify the 128-byte data packet. The CRC extension to the original protocol uses a more robust 16-bit CRC to validate the data block and is used here. Xmodem can be considered to be receiver driven. That is, the Receiver sends an initial character "C" to the sender indicating that it's ready to receive data in CRC mode. The Sender then sends a 133-byte packet, the Receiver validates it and responds with an ACK or a NACK at which time the sender will either send the next packet or re-send the last packet. This process is continued until an EOT is received at the Receiver side and is properly ACKed to the Sender. After the initial handshake the receiver controls the flow of data through ACKing and NACKing the Sender.

Table 2-1. XmodemCRC Packet Format

Byte 1	Byte 2	Byte 3	Bytes 4 - 131	Bytes 132 - 133
Start of Header	Packet Number	~(Packet Number)	Packet Data	16 bit CRC

3 Definitions

The following defines are used for protocol flow control.

Table 3-1. Protocol Flow Control

Symbol	Description	Value
SOH	Start of Header	0x01
EOT	End of Transmission	0x04
ACK	Acknowledge	0x06
NACK	Not Acknowledge	0x15
С	ASCII "C"	0x43

Byte one of the XmodemCRC packet can only have a value of SOH or EOT, anything else is an error. Bytes two and three form a packet number with checksum, add the two bytes together and they should always equal 0xff. Please note that the packet number starts out at "1" and rolls over to "0" if there are more than 255 packets to be received. Bytes 4 - 131 form the data packet and can be anything. Bytes 132 and 133 form the 16-bit CRC. The high byte of the CRC is located in byte 132.

4 Synchronization

The Receiver starts by sending an ASCII "C" (0x43) character to the sender indicating it wishes to use the CRC method of block validating. After sending the initial "C" the receiver waits for either a three second time out or until a buffer full flag is set. If the receiver is timed out then another "C" is sent to the sender and the three second time out starts again. This process continues until the receiver receives a complete 133-byte packet.

5 Receiver Considerations

This protocol NACKs the following conditions:

- 1. Framing error on any byte
- 2. OverRun error on any byte
- 3. CRC error
- 4. Receiver timed out (didn't receive packet within one second)

On any NACK, the sender will re-transmit the last packet. Items one and two should be considered serious hardware failures. Verify that sender and receiver are using the samebaud rate, start bits and stop bits. Item three is found in noisy environments, and the last issue should be self-correcting after the receiver NACKs the sender.

6 Data Flow Diagram

The data flow diagram below simulates a 5-packet file being sent.

Table 6-1. Data Flow Diagram

Sender					Receiver	
				<	"C"	
					Times Out after Three Seconds	
				<	"C"	
SOH	0x01	0xFE	Data	CRC	>	Packet OK
	•		•	•	<	ACK
SOH	0x02	0xFD	Data	CRC	>	(Line Hit during Data Transmission)
					<	NACK
SOH	0x02	0xFD	Data	CRC	>	Packet OK
					<	ACK
SOH	0x03	0xFC	Data	CRC	>	Packet OK
(ACK Gets Garbled)				<	ACK	
SOH	0x03	0xFC	Data	CRC	>	Duplicate Packet
					<	ACK
SOH	0x04	0xFB	Data	CRC	>	(UART Framing Error on Any Byte)
					<	NACK
SOH	0x04	0xFB	Data	CRC	>	Packet OK
					<	ACK
SOH	0x05	0xFA	Data	CRC	>	(UART Overrun Error on Any Byte)
					<	NACK
SOH	0x05	0xFA	Data	CRC	>	Packet OK
					<	ACK
ЕОТ				>	Packet OK	
(ACK Gets Garbled)				<	ACK	
EOT				>	Packet OK	
Finished					<	ACK





7 Modifications to Receive Protocol

Users may wish to count how many "C's" were sent during synchronization and after "n" number of tries abort the receive attempt. For embedded applications it's not mandatory to have a 128-byte packet. You could have 64, 32, or even a 16-byte packet. The sender of course would have to comprehend this.

If users do not wish to use the CRC method of data verification, simply replace sending a "C" for synchronization with a NACK instead. The sender will then send only the simple checksum of the data packet. Of course, the buffer size decreases by one and data errors may occur. This modification would allow communication with equipment that supports only the checksum method of data verification.

8 Software

Routines were compiled using IAR Workbench version 4.11A with high optimization. The software was tested using Hyperterminal at baud rates up to 115.2K. The receiver expects 8 start bits, 1 stop bit, and no parity bits.

The STK500 starter kit is used as a test platform for an ATmega88 running from its calibrated 8MHz internal RC oscillator. This is sufficiently accurate at room temperature for operation up to 38.4K Baud. For higher Baud rates the on-board 3.6864MHz oscillator or a 7.3728 MHz crystal should be used, with the init routine modified to properly set up the UART baud rate register UBRR0. Wait loops in the sendc and the recv wait routines would also need modification.

To verify proper operation of this code on the STK500, connect:

- PD0 to 'RS232 SPARE' RXD.
- PD1 to 'RS232 SPARE' TXD.
- PD2 to switch SW0.

Refer to the STK500 user manual for jumper locations and definitions. Connect a 9-pin serial cable from a PC to the STK500 "RS232 SPARE" port, turn on power and use SW0 as a start of reception signal. Use an ATmega48/88/168 fitted to socket SCKT3200A2 to execute the code.

Table 8-1. Protocol Flow Control

Name	Size in Bytes	Function
calcrc	46	Calculates 16-bit CRC
init	36	Low-level Hardware Initialisation
purge	50	Reads UART Data Register for One Second
receive	52	Main Receive Routine
recv_wait	46	Waits until Buffer Full Flag is Set or One Second Timeout
respond	56	Sends an ACK or a NACK to the Sender
sendc	100	Sends an ASCII "C" Character to the Sender until the Buffer Full Flag is Set
timer1	14	Timer1 Interrupt
uart	96	Uart Receive Interrupt
validate_packet	136	Validates Senders Packet
xmodem	42	Main

9 Pseudo-Code

9.1 purge.c

initialize timer1 counter for a 1 second delay read uart for 1 \sec ond

9.2 receive.c

send a 'C' character to sender until receive buffer is full
validate received packet send an ACK or a NACK to sender
 if packet was bad then wait for new good packet
while not end of transmission
 wait for buffer to fill
 validate the packet
 Act on data received or monitor errors
 send an ACK or a NACK to sender

9.3 recv_wait.c

initialize timer1 counter for a 1 second delay wait till buffer is full or timeout

9.4 respond.c

clear error flags
If packet was good or end of transmission then
 Send an ACK
Else
 Purge senders uart transmit buffer
 Send a NACK

9.5 sendc.c

initialize timer1 counter for a 3 second delay
 clear error flags
while buffer is not full
 send 'C' character to sender, signaling CRC mode
enable timer counter
 wait for buffer full or timeout
if timed out clear error flags
 restart timer

9.6 uart.c

check uart for framing or overrun errors
 read byte from uart
verify first byte in receive buffer is valid
 if buffer is full set buffer full flag





9.7 validate_packet.c

```
if not timed out then
    if no uart framing or overrun errors then
    if first character in buffer is SOH then
           if second character in buffer is the next packet number
then
           if second character in buffer plus the third character in
    buffer = 0xff
then
           compute CRC on packet data
           if CRC ok
then
    increment packet number
    packet = good
    packet = bad
else
    bad packet number checksum
else
    duplicate packet number
else
    if first character in buffer is EOT then
    end of transmission
    at least 1 byte had a framing or overrun error, packet is bad
else
    timed-out without receiving all characters, packet is bad
```



Headquarters

Atmel Corporation

2325 Orchard Parkway San Jose, CA 95131 USA

Tel: 1(408) 441-0311 Fax: 1(408) 487-2600

International

Atmel Asia

Room 1219 Chinachem Golden Plaza 77 Mody Road Tsimshatsui East Kowloon Hong Kong

Tel: (852) 2721-9778 Fax: (852) 2722-1369 Atmel Europe

Le Krebs 8, Rue Jean-Pierre Timbaud BP 309 78054 Saint-Quentin-en-Yvelines Cedex France

Tel: (33) 1-30-60-70-00 Fax: (33) 1-30-60-71-11 Atmel Japan

9F, Tonetsu Shinkawa Bldg. 1-24-8 Shinkawa Chuo-ku, Tokyo 104-0033

Tel: (81) 3-3523-3551 Fax: (81) 3-3523-7581

Product Contact

Web Site

www.atmel.com

Technical Support avr@atmel.com

Sales Contact

www.atmel.com/contacts

Literature Request www.atmel.com/literature

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN ATMEL'S TERMS AND CONDITIONS OF SALE LOCATED ON ATMEL'S WEB SITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel's products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

© 2008 Atmel Corporation. All rights reserved. Atmel®, logo and combinations thereof, AVR® and others, are the registered trademarks or trademarks of Atmel Corporation or its subsidiaries. Other terms and product names may be trademarks of others.