RetroModem

ONE-PAGE QUICK REFERENCE - ACCESS, URLS, DIALLING AND CONTROLS

Access and default credentials

Administration	`http://retromodem.local/`
Web login	`retromodem / retromodem`
Fallback access point	`retromodem`
Access-point password	`12345678`
Administration via AP	`http://10.42.0.1/`
SSH	`Imager account @ retromodem.local`

First use

1. Power on and wait about 20 seconds. **2.** If normal Wi-Fi is unavailable, join **retromodem** using **12345678**; choose *stay connected* if warned that it has no internet. **3.** Open **retromodem.local** or **10.42.0.1**, sign in and select Wi-Fi. **4.** Rejoin normal Wi-Fi and reopen **retromodem.local**. **5.** Select the adapter and either Direct PPP or Hayes dial-up/BBS.

Pages for the retro device

Start	`http://start.retromodem/`
Client settings	`http://setup.retromodem/`
Wi-Fi setup	`http://wifi.retromodem/`
Proxy routing/images	`http://proxy.retromodem/`
Search	`http://search.retromodem/`
ChatGPT	`http://chatgpt.retromodem/`

Network and proxy

The retro device must use RetroModem DNS **192.168.77.1**. Direct PPP and dial-up PPP assign addresses automatically. Palm fallback: device IP **192.168.77.2**, primary and secondary DNS **192.168.77.1**. Fresh installations automatically send HTTP traffic through RetroWEB; change this at **proxy.retromodem**. Manual proxy: **192.168.77.1:8080**.

Virtual modem and dialling

Internet PPP	`ATDT5559000 | user / blank`
Bundled BBS entries	`ATDT5551000 ... 5551009`
ChatGPT BBS	`ATDT5559999`
Virtual Hayes speed	`115200 bit/s`
Test command	`AT -> OK`

Phone-book numbers map modern Telnet BBS hostnames and ports to virtual telephone numbers; no physical telephone call is made.

Button and LEDs

Short button press: switch Direct PPP / Hayes dial-up-BBS.
Hold 3 seconds: safe shutdown. Release when both LEDs flash; disconnect power only after the LEDs turn off.
Status LEDs: show the active modem mode plus startup/network state.

Connection hardware

MY018 GPIO/UART: preferred infrared build, tested up to 57.6 kbit/s. **Prolific USB-RS-232:** main wired route; use the correct device/null-modem cable. **MA-620 USB IR:** fallback infrared adapter at 9600 bit/s.

SSH

`ssh YOUR_USERNAME@retromodem.local`
Use the account/password or key created in Raspberry Pi Imager. Through the fallback access point, replace the hostname with **10.42.0.1**.

Safety and help

Do not use the rewriting proxy for passwords, payments or sensitive accounts. Use **http://** addresses in old browsers. Complete installation, wiring and device guides: `github.com/BjornB2/retromodem`.