

**IVY METERING CO.,LTD****Add:** Room 1206, AFC Grand Hongqiao International, No.999/1009 Li'an Rd, Minhang District,
Shanghai 201100 , China **Tel:**86 21 62201708 **Fax:**86 21 62209608

写数据Write data

功能名称 Feature name	控制码 (1个字节) Control code (1 byte)	数据长度 (字节) Data length (bytes)	标识码 Identification code	数据格式 Data Format	举例 For example	解析 Parse
日期及星期 Date and week	0x14	4	0x04000101	YYMMDDWW(BCD)	02 21 04 19	19-04-21星期二 19-04-21 Tuesday
时间 Time	0x14	3	0x04000102	hhmmss(BCD)	45 23 12	12:23:45
轮显时间 Scroll display time	0x14	1	0x04000302	XX(BCD)	34	34
序列号 Serial No.	0x14	6	0x04000401	XXXXXXXXXX(BCD)	23 43 67 89 54 27	275489674323
时段表 Time interval sheet	0x14	3*8	0x04010001	HHMMRR*8(BCD)	02 45 21	21:45费率2 21:45 tariff 2
置起升级标志 Set up the upgrade flag	0x14	5	0x50000001	ASCII	4A 53 4C 54 59	YTLSJ
过压阈值+触发时间 Overvoltage threshold + trigger Time	0x14	2+1	0x50000420	XXXX(BCD)+XX(BCD)	34 02 12	234V+12s
欠压阈值+触发时间 Undervoltage threshold + trigger time	0x14	2+1	0x50000520	XXXX(BCD)+XX(BCD)	34 02 12	234V+12s
过流阈值+触发时间 Overcurrent threshold + trigger time	0x14	2+1	0x50000620	XXXX(BCD)+XX(BCD)	34 02 12	234A+12A
阈值统一设置 Threshold uniform setting	0x14	9	0x50000640	XXXX(BCD)+XX(BCD)	顺序为过压、欠压、过流 The sequence is overvoltage, undervoltage, overcurrent	/

[illegible]