

# User's Guide

## PMD-1208FS

Low-cost, USB-based Personal Measurement Device™ brand module with 8 channels, 12-bit input

# **PMD-1208FS**

**Personal Measurement Device™ brand**

**USB-based  
Analog and Digital I/O Module**

## **User's Guide**



**MEASUREMENT  
COMPUTING™**

Document Revision 4, May, 2005  
© Copyright 2005, Measurement Computing Corporation

**Your new Measurement Computing product comes with a fantastic extra —**

## **Management committed to your satisfaction!**

Refer to [www.mccdaq.com/execteam.html](http://www.mccdaq.com/execteam.html) for the names, titles, and contact information of each key executive at Measurement Computing.

Thank you for choosing a Measurement Computing product—and congratulations! You own the finest, and you can now enjoy the protection of the most comprehensive warranties and unmatched phone tech support. It's the embodiment of our two missions:

- To offer the highest-quality, computer-based data acquisition, control, and GPIB hardware and software available—at the best possible price.
- To offer our customers superior post-sale support—FREE. Whether providing unrivaled telephone technical and sales support on our latest product offerings, or continuing that same first-rate support on older products and operating systems, we're committed to you!

**Lifetime warranty:** Every hardware product manufactured by Measurement Computing Corporation is warranted against defects in materials or workmanship for the life of the product. Products found defective are repaired or replaced promptly.

**Lifetime Harsh Environment Warranty®:** We will replace any product manufactured by Measurement Computing Corporation that is damaged (even due to misuse) for only 50% of the current list price. I/O boards face some tough operating conditions—some more severe than the boards are designed to withstand. When a board becomes damaged, just return the unit with an order for its replacement at only 50% of the current list price. We don't need to profit from your misfortune. By the way, we honor this warranty for any manufacturer's board that we have a replacement for.

**30 Day Money Back Guarantee:** You may return any Measurement Computing Corporation product within 30 days of purchase for a full refund of the price paid for the product being returned. If you are not satisfied, or chose the wrong product by mistake, you do not have to keep it. Please call for an RMA number first. No credits or returns accepted without a copy of the original invoice. Some software products are subject to a repackaging fee.

*These warranties are in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability or fitness for a particular application. The remedies provided herein are the buyer's sole and exclusive remedies. Neither Measurement Computing Corporation nor its employees shall be liable for any direct or indirect, special, incidental or consequential damage arising from the use of its products, even if Measurement Computing Corporation has been notified in advance of the possibility of such damages.*

### **Trademark and Copyright Information**

Personal Measurement Device brand, TracerDAQ, Universal Library, *InstaCal*, Harsh Environment Warranty, Measurement Computing Corporation, and the Measurement Computing logo, are either trademarks or registered trademarks of Measurement Computing Corporation.

SoftWIRE and the SoftWIRE logo are registered trademarks of SoftWIRE Technology, Inc.

PC is a trademark of International Business Machines Corp.

Microsoft, Windows, and Visual Studio are either trademarks or registered trademarks of Microsoft Corporation.

LabVIEW is a trademark of National Instruments.

All other trademarks are the property of their respective owners.

Information furnished by Measurement Computing Corporation is believed to be accurate and reliable. However, no responsibility is assumed by Measurement Computing Corporation neither for its use; nor for any infringements of patents or other rights of third parties, which may result from its use. No license is granted by implication or otherwise under any patent or copyrights of Measurement Computing Corporation.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form by any means, electronic, mechanical, by photocopying, recording, or otherwise without the prior written permission of Measurement Computing Corporation.

### **Notice**

Measurement Computing Corporation does not authorize any Measurement Computing Corporation product for use in life support systems and/or devices without the written approval of the CEO of Measurement Computing Corporation. Life support devices/systems are devices or systems which, a) are intended for surgical implantation into the body, or b) support or sustain life and whose failure to perform can be reasonably expected to result in injury. Measurement Computing Corporation products are not designed with the components required, and are not subject to the testing required to ensure a level of reliability suitable for the treatment and diagnosis of people.

---

# Table of Contents

<b>Preface</b>	
<b>About this User's Guide .....</b>	<b>vi</b>
What you will learn from this user's guide .....	vi
Conventions in this user's guide .....	vi
Where to find more information .....	vi
<b>Chapter 1</b>	
<b>Introducing the PMD-1208FS .....</b>	<b>1-1</b>
PMD-1208FS block diagram .....	1-2
Software features .....	1-2
Connecting a PMD-1208FS to your computer is easy .....	1-3
<b>Chapter 2</b>	
<b>Installing the PMD-1208FS .....</b>	<b>2-1</b>
What comes with your PMD-1208FS shipment? .....	2-1
Hardware .....	2-1
Software .....	2-1
Documentation .....	2-2
Unpacking the PMD-1208FS .....	2-2
Installing the software .....	2-2
Installing the hardware .....	2-2
<b>Chapter 3</b>	
<b>Functional Details .....</b>	<b>3-1</b>
Theory of operation - analog input acquisition modes .....	3-1
Software paced mode .....	3-1
Continuous scan mode .....	3-1
External components .....	3-1
USB connector .....	3-2
LED .....	3-2
Screw terminal wiring .....	3-2
Main connector and pin out .....	3-3
Analog input terminals (CH0 IN - CH7 IN) .....	3-4
Analog output terminals (D/A OUT 0 and D/A OUT 1) .....	3-6
Digital I/O terminals (Port A0 to A7, and Port B0 to B7) .....	3-7
Power terminals .....	3-7
Calibration terminal .....	3-8
Ground terminals .....	3-8
External trigger terminal .....	3-8
SYNC terminal .....	3-8
Counter terminal .....	3-9
Accuracy .....	3-9
PMD-1208FS channel gain queue feature .....	3-11
Synchronizing multiple units .....	3-12
<b>Chapter 4</b>	
<b>Specifications .....</b>	<b>4-1</b>
Analog input section .....	4-1
Analog output section .....	4-3
Digital input/output .....	4-3
External trigger .....	4-4
External clock input/output .....	4-4
Counter section .....	4-5

Non-volatile memory.....	4-5
Microcontroller.....	4-5
Power.....	4-5
General .....	4-6
Environmental .....	4-6
Mechanical .....	4-6
Main connector and pin out .....	4-6
4-channel differential mode .....	4-7
8-channel single-ended mode.....	4-7

# About this User's Guide

## What you will learn from this user's guide

This user's guide explains how to install, configure, and use the PMD-1208FS so that you get the most out of its USB data acquisition features.

This user's guide also refers you to related documents available on our web site, and to technical support resources that can also help you get the most out of the PMD-1208FS.

## Conventions in this user's guide

### For more information on ...

Text presented in a box signifies additional information and helpful hints related to the subject matter you are reading.

**Caution!** Shaded caution statements present information to help you avoid injuring yourself and others, damaging your hardware, or losing your data.

<#: #:> Angle brackets that enclose numbers separated by a colon signify a range of numbers, such as those assigned to registers, bit settings, etc.

**bold** text **Bold** text is used for the names of objects on the screen, such as buttons, text boxes, and check boxes. For example:

1. Insert the disk or CD and click the **OK** button.

*italic* text *Italic* text is used for the names of manuals and help topic titles, and to emphasize a word or phrase. For example:

- The *InstaCal®* installation procedure is explained in the *DAQ Software Quick Start*.
- *Never* touch the exposed pins or circuit connections on the board

## Where to find more information

The following electronic documents provide information that can help you get the most out of your Personal Measurement Device™ brand PMD-1208FS.

- MCC's *Specifications: PMD-1208FS* (the PDF version of Chapter 4 in this guide) is available on our web site at [www.mccdaq.com/pdfs/PMD-1208FS.pdf](http://www.mccdaq.com/pdfs/PMD-1208FS.pdf).
- MCC's *DAQ Software Quick Start* is available on our web site at [www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf](http://www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf).
- MCC's *Guide to Signal Connections* is available on our web site at [www.mccdaq.com/signals/signals.pdf](http://www.mccdaq.com/signals/signals.pdf).
- MCC's *Universal Library User's Guide* is available on our web site at <http://www.mccdaq.com/PDFmanuals/sm-ul-user-guide.pdf>.
- MCC's *Universal Library Function Reference* is available on our web site at <http://www.mccdaq.com/PDFmanuals/sm-ul-functions.pdf>.
- MCC's *Universal Library for LabVIEW™ User's Guide* is available on our web site at [www.mccdaq.com/PDFmanuals/SM-UL-LabVIEW.pdf](http://www.mccdaq.com/PDFmanuals/SM-UL-LabVIEW.pdf).

*PMD-1208FS User's Guide* (this document) is available on our web site at [www.mccdaq.com/PDFmanuals/PMD-1208FS.pdf](http://www.mccdaq.com/PDFmanuals/PMD-1208FS.pdf).

## Introducing the PMD-1208FS

This user's guide contains all of the information you need to connect the PMD-1208FS to your computer and to the signals you want to measure. The PMD-1208FS is part of the Personal Measurement Device™ brand of USB-based data acquisition products.

The PMD-1208FS is a USB 2.0 full-speed device supported under Microsoft® Windows® 98 (2<sup>nd</sup> edition), Windows ME, Windows 2000, and Window XP. It is designed for USB 1.1 ports, and was tested for full compatibility with both USB 1.1 and USB 2.0 ports.

Refer to the "Be sure you are using the latest system software" note in Chapter 2, "Installing the PMD-1208FS," to make sure you are using the latest USB drivers.

The PMD-1208FS features eight analog inputs, two 12-bit analog outputs, 16 digital I/O connections, and one 32-bit external event counter. The PMD-1208FS is powered by the +5 volt USB supply from your computer. No external power is required.

The PMD-1208FS analog inputs are software configurable for either eight 11-bit single-ended inputs, or four 12-bit differential inputs. Sixteen digital I/O lines are independently selectable as input or output in two 8-bit ports.

A 32-bit counter can count TTL pulses.

A SYNC (synchronization) input / output line allows you to pace the analog input acquisition of one PMD module from the clock output of another.

The PMD-1208FS is shown in Figure 1-1. I/O connections are made to the screw terminals located along each side of the PMD-1208FS.



Figure 1-1. PMD-1208FS

## PMD-1208FS block diagram

PMD-1208FS functions are illustrated in the block diagram shown here.




Figure 1-2. PMD-1208FS functional block diagram

## Software features

The following software ships with the PMD-1208FS free of charge.

- *InstaCal* installation, calibration, and test utility
- TracerDAQ™ suite of virtual instruments
- SoftWIRE® for Visual Studio® .NET graphical programming
- MCC DAQ Components for VS .NET (installed with SoftWIRE® for VS .NET)

For information on the features of *InstaCal*, TracerDAQ, and SoftWIRE, refer to the *DAQ Software Quick Start* booklet that shipped with the PMD-1208FS.

## Connecting a PMD-1208FS to your computer is easy

Installing a data acquisition device has never been easier.

- The PMD-1208FS relies upon the Microsoft Human Interface Device (HID) class drivers. The HID class drivers ship with every copy of Windows that is designed to work with USB ports. We use the Microsoft HID because it is a standard, and its performance delivers full control and maximizes data transfer rates for your PMD-1208FS. No third-party device driver is required.
- The PMD-1208FS is plug-and-play. There are no jumpers to position, DIP switches to set, or interrupts to configure.
- You can connect the PMD-1208FS before or after you install the software, and without powering down your computer first. When you connect an HID to your system, your computer automatically detects it and configures the necessary software. You can connect and power multiple HID peripherals to your system using a USB hub.
- You can connect your system to various devices using a standard four-wire cable. The USB connector replaces the serial and parallel port connectors with one standardized plug and port combination.
- You do not need a separate power supply module. The USB automatically delivers the electrical power required by each peripheral connected to your system.
- Data can flow two ways between a computer and peripheral over USB connections.

## Installing the PMD-1208FS

### What comes with your PMD-1208FS shipment?

As you unpack your PMD-1208FS, verify that the following components are included.

#### Hardware

- PMD-1208FS



- USB cable (2 meter length)



#### Software


The *Measurement Computing Data Acquisition Software* CD contains the following software:

- *InstaCal* installation, calibration, and test utility
- TracerDAQ suite of virtual instruments
- SoftWIRE for VS .NET
- SoftWIRE MCC DAQ Components for .NET



## Documentation

In addition to this hardware user's guide, you should also receive the *DAQ Software Quick Start* (available in PDF at [www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf](http://www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf)). Please read this booklet completely before installing any software and hardware.



## Unpacking the PMD-1208FS

As with any electronic device, you should take care while handling to avoid damage from static electricity. Before removing the PMD-1208FS from its packaging, ground yourself using a wrist strap or by simply touching the computer chassis or other grounded object to eliminate any stored static charge.

If any components are missing or damaged, notify Measurement Computing Corporation immediately by phone, fax, or e-mail:

- Phone: 508-946-5100 and follow the instructions for reaching Tech Support.
- Fax: 508-946-9500 to the attention of Tech Support
- Email: [techsupport@measurementcomputing.com](mailto:techsupport@measurementcomputing.com)

## Installing the software

Refer to the *DAQ Software Quick Start* for instructions on installing the software on the *Measurement Computing Data Acquisition Software CD*. This booklet is available in PDF at [www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf](http://www.mccdaq.com/PDFmanuals/DAQ-Software-Quick-Start.pdf).

## Installing the hardware


### Be sure you are using the latest system software

Before you connect the PMD-1208FS, make sure that you are using the latest versions of the USB drivers.

Before installing the PMD-1208FS, download and install the latest Microsoft Windows updates. In particular, when using Windows XP, make sure you have XP Hotfix KB822603 installed. This update is intended to address a serious error in Usbport.sys when you operate a USB device. You can run Windows Update or download the update from [www.microsoft.com/downloads/details.aspx?familyid=733dd867-56a0-4956-b7fe-e85b688b7f86&displaylang=en](http://www.microsoft.com/downloads/details.aspx?familyid=733dd867-56a0-4956-b7fe-e85b688b7f86&displaylang=en). For more information, refer to the Microsoft Knowledge Base article "Availability of the Windows XP SPI USB 1.1 and 2.0 update." This article is available at [support.microsoft.com/?kbid=822603](http://support.microsoft.com/?kbid=822603).

To connect the PMD-1208FS to your system, turn your computer on, and connect the USB cable to a USB port on your computer or to an external USB hub that is connected to your computer. The USB cable provides power and communication to the PMD-1208FS.

When you connect the PMD-1208FS for the first time, a series of **Found New Hardware** popup balloons (Windows XP) or dialogs (other Windows versions) opens as the PMD-1208FS is detected by your computer.



It is normal for multiple dialogs to open when you connect the PMD-1208FS for the first time. For additional information, refer to the "*Notes on installing and using the PMD-1208FS*" that was shipped with the PMD-1208FS.

The last popup balloon or dialog states "Your new hardware is installed and ready to use," and the LED on the PMD-1208FS should flash and then remain lit. This indicates that communication is established between the PMD-1208FS and your computer.



On most computers, you can install up to two PMD-1208FS units. If you need to connect more than two PMD-1208FS units to your computer, contact Tech Support by phone (508-946-5100), fax (508-946-9500), or email ([techsupport@measurementcomputing.com](mailto:techsupport@measurementcomputing.com))

**Caution!** Do not disconnect **any** device from the USB bus while the computer is communicating with the PMD-1208FS, or you may lose data and/or your ability to communicate with the PMD-1208FS.

#### If the LED turns off

If the LED is illuminated but then turns off, the computer has lost communication with the PMD-1208FS. To restore communication, disconnect the USB cable from the computer, and then reconnect it. This should restore communication, and the LED should turn back *on*.

## Functional Details

### Theory of operation - analog input acquisition modes

The PMD-1208FS can acquire analog input data in two different modes – software paced and continuous scan.

#### Software paced mode

In software paced mode, you can acquire one analog sample at a time. You initiate the A/D conversion by calling a software command. The analog value is converted to digital and returned to the computer. You can repeat this procedure until you have the total number of samples that you want from one channel.

The maximum throughput sample rate in software paced mode is system-dependent.

#### Continuous scan mode

In continuous scan mode, you can acquire data from up to eight channels. The analog data is continuously acquired, converted to digital values, and written to an on-board FIFO buffer until you stop the scan. The FIFO buffer is serviced in blocks as the data is transferred from the PMD-1208FS to the memory buffer on your computer.

The maximum continuous scan rate of 50 kS/s is an aggregate rate. The total acquisition rate for all channels cannot exceed 50 kS/s. You can acquire data from one channel at 50 kS/s, two channels at 25 kS/s, and four channels at 12.5 kS/s. You can start a continuous scan with either a software command or with an external hardware trigger event.

### External components

The PMD-1208FS has the following external components, as shown in Figure 3-1.

- USB connector
- LED
- Screw terminal banks (2)




Figure 3-1. PMD-1208FS external components

## USB connector

The USB connector is on the right side of the PMD-1208FS. This connector provides +5 V power and communication. The voltage supplied through the USB connector is system-dependent, and may be less than 5 V. No external power supply is required.

## LED

The LED on the front of the housing indicates the communication status of the PMD-1208FS. It uses up to 5 mA of current and cannot be disabled. Table 3-1 defines the function of the PMD-1208FS LED.

Table 3-1. LED Illumination

LED Illumination	Indication
Steady green	The PMD-1208FS is connected to a computer or external USB hub.
Blinks continuously	Data is being transferred.

## Screw terminal wiring

The PMD-1208FS has two rows of screw terminals—one row on the top edge of the housing, and one row on the bottom edge. Each row has 20 connections. Pin numbers are identified in Figure 3-2.



Figure 3-2. PMD-1208FS Screw terminal pin numbers

### Screw terminal – pins 1-20

The screw terminals on the top edge of the PMD-1208FS (pins 1 to 20) provide the following connections:

- Eight analog input connections (**CH0 IN** to **CH7 IN**)
- Two analog output connections (**D/A OUT 0** to **D/A OUT 1**)
- One external trigger source (**TRIG\_IN**)
- One SYNC terminal for external clocking and multi-unit synchronization (**SYNC**)
- One calibration terminal (**CAL**)
- Five analog ground connections (**AGND**)
- One ground connection (**GND**)
- One external event counter connection (**CTR**)


## Screw terminal – pins 21-40

The screw terminals on the bottom edge of the (pins 21 to 40) provide the following connections:

- 16 digital I/O connections (**Port A0** to **Port A7**, and **Port B0** to **Port B7**)
- One power connection (**PC+5 V**)
- Three ground connections (**GND**)

## Main connector and pin out

Connector type	Screw terminal
Wire gauge range	16 AWG to 30 AWG



## Analog input terminals (CH0 IN - CH7 IN)

You can connect up to eight analog input connections to the screw terminal containing pins 1 to 20 (**CH0 IN** through **CH7 IN**.) Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of these pins.

You can configure the analog input channels as eight single-ended channels or four differential channels. When configured for differential mode, each analog input has 12-bit resolution. When configured for single-ended mode, each analog input has 11-bit resolution, due to restrictions imposed by the A/D converter.

### Single-ended configuration

When all of the analog input channels are configured for single-ended input mode, eight analog channels are available. The input signal is referenced to signal ground (GND), and delivered through two wires:

- The wire carrying the signal to be measured connects to CH# IN.
- The second wire connects to AGND.

The input range for single-ended mode is  $\pm 10$  V. No other ranges are supported in single-ended mode. Figure 3-3 illustrates a typical single-ended measurement connection.




Figure 3-3. Single-ended measurement connection

The following example shows the single-ended measurement data acquired by TracerDAQ.




Figure 3-4. TracerDAQ plot of single-ended measurement data

## Single-ended measurements using differential channels

To perform a single-ended measurement using differential channels, connect the signal to "CH<sub>n</sub> IN HI" input, and ground the associated "CH<sub>n</sub> IN LO" input.

### Differential configuration

When all of the analog input channels are configured for differential input mode, four analog channels are available. In differential mode, the input signal is measured with respect to the low input.

The input signal is delivered through three wires:

- The wire carrying the signal to be measured connects to CH0 IN HI, CH1 IN HI, CH2 IN HI, or CH3 IN HI.
- The wire carrying the reference signal connects to CH0 IN LO, CH1 IN LO, CH2 IN LO, or CH3 IN LO.
- The third wire connects to GND.

A low-noise precision programmable gain amplifier (PGA) is available on differential channels to provide gains of up to 20 and a dynamic range of up to 12-bits. Differential mode input voltage ranges are  $\pm 20$  V,  $\pm 10$  V,  $\pm 5$  V,  $\pm 4$  V,  $\pm 2.5$  V,  $\pm 2.0$  V, 1.25 V, and  $\pm 1.0$  V.

In differential mode, the following two requirements must be met for linear operation:

- Any analog input must remain in the -10V to +20V range with respect to ground at all times.
- The maximum differential voltage on any given analog input pair must remain within the selected voltage range.

The input [*common-mode voltage + signal*] of the differential channel must be in the -10 V to +20 V range in order to yield a useful result. For example, you input a 4 V pp sine wave to CHHI, and apply the same sine wave 180° out of phase to CHLO. The common mode voltage is 0 V. The differential input voltage swings from 4 V - (-4 V) = 8 V to -4 V - 4 V = -8 V. Both inputs satisfy the -10 V to +20 V input range requirement, and the differential voltage is suited for the  $\pm 10$  V input range (see Figure 3-5).




Figure 3-5. Differential voltage example: common mode voltage of 0 V

If you increase the common mode voltage to 11 V, the differential remains at  $\pm 8$  V. Although the [*common-mode voltage + signal*] on each input now has a range of +7 V to +15 V, both inputs still satisfy the -10 V to +20 V input requirement (see Figure 3-6).




Figure 3-6. Differential voltage example: common mode voltage of 11 V

If you decrease the common-mode voltage to -7 V, the differential stays at  $\pm 8$  V. However, the solution now violates the input range condition of -10 V to +20 V. The voltage on each analog input now swings from -3V to -11V. Voltages between -10 V and -3 V are resolved, but those below -10 V are clipped (see Figure 3-7).




Figure 3-7. Differential voltage example: common mode voltage of -7 V

Since the analog inputs are restricted to a -10 V to +20 V signal swing with respect to ground, all ranges *except*  $\pm 20$  V can realize a linear output for any differential signal with zero common mode voltage and full scale signal inputs. The  $\pm 20$  V range is the exception. You cannot put -20 V on CHHI and 0 V on CHLO since this violates the input range criteria.

Table 3-2 shows some possible inputs and the expected results.

Table 3-2. Sample inputs and differential results

<b>CHHI</b>	<b>CHLO</b>	<b>Result</b>
-20 V	0 V	In Valid
-15 V	+5 V	In Valid
-10 V	0 V	-10 V
-10 V	+10 V	-20 V
0 V	+10 V	-10 V
0 V	+20 V	-20 V
+10 V	-10 V	+20 V
+10 V	0 V	+10 V
+15 V	-5 V	+20 V
+20 V	0	+20 V

#### For more information on analog signal connections

For more information on single-ended and differential inputs, refer to the *Guide to Signal Connections* (this document is available on our web site at [www.mccdaq.com/signals/signals.pdf](http://www.mccdaq.com/signals/signals.pdf))

#### Analog output terminals (D/A OUT 0 and D/A OUT 1)

You can connect up to two analog output connections to the screw terminal pins 13 and 14 (**D/A OUT 0** and **D/A OUT 1**). Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of these pins.

Each channel can be paced individually at rates up to 10,000 updates per second. Both channels can be paced simultaneously using the same time base at 5000 updates per channel. The 0-4.096 V output range provides a convenient 1 mV per LSB when setting the output voltage levels.

## Digital I/O terminals (Port A0 to A7, and Port B0 to B7)

You can connect up to 16 digital I/O lines to the screw terminal containing pins 21 to 40 (**Port A0 to Port A7, and Port B0 to Port B7.**) Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of these pins. You can configure each digital port for either input or output.

When you configure the digital bits for input, you can use the digital I/O terminals to detect the state of any TTL level input. Refer to the switch shown in Figure 3-8 and the schematic shown in Figure 3-9. If the switch is set to the +5 V input, Port A0 reads *TRUE* (1). If you move the switch to GND, Port A0 reads *FALSE*.




Figure 3-8. Digital connection Port A0 detecting the state of a switch




Figure 3-9. Schematic showing switch detection by digital channel Port A0

### For more information on digital signal connections

For more information on digital signal connections and digital I/O techniques, refer to the *Guide to Signal Connections* (available on our web site at [www.mccdaq.com/signals/signals.pdf](http://www.mccdaq.com/signals/signals.pdf)).

## Power terminals

The **PC +5V** connection (pin 30) is on the bottom screw terminal of the PMD-1208FS. Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of this pin. This terminal draws power from the USB connector. The +5 V screw terminal is a 5 volt output that is supplied by the host computer.

**Caution!** The +5 V terminal is an output. Do not connect to an external power supply or you may damage the PMD-1208FS and possibly the computer.

The maximum total output current that can be drawn from all PMD-1208FS connections (power, analog and digital outputs) is 420 mA. This maximum applies to most personal computers and self-powered USB hubs. Bus-powered hubs and notebook computers may limit the maximum available output current to 100 mA.

Just connecting the PMD-1208FS to your computer draws 80 mA of current from the USB +5 V supply. Once you start running applications with the PMD-1208FS, each DIO bit can draw up to 2.5 mA, and each analog output can draw 15 mA. The maximum amount of +5 V current available for experimental use, over and above that required by the PMD-1208FS, is the difference between the *total current requirement* of the PMD (based on the application), and the *allowed current draw* of the PC platform (500 mA for desktop PCs and self-powered hubs, or 100 mA for bus-powered hubs and notebook computers).

With all outputs at their maximum output current, you can calculate the total current requirement of the PMD-1208FS USB +5 V as follows:

$$(\text{PMD-1208FS @ 80 mA}) + (16 \text{ DIO @ 2.5 mA ea}) + (2 \text{ AO @ 15 mA ea}) = 150 \text{ mA}$$

For an application running on a PC or powered hub, the maximum available excess current is 500 mA - 150 mA = 350 mA. This number is the total maximum available current at the PC +5 V screw terminals. Measurement Computing highly recommends that you figure in a safety factor of 20% below this maximum current loading for your applications. A conservative, safe user maximum in this case would be in the 350-380 mA range.

Since laptop computers typically allow up to 100 mA, the PMD-1208FS in a fully-loaded configuration may be above that allowed by the computer. In this case, you must determine the per-pin loading in the application to ensure that the maximum loading criteria is met. The per-pin loading is calculated by simply dividing the +5 V by the load impedance of the pin in question.

## Calibration terminal

The **CAL** connection (pin 16) is an output you should use only to calibrate the PMD-1208FS. Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of this pin. Calibration of the PMD-1208FS is software-controlled via *InstaCal*.

## Ground terminals

The four analog ground (**AGND**) connections provide a common ground for all PMD-1208FS input channels. Four ground (GND) connections provide a common ground for the **DIO**, **TRIG\_IN**, **CTR**, **SYNC** and **PC +5V** connections. Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of the **AGND** and **GND** terminal pins.

## External trigger terminal

The **TRIG\_IN** connection (pin 18) can be configured for either rising or falling edge. Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of the **TRIG\_IN** terminal pin.

## SYNC terminal

The **SYNC** connection (pin 19) is a bidirectional I/O signal. You can use it for two purposes:

- Configure as an external clock input to externally source the A/D conversions. The **SYNC** terminal supports TTL-level input signals of up to 50 kHz.
- Configure as an output to synchronize with a second PMD unit and acquire data from 16 channels.

Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of this pin. For more information, refer to page 3-12.

## Counter terminal

The CTR connection (pin 20) is input to the 32-bit external event. Refer to the [pinout diagrams](#) on pages 3-3 and 3-3 for the location of this pin. The internal counter increments when the TTL levels transition from low to high. The counter can count frequencies of up to 1 MHz.

## Accuracy

The overall accuracy of any instrument is limited by the error components within the system. Quite often, resolution is incorrectly used to quantify the performance of a measurement product. While "12-bits" or "1 part in 4096" does indicate what can be resolved, it provides little insight into the quality of an absolute measurement. Accuracy specifications describe the actual results that can be realized with a measurement device.

There are three types of errors which affect the accuracy of a measurement system:

- offset
- gain
- nonlinearity.

The primary error sources in the PMD-1208FS are offset and gain. Nonlinearity is small in the PMD-1208FS, and is not significant as an error source with respect to offset and gain.

Figure 3-10 shows an ideal, error-free, PMD-1208FS transfer function. The typical calibrated accuracy of the PMD-1208FS is range-dependent, as explained in the "[Specifications](#)" chapter of this document. We use a  $\pm 10$  V range here as an example of what you can expect when performing a measurement in this range.




Figure 3-10. Ideal ADC transfer function

The PMD-1208FS offset error is measured at mid-scale. Ideally, a zero volt input should produce an output code of 2048. Any deviation from this is an offset error. Figure 3-11 shows the PMD-1208FS transfer function with an offset error. The typical offset error specification on the  $\pm 10$  V range is  $\pm 9.77$  mV. Offset error affects all codes equally by shifting the entire transfer function up or down along the input voltage axis.

**The accuracy plots in Figure 3-11 are drawn for clarity and are not drawn to scale.**




Figure 3-11. ADC transfer function with offset error

Gain error is a change in the slope of the transfer function from the ideal, and is typically expressed as a percentage of full-scale. Figure 3-12 shows the PMD-1208FS transfer function with gain error. Gain error is easily converted to voltage by multiplying the full-scale (FS) input by the error.

**The accuracy plots in Figure 3-12 are drawn for clarity and are not drawn to scale.**




Figure 3-12. ADC Transfer function with gain error

For example, the PMD-1208FS exhibits a typical calibrated gain error of  $\pm 0.2\%$  on all ranges. For the  $\pm 10$  V range, this would yield  $10\text{ V} \times \pm 0.002 = \pm 20\text{ mV}$ . This means that at full scale, neglecting the effect of offset for the moment, the measurement would be within 20 mV of the actual value. Note that gain error is expressed as a ratio. Values near  $\pm\text{FS}$  are more affected from an absolute voltage standpoint than are values near mid-scale, which see little or no voltage error.

Combining these two error sources in Figure 3-13, we have a plot of the error band of the PMD-1208FS for the  $\pm 10$  V range. This is a graphical version of the typical accuracy specification of the product.

The accuracy plots in Figure 3-13 are drawn for clarity and are not drawn to scale




Figure 3-13. Error band plot

## PMD-1208FS channel gain queue feature

The PMD-1208FS's channel gain queue feature allows you to set up a scan sequence with a unique per-channel gain setting and channel sequence.

The channel gain queue feature removes the restriction of using an ascending channel sequence at a fixed gain. This feature creates a channel list which is written to local memory on the PMD-1208FS. The channel list is made up of a channel number and range setting. An example of a four-element list is shown in Table 3-3.

Table 3-3. Sample channel gain queue list

Element	Channel	Range	
0	CH0	BIP10V	
1	CH0	BIP5V	
2	CH7	BIP10V	
3	CH2	BIP1V	

When a scan begins with the gain queue enabled, the PMD-1208FS reads the first element, sets the appropriate channel number and range, and then acquires a sample. The properties of the next element are then retrieved, and another sample is acquired. This sequence continues until all elements in the gain queue have been selected. When the end of the channel list is detected, the sequence returns to the first element in the list.

This sequence repeats until the specified number of samples is gathered. You must carefully match the gain to the expected voltage range on the associated channel—otherwise, an over range condition can occur. Although this condition does not damage the PMD-1208FS, it does produce a useless full-scale reading. It can also introduce a long recovery time from saturation, which can affect the next measurement in the queue.

## Synchronizing multiple units

You can connect the SYNC pin of two PMD-1208FS units together in a master/slave configuration and acquire data from the analog inputs of both devices using one clock. When the SYNC pin is configured as an output, the internal A/D pacer clock is sent to the screw terminal. You can use this signal as a clock input to a second PMD by connecting it to the SYNC pin of the second PMD.


When used as a clock input, the SYNC pin operates in one of two modes – *Continuous* or *Gated*.

In the default *Continuous* mode, a PMD-1208FS ignores the first clock pulse in order to ensure adequate setup time. Use this mode if the unit is being paced from a continuous clock source, such as a generator.

In the *Gated* mode, it is assumed that the clock signal will be held off for an adequate amount of time for setup to occur. No clock pulses are ignored. Use this mode if the PMD-1208FS is set up as a slave and the source of the external clock is another PMD.

The SYNC pin (pin 19) is set for pacer output by default. To synchronize a master PMD-1208FS with a slave PMD-1208FS and acquire data, follow the steps below.

1. Connect the SYNC pin of the master PMD-1208FS to the SYNC pin of the slave PMD-1208FS.
2. Run InstaCal.
3. From the **PC Board List** on the **InstaCal** main form, double-click on the PMD-1208FS you want to use as a slave. The **Board Configuration** dialog opens.
4. Select *Gated* from the **Ext. Clock Type** drop-down list.



5. Set the Universal Library `EXTCLOCK` option with `cbAInScan()` / `AInScan` for the slave PMD-1208FS to enable pacing from the master PMD device.

This *InstaCal* option does not affect internally paced acquisition. It only affects scans that use the `EXTCLOCK` option.

An example of a master/slave configuration is shown below.




Figure 3-14. Configuring for synchronous data acquisition

When you are operating one PMD-1208FS, do not set the `EXTCLOCK` option unless you are using an external clock for A/D pacing.

# Specifications

**Typical for 25 °C unless otherwise specified.**

**Specifications in *italic* text are guaranteed by design.**

## Analog input section

Table 4-1. Analog input specifications

Parameter	Conditions	Specification
A/D converter type		Successive approximation type
Input voltage range for linear operation, single-ended mode	CHx to GND	$\pm 10$ volts (V) max
Input common-mode voltage range for linear operation, differential mode	CHx to GND	-10 V min, +20 V max
<i>Absolute maximum input voltage</i>	<i>CHx to GND</i>	$\pm 28$ V max
Input current (Note 1)	V <sub>in</sub> = +10 V	70 microamperes ( $\mu$ A) typ
	V <sub>in</sub> = 0 V	-12 $\mu$ A typ
	V <sub>in</sub> = -10 V	-94 $\mu$ A typ
Number of channels		8 single-ended / 4 differential, software selectable
Input ranges, single-ended mode		$\pm 10$ V, G=2
Input ranges, differential mode		$\pm 20$ V, G=1 $\pm 10$ V, G=2 $\pm 5$ V, G=4 $\pm 4$ V, G=5 $\pm 2.5$ V, G=8 $\pm 2.0$ V, G=10 $\pm 1.25$ V, G=16 $\pm 1.0$ V, G=20 Software selectable
Throughput (Note 2)	Software paced	250 samples per second (S/s) typ, PC-dependent
	Continuous scan	50 kilosamples per second (kS/s)
Channel gain queue	Up to 16 elements	Software configurable channel, range, and gain.
Resolution (Note 3)	Differential	12 bits, no missing codes
	Single-ended	11 bits
CAL accuracy	CAL = 2.5 V	$\pm 36.25$ mV max
Integral linearity error		$\pm 1$ least significant bit (LSB) typ
Differential linearity error		$\pm 0.5$ LSB typ
Repeatability		$\pm 1$ LSB typ
CAL current	Source	5 milliamperes (mA) max
	Sink	20 $\mu$ A min, 100 $\mu$ A typ
Trigger source	Software selectable	External digital: TRIG_IN

**Note 1:** Input current is a function of applied voltage on the analog input channels. For a given input voltage, V<sub>in</sub>, the input leakage is approximately equal to  $(8.181 \times V_{in} - 12)$   $\mu$ A.

**Note 2:** Maximum throughput scanning to PC memory is machine dependent. The rates specified are for Windows XP only. Maximum rates on operating systems that predate XP may be less and must be determined through testing on your machine.

**Note 3:** The AD7870 converter only returns 11-bits (0-2047 codes) in single-ended mode.

Table 4-2. Accuracy, differential mode

Range	Accuracy (LSB)
±20 V	5.1
±10 V	6.1
±5 V	8.1
±4 V	9.1
±2.5 V	12.1
±2 V	14.1
±1.25 V	20.1
±1 V	24.1

Table 4-3. Accuracy, single-ended mode

Range	Accuracy (LSB)
±10 V	4.0

Table 4-4. Accuracy components, differential mode - All values are (±)

Range	% of Reading	Gain Error at full scale (FS) (millivolts (mV))	Offset (mV)	Accuracy at FS (mV)
±20 V	0.2	40	9.766	49.766
±10 V	0.2	20	9.766	29.766
±5 V	0.2	10	9.766	19.766
±4 V	0.2	8	9.766	17.766
±2.5 V	0.2	5	9.766	14.766
±2 V	0.2	4	9.766	13.766
±1.25 V	0.2	2.5	9.766	12.266
±1 V	0.2	2	9.766	11.766

Table 4-5. Accuracy components, single-ended mode - All values are (±)

Range	% of Reading	Gain Error at FS (mV)	Offset (mV)	Accuracy at FS (mV)
±10 V	0.2	20	19.531	39.531

Table 4-6. Noise performance, differential mode

Range	Typical counts	Least significant bit <sub>root mean square</sub> (LSB <sub>rms</sub> )
±20 V	2	0.30
±10 V	2	0.30
±5 V	3	0.45
±4 V	3	0.45
±2.5 V	4	0.61
±2 V	5	0.76
±1.25 V	7	1.06
±1 V	8	1.21

Table 4-7. Noise performance, single-ended mode

Range	Typical Counts	LSB <sub>rms</sub>
±10 V	2	0.30

## Analog output section

Table 4-8. Analog output specifications

Parameter	Conditions	Specification
Resolution		12-bits, 1 in 4096
<i>Output range</i>		$0 - 4.096 \text{ V}$ , 1 mV per LSB.
Number of channels		2
Throughput (Note 4)	Software paced	250 S/s single channel typical, PC dependent
	Single channel, continuous scan	10 kS/s
	Dual channel, continuous scan, simultaneous update	5 kS/s
Power on and reset voltage		Initializes to 000h code
Output drive	Each D/A OUT	15 mA
Slew rate		0.8 V/microsecond ( $\mu\text{s}$ ) typ

**Note 4:** Maximum throughput scanning to PC memory is machine dependent. The rates specified are for Windows XP only. Maximum rates on operating systems that predate XP may be less and must be determined through testing on your machine

Table 4-9. Analog output accuracy, all values are ( $\pm$ )

Range	Accuracy (LSB)
0-4.096 V	4.0 typ, 45.0 max

Table 4-10. Analog output accuracy components, all values are ( $\pm$ )

Range	% of FSR	Gain Error at FS (mV)	Offset (mV) (Note 5)	Accuracy at FS (mV)
0-4.096 V	0.1 typ, 0.9 max	4.0 typ, 36.0 max	1.0 typ, 9.0 max	4.0 typ, 45.0 max

**Note 5:** Negative offsets will result in a fixed zero-scale error or “dead band.” At the maximum offset of -9 mV, any input code of less than 0x009 will not produce a response in the output.

## Digital input/output

Table 4-11. Digital I/O specifications

Digital type	CMOS
Number of I/O	16 (Port A0 through A7, Port B0 through B7)
Configuration	2 banks of 8
Pull up/pull-down configuration	All pins pulled up to Vs via 47 K resistors (default). Positions available for pull down to ground. Hardware selectable via zero ohm ( $\Omega$ ) resistors as a factory option.
Input high voltage	2.0 V min, 5.5 V absolute max
Input low voltage	0.8 V max, -0.5 V absolute min
Output high voltage (IOH = -2.5 mA)	3.8 V min
Output low voltage (IOL = 2.5 mA)	0.7 V max
Power on and reset state	Input

## External trigger

Table 4-12. Digital trigger specifications

Parameter	Conditions	Specification
Trigger source (Note 6)	External Digital	TRIG_IN
Trigger mode	Software selectable	Edge sensitive: user configurable for CMOS compatible rising or falling edge.
Trigger latency		10 µs max
Trigger pulse width		1 µs min
Input high voltage		4.0 V min, 5.5 V absolute max
Input low voltage		1.0 V max, -0.5 V absolute min
<i>Input leakage current</i>		$\pm 1.0 \mu A$

**Note 6:** TRIG\_IN is a Schmitt trigger input protected with a 1.5 kilohm ( $k\Omega$ ) series resistor.

## External clock input/output

Table 4-13. External clock I/O specifications

Parameter	Conditions	Specification
Pin name		SYNC
Pin type		Bidirectional
Software selectable direction	Output (default)	Outputs internal A/D pacer clock.
	Input	Receives A/D pacer clock from external source.
Input clock rate		50 KHz, maximum
Clock pulse width	Input mode	1 µs min
	Output mode	5 µs min
<i>Input leakage current</i>	<i>Input mode</i>	$\pm 1.0 \mu A$
Input high voltage		4.0 V min, 5.5 V absolute max
Input low voltage		1.0 V max, -0.5 V absolute min
Output high voltage (Note 7)	IOH = -2.5 mA	3.3 V min
	No Load	3.8 V min
Output low voltage (Note 7)	IOL = 2.5 mA	1.1 V max
	No Load	0.6 V max

**Note 7:** SYNC is a Schmitt trigger input and is over-current protected with a 200  $\Omega$  series resistor.

## Counter section

Table 4-14. Counter specifications

Pin name (Note 8)	CTR
Counter type	Event counter
Number of channels	1
<i>Input source</i>	<i>CTR screw terminal</i>
Resolution	32 bits
<i>Schmidt trigger hysteresis</i>	<i>20 mV to 100 mV</i>
<i>Input leakage current</i>	$\pm 1 \mu A$
Maximum input frequency	1 MHz
<i>High pulse width</i>	<i>500 ns min</i>
<i>Low pulse width</i>	<i>500 ns min</i>
Input high voltage	4.0 V min, 5.5 V absolute max
Input low voltage	1.0 V max, -0.5 V absolute min

**Note 8:** CTR is a Schmitt trigger input protected with a 1.5 K  $\Omega$  series resistor.

## Non-volatile memory

Table 4-15. Non-volatile memory specifications

EEPROM	1,024 bytes		
EEPROM Configuration	<b>Address Range</b>	<b>Access</b>	<b>Description</b>
	0x000-0x07F	Reserved	128 bytes system data
	0x080-0x1FF	Read/write	384 bytes cal data
	0x200-0x3FF	Read/write	512 bytes user area

## Microcontroller

Table 4-16. Microcontroller specifications

Type	High performance 8-bit RISC microcontroller
Program Memory	16,384 words
Data Memory	2,048 bytes

## Power

Table 4-17. Power specifications

Parameter	Conditions	Specification
Supply current (Note 9)		80 mA
+5V USB power available (Note 10)	Connected to self-powered hub	4.5 V min, 5.25 V max
	Connected to externally-powered root port hub	
	Connected to bus-powered hub	4.1 V min, 5.25 V max
Output current (Note 11)	Connected to self-powered hub	420 mA max
	Connected to externally-powered root port hub	
	Connected to bus-powered hub	20 mA max

**Note 9:** This is the total current requirement for the PMD-1208FS which includes up to 10 mA for the status LED.

**Note 10:** *Self-powered hub* refers to a USB hub with an external power supply. Self-powered hubs allow a connected USB device to draw up to 500 mA.

*Root port hubs* reside in the PC's USB host controller. The USB port(s) on your PC are root port hubs. All externally powered root port hubs (desktop PCs) provide up to 500 mA of current for a USB device. Battery-powered root port hubs provide 100 mA or 500 mA, depending upon the manufacturer. A laptop PC that is not connected to an external power adapter is an example of a battery-powered root port hub.

*Bus powered hubs* receive power from a self-powered or root port hub. In this case the maximum current available from the USB +5 V is 100 mA. The minimum USB +5 V voltage level can be as low as 4.1 V.

**Note 11:** This refers to the total amount of current that can be sourced from the USB +5 V, analog outputs and digital outputs.

## General

Table 4-18. General specifications

Parameter	Conditions	Specification
Device type		USB 2.0 full speed
Device compatibility		USB 1.1, USB 2.0

## Environmental

Table 4-19. Environmental specifications

Operating Temperature range	0 to 70 °C
Storage temperature range	-40 to 85 °C
Humidity	0 to 90% non-condensing

## Mechanical

Table 4-20. Mechanical specifications

Dimensions	79 millimeters (mm) long x 82 mm wide x 25 mm high
USB cable length	3 meters max
User connection length	3 meters max

## Main connector and pin out

Table 4-21. Main connector specifications

Connector type	Screw terminal
Wire gauge range	16 AWG to 30 AWG

## 4-channel differential mode

Pin	Signal Name	Pin	Signal Name
1	CH0 IN HI	21	Port A0
2	CH0 IN LO	22	Port A1
3	AGND	23	Port A2
4	CH1 IN HI	24	Port A3
5	CH1 IN LO	25	Port A4
6	AGND	26	Port A5
7	CH2 IN HI	27	Port A6
8	CH2 IN LO	28	Port A7
9	AGND	29	GND
10	CH3 IN HI	30	PC+5V
11	CH3 IN LO	31	GND
12	AGND	32	Port B0
13	D/A OUT 0	33	Port B1
14	D/A OUT 1	34	Port B2
15	AGND	35	Port B3
16	CAL	36	Port B4
17	GND	37	Port B5
18	TRIG IN	38	Port B6
19	SYNC	39	Port B7
20	CTR	40	GND

## 8-channel single-ended mode

Pin	Signal Name	Pin	Signal Name
1	CH0 IN	21	Port A0
2	CH1 IN	22	Port A1
3	AGND	23	Port A2
4	CH2 IN	24	Port A3
5	CH3 IN	25	Port A4
6	AGND	26	Port A5
7	CH4 IN	27	Port A6
8	CH5 IN	28	Port A7
9	AGND	29	GND
10	CH6 IN	30	PC+5V
11	CH7 IN	31	GND
12	AGND	32	Port B0
13	D/A OUT 0	33	Port B1
14	D/A OUT 1	34	Port B2
15	AGND	35	Port B3
16	CAL	36	Port B4
17	GND	37	Port B5
18	TRIG IN	38	Port B6
19	SYNC	39	Port B7
20	CTR	40	GND

# CE Declaration of Conformity

Manufacturer: Measurement Computing Corporation  
Address: 16 Commerce Boulevard  
Middleboro, MA 02346  
USA

Category: Electrical equipment for measurement, control and laboratory use.

Measurement Computing Corporation declares under sole responsibility that the product

PMD-1208FS

to which this declaration relates is in conformity with the relevant provisions of the following standards or other documents:

**EU EMC Directive 89/336/EEC: Electromagnetic Compatibility, EN 61326 (1997) Amendment 1 (1998)**

Emissions: Group 1, Class A

- EN 55011 (1998)/CISPR 11: Radiated and Conducted emissions.

Immunity: EN61326, Annex A

- EN 61000-4-2 (1995): Electrostatic Discharge immunity, Criteria C.
- EN 61000-4-3 (1997): Radiated Electromagnetic Field immunity Criteria A.
- EN 61000-4-8 (1995): Power Frequency Magnetic Field immunity Criteria A.

Power line and I/O tests to EN61000-4-4, EN61000-4-5, EN61000-4-6, and EN61000-4-11 were not required. The device is DC powered from an I/O cable which is less than three meters long.

Declaration of Conformity based on tests conducted by Chomerics Test Services, Woburn, MA 01801, USA in August, 2004. Test records are outlined in Chomerics Test Report #EMI3948.04.

We hereby declare that the equipment specified conforms to the above Directives and Standards.



Carl Haapaoja, Vice-President of Design Verification

**Measurement Computing Corporation**  
**16 Commerce Boulevard,**  
**Middleboro, Massachusetts 02346**  
**(508) 946-5100**  
**Fax: (508) 946-9500**  
**E-mail: [info@mccdaq.com](mailto:info@mccdaq.com)**  
**[www.mccdaq.com](http://www.mccdaq.com)**