

IQC: Incoming Quality Check

Inspect incoming devices, capture hardware specs, assess cosmetic condition, and assign grade, floor, and warehouse location.

Step 1: Open the IQC Queue

- Go to IQC from the left navigation.
- The queue shows all devices registered in Stock Inward that have not yet been inspected.
- Click the 'IQC' button next to the device you want to inspect.

Step 2: Set Up the OxyQC Diagnose Agent

- On the IQC form, click the blue 'Download Agent' button.
- Run Diagnose_Device_Agent.exe on the inspection station. No admin rights needed.
- The agent installs to the user's local app folder and persists across reboots.
- Once installed, the button turns green -- you only need to do this once per station.

Step 3: Auto-Detect Hardware with Diagnose

- Plug the laptop in and connect to the same network as the inspection station.
- Click 'Diagnose this Device' on the IQC form.
- The system fills CPU, Generation, RAM GB, Storage GB, Battery Health %, and Screen Size automatically via WMI.
- Alternatively, plug in the OxyQC USB drive and click 'USB Import' to read offline scan results.
- Review all auto-filled values and correct any that the agent could not detect.

Step 4: Fill Hardware Fields

- Device Type: select Laptop, Desktop, or Tablet.
- Brand, Model: select or type the manufacturer and model name.
- Serial Number: enter the serial number printed on the device (mandatory).
- CPU: enter the processor name as it appears in Device Manager.
- Generation: enter the CPU generation number (e.g., 8 for 8th Gen Intel).
- RAM GB: enter total installed RAM in gigabytes.
- Storage GB: enter the primary drive capacity; select Type (SSD/HDD/eMMC/NVMe).
- HDD Capacity GB: enter secondary HDD size if a second drive is present.
- Battery Health %: enter the battery wear level (100% = new).
- Screen Size: enter diagonal screen size in inches.
- Color: select the device body colour.
- BIOS Password: tick if a BIOS password is set and cannot be removed.

Step 5: Assess Screen Condition

- Screen Functional: select Yes or No -- this is whether the screen works at all.
- Screen Defects: check all applicable defect boxes from 13 options:
 - Dot, Line, Discoloration, Patch, Broken, Flickering, Scratch, Loose, Missing,
 - Hinge Broken, Colour Spread, Keyboard Mark, Hard Press.

- Each checked defect is recorded for downstream QC reference.

Step 6: Assess Panels A to D

- Panel A (Screen Lid): check Scratch / Broken / Missing / Dent / Colour Fade.
- Panel B (Bottom): same as A plus Rubber Cut.
- Panel C (Front Bezel): check Scratch / Broken / Missing / Dent / Colour Fade.
- Panel D (Keyboard Deck): same as C.
- Be precise -- Panel notes appear on the device card throughout the workflow.

Step 7: Assess Keyboard, Speaker, Touchpad, and Ports

- Keyboard: check Working status; flag Colour Fade / Key Missing / Hard Press if present.
- Speaker: select OK / Not Working / Not Checked.
- Touchpad: check Working / Click Working; flag Scratch / Colour Fade / Missing.
- Ports: select HDMI status, USB Working status, Audio Jack status.
- Count the number of USB-A ports, USB-C ports, and Ethernet ports.
- Charging Port: select status (Working / Not Working / Missing).
- WiFi: select Detected / Not Detected / Not Tested.
- Webcam: select Working / Not Working / Not Present.
- HDD Connector and Casing: tick if the internal connector or casing has damage.

Step 8: Assign Grade, Floor, and Warehouse

- Grade: select A (excellent, no significant defects), B (minor cosmetic issues), or C (notable cosmetic defects).
- Grade D is not used in this system.
- R2V3 Grade Category: select the environmental grade category per R2V3 standard.
- Floor: enter the physical floor number where the device will be stored.
- Warehouse: select the warehouse bin location.
- Click 'Save IQC'. The device moves to the next stage.

Tips & Best Practices

- * Serial Number is mandatory -- IQC cannot be saved without it.
- * Grade A = no significant defects; Grade B = minor cosmetic; Grade C = notable cosmetic damage.
- * Battery Health below 80% should always be flagged in the notes for L1 review.
- * The Diagnose agent persists per station -- install once and it works for all future inspections.
- * USB Import is the backup method when the device cannot connect to the station network.