
CeramaTek™ eBallasts




Installation Guide

❖ Wiring Diagram for 175W-450W CeramaTek Ballasts



* Above 26 Ft. distance, new ballast setup is required.




* Above 8 meters distance, new ballast setup is required.


Global Energy & Lighting 560 S. Winchester Blvd,

Suite 500, San Jose, CA 95128, USA










- USE CORD CABLE OR PLASTIC CONDUIT ONLY
- DO NOT connect EARTH/GROUND wire of the output cable



DO NOT connect the Input to the Output

WARNING:

- ❖ Failure to install the Ballast properly could void the product's warranty.
- ❖ All sockets must be rated to at least 4KV and must be Pulse Rated.
- **❖** Lamp wires and connections must be well isolated from chassis (EARTH/GROUND).
- Verify that wire insulation is not damaged (without cuts).
 Damaged wires' are dangerous and might cause harm to people and/or equipment.
- **❖** For MH lamps use only PULSE START lamps.


Global Energy & Lighting

560 S. Winchester Blvd, Suite 500, San Jose, CA 95128, USA

CeramaTek™ eBallasts



***** Ballast Mechanical Mounting



- Mount the Ballast as far away from the lamp reflector.
- Mounting should be secure flat/flush to aluminum plate.

CeramaTek™ eBallasts



Labeling information

Please pay attention to the red remarks.

