BP555 settings cheat sheet

Every setting an operator can change, with the exact buttons. Examples use the 24 inch button.

⚠ Press **+** **−** or **2x** first, then the length. The length button feeds the tape straight away.

Set a length

24

24 in

14 buttons, 6 to 45 in. Long models 12 to 90 in, metric 15 to 145 cm.

Half an inch longer

+ → **24**

24.5 in +13 mm

Each press of **+** adds half an inch.

One inch longer

+ → **+** → **24**

25 in +25 mm

Press **+** twice.

Shorter

− → **24**

23.5 in −13 mm

Twice, **−** → **−** → **24**, gives 23 in.

Double

2x → **24**

48 in

For cartons longer than the biggest button.

Double and add

+ → **+** → **+** → **2x** → **24**

49.5 in

Doubled first, then 1.5 in added.

Same again

REPEAT START

Feeds the last length again.

The one before

REPEAT 2 ENTER

Feeds the second-to-last length.

`Automatic models`

Any length

⬇

Hold it down. Tape feeds until you let go.

Heat and water

Heater Control Dial: OFF, five dots, MAX. Halfway is enough indoors.

Water Level Slider: towards the machine for wetter tape.

Automatic Mode `Automatic models`

1. Press **A**: beep, red light on.
2. Press a length and apply the tape, then **REPEAT 2 ENTER** to store it. Up to three lengths.
3. Press **REPEAT START**. Each piece feeds out when you tear off the last, on a loop.

H pattern: store **24** **6** **6**. Press **A** or switch off to stop. Both clear the program.

Source: Better Packages 555e User Manual, Rev 3.1

Supplied by Cotswold Packaging Group. Jo Lavene, 07930 404517