BTECH UV-PRO Getting Started

Turn on your radio, connect your phone, and save Heights 6, the La Habra Heights Firewatch channel identified in this project's channel plan.

1. FIND THE CONTROLS FIRST

Hold the radio with the screen facing you, as in the supplied photo.

Control	Where to find it	What you will do
Power / Volume	Top-right knob with orange stripe	Turn it to switch on and adjust sound.
Menu / Confirm	Green button below the screen, on the left; overlapping rectangles	Press to open a menu or confirm a choice.
Arrow pad	Four arrows below the screen, in the middle	Use up/down to move through choices; left/right as a menu requires.
Return / Back	Red curved-arrow button below the screen, on the right	Press briefly to go back.
Star (*)	Right end of the first number-key row	Hold to switch between frequency and saved-channel modes.
Hash (#)	Bottom-right keypad button	If the keypad is locked, hold to unlock.
PTT — push to talk	Long orange button on the left side	Leave it alone during setup. Use only for an authorized radio check.

Press means press briefly and release. **Hold** means keep pressing until the mode changes. **Tap** means touch a control on your phone.

2. TURN ON THE RADIO

1. **Attach the antenna and charged battery.** Use the supplied charging instructions if the battery needs charging.
2. **Turn the top-right knob clockwise past the click.** Wait for the screen to start.
3. **Turn the knob a little farther clockwise** to raise the volume.

You should see: the radio's operating screen. To switch off later, turn the same knob counterclockwise past the click.

SOURCES

Button locations: supplied radio photo; functions: BTECH UV-PRO Manual, pp. 4–7. Channel plan: preserved source history and project-owner confirmation, October 9, 2026. Draft for training review.

BTECH UV-PRO Getting Started — continued

Connect the phone to your own radio before changing a channel.

3. LINK THE RADIO TO YOUR PHONE

1. **Install BTECH UV Programmer** on your Android phone or iPhone. Use the app links on BTECH's UV-PRO product page.
2. **Turn on Bluetooth on your phone.** Keep the phone beside the powered-on radio. Allow the app's requested Bluetooth or nearby-device permissions.
3. **Open the radio menu.** Press the green **Menu / Confirm** button.
4. **Choose Connections, then Pairing.** Use the arrow pad to highlight each choice and the green button to select it. The owner-confirmed shortcut from the operating screen is **green button → up → up → green button**; check that Pairing is selected. If pairing is already active, continue. The manual says the red and green indicator lights flash in pairing mode.
5. **Open BTECH UV Programmer on the phone.** Tap the **three-line menu** to find the connection panel. Look for **Bindable Device** and tap your UV-PRO. If several radios appear, ask the lead to identify yours.
6. **Wait for the radio's operating screen and channel list in the app.** If they do not appear, check **Connection management** in the app's device settings and select your radio.

You should see: the connected radio's controls and numbered channel tiles in the app.

RECOGNIZE THESE PHONE CONTROLS

Phone control	Use it for
Three lines	Opening the panel with numbered channel tiles.
Gear in that panel	Opening device settings, including Connection management and Channel & Groups.
Numbered channel tile	Tap to select; press and hold to open **Edit channel**.

Screen differences: the supplied Android captures show the three-line menu at the upper left; older manual pictures show it at the lower left. Recognize the symbol. iPhone and newer app layouts may differ.

SOURCES

BTECH UV-PRO Manual, pp. 11–15, 22, 26; supplied Android captures and project-owner confirmation of the press-and-hold gesture.

BTECH UV-PRO Getting Started — continued

Heights 6 uses two frequencies: one to listen and one to transmit.


4. OPEN AN UNUSED CHANNEL AND ENTER THE FREQUENCIES

1. **Tap the three-line menu** to open the channel panel.
2. **Find an unused numbered tile** in the channel group assigned by your radio lead. The tile number does not need to be 6. Do not overwrite an existing channel.
3. **Press and hold that tile.** Tap **Edit channel** in the menu that appears.
4. **Tap Title.** Enter **Heights 6**.
5. **Tap RX Freq.** Enter **462.38750 MHz**. If asked for a mode, choose **FM**. Confirm the entry.
6. **Tap TX Freq.** Enter **467.38750 MHz**. Choose **FM** if asked, then confirm.

◎ LOCAL INFORMATION — VERIFY BEFORE APPROVAL

Heights 6 — project-owner-confirmed settings, October 9, 2026.

RX / listen: 462.38750 MHz
TX / transmit: 467.38750 MHz
Both receive and transmit DCS: **331N** (set on the next page).



Screen reference adapted from the supplied Android captures. **Enter the values above.** RX and TX are shown with the confirmed target values.
Original captures: project owner; adaptation: OpenAI.

Check: RX starts with **462**; TX starts with **467**. Both end in **.38750**. A final zero may disappear without changing the value; an extra nonzero digit needs the lead's check. Keep Talk Around off for normal repeater use; use it during repeater failure only under the lead's instructions.

SOURCES

Channel-plan source history; project-owner frequency confirmation; supplied Android channel-editor and channel-panel captures.

BTECH UV-PRO Getting Started — continued

Set the receive and transmit codes separately, then save.

5. SET DCS AND SAVE HEIGHTS 6

1. **Tap RX CTCSS/DCS.** Choose **DCS 331N** and confirm. The **N** means normal polarity.
2. **Tap TX CTCSS/DCS.** Choose **DCS 331N** again and confirm. Both fields must be set.
3. **Check the other channel settings with your radio lead.** Set **Bandwidth to 12.5 kHz**, as specified in the owner's current channel instructions. Use the transmit power required by your radio lead; the captured **High** setting alone does not establish the approved power.
4. **Leave Talk Around and Reverse Frequency off.** Heights 6 needs the separate RX and TX frequencies entered on the previous page.
5. **Tap SAVE at the upper right.** Keep the phone connected to the radio until saving finishes.

If the DCS list looks different: the supplied app displays **DCS-331N/465I**. Select the entry containing **331N**. This is one selection label; do not enter a second code or choose **331I**.

COMPARE BEFORE YOU CONTINUE

Field	Correct entry
Title	Heights 6
RX Freq	**462.38750 MHz**, FM
TX Freq	**467.38750 MHz**, FM
RX CTCSS/DCS	**331N**
TX CTCSS/DCS	**331N**
Talk Around / Reverse Frequency	Both off
Bandwidth / TX Power	12.5 kHz / power assigned by the radio lead

You should see: your saved channel in the numbered grid. If saving reports an error, reconnect and check the entry before continuing.

Protect existing programming: use SAVE. Do not use DELETE, factory reset, an unknown channel import, or a firmware update during this setup.

SOURCES

Project-owner-confirmed frequencies and DCS; supplied editor captures 6–7; BTECH UV-PRO Manual, p. 31 (Talk Around). Draft; the radio lead must verify settings before duty.

BTECH UV-PRO Getting Started — continued

Make sure the channel was saved to the radio and works without the phone.

6. SELECT AND CHECK HEIGHTS 6

1. **Reopen the saved channel.** Press and hold its tile, then tap **Edit channel**. Compare both frequencies and both DCS fields with the table on the previous page.
2. **Return to the grid and tap the Heights 6 tile.** Check that it is selected and that the radio shows the same channel. The captured name **LHH FW** refers to this channel; use the lead's agreed label if different.
3. **Select Single CH** in the app panel's **Work Mode** row. This makes the first check easier to follow.
4. **Disconnect the app.** Turn the radio off, then on again with the top knob.
5. **Find Heights 6 on the radio.** If it is in frequency mode, hold ***** to switch to saved-channel mode. Use **up/down** to select Heights 6. If the keypad is locked, hold # to unlock it.
6. **Ask the radio lead to verify the stored settings.** The lead can inspect the radio's channel-list **Edit** view or read back its settings after reconnecting. The phone's editor alone may show cached data.

You should see: Heights 6 available after restarting, with the phone disconnected. Normal radio voice operation does not require the phone or internet.

7. LISTEN, THEN MAKE AN AUTHORIZED RADIO CHECK

1. **Arrange a check with your radio lead.** Have the lead confirm the radio and settings are authorized for this channel. Listen first; avoid emergency traffic.
2. **Check reception.** Turn the volume up enough to hear the lead clearly. Silence may simply mean nobody is talking.
3. **When the lead says to call, press the orange side PTT.** Pause briefly, then say your assigned callsign and “radio check.”
4. **Release PTT to listen.** Confirm that you hear the reply and that the other station heard you clearly.

SOURCES

BTECH UV-PRO Manual, pp. 4, 7–8; COM-002 net procedures; supplied channel-panel captures. A physical radio check is still required before duty.

BTECH UV-PRO Getting Started — continued

If a step fails, check the matching item below before changing anything else.

HELP WHEN SOMETHING DOES NOT WORK

Problem	What to do
Radio will not turn on	Check that the battery is charged and fitted securely. Turn the top knob past the click.
Buttons do not respond	At the operating screen, hold # to unlock a locked keypad.
Phone cannot find the radio	Check radio power, phone Bluetooth, app permissions, and radio pairing mode. Keep them close; confirm the selected device.
Channel cannot be edited	Ask the lead to check **Device settings → General settings → Lock channel data**. Do not reset the radio.
Heights 6 is missing after restart	Check the channel group and saved-channel mode. Reconnect, repeat SAVE, and have the lead read back the stored settings.
No speech is heard	Check volume, selected channel, RX frequency, and RX DCS. Arrange a known transmission with the lead.
The lead cannot hear you	Ask the lead to check TX frequency, TX DCS, Disable TX, power, and coverage before trying again.

READY-TO-USE CHECKLIST

- ☐ Battery charged and antenna attached
- ☐ Heights 6 selected on the radio
- ☐ Both frequencies and both DCS fields checked
- ☐ Bandwidth and power confirmed by the radio lead
- ☐ Channel remains saved after restarting
- ☐ Reception and authorized two-way check passed

Checked by: _____ Date: _____
Bandwidth / power: _____

Related guides: COM-009 covers general programming and verification. For radio etiquette and net calls, follow COM-002 and your assigned callsign. For immediate danger, call 911 when available.

SOURCES

References: BTECH UV-PRO Manual, Rev. 3, pp. 4–8, 11–15, 22, 26, 31; BTECH UV-PRO product page; COM-002; project-owner confirmations and supplied Android captures/photo, October 9, 2026. Draft requires editor and subject-matter review before publication.