



Mitsubishi Industrial Robot

CR750-D/CR751-D Controller

RV-4/7/13/20FM-D-SE Series
Standard Specifications Manual

MELFA
BFP-A3322-G

Safety Precautions

Always read the following precautions and the separate "Safety Manual" before starting use of the robot to learn the required measures to be taken.

CAUTION

All teaching work must be carried out by an operator who has received special training. (This also applies to maintenance work with the power source turned ON.)

Enforcement of safety training

CAUTION

For teaching work, prepare a work plan related to the methods and procedures of operating the robot, and to the measures to be taken when an error occurs or when restarting. Carry out work following this plan. (This also applies to maintenance work with the power source turned ON.)

Preparation of work plan

WARNING

Prepare a device that allows operation to be stopped immediately during teaching work. (This also applies to maintenance work with the power source turned ON.)

Setting of emergency stop switch

CAUTION

During teaching work, place a sign indicating that teaching work is in progress on the start switch, etc. (This also applies to maintenance work with the power source turned ON.)

Indication of teaching work in progress

DANGER

Provide a fence or enclosure during operation to prevent contact of the operator and robot.

Installation of safety fence

CAUTION

Establish a set signaling method to the related operators for starting work, and follow this method.

Signaling of operation start

CAUTION

As a principle turn the power OFF during maintenance work. Place a sign indicating that maintenance work is in progress on the start switch, etc.

Indication of maintenance work in progress

CAUTION

Before starting work, inspect the robot, emergency stop switch and other related devices, etc., and confirm that there are no errors.

Inspection before starting work

The points of the precautions given in the separate "Safety Manual" are given below.
Refer to the actual "Safety Manual" for details.

DANGER

When automatic operation of the robot is performed using multiple control devices (GOT, programmable controller, push-button switch), the interlocking of operation rights of the devices, etc. must be designed by the customer.

CAUTION

Use the robot within the environment given in the specifications. Failure to do so could lead to a drop or reliability or faults. (Temperature, humidity, atmosphere, noise environment, etc.)

CAUTION

Transport the robot with the designated transportation posture. Transporting the robot in a non-designated posture could lead to personal injuries or faults from dropping.

CAUTION

Always use the robot installed on a secure table. Use in an instable posture could lead to positional deviation and vibration.

CAUTION

Wire the cable as far away from noise sources as possible. If placed near a noise source, positional deviation or malfunction could occur.

CAUTION

Do not apply excessive force on the connector or excessively bend the cable. Failure to observe this could lead to contact defects or wire breakage.

CAUTION

Make sure that the workpiece weight, including the hand, does not exceed the rated load or tolerable torque. Exceeding these values could lead to alarms or faults.

WARNING

Securely install the hand and tool, and securely grasp the workpiece. Failure to observe this could lead to personal injuries or damage if the object comes off or flies off during operation.

WARNING

Securely ground the robot and controller. Failure to observe this could lead to malfunctioning by noise or to electric shock accidents.

CAUTION

Indicate the operation state during robot operation. Failure to indicate the state could lead to operators approaching the robot or to incorrect operation.

WARNING

When carrying out teaching work in the robot's movement range, always secure the priority right for the robot control. Failure to observe this could lead to personal injuries or damage if the robot is started with external commands.

CAUTION

Keep the jog speed as low as possible, and always watch the robot. Failure to do so could lead to interference with the workpiece or peripheral devices.

CAUTION

After editing the program, always confirm the operation with step operation before starting automatic operation. Failure to do so could lead to interference with peripheral devices because of programming mistakes, etc.

CAUTION

Make sure that if the safety fence entrance door is opened during automatic operation, the door is locked or that the robot will automatically stop. Failure to do so could lead to personal injuries.

CAUTION

Never carry out modifications based on personal judgments, or use non-designated maintenance parts.

Failure to observe this could lead to faults or failures.

WARNING

When the robot arm has to be moved by hand from an external area, do not place hands or fingers in the openings. Failure to observe this could lead to hands or fingers catching depending on the posture.

CAUTION

Do not stop the robot or apply emergency stop by turning the robot controller's main power OFF. If the robot controller main power is turned OFF during automatic operation, the robot accuracy could be adversely affected. Moreover, it may interfere with the peripheral device by drop or move by inertia of the arm.

CAUTION

Do not turn off the main power to the robot controller while rewriting the internal information of the robot controller such as the program or parameters. If the main power to the robot controller is turned off while in automatic operation or rewriting the program or parameters, the internal information of the robot controller may be damaged.

DANGER

Do not connect the Handy GOT when using the GOT direct connection function of this product. Failure to observe this may result in property damage or bodily injury because the Handy GOT can automatically operate the robot regardless of whether the operation rights are enabled or not.

DANGER

Do not remove the SSCNET III cable while power is supplied to the controller. Do not look directly at light emitted from the tip of SSCNET III connectors or SSCNET III cables. Eye discomfort may be felt if exposed to the light.
(Reference: SSCNET III employs a Class 1 or equivalent light source as specified in JIS C 6802 and IEC60825-1 (domestic standards in Japan).)

DANGER

Attach the cap to the SSCNET III connector after disconnecting the SSCNET III cable. If the cap is not attached, dirt or dust may adhere to the connector pins, resulting in deterioration connector properties, and leading to malfunction.

CAUTION

Make sure there are no mistakes in the wiring. Connecting differently to the way specified in the manual can result in errors, such as the emergency stop not being released. In order to prevent errors occurring, please be sure to check that all functions (such as the teaching box emergency stop, customer emergency stop, and door switch) are working properly after the wiring setup is completed.

CAUTION


Use the network equipments (personal computer, USB hub, LAN hub, etc) confirmed by manufacturer. The thing unsuitable for the FA environment (related with conformity, temperature or noise) exists in the equipments connected to USB. When using network equipment, measures against the noise, such as measures against EMI and the addition of the ferrite core, may be necessary. Please fully confirm the operation by customer. Guarantee and maintenance of the equipment on the market (usual office automation equipment) cannot be performed.

*CR751-D or CR751-Q controller

Notes of the basic component are shown.

⚠ CAUTION

Please install the earth leakage breaker in the primary side supply power supply of the controller of CR751-D or CR751-Q because of leakage protection.



Note 1) Crimping swage is recommended for connecting the attachment ACIN connector (soldering is also possible)
Recommendation compression tools: 234171-1(Tyco Electronics)

Note 2) The earth leakage breaker is the customer preparation. Always use the cover below.

Recommendation: For single primary power supply NV30FAU-2P-10A-AC100-240V-30mA, (Cover: TCS-05FA2)

For three primary power supply NV30FAU-3P-10A-AC100-240V-30mA, (Cover: TCS-05FA3)

Note 3) If necessary, as shown in the figure, connects the noise filter between ACIN terminal blocks and primary power supply.
(Recommended noise filter: SUP-EL20-ER6 *OKAYA ELECTRIC INDUSTRIES)

- 1) Please prepare the following: Leakage current breaker (with the terminal cover), cable for connecting the primary power supply (AWG #14 (2mm² or above), cables to ground the primary power supply (AWG #12 (3.5mm² or above).
The secondary power cable (with the ACIN connector) for single phase or three phase power is supplied with the product to match the specifications. When you build a cable suitable for your environment using the ACIN connector and the ACIN terminal supplied, prepare a secondary power cable (AWG #14 (2mm²) or above).
- 2) Confirm that the primary power matches the specifications.
- 3) Confirm that the primary power is OFF and that the earth leakage breaker power switch is OFF.
- 4) Connect the secondary power cable.
 - a) When using the supplied power cable with the ACIN connector
Refer to the figure above and connect the cable from the secondary side of the earth leakage breaker.
 - b) When building a power cable using the ACIN connector and the ACIN terminals supplied
Connect the ACIN terminals with the secondary power cable (prepared by customers), and insert the ACIN terminals to the ACIN connector pins with the following numbers. Crimping caULKING is recommended to connect the ACIN terminals.
For single phase: 1 and 3
For three phase: 1, 2, and 3
Refer to the figure above and connect the cable from the secondary side of the earth leakage breaker.
- 5) Connect this ACIN connector to the ACIN connector on the front of the controller.
- 6) Connect the grounding cable to the PE terminal. (M4 screw)
- 7) Connect the primary power cable to the primary side terminal of the earth leakage breaker.

■ Revision history

Date of print	Specifications No.	Details of revisions
2014-08-20	BFP-A3322	<ul style="list-style-type: none"> ▪ First print.
2014-12-24	BFP-A3322-A	<ul style="list-style-type: none"> ▪ The type of the optional hand input cable was corrected. (error: 1F-HC35C-C02) ▪ Explanation of the maximum load was added. ▪ The models of the CE Marking specification were added. ▪ Correction of errors in the Specifications discussion materials. (Network vision sensor: 4D-2CG5***-PKG was deleted.) ▪ The corporate logo mark of illustrations in this manual was changed. ▪ "6.4 EMC installation guideline" was added.
2015-02-10	BFP-A3322-B	<ul style="list-style-type: none"> ▪ The special hexagon flange bolts are also used for SE1502 model.
2015-11-18	BFP-A3322-C	<ul style="list-style-type: none"> ▪ "Declaration of Incorporation" and "EC-Statement of Compliance" were updated. ▪ Shape of base section of RV-7F series robot was changed. ▪ Transportation precaution of the lithium battery was modified. ▪ List of parts and manufacturer of parallel I/O unit was corrected. ▪ Note1) in "Table3-6: Function of the key switch interface" was corrected.
2015-12-14	BFP-A3322-D	<ul style="list-style-type: none"> ▪ The figures of "Position of center of gravity for loads" were modified. ▪ The explanation of the solenoid valve set for the chemical-resistant specification (SExx01) was added. ▪ Circuit diagrams in "3.6.1 Connection of the external emergency stop" and "6.1.7 Examples of safety measures" were modified.
2016-04-07	BFP-A3322-E	<ul style="list-style-type: none"> ▪ Windows10 was supported by RT ToolBox2. ▪ "EC DECLARATION OF CONFORMITY" pages were deleted.
2017-05-22	BFP-A3322-F	<ul style="list-style-type: none"> ▪ Configuration device of CC-Link interface option was modified. ▪ Contact information of the authorized representative was updated.
2017-09-25	BFP-A3322-G	<ul style="list-style-type: none"> ▪ "2.8 About Overhaul" was modified.

■ Introduction

This series offers small-size industrial robots developed using Mitsubishi's latest technology. They are especially designed to handle and assemble mechanical parts. They are Mitsubishi's answer to the customer's need to achieve a compact manufacturing facility capable of highly flexible production, as necessitated by the diffusion of high-density product groups and the shorter product life cycles that have become common-place in recent years.

In order to support transportation and processing in food and pharmaceutical plants, we offer a product lineup with multiple-resistant specifications with improved corrosion resistance or washability of the robot arm. The products with chemical-resistant specifications (SExx01) and food machinery grade H1 grease specifications (SExx02) are available.

However, to comply with the target application, a work system having a well-balanced robot arm, peripheral devices or robot and hand section must be structured.

When creating these standard specifications, we have edited them so that the Mitsubishi robot's characteristics and specifications can be easily understood by users considering the implementation of robots. However, if there are any unclear points, please contact your nearest Mitsubishi branch or dealer.

Mitsubishi hopes that you will consider these standard specifications and use our robots.

Note that in this specification document the specifications related to the robot arm is described [Page 11, "2 Robot arm"](#), the specifications related to the controller [Page 72, "3 Controller"](#), and software functions and a command list [Page 153, "4 Software"](#) separately.

This document has indicated the specification of the following types robot.

Robot type	Series (generic name used in this document for robots listed in each row)
RV-4F-D, RV-4FL-D	RV-4F series
RV-7F-D RV-7FL-D	RV-7F series
RV-7FLL-D, RV-13F-D, RV-13FL-D, RV-20F-D	RV-13F series

- About CE Marking in the automation system
The Guidelines of the measures against EMC in the automation system manufactured by the customer is shown in [Page 177, "6.4 EMC installation guideline"](#).
Please refer to it and carry out the measures against EMC of the automation system of the customer.

- No part of this manual may be reproduced by any means or in any form, without prior consent from Mitsubishi.
- The contents of this manual are subject to change without notice.
- The specifications values are based on Mitsubishi standard testing methods.
- The information contained in this document has been written to be accurate as much as possible. Please interpret that items not described in this document "cannot be performed." or "alarm may occur".
Please contact your nearest dealer if you find any doubtful, wrong or skipped point.
- This specifications is original.
- Microsoft, Windows, Windows XP, Windows Vista, Windows 7, Windows 8, Windows 8.1, Windows 10 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- The official name of Windows® is Microsoft®Windows®Operating System.
- Windows®XP, Windows Vista®, Windows® 7, Windows® 8, Windows® 8.1, Windows® 10 are either product names of Microsoft Corporation in the United States.
- Ethernet is registered trademarks or trademarks of Xerox Corporation in the United States.
- All other company names and production names in this document are the trademarks or registered trademarks of their respective owners.

Contents

	Page
1 General configuration	1-1
1.1 Structural equipment	1-1
1.1.1 Standard structural equipment	1-1
1.1.2 Special specifications	1-1
1.1.3 Options	1-1
1.1.4 Maintenance parts	1-1
1.2 Model type name of robot	1-2
1.2.1 How to identify the robot model	1-2
1.2.2 Combination of the robot arm and the controller	1-3
(1) CR750 controller	1-3
(2) CR751 controller	1-3
1.3 CE marking specifications	1-4
(1) CR750 controller	1-4
(2) CR751 controller	1-4
1.4 Contents of the structural equipment	1-5
1.4.1 Robot arm	1-5
1.4.2 Controller	1-6
(1) CR750 controller	1-6
(2) CR751 controller	1-7
1.5 Contents of the Option equipment and special specification	1-8
2 Robot arm	2-11
2.1 Standard specifications	2-11
2.1.1 Basic specifications	2-11
(1) RV-4F/7F series	2-11
(2) RV-13F series	2-13
2.1.2 The counter-force applied to the installation surface	2-14
2.2 Definition of specifications	2-15
2.2.1 Pose repeatability	2-15
2.2.2 Rated load (mass capacity)	2-16
2.2.3 Relationships Among Mass Capacity, Speed, and Acceleration/Deceleration Speed	2-19
(1) Setting Load Capacity and Size (Hand Conditions)	2-19
2.2.4 Vibrations at the Tip of the Arm during Low-Speed Operation of the Robot	2-19
2.2.5 Collision detection	2-19
2.2.6 Protection specifications	2-20
(1) Types of protection specifications	2-20
(2) About using the robot in the sterilization environment	2-21
2.3 Names of each part of the robot	2-22
2.4 Outside dimensions • Operating range diagram	2-23
(1) RV-4F	2-23
(2) RV-4FL	2-25
(3) RV-7F	2-27
(4) RV-7FL	2-29
(5) RV-7FLL	2-31
(6) RV-13F/20F	2-33
(7) RV-13FL	2-35
2.4.1 Outside dimensions of machine cables	2-37
(1) Connection with the CR750 controller	2-37
(2) Connection with the CR751 controller	2-37
2.5 Tooling	2-38
2.5.1 Wiring and piping for hand	2-38
2.5.2 Internal air piping	2-39
2.5.3 Internal wiring for the hand output cable	2-39
2.5.4 Internal wiring for the hand input cable	2-39
2.5.5 Ethernet cable, option wiring cable	2-39
2.5.6 Wiring and piping system diagram for hand	2-40

Contents

	Page
2.5.7 Electrical specifications of hand input/output	2-41
2.5.8 Air supply circuit example for the hand	2-42
2.5.9 About the Installation of Tooling Wiring and Piping	2-42
2.6 Shipping special specifications, options, and maintenance parts	2-43
2.6.1 Shipping special specifications	2-43
2.7 Options	2-44
(1) Machine cable extension	2-45
(2) J1 axis operating range change	2-50
(3) Solenoid valve set	2-56
(4) Hand input cable	2-62
(5) Hand output cable	2-63
(6) Hand curl tube	2-64
(7) Forearm external wiring set/ Base external wiring set	2-66
2.8 About Overhaul	2-70
2.9 Maintenance parts	2-71
 3 Controller	 3-72
3.1 Standard specifications	3-72
3.1.1 Basic specifications	3-72
3.1.2 Protection specifications and operating supply	3-73
3.2 Names of each part	3-74
3.2.1 Controller	3-74
(1) CR750 controller	3-74
(2) CR751 controller	3-77
3.3 Outside dimensions/Installation dimensions	3-79
3.3.1 Outside dimensions	3-79
(1) CR750 controller	3-79
(2) CR751 controller	3-80
3.3.2 Installation dimensions	3-82
(1) CR750 controller	3-82
(2) CR751 controller: RV-4F/7F series	3-84
(3) CR751 controller: RV-13F series	3-86
3.4 External input/output	3-88
3.4.1 Types	3-88
3.5 Dedicated input/output	3-89
3.6 Emergency stop input and output etc.	3-92
3.6.1 Connection of the external emergency stop	3-92
(1) CR750 controller	3-93
(2) CR751 controller	3-97
3.6.2 Special stop input (SKIP)	3-100
(1) CR750 controller	3-100
(2) CR751 controller	3-101
3.6.3 Door switch function	3-102
3.6.4 Enabling device function	3-102
(1) When door is opening	3-102
(2) When door is closing	3-102
(3) Automatic Operation/Jog Operation/Brake Release and Necessary Switch Settings	3-103
3.7 Mode changeover switch input	3-104
(1) Specification of the key switch interface	3-104
(2) Connection of the mode changeover switch input	3-105
3.8 Additional Axis Function	3-106
3.8.1 Wiring of the Additional Axis Interface	3-106
(1) CR750 controller	3-106
(2) CR751 controller	3-107
3.9 Magnet contactor control connector output (AXMC) for addition axes	3-110
(1) CR750 controller	3-111

Contents

	Page
(2) CR751 controller	3-111
3.10 Options	3-112
(1) Teaching pendant (T/B)	3-113
(2) Parallel I/O interface	3-116
(3) External I/O cable	3-121
(4) Parallel I/O unit	3-123
(5) External I/O cable	3-134
(6) CC-Link interface	3-136
(7) Controller protection box	3-139
(8) MELSOFT RT ToolBox2/RT ToolBox2 mini	3-149
(9) Instruction Manual (bookbinding)	3-151
3.11 Maintenance parts	3-152
4 Software	4-153
4.1 List of commands	4-153
4.2 List of parameters	4-156
5 Instruction Manual	5-158
5.1 The details of each instruction manuals	5-158
6 Safety	6-159
6.1 Safety	6-159
6.1.1 Self-diagnosis stop functions	6-159
6.1.2 External input/output signals that can be used for safety protection measures	6-160
6.1.3 Precautions for using robot	6-160
6.1.4 Safety measures for automatic operation	6-161
6.1.5 Safety measures for teaching	6-161
6.1.6 Safety measures for maintenance and inspections, etc.	6-161
6.1.7 Examples of safety measures	6-162
(1) CR750 controller	6-162
(2) CR751 controller	6-167
(3) External emergency stop connection [supplementary explanation]	6-172
6.2 Working environment	6-175
6.3 Precautions for handling	6-175
6.4 EMC installation guideline	6-177
6.4.1 Outlines	6-177
6.4.2 EMC directive	6-177
6.4.3 EMC measures	6-178
6.4.4 Component parts for EMC measures	6-178
(1) Ferrite core	6-178
(2) Line noise filter	6-178
7 Appendix	Appendix-179
Appendix 1 : Specifications discussion material (RV-4F/7F series)	Appendix-179
Appendix 2 : Specifications discussion material (RV-7FLL)	Appendix-181
Appendix 3 : Specifications discussion material (RV-13F/13FL)	Appendix-183
Appendix 4 : Specifications discussion material (RV-20F)	Appendix-185

1 General configuration

1.1 Structural equipment

Structural equipment consists of the following types.

1.1.1 Standard structural equipment

The following items are enclosed as a standard.

- (1) Robot arm
- (2) Controller
- (3) Machine cable
- (4) Robot arm installation bolts
- (5) Safety manual, CD-ROM (Instruction manual)
- (6) Guarantee card

1.1.2 Special specifications

For the special specifications, some standard configuration equipment and specifications have to be changed before factory shipping. Confirm the delivery date and specify the special specifications at the order.

1.1.3 Options

User can install options after their delivery.

1.1.4 Maintenance parts

Materials and parts for the maintenance use.

1.2 Model type name of robot

This robot has arranged the type name corresponding to load mass, arm length, and environment specification. Details are shown below, please select the robot suitable for the customer's use.

1.2.1 How to identify the robot model

RV - ◇ F L M - ● D ▲ -SExxxx

(a) (b) (c) (d) (e) (f) (g) (h)

(a). RV Indicates the vertical multiple-joint robot.

(b). ◇ Indicates the maximum load.
Ex.)

4: 4kg
7: 7kg
13: 13kg
20: 20kg

(c). F Indicates the F series.

(d). L Indicates long arm type.
Ex)

Omitted: Standard type
L or LL: Long arm type

(e). ● Indicates the controller series.
Ex.)

Omitted: CR750 controller
1: CR751 controller

(f). D Indicates the controller type.
D: Stand alone type

(g). ▲ Technical standard of Conformity.
Ex.)

Omitted: No conformity of technical standard.
1: Conforms to the CE Marking

(h). - SExxxx Indicates a model with the multiple-resistant specifications.

SE1101: Chemical-resistant
SE1102: H1 grease for food machinery
SE1501: Chemical-resistant with CE
SE1502: H1 grease for food machinery with CE

Table 1-1 : Multiple-resistant correspondence table

Specification	Item	Chemical-resistant specifications (SExx01)	Food machinery grade H1 grease specifications (SExx02)
A	Application of NSF H1 certified grease	○	○
B	Use of stainless steel at the end of the robot	○	○
C	Adoption of special hexagon flange bolts	○	○ (- Note1))
D	Chemical-resistant body coating	○	-
E	Use of a chemical-resistant sealing material	○	-

Note1) Not apply for SE1102.

1.2.2 Combination of the robot arm and the controller

(1) CR750 controller

Table 1-2 : Combination of the robot arm and the CR750 controller

Robot arm				Controller	
Type name ^{Note1)}	Protection specification	Arm length	Internal wiring and piping specification (Mechanical I/F)		
RV- □ FM-D-SE1101	Chemical-resistant specifications (SE1101) ^{Note2)}	Standard arm	-	CR750- □ VD-1-SE1101	
RV-20FM-D-SE1101				CR750-20VD-1-SE1101	
RV- □ FLM-D-SE1101		Long arm		CR750- □ VD-1-SE1101	
RV-7FLLM-D-SE1101				CR750-07VLD-1-SE1101	
RV- □ FM-D-SE1102		Standard arm		CR750- □ VD-1-SE1102	
RV-20FM-D-SE1102				CR750-20VD-1-SE1102	
RV- □ FLM-D-SE1102		Long arm		CR750- □ VD-1-SE1102	
RV-7FLLM-D-SE1102				CR750-07VLD-1-SE1102	

Note1) The " □ " indicates the load mass."4" for 4kg, "7" for 7kg, "13" for 13kg. (" □ " of the controller type name is "04", "07" or "13".)

Note2) This robot arm's protective structure is IP65. The protective structure of all the controllers is IP20 (open type). To protect a controller, use the optional controller protection box (IP54). However, the controller is not chemical-resistant.

(2) CR751 controller

Table 1-3 : Combination of the robot arm and the CR751 controller

Robot arm				Controller	
Type name ^{Note1)}	Protection specification	Arm length	Internal wiring and piping specification (Mechanical I/F)		
RV- □ FM-1D-SE1101	Chemical-resistant specifications (SE1101) ^{Note2)}	Standard arm	-	CR751- □ VD-0-SE1101	
RV-20FM-1D-SE1101				CR751-20VD-0-SE1101	
RV- □ FLM-1D-SE1101		Long arm		CR751- □ VD-0-SE1101	
RV-7FLLM-1D-SE1101				CR751-07VLD-0-SE1101	
RV- □ FM-1D-SE1102		Standard arm		CR751- □ VD-0-SE1102	
RV-20FM-1D-SE1102				CR751-20VD-0-SE1102	
RV- □ FLM-1D-SE1102		Long arm		CR751- □ VD-0-SE1102	
RV-7FLLM-1D-SE1102				CR751-07VLD-0-SE1102	

Note1) The " □ " indicates the load mass."4" for 4kg, "7" for 7kg, "13" for 13kg. (" □ " of the controller type name is "04", "07" or "13".)

Note2) This robot arm's protective structure is IP65. The protective structure of all the controllers is IP20 (open type). To protect a controller, use the optional controller protection box (IP54). However, the controller is not chemical-resistant.

1.3 CE marking specifications

The robot shown in [Table 1-4](#) or [Table 1-5](#) are the CE marking specification.

(1) CR750 controller

Table 1-4 : Robot models with CE marking specifications

Robot type ^{Note1)}	Controller	External signal logic	Language setting
RV- □ FM-D1-SE1501 RV- □ FLM-D1-SE1501	CR750- □ VD1-1-SE1501	Source type	English (ENG)
RV- □ FM-D1-SE1502 RV- □ FLM-D1-SE1502	CR750- □ VD1-1-SE1502		
RV-20FM-D1-SE1501	CR750-20VD1-1-SE1501		
RV-20FM-D1-SE1502	CR750-20VD1-1-SE1502		
RV-7FLLM-D1-SE1501	CR750-07VLD1-1-SE1501		
RV-7FLLM-D1-SE1502	CR750-07VLD1-1-SE1502		

Note1) The " □ " indicates the load mass."4" for 4kg, "7" for 7kg, "13" for 13kg. (" □ " of the controller type name is "04", "07" or "13".)

(2) CR751 controller

Table 1-5 : Robot models with CE marking specifications

Robot type ^{Note1)}	Controller	External signal logic	Language setting
RV- □ FM-1D1-SE1501 RV- □ FLM-1D1-SE1501	CR751- □ VD1-0-SE1501	Source type	English (ENG)
RV- □ FM-1D1-SE1502 RV- □ FLM-1D1-SE1502	CR751- □ VD1-0-SE1502		
RV-20FM-1D1-SE1501	CR751-20VD1-0-SE1501		
RV-20FM-1D1-SE1502	CR751-20VD1-0-SE1502		
RV-7FLLM-1D1-SE1501	CR751-07VLD1-0-SE1501		
RV-7FLLM-1D1-SE1502	CR751-07VLD1-0-SE1502		

Note1) The " □ " indicates the load mass."4" for 4kg, "7" for 7kg, "13" for 13kg. (" □ " of the controller type name is "04", "07" or "13".)

1.4 Contents of the structural equipment

1.4.1 Robot arm

The list of structural equipment is shown in below.



<p>Vertical six-axis multiple-jointed type (RV-4F/4FL、RV-7F/7FL)</p>  <p>Vertical six-axis multiple-jointed type (RV-13F/13FL、RV-7FLL、RV-20F)</p>  <p>Either one</p>	<p>Machine cable</p> <p>Fixed type: RV-4F/7F series.....5m RV-13F series.....7m</p> <p>For CR751 controller</p>  <p>For CR750 controller</p> 
<p>Machine cable extension</p> <ul style="list-style-type: none"> ▪ CR750 controller <ul style="list-style-type: none"> Fixed type: 1S-□□ CBL-01 (For SExx01/02) Flexed type: 1S-□□ LCBL-01 (For SExx01/02) ▪ CR751 controller <ul style="list-style-type: none"> Fixed type: 1F-□□ UCBL-03 (For SExx01) Flexed type: 1F-□□ LUCBL-03 (For SExx01) Fixed type: 1F-□□ UCBL-02 (For SExx02) Flexed type: 1F-□□ LUCBL-02 (For SExx02) <p>Note1) □□ refer the length. Refer to Table 1-6 for details.</p>	
<p>Solenoid valve set (Special hand output cable is attached) <Sink type/Source type></p> <ul style="list-style-type: none"> ▪ 1 set: 1F-VD01-**/1F-VD01E-** ▪ 2 set: 1F-VD02-**/1F-VD02E-** ▪ 3 set: 1F-VD03-**/1F-VD03E-** ▪ 4 set: 1F-VD04-**/1F-VD04E-** <p>1F-VD04-02 1F-VD04-03</p>   <p>Hand output cable</p> <ul style="list-style-type: none"> ▪ 1F-GR35S-02 <p>Hand input cable</p> <ul style="list-style-type: none"> ▪ 1F-HC35S-02 <p>Hand curl tube</p> <p>RV-4F/7F series, RV-7FLL</p> <ul style="list-style-type: none"> ▪ 1E-ST040*C (1 - 4 set) <p>RV-13F/13FL/20F</p> <ul style="list-style-type: none"> ▪ 1N-ST060*C (1 - 4 set) <p>Note) ** differs by 1 - 4 set. Refer to Table 1-6 for details.</p>	<p>Pulled out from robot arm</p> <p>Forearm external wiring set/ Base external wiring set</p> <p>*The figure is an example.</p>  <p>J1 axis operating range change (Stopper parts)</p> <ul style="list-style-type: none"> ▪ RV-4F series: 1F-DH-06 (For SExx01) 1F-DH-03 (For SExx02) ▪ RV-7F series: 1F-DH-07 (For SExx01) 1F-DH-04 (For SExx02) ▪ RV-13F series: 1F-DH-08 (For SExx01) 1F-DH-05J1 (For SExx02) <p>* Installed by customer.</p> <p>[Caution]</p> <ul style="list-style-type: none"> □ Standard configuration equipment □ Special specifications □ Option □ Prepared by customer

Fig.1-1 : Structural equipment (Robot arm)

1.4.2 Controller

The devices shown below can be installed on the controller.

The controllers that can be connected differ depending on the specification of the robot. (Refer to [Page 2, "1.2 Model type name of robot"](#).)

(1) CR750controller




Fig.1-2 : Structural equipment (CR750 controller)

(2) CR751 controller




Fig.1-3 : Structural equipment (CR751 controller)

1.5 Contents of the Option equipment and special specification

A list of all Optional equipment and special specifications are shown below.

Table 1-6 : The list of the robot arm option equipment and special specification

Item	Type	Specifications	Classification Note1)		Description
			CR750	CR751	
J1 axis operating range change	1F-DH-06	Stopper part for RV-4F series: Sets as the + side/- side each by the combination within 30, 73, 103 and 146.	<input type="radio"/>	<input type="radio"/>	This must be installed and setting the parameter by the customer. For SExx01 (Chemical-resistant specifi- cations).
	1F-DH-07	Stopper part for RV-7F series: Sets as the + side/- side each by the combination within 35, 77, 99 and 141.	<input type="radio"/>	<input type="radio"/>	* Refer to Page 50, "(2) J1 axis operating range change" for details.
	1F-DH-08	Stopper part for RV-13F series: Sets as the + side/- side each by the combination within 30, 73, 103 and 146.	<input type="radio"/>	<input type="radio"/>	
	1F-DH-03	Stopper part for RV-4F series: Sets as the + side/- side each by the combination within 30, 73, 103 and 146.	<input type="radio"/>	<input type="radio"/>	This must be installed and setting the parameter by the customer. For SExx02 (Food machinery grade H1 grease specifications).
	1F-DH-04	Stopper part for RV-7F series: Sets as the + side/- side each by the combination within 35, 77, 99 and 141.	<input type="radio"/>	<input type="radio"/>	* Refer to Page 50, "(2) J1 axis operating range change" for details.
	1F-DH-05J1	Stopper part for RV-13F series: Sets as the + side/- side each by the combination within 30, 73, 103 and 146.	<input type="radio"/>	<input type="radio"/>	
Extended machine cable (extension type)	1S- □□ CBL-01	For fixing (Set of power and signal) Extension type	<input type="radio"/>	-	" □□ " in type shows the length of the cables as follows. 05=5m, 10=10m, 15=15m
	1S- □□ LCBL-01	For flexing (Set of power and signal) Extension type	<input type="radio"/>	-	For SExx01 (Chemical-resistant specifi- cations)/SExx02(Food machinery grade H1 grease specifications).
Extended machine cable (direct type)	1F- □□ UCBL-03	For fixing (Set of power and signal) Extension type	-	<input type="radio"/>	" □□ " in type shows the length of the cables as follows. 10=10m, 15=15m, 20=20m
	1F- □□ LUCBL-03	For flexing (Set of power and signal) Extension type	-	<input type="radio"/>	For SExx01 (Chemical-resistant specifi- cations).
	1F- □□ UCBL-02	For fixing (Set of power and signal) Extension type	-	<input type="radio"/>	" □□ " in type shows the length of the cables as follows. 10=10m, 15=15m, 20=20m
	1F- □□ LUCBL-02	For flexing (Set of power and signal) Extension type	-	<input type="radio"/>	For SExx02 (Food machinery grade H1 grease specifications).
Solenoid valve set	1F-VD01-04/VD01E-04	1 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	The solenoid-valve set for the hand of the customer setup.
	1F-VD02-04/VD02E-04	2 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	Use for SExx01 (Chemical-resistant specifications) of the RV-4F/7F series and RV-7FL.
	1F-VD03-04/VD03E-04	3 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	
	1F-VD04-04/VD04E-04	4 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	
	1F-VD01-05/VD01E-05	1 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	The solenoid-valve set for the hand of the customer setup.
	1F-VD02-05/VD02E-05	2 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	Use for SExx01 (Chemical-resistant specifications) of the RV-13F/13FL and RV-20F.
	1F-VD03-05/VD03E-05	3 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	
	1F-VD04-05/VD04E-05	4 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	
	1F-VD01-02/VD01E-02	1 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	The solenoid-valve set for the hand of the customer setup.
	1F-VD02-02/VD02E-02	2 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	Use for SExx02 (Food machinery grade H1 grease specifications) of the RV-4F/ 7F series and RV-7FL.
	1F-VD03-02/VD03E-02	3 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	
	1F-VD04-02/VD04E-02	4 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	
	1F-VD01-03/VD01E-03	1 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	The solenoid-valve set for the hand of the customer setup.
	1F-VD02-03/VD02E-03	2 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	Use for SExx02 (Food machinery grade H1 grease specifications) of the RV- 13F/13FL and RV-20F.
	1F-VD03-03/VD03E-03	3 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	
	1F-VD04-03/VD04E-03	4 set (Sink type)/(Source type)	<input type="radio"/>	<input type="radio"/>	

1 General configuration

Item	Type	Specifications	Classification Note1)		Description
			CR750	CR751	
Hand input cable	1F-HC35S-02	Robot side: connector. Hand side: wire.	<input type="radio"/>	<input type="radio"/>	The cable is connected to the sensor by the customer.
Hand output cable	1F-GR35S-02	Robot side: connector. Hand side: wire	<input type="radio"/>	<input type="radio"/>	This cable can be used for the solenoid valve prepared by the customer.
Hand curl tube	1E-ST0402C	For solenoid valve 1set.: $\phi 4 \times 2$	<input type="radio"/>	<input type="radio"/>	Curl type air tube For RV-4F/7F series and RV-7FLL.
	1E-ST0404C	For solenoid valve 2set.: $\phi 4 \times 4$	<input type="radio"/>	<input type="radio"/>	
	1E-ST0406C	For solenoid valve 3set.: $\phi 4 \times 6$	<input type="radio"/>	<input type="radio"/>	
	1E-ST0408C	For solenoid valve 4set.: $\phi 4 \times 8$	<input type="radio"/>	<input type="radio"/>	
	1N-ST0602C	For solenoid valve 1set.: $\phi 6 \times 2$	<input type="radio"/>	<input type="radio"/>	Curl type air tube For RV-13F/13FL and RV-20F.
	1N-ST0604C	For solenoid valve 2set.: $\phi 6 \times 4$	<input type="radio"/>	<input type="radio"/>	
	1N-ST0606C	For solenoid valve 3set.: $\phi 6 \times 6$	<input type="radio"/>	<input type="radio"/>	
	1N-ST0608C	For solenoid valve 4set.: $\phi 6 \times 8$	<input type="radio"/>	<input type="radio"/>	
Forearm external wiring set	1F-HB01S-02	The following cables can be wired outside: hand input signals, force sensor and vision sensor.	<input type="radio"/>	<input type="radio"/>	Pulls out from forearm lower part. Use for SExx01 (Chemical-resistant specifications).
	1F-HB02S-02	The following cables can be wired outside: force sensor and vision-sensor.	<input type="radio"/>	<input type="radio"/>	
	1F-HB01S-01	The following cables can be wired outside: hand input signals, force sensor and vision sensor.	<input type="radio"/>	<input type="radio"/>	Pulls out from forearm lower part. For SExx02 (Food machinery grade H1 grease specifications).
	1F-HB02S-01	The following cables can be wired outside: force sensor and vision-sensor.	<input type="radio"/>	<input type="radio"/>	
Base external wiring set	1F-HA01S-02	The following cables can be wired outside: force sensor and vision-sensor.	<input type="radio"/>	<input type="radio"/>	Pulls out from base side. Use for SExx01 (Chemical-resistant specifications).
	1F-HA02S-02	The following cables can be wired outside: force sensor and vision-sensor.	<input type="radio"/>	<input type="radio"/>	
	1F-HA01S-01	The following cables can be wired outside: force sensor and vision-sensor.	<input type="radio"/>	<input type="radio"/>	Pulls out from base side. For SExx02 (Food machinery grade H1 grease specifications).
	1F-HA02S-01	The following cables can be wired outside: force sensor and vision-sensor.	<input type="radio"/>	<input type="radio"/>	

Note1) : option, : special specifications.

Table 1-7 : The list of the controller option equipment and special specification

Item	Type	Specifications	Classification Note1)		Description
			CR750	CR751	
Simple teaching pendant	R32TB	Cable length 7m	<input type="radio"/>	-	With 3-position enable switch IP65
	R32TB-15	Cable length 15m	<input type="radio"/>	-	
	R33TB	Cable length 7m	-	<input type="radio"/>	
	R33TB-15	Cable length 15m	-	<input type="radio"/>	
Highly efficient teaching pendant	R56TB	Cable length 7m	<input type="radio"/>	-	
	R56TB-15	Cable length 15m	<input type="radio"/>	-	
	R57TB	Cable length 7m	-	<input type="radio"/>	
	R57TB-15	Cable length 15m	-	<input type="radio"/>	
Parallel I/O Interface	2D-TZ368(Sink type)/ 2D-TZ378(Source type)	DO: 32 point DI: 32 point Insulated type output signal (0.1A/24V /point) Insulated type input signal (9mA/ 24V /point)	<input type="radio"/>	<input type="radio"/>	The card type external input-and-output Interface. Install to the slot of controller.
External I/O cable (For Parallel I/O Interface)	2D-CBL05	5m	<input type="radio"/>	<input type="radio"/>	Use to connect the external peripheral device to the parallel input/output interface.
	2D-CBL15	15m	<input type="radio"/>	<input type="radio"/>	
Parallel I/O Unit	2A-RZ361(Sink type)/ 2A-RZ371(Source type)	DO: 32 point/ DI: 32 point Insulated type output signal (0.1A/24V /point) Insulated type input signal (7mA/ 24V /point)	<input type="radio"/>	<input type="radio"/>	The unit for expansion the external input/output. Electrical isolated Type (100mA/Point)
External I/O cable (For Parallel I/O Unit)	2A-CBL05	5m	<input type="radio"/>	<input type="radio"/>	Use to connect the external peripheral device to the parallel input/output unit
	2A-CBL15	15m	<input type="radio"/>	<input type="radio"/>	
CC-Link interface	2D-TZ576	Only Intelligent device station, Local station	<input type="radio"/>	<input type="radio"/>	For MELSEC PLC with CC-Link connection.

Item	Type	Specifications	Classification Note1)		Description
			CR750	CR751	
Controller protection box	CR750-MB	IP54	<input type="radio"/>	-	The controller protection box is used to protect the controller from an oil mist or other operating environment.
	CR751-MB		-	<input type="radio"/>	
RT ToolBox2 (Personal computer Support software)	3D-11C-WINE	CD-ROM	<input type="radio"/>	<input type="radio"/>	Windows XP, Windows Vista, Windows 7, Windows 8, Windows 8.1, Windows 10 (With the simulation function)
RT ToolBox2 mini (Personal computer Support software mini)	3D-12C-WINE	CD-ROM	<input type="radio"/>	<input type="radio"/>	Windows XP, Windows Vista, Windows 7, Windows 8, Windows 8.1, Windows 10
Instruction Manual	5F-FF03-PE01	RV-4F/7F/13F-D series multiple-resistant specification	<input type="radio"/>	<input type="radio"/>	

Note1) : option, : special specifications.

[Reference]:The recommendation products of the USB cable are shown below

Table 1-8 : Recommendation article of the USB cable

Name	Type name	Supplier
USB cable (USB A type-USB mini B type)	KU-AMB530	SANWA SUPPLY INC.
	USB-M53	ELECOM CO., LTD.
	GT09-C30USB-5P	MITSUBISHI ELECTRIC SYSTEM & SERVICE CO., LTD.
	MR-J3USBCBL3M	MITSUBISHI ELECTRIC CO., LTD.
USB adapter (USB B type-USB mini B type)	AD-USBBFTM5M	ELECOM CO., LTD.

⚠ Caution

Be careful to the USB cable to apply neither the static electricity nor the noise. Otherwise, it becomes the cause of malfunction.

⚠ Caution

Use the network equipments (personal computer, USB hub, LAN hub, etc) confirmed by manufacturer. The thing unsuitable for the FA environment (related with conformity, temperature or noise) exists in the equipments connected to USB. When using network equipment, measures against the noise, such as measures against EMI and the addition of the ferrite core, may be necessary. Please fully confirm the operation by customer. Guarantee and maintenance of the equipment on the market (usual office automation equipment) cannot be performed.

2 Robot arm

2.1 Standard specifications

2.1.1 Basic specifications

(1) RV-4F/7F series

Table 2-1 : Standard specifications of robot

Item		Unit	Specifications					
Type			RV-4FM-SExx01 RV-4FM-SExx02		RV-4FLM-SExx01 RV-4FLM-SExx02			
Environment			SExx01: Chemical-resistant specifications SExx02: Food machinery grade H1 grease specifications					
Degree of freedom			6					
Installation posture			On floor, hanging, (against wall ^{Note1)})					
Structure			Vertical, multiple-joint type					
Drive system			AC servo motor (brake provided on all axes)					
Position detection method			Absolute encoder					
Motor capacity	Waist (J1)	W	400		750			
	Shoulder (J2)		400		750			
	Elbow (J3)		100		400			
	Wrist twist (J4)		100		100			
	Wrist pitch (J5)		100		100			
	Wrist roll (J6)		50		50			
Operating range	Waist (J1)	Degree	± 240					
	Shoulder (J2)		± 120		-115 to 125			
	Elbow (J3)		0 to 161	0 to 164	0 to 156	0 to 162		
	Wrist twist (J4)		± 200					
	Wrist pitch (J5)		± 120					
	Wrist roll (J6)		± 360					
Speed of motion	Waist (J1)	Degree/s	450	420	360	288		
	Shoulder (J2)		450	336	401	321		
	Elbow (J3)		300	250	450	360		
	Wrist twist (J4)		540		337			
	Wrist pitch (J5)		623		450			
	Wrist roll (J6)		720					
Maximum reach radius (P point)	mm	514.5	648.7	713.4	907.7			
Maximum resultant velocity ^{Note2)}	mm/sec	9,000		11,000				
Load	kg(N)	4		7				
Pose repeatability ^{Note3)}	mm	± 0.02						
Cycle time ^{Note4)}	sec	0.36		0.32	0.35			
Ambient temperature ^{Note5)}	°C	0 to 40						
Mass	kg	39	41	65	67			
Allowable moment load	Wrist twist (J4)	N · m	6.66		16.2			
	Wrist pitch (J5)		6.66		16.2			
	Wrist roll (J6)		3.90		6.86			
Allowable inertia	Wrist twist (J4)	kg · m ²	0.20		0.45			
	Wrist pitch (J5)		0.20		0.45			
	Wrist roll (J6)		0.10					
Tool wiring	Hand input/output	Hand input eight points / hand output eight points						
	LAN cable	Equipped (eight cores) <100BASE-TX>						
	Wiring for user	Equipped (24 cores) <Force sensor etc.>						
Tool pneumatic pipes	Primary piping	$\phi 6 \times 2$						
	Secondary piping	$\phi 4 \times 8$						
Supply pressure	MPa	0.54						


Item	Unit	Specifications
Protection specification Note6) Note7)		Chemical-resistant specifications (SExx01)/Food machinery grade H1 grease specifications (SExx02): IP65
Painting color		Chemical-resistant specifications (SExx01): Gray (Coating agent's color) Food machinery grade H1 grease specifications (SExx02): Light gray (Equivalent to Munsell: 0.6B7.6/0.2)

Note1) When used by mounting on the wall, a special specification that limits the operating range of the J1 axis will be used.
Please give an order separately.

Note2) This is the value on the mechanical interface surface when all axes are combined.

Note3) The pose repeatability details are given in [Page 15, "2.2.1 Pose repeatability"](#)

Note4) The required time period to execute one cycle of the following operation pattern with 1kg load. The cycle time may be longer depending on the required positioning accuracy for the workpiece and the operating position.



Note5) Sets the robot's operating environmental temperature as parameter OLTMX. Corresponding to the environment, the continuous control action performance and the overload-protection function are optimized. (Refers to "Optimizing the overload level" described in "Chapter 5 Functions set with parameters" of separate instruction manual/ Detailed explanations of functions and operations for details.)

Note6) The protection specification details are given in [Page 20, "2.2.6 Protection specifications"](#).

Note7) The controller is not chemical-resistant. For installing the controller, avoid places where adhesion of chemicals may occur.

(2) RV-13F series

Table 2-2 : Standard specifications of robot


Item	Unit	Specifications					
Type		RV-13FM-SExx01 RV-13FM-SExx02	RV-13FLM-SExx01 RV-13FLM-SExx02	RV-20FM-SExx01 RV-20FM-SExx02	RV-7FLLM-SExx01 RV-7FLLM-SExx02		
Environment		SExx01: Chemical-resistant specifications SExx02: Food machinery grade H1 grease specifications					
Degree of freedom		6					
Installation posture		On floor, hanging (against wall ^{Note1)})					
Structure		Vertical, multiple-joint type					
Drive system		AC servo motor (brake provided on all axes)					
Position detection method		Absolute encoder					
Motor capacity	Waist (J1)	W	1500				
	Shoulder (J2)		1500				
	Elbow (J3)		750				
	Wrist twist (J4)		400				
	Wrist pitch (J5)		200		100		
	Wrist roll (J6)		100		50		
Operating range	Waist (J1)	Degree	±190				
	Shoulder (J2)		-90 to +150				
	Elbow (J3)		-10 to +157.5				
	Wrist twist (J4)		±200				
	Wrist pitch (J5)		±120				
	Wrist roll (J6)		±360				
Speed of motion	Waist (J1)	Degree/s	290	234	110		
	Shoulder (J2)		234	164	110		
	Elbow (J3)		312	219	110		
	Wrist twist (J4)		375		124		
	Wrist pitch (J5)		375		125		
	Wrist roll (J6)		720		360		
Maximum reach radius (P point)	mm	1,094	1,388	1,094	1,503		
Maximum resultant velocity ^{Note2)}	mm/sec	10,450	9,700	4,200	15,300		
Load Rating (Maximum)	kg	12(13)		15(20)	7(7)		
Pose repeatability ^{Note3)}	mm	±0.05			±0.06		
Cycle time ^{Note4)}	sec	0.53	0.68	0.70	0.63		
Ambient temperature ^{Note5)}	°C	0 to 40					
Mass	kg	120	130	120	130		
Allowable moment load	Wrist twist (J4)	N · m	19.3		49		
	Wrist pitch (J5)		19.3		49		
	Wrist roll (J6)		11		6.86		
Allowable inertia	Wrist twist (J4)	kg · m ²	0.47		1.4		
	Wrist pitch (J5)		0.47		1.4		
	Wrist roll (J6)		0.14		0.1		
Tool wiring	Hand input/output	Hand input eight points / hand output eight points					
	LAN cable	Equipped (eight cores) <100BASE-TX>					
	Wiring for user	Equipped (24 cores) <Force sensor etc.>					
Tool pneumatic pipes	Primary piping	φ 6 × 2					
	Secondary piping	φ 6 × 8					
Supply pressure	MPa	0.54					
Protection specification Note6)		Chemical-resistant specifications (SExx01)/Food machinery grade H1 grease specifications (SExx02): IP65					
Painting color		Chemical-resistant specifications (SExx01): Gray (Coating agent's color) Food machinery grade H1 grease specifications (SExx02): Light gray (Equivalent to Munsell: 0.6B7.6/0.2)					

Note1) When used by mounting on the wall, a special specification that limits the operating range of the J1 axis will be used.
Please give an order separately.

Note2) This is the value on the mechanical interface surface when all axes are combined.

Note3) The pose repeatability details are given in [Page 15, "2.2.1 Pose repeatability"](#)

Note4) The required time period to execute one cycle of the following operation pattern with 5kg load. The cycle time may be longer depending on the required positioning accuracy for the workpiece and the operating position.



Note5) Sets the robot's operating environmental temperature as parameter OLTMX. Corresponding to the environment, the continuous control action performance and the overload-protection function are optimized. (Refers to "Optimizing the overload level" described in "Chapter 5 Functions set with parameters" of separate instruction manual/ Detailed explanations of functions and operations for details.)

Note6) The protection specification details are given in [Page 20, "2.2.6 Protection specifications"](#).

Note7) The controller is not chemical-resistant. For installing the controller, avoid places where adhesion of chemicals may occur.

2.1.2 The counter-force applied to the installation surface

The counter-force applied to the installation surface for the strength design of the robot installation surface is shown.

Table 2-3 : Value of each counter-force

Item	Unit	Value		
		RV-4F series	RV-7F series	RV-7FLL RV-13F series RV-20F
Falls moment: M_L	N · m	410	900	2,060
Torsion moment: M_T	N · m	400	900	2,060
Horizontal translation force: F_H	N	700	1,000	1,750
Vertical translation force: F_V	N	1,200	1,700	2,900

2.2 Definition of specifications

The accuracy of pose repeatability mentioned in catalogs and in the specification manual is defined as follows.

2.2.1 Pose repeatability

For this robot, the pose repeatability is given in accordance with JIS B 8432 (Pose repeatability). Note that the value is based on 100 measurements (although 30 measurements are required according to JIS).

[Caution] The specified "pose repeatability" is not guaranteed to be satisfied under the following conditions.

[1] Operation pattern factors

- 1) When an operation that approaches from different directions and orientations are included in relation to the teaching position during repeated operations
- 2) When the speed at teaching and the speed at execution are different

[2] Load fluctuation factor

- 1) When work is present/absent in repeated operations

[3] Disturbance factor during operation

- 1) Even if approaching from the same direction and orientation to the teaching position, when the power is turned OFF or a stop operation is performed halfway

[4] Temperature factors

- 1) When the operating environment temperature changes
- 2) When accuracy is required before and after a warm-up operation

[5] Factors due to differences in accuracy definition

- 1) When accuracy is required between a position set by a numeric value in the robot's internal coordinate system and a position within the actual space
- 2) When accuracy is required between a position generated by the pallet function and a position within the actual space

2.2.2 Rated load (mass capacity)

The robot's mass capacity is expressed solely in terms of mass, but even for tools and works of similar mass, eccentric loads will have some restrictions. When designing the tooling or when selecting a robot, consider the following issues.

- (1) The tooling should have the value less or equal than the smaller of the tolerable inertia and the tolerable moment found in [Page 11, "2.1.1 Basic specifications"](#).
- (2) [Fig. 2-1 to Fig. 2-4](#) shows the distribution dimensions for the center of gravity in the case where the volume of the load is relatively small. Use this figure as a reference when designing the tooling.
- (3) Even if the load is force, not the mass, design the tooling so that moment does not exceed the allowable moment. Refer to [Page 11, "2.1 Standard specifications"](#) for details of allowable moment value.

[Caution] The mass capacity is greatly influenced by the operating speed of the robot and the motion posture.

Even if you are within the allowable range mentioned previously, an overload or generate an overcurrent alarm could occur. In such cases, it will be necessary to change the time setting for acceleration/deceleration, the operating speed, and the motion posture.

[Caution] The overhang amount of the load, such as the mass capacity and the allowable moment of inertia defined in this section, are dynamic limit values determined by the capacity of the motor that drives axes or the capacity of the speed reducer. Therefore, it does not guarantee the accuracy on all areas of tooling. Guaranteed accuracy is measured from the center point of the mechanical interface surface. Please note that if the point of operation is kept away from the mechanical interface surface by long and low-rigid tooling, the positioning accuracy may deteriorate or may cause vibration.

[Caution] Even within the allowable range previously mentioned, an overload alarm may be generated if an ascending operation continues at a micro-low speed. In such a case, it is necessary to increase the ascending speed.




Fig.2-1 : Position of center of gravity for loads (for loads with comparatively small volume): RV-4F/4FL




Fig.2-2 : Position of center of gravity for loads (for loads with comparatively small volume): RV-7F/7FL/7FLL




Fig.2-3 : Position of center of gravity for loads (for loads with comparatively small volume): RV-13F/13FL




Fig.2-4 : Position of center of gravity for loads (for loads with comparatively small volume): RV-20F

2.2.3 Relationships Among Mass Capacity, Speed, and Acceleration/Deceleration Speed

This robot automatically sets the optimum acceleration and deceleration speeds and maximum speed, according to the load capacity and size that have been set, and operates using these automatically set speeds.

To achieve that, it is necessary to correctly set the actual load data (mass and size of hand and work) to be used. However, vibration, overheating and errors such as excessive margin of error and overload may occur, depending on the robot operation pattern or ambient temperature.

In such a case, change the setting value to the +20% range.

If a setting is performed in such a way that it falls below the mounted load, the life span of the mechanism elements used in the robot may be shortened. In the case of a work requiring a high degree of accuracy, set up the load correctly and use the robot by lowering the ratios of the acceleration and deceleration speeds.

(1) Setting Load Capacity and Size (Hand Conditions)

Set up the capacity and size of the hand with the "HNDDAT*" parameter (optimum acceleration/deceleration setting parameter), and set up the capacity and size of the work with the "WRKDAT*" parameter. Numbers 0 to 8 can be used for the asterisk (*) part. Designate the "HNDDAT*" and "WRKDAT*" parameters to be used using the "LoadSet" command in a program.

For more details, refer to the separate "Instruction Manual/Detailed Explanation of Functions and Operations." It is the same meaning as "LoadSet 0.0" if not using the "LoadSet".

2.2.4 Vibrations at the Tip of the Arm during Low-Speed Operation of the Robot

Vibrations at the tip of the arm may increase substantially during the low-speed operation of the robot, depending on the combination of robot operation, hand mass and hand inertia. This problem occurs when the vibration count specific to the robot arm and the vibration count of the arm driving force are coming close to each other. These vibrations at the tip of the arm can be reduced by taking the following measures:

- 1) Lower the robot's operating speed by approximately 5% from high speed using the Ovrd command.
- 2) Change and move the teaching points of the robot.
- 3) Change the hand mass and hand inertia.

2.2.5 Collision detection

This series have the "collision detection function" which detects the abnormalities by the collision of the robot arm, however initial setting is in invalid condition.

The enable/disable of this function can be changed by parameter: COL and command: ColChk, this function is effective for protect of the robot and of the peripheral equipment.

The abnormalities are detected by the robot's kinetics model, presuming torque necessary for movement at any time. Therefore, the setting parameter (HNDDAT*, WRKDAT*) of the hand and the work piece conditions should be right. And, it may be detected as the collision in movement as speed and motor torque are changed rapidly. (for example, the movement near the place of the origin by linear interpolation, the reversal movement, the cold condition, the operation after long term stoppage)

In such a case, by adjusting the value of the setting parameter (COLLVL, COLLVLJG) of the collision detection level according to actual use environment, the sensitivity of collision detection can be optimized and the damage risk can be reduced further. And, in the operation after the low temperature or long term stoppage, please operate by accustoming at low speed (warm-up), or use the warm-up operation mode.

Refer to the separate instruction manual "Detailed explanations of functions and operations" for details of related parameter.

Table 2-4 : Factory-shipments condition

	JOG operation	Automatic
RV-4F/7F/13F series	Invalid	Invalid

2.2.6 Protection specifications

(1) Types of protection specifications

The robot arm has protection specifications that comply with the IEC Standards. The protection specifications and applicable fields are shown in [Table 2-5](#).

Table 2-5 : Protection specifications and applicable fields

Type	Protection specifications (IEC Standards value)	Classification	Applicable field
RV-4FM/4FLM-SExx01 RV-7FM/7FLM-SExx01 RV-7FLLM-SExx01 RV-13FM/13FLM-SExx01 RV-20FM-SExx01	IP65	Chemical-resistant specifications (SExx01)	Transportation and processing of medicine and food. Worksites that require chemical sterilization/cleaning of the robot arm.
RV-4FM/4FLM-SExx02 RV-7FM/7FLM-SExx02 RV-7FLLM-SExx02 RV-13FM/13FLM-SExx02 RV-20FM-SExx02		Food machinery grade H1 grease specifications (SExx02)	Transportation and processing of food. Worksites that require cleaning of the robot arm by wiping.



CAUTION

Do not use the controller in the sterilization/cleaning environment shown in [Table 2-5](#). Avoid places where adhesion of chemicals may occur.

The IEC IP symbols define the degree of protection against solids and fluids, and do not indicate a protective structure against the entry of chemicals.

The IEC standard is described by the following "Information" The robots with food machinery grade H1 grease specifications (SExx02) may be corroded with rust due to liquids such as chemicals, water, or oil.

【Information】

• The IEC IP65

Protection against water infiltration as specified in IP65 indicates a protective structure that is not harmfully affected when $12.5 \pm 5\%$ liters of water is supplied from a test device at a position approx. 3m away in various directions and a water pressure of 30kPa at the nozzle section. The water is filled one minute per 1m² of test device surface area for a total of three minutes.

(2) About using the robot in the sterilization environment

The multiple-resistant specification robot is made by order. This robot has protection methods that conform to IEC's IP65 standards (splashproof type). Recommended usage conditions.

- 1) Robots with multiple-resistant specifications are supposed to be used in applications such as transportation/processing systems in pharmaceutical and food plants.
- 2) In our company, chemical resistance of the robots is confirmed by the sterilization environment test with hydrogen peroxide gas^{*1)} (for chemical-resistant specifications (SExx01) only). The robot arm may be adversely affected when used in the sterilization environment other than the above, or in direct contact with water or other liquids in excess of the amount indicated in the protection specifications. If you have any specific requests for surface treatment, materials, etc., contact your dealer.
- 3) Take measures to protect the robot arm against the sterilization environment other than the above or direct contact with water, oil, or cut chips in excess of the amount indicated in the protection specifications.
- 4) The packing gets deteriorated with the passage of time and must be replaced as required. If you find that the packing is torn or separated while removing/installing the cover, replace the packing. Failure to replace the packing permits chemicals, water or oil to enter the interior of the robot, possibly causing it to become inoperable. Packing required and liquid gasket used therewith are available from dealer.

Although the robot with food machinery grade H1 grease specifications (SExx02) may become rusty from water splashes, the operating performance of the robot is not disturbed.

The warranty is invalid for any faults that occur when the robot is used under the following conditions.

Also, if the cover and/or other parts are damaged by interferences caused by the peripheral devices and the robot, the protection specification (seal performance, etc.) may be degraded. Therefore, please pay extra attention when handling the robot.

Refer to [Page 175, "6.2 Working environment"](#).

- 1) In surroundings that generate inflammable gases or corrosive gasses *2) .
- 2) Atmosphere of the mist containing polish liquid etc.
- 3) Atmosphere in which the water, the oil, and the dust exceeding protection specification fall on the robot arm directly.

*1) <Sterilization environment test> 6-h exposure in the environment of 120-ppm concentration of hydrogen peroxide gas X 14 times

*2) Chemical resistance of the robots is confirmed by the sterilization environment test with hydrogen peroxide gas^{*1)} for the models with chemical-resistant specifications (SExx01).

2.3 Names of each part of the robot




Fig.2-5 : Names of each part of the robot

2.4 Outside dimensions • Operating range diagram

(1) RV-4F


Notes

Rev. B

1. *1) Ensure the cable connection space to connect machine cables.
2. *2) Ensure the maintenance space to take out the cover.
3. *3) The screw should go in to a depth of 7.5mm to 8mm.
4. *4) Screw hole (M4 depth 8) for securing the user cables/piping.
5. *5) The depth is 3.5mm.
6. *6) The dimension a shows the distance to a minimum bendable radius of the machine cable.

Controller	Specifications Note1)	Dimension a
CR750	SExx01	Minimum 366
	SExx02	
CR751	SExx01	Minimum 310
	SExx02	Minimum 300

Note1) SExx01: Chemical-resistant specifications
 SExx02: Food machinery grade H1 grease specifications



View B bottom view drawing: Detail of installation dimension

View A: Detail of mechanical interface

Note) The drawing shows an example of the CR750 controller connection robot.


Note) Don't install the robot arm in the position where direct rays or the heat of lighting hits. The skin temperature of the robot arm may rise, and the error may occur.

Fig.2-6 : Outside dimensions: RV-4F

Rev. B

Notes

1. *1) Rear face operation limit: When the J axis angle is $-60^\circ \leq J_1 \leq +140^\circ$, the J2 axis operation is limited to $-113^\circ \leq J_2 \leq +120^\circ$.
2. The following figure shows a robot at the position of:
 $J_1=0^\circ$, $J_2=0^\circ$, $J_3=90^\circ$, $J_4=0^\circ$, $J_5=0^\circ$, and $J_6=0^\circ$
3. *3) The area which P point cannot be moved: P point cannot move to this area. This limitation is valid at factory shipping, but it can be released by parameter MELTEXS.



Operating range of each axis:

J1 : $\pm 240^\circ$
 J2 : $\pm 120^\circ$
 J3 : $0^\circ \sim 161^\circ$
 J4 : $\pm 200^\circ$
 J5 : $\pm 120^\circ$
 J6 : $\pm 360^\circ$

Top view

*3)

The area which P point cannot be moved



Side view

Fig.2-7 : Operating range diagram: RV-4F

(2) RV-4FL






Notes

Rev. B

1. *1) Ensure the cable connection space to connect machine cables.
2. *2) Ensure the maintenance space to take out the cover.
3. *3) The screw should go in to a depth of 7.5mm to 8mm.
4. *4) Screw hole (M4 depth 8) for securing the user cables/piping.
5. *5) The depth is 3.5mm.
6. *6) The dimension a shows the distance to a minimum bendable radius of the machine cable.

Controller	Specifications Note1)	Dimension a
CR750	SExx01	Minimum 366
	SExx02	
CR751	SExx01	Minimum 310
	SExx02	Minimum 300

Note1) SExx01: Chemical-resistant specifications
 SExx02: Food machinery grade H1 grease specifications



View B bottom view drawing: Detail of installation dimension

View A: Detail of mechanical interface

Note) The drawing shows an example of the CR750 controller connection robot.


Note) Don't install the robot arm in the position where direct rays or the heat of lighting hits. The skin temperature of the robot arm may rise, and the error may occur.

Fig.2-8 : Outside dimensions: RV-4FL

Rev. B

Notes

1. *1) Rear face operation limit: When the J axis angle is $-35^\circ \leq J_1 \leq +35^\circ$, the J2 axis operation is limited to $-114^\circ \leq J_2 \leq +120^\circ$.
2. The following figure shows a robot at the position of:
 $J_1=0^\circ$, $J_2=0^\circ$, $J_3=90^\circ$, $J_4=0^\circ$, $J_5=0^\circ$, and $J_6=0^\circ$
- 3.*3) The area which P point cannot be moved: P point cannot move to this area. This limitation is valid at factory shipping, but it can be released by parameter MELTEXS.



Operating range of each axis:

J1: $\pm 240^\circ$
 J2: $\pm 120^\circ$
 J3: $0^\circ \sim 164^\circ$
 J4: $\pm 200^\circ$
 J5: $\pm 120^\circ$
 J6: $\pm 360^\circ$

Top view

*3)
 The area which P point cannot be moved



Side view

Fig.2-9 : Operating range diagram: RV-4FL

(3) RV-7F






Notes

Rev. C

1. *1) Ensure the cable connection space to connect machine cables.
2. *2) Ensure the maintenance space to take out the cover.
3. *3) The screw should go in to a depth of 7.5mm to 8mm.
4. *4) Screw hole (M4 depth 8) for securing the user cables/piping.
5. *5) The depth is 3.5mm.
6. *6) The dimension a shows the distance to a minimum bendable radius of the machine cable.

Controller	Specifications Note1)	Dimension a
CR750	SExx01 SExx02	Minimum 390
CR751	SExx01 SExx02	Minimum 334 Minimum 324

Note1) SExx01: Chemical-resistant specifications
 SExx02: Food machinery grade H1 grease specifications



View B bottom view drawing: Detail of installation dimension

View A: Detail of mechanical interface

Note) The drawing shows an example of the CR750 controller connection robot.


Note) Don't install the robot arm in the position where direct rays or the heat of lighting hits. The skin temperature of the robot arm may rise, and the error may occur.

Fig.2-10 : Outside dimensions: RV-7F

Rev. C

Notes

1. The following figure shows a robot at the position of:
J1=0°, J2=0°, J3=90°, J4=0°, J5=0°, and J6=0°
2. *1) The area which P point cannot be moved: P point cannot move to this area. This limitation is valid at factory shipping, but it can be released by parameter MELTEXS.



**Operating range of each axis:**

J1 : $\pm 240^\circ$
 J2 : $-115^\circ \sim 125^\circ$
 J3 : $0^\circ \sim 156^\circ$
 J4 : $\pm 200^\circ$
 J5 : $\pm 120^\circ$
 J6 : $\pm 360^\circ$

Top view

*1)

The area which P point cannot be moved

**Side view****Fig.2-11 : Operating range diagram: RV-7F**

(4) RV-7FL






Notes

Rev. C

1. *1) Ensure the cable connection space to connect machine cables.
2. *2) Ensure the maintenance space to take out the cover.
3. *3) The screw should go in to a depth of 7.5mm to 8mm.
4. *4) Screw hole (M4 depth 8) for securing the user cables/piping.
5. *5) The depth is 3.5mm.
6. *6) The dimension a shows the distance to a minimum bendable radius of the machine cable.

Controller	Specifications Note1)	Dimension a
CR750	SExx01 SExx02	Minimum 390
CR751	SExx01 SExx02	Minimum 334 Minimum 324

Note1) SExx01: Chemical-resistant specifications
SExx02: Food machinery grade H1 grease specifications



View B bottom view drawing: Detail of installation dimension

View A: Detail of mechanical interface

Note) The drawing shows an example of the CR750 controller connection robot.

Note) Don't install the robot arm in the position where direct rays or the heat of lighting hits. The skin temperature of the robot arm may rise, and the error may occur.

Fig.2-12 : Outside dimensions: RV-7FL

Notes

Rev. C

1. The following figure shows a robot at the position of:
J1=0°, J2=0°, J3=90°, J4=0°, J5=0°, and J6=0°
2. *1) Front face operation limit: When the J1 axis angle is $+145^\circ \leq J1 \leq +215^\circ$ or $-145^\circ \leq J1 \leq -215^\circ$, the J2 axis operation is limited to $-110^\circ \leq J2 \leq +120^\circ$.
3. *2) The area which P point cannot be moved: P point cannot move to this area. This limitation is valid at factory shipping, but it can be released by parameter MELTEXS.




Fig.2-13 : Operating range diagram: RV-7FL

(5) RV-7FLL





Notes

Rev. B

1. *1) Ensure the cable connection space to connect machine cables.
2. *2) The screw should go in to a depth of 7.5mm to 8mm.
3. *3) Screw hole (M4 depth 8) for securing the user cables/piping.
4. *4) The depth is 3.5mm.
5. *5) The dimension a shows the distance to a minimum bendable radius of the machine cable.

Controller	Specifications Note1)	Dimension a
CR750	SExx01	Minimum 430
	SExx02	
CR751	SExx01	Minimum 385
	SExx02	Minimum 375

Note1) SExx01: Chemical-resistant specifications
 SExx02: Food machinery grade H1 grease specifications



View A: Detail of mechanical interface

View B bottom view drawing: Detail of installation dimension

Note) The drawing shows an example of the CR750 controller connection robot.


Note) Don't install the robot arm in the position where direct rays or the heat of lighting hits. The skin temperature of the robot arm may rise, and the error may occur.

Fig.2-14 : Outside dimensions: RV-7FLL

Notes

Rev. *

1. The following figure shows a robot at the position of:
J1=0°, J2=0°, J3=90°, J4=0°, J5=0°, and J6=0°
2. *1) Front face operation limit: When the J1 axis angle is $+120^\circ \leq J1$ or $J1 \leq -120^\circ$, the J2 axis operation is limited to $-90^\circ \leq J2 \leq +130^\circ$.
3. *2) The area which P point cannot be moved: P point cannot move to this area. This limitation is valid at factory shipping, but it can be released by parameter MELTEXS.

**Operating range of each axis:**

J1 : $\pm 190^\circ$
 J2 : $-90^\circ \sim +150^\circ$
 J3 : $-10^\circ \sim +157.5^\circ$
 J4 : $\pm 200^\circ$
 J5 : $\pm 120^\circ$
 J6 : $\pm 360^\circ$




Fig.2-15 : Operating range diagram: RV-7FLL

(6) RV-13F/20F



Notes

Rev. B

1. *1) Ensure the cable connection space to connect machine cables.
2. *2) The screw should go in to a depth of 9mm to 10mm.
3. *3) Screw hole (M4 depth 8) for securing the user cables/piping.
4. *4) The dimension a shows the distance to a minimum bendable radius of the machine cable.

Controller	Specifications Note1)	Dimension a
CR750	SExx01 SExx02	Minimum 430
CR751	SExx01 SExx02	Minimum 385 Minimum 375

Note1) SExx01: Chemical-resistant specifications
SExx02: Food machinery grade H1 grease specifications



View B bottom view drawing: Detail of installation dimension

Note) The drawing shows an example of the CR750 controller connection robot.

Note) Don't install the robot arm in the position where direct rays or the heat of lighting hits. The skin temperature of the robot arm may rise, and the error may occur.

Fig.2-16 : Outside dimensions: RV-13F/20F

Notes

Rev. A

1. The following figure shows a robot at the position of:
J1=0°, J2=0°, J3=90°, J4=0°, J5=0°, and J6=0°
2. *1) Front face operation limit: When the J1 axis angle is $+120^\circ \leq J1$ or $J1 \leq -130^\circ$, the J2 axis operation is limited to $-90^\circ \leq J2 \leq +130^\circ$.
3. *2) The area which P point cannot be moved: P point cannot move to this area. This limitation is valid at factory shipping, but it can be released by parameter MELTEX.




Fig.2-17 : Operating range diagram: RV-13F/20F

(7) RV-13FL





Notes

Rev. B

1. *1) Ensure the cable connection space to connect machine cables.
2. *2) The screw should go in to a depth of 9mm to 10mm.
3. *3) Screw hole (M4 depth 8) for securing the user cables/piping.
4. *4) The dimension a shows the distance to a minimum bendable radius of the machine cable.

Controller	Specifications Note1)	Dimension a
CR750	SExx01 SExx02	Minimum 430
CR751	SExx01 SExx02	Minimum 385 Minimum 375

Note1) SExx01: Chemical-resistant specifications
 SExx02: Food machinery grade H1 grease specifications



View A: Detail of mechanical interface

View B bottom view drawing: Detail of installation dimension

Note) The drawing shows an example of the CR750 controller connection robot.




Note) Don't install the robot arm in the position where direct rays or the heat of lighting hits. The skin temperature of the robot arm may rise, and the error may occur.

Fig.2-18 : Outside dimensions: RV-13FL

Notes

Rev. A


1. The following figure shows a robot at the position of:
J1=0°, J2=0°, J3=90°, J4=0°, J5=0°, and J6=0°
2. *1) Front face operation limit: When the J1 axis angle is $+130^\circ \leq J1$ or $J1 \leq -140^\circ$, the J2 axis operation is limited to $-90^\circ \leq J2 \leq +130^\circ$.
3. *2) The area which P point cannot be moved: P point cannot move to this area. This limitation is valid at factory shipping, but it can be released by parameter MELTEX5.

**Top view****Top view****Fig.2-19 : Operating range diagram: RV-13FL**

2.4.1 Outside dimensions of machine cables


(1) Connection with the CR750 controller

1) Power cable



Note) If using an optional machine cable extension, refer to [Page 45, "\(1\) Machine cable extension"](#) in a diameter of the cable.


2) Signal cable



Note) If using an optional machine cable extension, refer to [Page 45, "\(1\) Machine cable extension"](#) in a diameter of the cable.


(2) Connection with the CR751 controller

1) Power cable



Note) If using an optional machine cable extension, refer to [Page 45, "\(1\) Machine cable extension"](#) in a diameter of the cable.

2) Signal cable



Note) If using an optional machine cable extension, refer to [Page 45, "\(1\) Machine cable extension"](#) in a diameter of the cable.

2.5 Tooling

2.5.1 Wiring and piping for hand

Shows the wiring and piping configuration for a standard-equipped hand.




Fig.2-20 : Wiring and piping for hand

2.5.2 Internal air piping

- 1) The robot has two $\phi 6$ urethane hoses from the pneumatic entrance on the base section to the fore arm.
One hose is the primary piping for the pneumatic equipment, and the other pipe is used for air exhaust.
- 2) The optional solenoid is provided with a maximum of eight couplings for the air hose. The diameter of the couplings are shown below.
For SExx01.....1F-VD0*-04 (Sink type)/1F-VD0*E-04 (Source type): $\phi 4$
1F-VD0*-05 (Sink type)/1F-VD0*E-05 (Source type): $\phi 6$
For SExx02.....1F-VD0*-02 (Sink type)/1F-VD0*E-02 (Source type): $\phi 4$
1F-VD0*-03 (Sink type)/1F-VD0*E-03 (Source type): $\phi 6$
- 3) The pneumatic inlet in the base section has a $\phi 6$ pneumatic coupling bridge.
- 4) The solenoid valve set (optional) can be installed to the side on No.2 arm.
- 5) Refer to [Page 56, "\(3\) Solenoid valve set"](#) for details on the electronic valve set (optional).

2.5.3 Internal wiring for the hand output cable

- 1) The hand output primary cable extends from the connector PCB of the base section to the inside of the forearm. (AWG#24(0.2mm²) x 2 cores: 8 cables) The cable terminals have connector bridges for eight hand outputs. The connector names are GR1 and GR2.
To extend the wiring to the outside of the arm, a separate cable (optional "hand output cable 1F-GR35S-02") is required.

2.5.4 Internal wiring for the hand input cable

- 1) The hand input cable extends from the connector PCB of the base section to the inside of the forearm. (AWG#24(0.2mm²) for eight points) The cable terminals have connector bridges for eight hand inputs. The connector names are OP1 and OP3.
To extend the wiring to the outside of the arm, a separate cable (optional "hand input cable 1F-HC35S-02") is required.
- 2) The hand check signal of the pneumatic hand is input by connecting this connector.

2.5.5 Ethernet cable, option wiring cable

Ethernet cables, eight option signal cables, and four power supply cables internally run from the robot's base section up to the forearm area.

These cables can be also pulled out from the underneath of the forearm or from the side of the base area by using options. (Options "Forearm external wiring set" and "Base external wiring set".)

Table 2-6 : Ethernet cable specification

Item	Specification
Communication speed	100BASE-TX
Size	AWG #26 (0.13mm ²) x four pair (total eight cores)
Externality of insulator	Approx. 0.98 mm

2.5.6 Wiring and piping system diagram for hand

Shows the wiring and piping configuration for a standard-equipped hand.




Fig.2-21 : Wiring and piping system diagram for hand and example the solenoid valve installation

2.5.7 Electrical specifications of hand input/output

Table 2-7 : Electrical specifications of input circuit

Item		Specifications	Internal circuit
Type	DC input		<Sink type>
No. of input points	8		+24V +24V 820 3.3K HCn* 24G
Insulation method	Photo-coupler insulation		
Rated input voltage	24VDC		
Rated input current	approx. 7mA		
Working voltage range	DC10.2 to 26.4V (ripple rate within 5%)		
ON voltage/ON current	8VDC or more/2mA or more		
OFF voltage/OFF current	4VDC or less/1mA or less		
Input resistance	Approx. 3.3kΩ		
Response time	OFF-ON ON-OFF	10ms or less (DC24V) 10ms or less (DC24V)	<Source type> +24V +24V 3.3K HCn* 24G 820

* HCn = HC1 to HC8

Table 2-8 : Electrical specifications of output circuit

Item		Specification	Internal circuit
Type	Transistor output		<Sink type>
No. of output points	8		+24V(COM) (Initial power supply)
Insulation method	Photo coupler insulation		
Rated load voltage	DC24V		
Rated load voltage range	DC21.6 to 26.4VDC		
Max. current load	0.1A/ 1 point (100%)		
Current leak with power OFF	0.1mA or less		
Maximum voltage drop with power ON	DC0.9V(TYP.)		
Response time	OFF-ON ON-OFF	2ms or less (hardware response time) 2ms or less (resistance load) (hardware response time)	GRn* Protection of over-current 24G
Protects	Protects the over-current (0.9A)		<Source type> Protection of over-current 24G GRn*

* GRn = GR1 to GR8

2.5.8 Air supply circuit example for the hand

An example of pneumatic supply circuitry for the hand is shown below.

- (1) Make sure that a surge voltage protection circuit such as a diode is connected to the solenoid coil in parallel.
- (2) When the factory pneumatic pressure drops, as a result of the hand clamp strength weakening, there can be damage to the work. To prevent it, install a pressure switch to the source of the air as shown in Fig. 2-22 and use the circuit described so that the robot stops when pressure drops. Use a hand with a spring-pressure clamp, or a mechanical lock-type hand, that can be used in cases where the pressure switch becomes damaged.
- (3) The optional hand and solenoid valve are of an oilless type. If they are used, don't use any lubricator.
- (4) Supply clean air to the vacuum generation valve .
- (5) If the air supply temperature (primary piping) used for the tool etc. is lower than ambient air temperature, the dew condensation may occur on the coupling or the hose surface.




Fig.2-22 : Air supply circuit example for the hand

2.5.9 About the Installation of Tooling Wiring and Piping

The customer is required to provide tooling wiring, piping and metal fixtures.

Screw holes are provided on the robot arm for the installation of tooling wiring, piping and metal fixtures. (Refer to the [Page 23, "2.4 Outside dimensions • Operating range diagram"](#).)

The length of wiring and piping and the installation position on the robot must be adjusted according to the work to be done by the robot. Please use the following example as reference.

<Precautions>

- A hand input cable and a hand curl cable are available as optional accessories for your convenience.
- After performing wiring and piping to the robot, operate the robot at low speed to make sure that each part does not interfere with the robot arm and the peripheral devices.
- Please be aware that dust may be generated from friction if wires and pipes come into contact with the robot arm when using it according to the clean specifications.
- If you install metal fixtures and a solenoid valve using the screw holes on the No.2 arm portion, add the mass of the metal fixtures and the solenoid valve to mass of a hand and set to parameter: HNDDAT. Moreover, Fix the parts, such as a solenoid valve, firmly to prevent the parts getting shaky during operation of a robot.

2.6 Shipping special specifications, options, and maintenance parts

2.6.1 Shipping special specifications

■ What are shipping special specifications?

Shipping special specifications are changed before shipping from the factory. Consequently, it is necessary to confirm the delivery date by the customer.

To make changes to the specifications after shipment, service work must be performed at the work site or the robot must be returned for service.

■ How to order

- (1) Confirm beforehand when the factory special specifications can be shipped, because they may not be immediately available.
- (2) Specify, before shipping from our company.
- (3) Specified method Specify the part name, model, and robot model type.

2.7 Options

■ What are options?

There are a variety of options for the robot designed to make the setting up process easier for customer needs. customer installation is required for the options. Options come in two types: "set options" and "single options".

1. Set options A combination of single options and parts that together, form a set for serving some purpose.
2. Single options That are configured from the fewest number of required units of a part.
Please choose customer's purpose additionally.

(1) Machine cable extension

- Order type:
- CR750 controller.....Fixed type: 1S- □□ CBL-01 (For SExx01/SExx02)
Flexed type: 1S- □□ LCBL-01 (For SExx01/SExx02)
 - CR751 controller.....Fixed type: 1F- □□ UCBL-03 (For SExx01)
Flexed type: 1F- □□ LUCBL-03 (For SExx01)
Fixed type: 1F- □□ UCBL-02 (For SExx02)
Flexed type: 1F- □□ LUCBL-02 (For SExx02)
- Note) □□ refer the length.

■ Outline

<CR750 controller>



<CR751 controller>



The distance between the robot controller and the robot arm is extensible by this option.

A fixed type and flexible type are available.

The fix and flexible types are both configured of the motor signal cable and motor power cable.

The extension method is discriminated as follows depending on a controller.

- The cables for CR750 controller:
Adds to the machine cable attached in the standards.
- The cables for CR751 controller:
Exchanges with the machine cable attached in the standards.

■ Configuration

Table 2-9 : Configuration equipment and types

Part name	Type ^{Note1)}	Qty.		Mass(kg) ^{Note2)}	Remarks			
		Fixed	Flexed					
CR750 controller								
For SExx01/SExx02								
Fixed	Set of signal and power cables	1S- □□ CBL-01	1 set	–	6.7(5m) 12(10m) 17(15m)			
	Motor signal cable		(1 cable)	–				
	Motor power cable		(1 cable)	–				
	Flexed	Set of signal and power cables	1S- □□ LCBL-01	1 set	7(5m) 13(10m) 17(15m)			
				–				
				(1 cable)				
Flexed	Motor signal cable		–	(1 cable)	5m, 10m, or 15m each			
	Motor power cable		–	(1 cable)				
	Nylon clamp	NK-14N	–	2 pcs.				
	Nylon clamp	NK-18N	–	2 pcs.	–			
	Silicon rubber		–	4 pcs.	for motor signal cable			
				–	for motor power cable			
CR751 controller								
For SExx01								
Fixed	Set of signal and power cables	1F- □□ UCBL-03	1 set	–	6.7(10m) 12(15m) 17(20m)			
	Motor signal cable		(1 cable)	–				
	Motor power cable		(1 cable)	–				
	Flexed	Set of signal and power cables	1F- □□ LUCBL-03	1 set	7(10m) 13(15m) 17(20m)			
				–				
				(1 cable)				
Flexed	Motor signal cable		–	(1 cable)	10m, 15m, or 20m each			
	Motor power cable		–	(1 cable)				
	Nylon clamp	NK-14N	–	2 pcs.				
	Nylon clamp	NK-18N	–	2 pcs.	–			
	Silicon rubber		–	4 pcs.	for motor signal cable			
				–	for motor power cable			

Part name	Type ^{Note1)}	Qty.		Mass(kg) Note2)	Remarks	
		Fixed	Flexed			
For SExx02						
Fixed	Set of signal and power cables	1F- □□ UCBL-02	1 set	-	6.7(10m) 12(15m) 17(20m)	
	Motor signal cable		(1 cable)	-		
	Motor power cable		(1 cable)	-		
Flexed	Set of signal and power cables	1F- □□ LUCBL-02	-	1 set	7(10m) 13(15m) 17(20m)	
	Motor signal cable		-	(1 cable)		
	Motor power cable		-	(1 cable)		
Nylon clamp	NK-14N		-	2 pcs.	-	for motor signal cable
Nylon clamp	NK-18N		-	2 pcs.	-	for motor power cable
Silicon rubber			-	4 pcs.	-	

Note1) The numbers in the boxes □□ refer the length.

Note2) Mass indicates one set.

■ Specifications

The specifications for the fixed type cables are the same as those for standard cables.

Shows usage conditions for flexed type cables in [Table 2-10](#).

Table 2-10 : Conditions for the flexed type cables

Item	Specifications	
Cable	1S- □□ LCBL-01	1F- □□ UCBL-02 1F- □□ LUCBL-03
Minimum flexed radius	100mm or more	
Cableveyor, etc., occupation rate	50% or less	
Maximum movement speed	2,000mm/s or less	
Guidance of life count	7.5 million times (With silicone grease coating)	
Environmental proof	IP54	IP54 (except for the area approximately 500 mm from the end of the connector on the controller side)
Cable configuration	Motor signal cable	φ 6 x 5, φ 8.5 x 1, and φ 1.7 x 1
	Motor power cable	φ 6.5 x 8 and φ 8.9 x 2

[Caution] The guidance of life count may greatly differ according to the usage state items related to [Table 2-10](#) and to the amount of silicon grease applied in the cableveyor.

Recommendation grease: G-501 (Supplier: Shin-Etsu Chemical Co., Ltd.)

* The above-mentioned grease is not the food machinery grade H1 grease.

[Caution] The cleanliness of this option is not under warranty.

[Caution] When a cableveyor is used, partitions are required to avoid overlapping or riding up of the cables. Also, adjust the cable length to eliminate tension or excessive looseness, and fix it securely.

■ Cable configuration

The configuration of the flexible cable is shown in [Table 2–11](#). Refer to this table when selecting the cableveyor.

Table 2–11 : Cable configuration (Flexed type)

Item	Motor signal cable			Motor power cable	
CR750 controller					
No. of cores	AWG#24 (0.2mm ²)–4P	AWG#24 (0.2mm ²)–7P	AWG#18 (0.75mm ²)	AWG#16 (1.25mm ²)–4C	AWG#18 (0.75mm ²)–4C
Finish dimensions	Approx. φ 6mm	Approx. φ 8.5mm	Approx. φ 1.7mm	Approx. φ 8.9mm	Approx. φ 6.5mm
No.of cables used	5 cables	1 cable	1 cable	2 cable	8 cable
No. in total	7 cables			10 cables	
CR751 controller					
No. of cores	AWG#24 (0.2mm ²)–4P		AWG#18 (0.75mm ²)	AWG#16 (1.25mm ²)–4C	AWG#18 (0.75mm ²)–3C
Finish dimensions	Approx. φ 6mm		Approx. φ 1.7mm	Approx. φ 8.9mm	Approx. φ 6.5mm
No.of cables used	7 cables		1 cable	2 cable	8 cable
No. in total	8 cables			10 cables	


■ Fixing the flexible cable

<CR750 controller>

- (1) Connect the connector to the robot arm.

The connection method to a robot arm is the same as a standard machine cable. Please refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE" and connect.

- (2) Wind the silicon rubber around the cable at a position 300 to 400 mm from the side of robot arm and extension section as shown below, and fix with the nylon clamp to protect the cable from external stress.




CAUTION


Cover the extension terminal area with the cover etc. so that it may not be easily touched to the latch lever.

The bend size of cables are as follows.


<RV-4F series>



<RV-7F series>



<RV-7FLL/13F/20F series>



*1) The connection space for a machine cable.


Fig.2-23 : Fixing the flexible cable (CR750 controller)

<CR751 controller>

- (1) Connect the connector to the robot arm.

The connection method to a robot arm is the same as a standard machine cable. Please refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE" and connect.

- (2) For protection of wires from external stress, refer to following. Wrap the cable with the supplied silicon rubber and fix the cable with nylon clamps in the area between the heat shrink tubes on the robot and the controller sides (flexible cable area).




*1) Connect the robot arm side connector to the connector which is inside the CONBOX cover.


*2) The flexible cable area is the area between the heat shrink tubes on the robot and the controller sides.

The bend size of cables are as follows.


<RV-4F series>



<RV-7F series>



<RV-7FLL/13F/20F series>



*1) The connection space for a machine cable.

Model	RV-4F series		RV-7F series		RV-7FLL/13F/20F series	
Specification ^{Note1)}	SExx01	SExx02	SExx01	SExx02	SExx01	SExx02
Dimension a	Min. 310	Min. 300	Min. 310	Min. 300	Min. 310	Min. 300

Note1) SExx01: Chemical-resistant specifications. SExx02: Food machinery grade H1 grease specifications

Fig.2-24 : Fixing the flexible cable (CR751 controller)

(2) J1 axis operating range change

■ Order type	RV-4F series	1F-DH-06 (For SExx01)
		1F-DH-03 (For SExx02)
	RV-7F series	1F-DH-07 (For SExx01)
		1F-DH-04 (For SExx02)
	RV-13F series.....	1F-DH-08 (For SExx01)
		1F-DH-05J1 (For SExx02)

■ Outline



The operating range of J1 axis is limited by the robot arm's mechanical stopper and the controller parameters.

If the axis could interfere with the peripheral devices, etc., and the operating range need to be limited, use this.

■ Configuration

(1) RV-4F series (1F-DH-03, 1F-DH-06)

Table 2-12 : Configuration devices (RV-4F series)

No.	Part name	Qty.	Mass (kg)	Remarks
<1>	Stopper plate	2	1.1	One piece each for + side/- side
<2>	Fixing block A	2		One piece each for + side/- side
<3>	Fixing block B	1		+ side
<4>	Fixing block C	1		- side
<5>	Variable stopper block	2		One piece each for + side/- side
<6>	Screw (M10x20)	2		Use for mechanical stopper screw A and B
<7>	Screw (M6x25)	2		For fixing
<8>	Screw (M6x20)	16		For fixing




Table 2-13 : Changeable angle (RV-4F series)

Item	Standard	Changeable angle (combination of + side/- side) (Unit: Degree)			
+ (plus) side	+240	+30	+73	+103	+146
Variable stopper block angle	-	+33	+76	+106	+149
Variable stopper block position Note1)	-	(a)	(b)	(a)	(b)
Mechanical stopper screw A Note2)	-	Use		Disuse Note3)	
Parameter (MEJAR) setting value	+240	+30	+73	+103	+146
- (minus) side	-240	-30	-73	-103	-146
Variable stopper block angle	-	-33	-76	-106	-149
Variable stopper block position Note1)	-	(d)	(c)	(d)	(c)
Mechanical stopper screw B Note2)	-	Use		Disuse Note3)	
Parameter (MEJAR) setting value	-240	-30	-73	-103	-146

Note1) Symbol: "(a)" – "(d)" are related with the symbol of [Page 53 "Fig. 2-25: Installation image of J1axis operating range change option \(RV-4F/7F series\)".](#)

Note2) In the table, it means that "Disuse" does not install the screw, and "Use" does install the screw.

Note3) Mechanical stopper screw which is either one of the two is always necessary. For this reason, the combination enclosed by the thick line of the square in the table (both of + (plus) side and - (minus) side are 103 or 146) cannot be used.


Example) It cannot be used that set +146 as the plus side and set -103 as the minus side simultaneously. The other combination can be set up.

- 1) The changeable angle of RV-4F series is shown in [Table 2-13](#). The changeable angle shown in [Table 2-13](#) indicates the operation range by the software. The limit by the mechanical stopper is positioned three degrees outward from that angle, so take care when designing the layout.
- 2) The changeable angle can be set independently on the + (plus) side/ - (minus) side, within the condition shown in [Table 2-13](#).
- 3) The operating range is changed with robot arm settings and parameter settings. Refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE" or "Instruction Manual/Detailed Explanation of Functions and Operations" for details.

(2) RV-7F series (1F-DH-04, 1F-DH-07)

Table 2-14 : Configuration devices (RV-7F series)

No.	Part name	Qty.	Mass (kg)	Remarks
<1>	Stopper plate	2	1.1	One piece each for + side/- side
<2>	Fixing block A	2		One piece each for + side/- side
<3>	Fixing block B	1		+ side
<4>	Fixing block C	1		- side
<5>	Variable stopper block	2		One piece each for + side/- side
<6>	Screw (M12x25)	2		Use for mechanical stopper screw A and B
<7>	Screw (M8x25)	14		For fixing
<8>	Screw (M8x20)	4		For fixing



Install each parts to the upper arm lower part with attached screw.

Table 2-15 : Changeable angle (RV-7F series)

Item	Standard	Changeable angle (combination of + side/- side) (Unit: Degree)				
+ (plus) side	+240	+35	+77		+99	+141
Variable stopper block angle	-	+38	+80		+102	+144
Variable stopper block position Note1)	-	(a)	(b)		(a)	(b)
Mechanical stopper screw A Note2)	-	Use			Disuse Note3)	
Parameter (MEJAR) setting value	+240	+35	+77		+99	+141
- (minus) side	-240	-35	-77		-99	-141
Variable stopper block angle	-	-38	-80		-102	-144
Variable stopper block position Note1)	-	(d)	(c)		(d)	(c)
Mechanical stopper screw B Note2)	-	Use			Disuse Note3)	
Parameter (MEJAR) setting value	-240	-35	-77		-99	-141

Note1) Symbol: "(a)" – "(d)" are related with the symbol of [Page 53 "Fig. 2-25: Installation image of J1axis operating range change option \(RV-4F/7F series\)"](#).

Note2) In the table, it means that "Disuse" does not install the screw, and "Use" does install the screw.

Note3) Mechanical stopper screw which is either one of the two is always necessary. For this reason, the combination enclosed by the thick line of the square in the table (both of + (plus) side and - (minus) side are 99 or 141) cannot be used.

Example) It cannot be used that set +141 as the plus side and set -99 as the minus side simultaneously. The other combination can be set up.

- The changeable angle of RV-7F series is shown in [Table 2-15](#). The changeable angle shown in [Table 2-15](#) indicates the operation range by the software. The limit by the mechanical stopper is positioned three degrees outward from that angle, so take care when designing the layout.
- The changeable angle can be set independently on the + (plus) side/ - (minus) side, within the condition shown in [Table 2-15](#).

- 3) The operating range is changed with robot arm settings and parameter settings. Refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE" or "Instruction Manual/Detailed Explanation of Functions and Operations" for details.

(3) Installation image (RV-4F/7F series)




Fig.2-25 : Installation image of J1axis operating range change option (RV-4F/7F series)

[Example] In the RV-7F series, when limiting the +side to +35 degree, and the -side to -141 degree, install as following.
Variable stopper block: Installs in the position of (a), and the position of (c).
Mechanical stopper screw A: Install.
Mechanical stopper screw B: Do not install.

(4) RV-13F series (1F-DH-05J1, 1F-DH-08)

Table 2-16 : Configuration devices (RV-13F series)

No.	Part name	Qty.	Mass (kg)	Remarks
<1>	Stopper Block J1	1	0.3	
<2>	Resin Stopper B	2		One piece each for + side/- side
<3>	Screw (M12 × 20)	2		Mechanical Stopper screw
<4>	Screw (M10 × 40)	2		For Stopper Block J1 fixing
<5>	Screw (M4 × 12)	4		For Resin Stopper B fixing

<1>Stopper Block J1
<2>Resin Stopper B

The image shows three 3D-style technical drawings. On the left is a rectangular 'Stopper Block J1' with two circular holes on top and a small protrusion on one side. To its right are two smaller, L-shaped 'Resin Stopper B' components, each with a central slot and a protrusion on one end.

Install each parts to behind the J1 axis of robot arm with attached screw.

Table 2-17 : Changeable angle (RV-13F series)

Item	Standard	Changeable angle	
+ (plus) side	+190	+30	+120
Mechanical Stopper screw position Note1)	-	(A)	(B)
Mechanical Stopper position	+193	+32.5	+122.5
Parameter (MEJAR) setting value	+190	+30	+120
+ (minus) side	-190	-30	-120
Mechanical Stopper screw position ^{Note1)}	-	(D)	(C)
Mechanical Stopper position	-193	-32.5	-122.5
Parameter (MEJAR) setting value	-190	-30	-120

Note1) Symbol: "(A)" – "(D)" in the Table 2-17 is related with the symbol of "Fig. 2-26: Installation image of J1axis operating range change option (RV-13F series)".

- 1) The changeable angle of RV-13F series is shown in Table 2-17. The changeable angle shown in Table 2-17 indicates the operation range by the software. The limit by the mechanical stopper is positioned three degrees outward from that angle, so take care when designing the layout.
- 2) The changeable angle can be set independently on the + (plus) side/ - (minus) side, within the condition shown in Table 2-17.
- 3) The operating range is changed with robot arm settings and parameter settings. Refer to the separate "Instruction Manual/ROBOT ARM SETUP & MAINTENANCE" or "Instruction Manual/Detailed Explanation of Functions and Operations" for details.




Fig.2-26 : Installation image of J1axis operating range change option (RV-13F series)

[Example] In the RV-13F series, when limiting + side to +32.5 degree and - side to -122.5 degree, install the Mechanical Stopper screw in the position of (A) and (C).

(3) Solenoid valve set

- Order type: One set: 1F-VD01-**(Sink type)/1F-VD01E-** (Source type)
 Two sets: 1F-VD02-** (Sink type)/1F-VD02E-** (Source type)
 Three sets: 1F-VD03-** (Sink type)/1F-VD03E-** (Source type)
 Four sets: 1F-VD04-** (Sink type)/1F-VD04E-** (Source type)
- Note) “-**” differs by robot arm.
 · RV-4F/7F series and RV-7FL “-04” (For SExx01), “-02” (For SExx02)
 · RV-13F/13FL and RV-20F “-05” (For SExx01), “-03” (For SExx02)

■ Outline

1F-VD0*-02



1F-VD0*-03



The solenoid valve set is an option that is used for controlling toolings when various toolings, such as the hand, are installed at the end of the arm.

Also, for easy installation of this electromechanical set onto the robot, it comes equipped with a manifold, couplings, connectors, among other things.

■ Configuration

Table 2-18 : Configuration equipment

Part name	Type ^{Note1)}	Q'ty				Mass(kg) Note2)	Remark
		One set	Two sets	Three sets	Four sets		
Solenoid valve set (1 set)	1F-VD01-**/ 1F-VD01E-**	1 pc.	—	—	—	0.3	Hand output cable is already connected. Refer to Page 63, "(5) Hand output cable". 1F-VD0*-01: Sink type 1F-VD0*-01: Source type.
Solenoid valve set (2 sets)	1F-VD02-**/ 1F-VD02E-**	—	1 pc.	—	—	0.4	Coupling size of A/B-port (output side of solenoid valve) · 1F-VD0*-02/1F-VD0*-02 : Φ4 · 1F-VD0*-03/1F-VD0*-03 : Φ6 · 1F-VD0*-04/1F-VD0*-04 : Φ4 · 1F-VD0*-05/1F-VD0*-05 : Φ6
Solenoid valve set (3 sets)	1F-VD03-**/ 1F-VD03E-**	—	—	1 pc.	—	0.4	
Solenoid valve set (4 sets)	1F-VD04-**/ 1F-VD04E-**	—	—	—	1 pc.	0.5	

Note1) “-**” differs by robot arm. (Refer to “ ■ Order type” above)

Note2) Mass indicates one set.

■ Specifications

Table 2-19 : Valve specifications

Item	Specifications
Number of positions	2
Port	5 Note1)
Valve function	Double solenoid
Operating fluid	Clean air Note2)
Operating method	Internal pilot method
Effective sectional area (CV value)	1.1mm ² (0.06)
Oiling	Unnecessary
Operating pressure range	0.1 to 0.7MPa
Response time	22msec or less (at 0.5 MPa)
Max. operating frequency	5Hz
Ambient temperature	-10 to 50 °C (However, there must be no condensation.)

Note1) Couplings of unused solenoid valves must be blocked with plugs. If they are not blocked, supplied air will blow out from the couplings, lowering the air pressure of the solenoid valves being used and making them nonfunctional.

Recommended plugs: KQ2P-04 plug made by SMC (for 1F-VD0*-02/1F-VD0*-02)

KQ2P-06 plug made by SMC (for 1F-VD0*-03/1F-VD0*-03)

KQG2P-04 plug made by SMC (for 1F-VD0*-04/1F-VD0*-04)

KQG2P-06 plug made by SMC (for 1F-VD0*-05/1F-VD0*-05)

Note2)



CAUTION

The air to be provided must be clean, i.e., filtered with a mist separator or air filter. Failing to do so may lead to malfunctions.

Table 2–20 : Solenoid specifications

Item	Specifications
Method	Built-in fly-wheel diodes with surge protection
Coil rated voltage	DC24V $\pm 10\%$
Power consumption	0.55W
Voltage protection circuit with power surge protection	Diode




Fig.2-27 : Outline dimensional drawing (1F-VDO*-02/1F-VDO*-E-02)




Fig.2-28 : Outline dimensional drawing (1F-VD0*-03/1F-VD0*E-03)




Fig.2-29 : Outline dimensional drawing (1F-VD0*-04/1F-VD0*-E-04)




Fig.2-30 : Outline dimensional drawing (1F-VD0*-05/1F-VD0*E-05)

(4) Hand input cable

■ Order type: 1F-HC35S-02

■ Outline



The hand input cable is used for customer-designed pneumatic hands. It is necessary to use this to receive the hand's open/close confirmation signals and grasping confirmation signals, at the controller. One end of the cable connects to the connector for hand input signals, which is in the wrist section of the hand. The other end of the cable connected to the sensor inside the hand customer designed.

■ Configuration

Table 2-21 : Configuration equipment

Part name	Type	Qty.	Mass (kg) ^{Note1)}	Remarks
Hand input cable	1F-HC35S-02	1 cable	0.2	

Note1) Mass indicates one set.

■ Specifications

Table 2-22 : Specifications

Item	Specifications	Remarks
Size x cable core	AWG#24 (0.2 mm ²)× 10 cores	One-sided connector, one-sided cable bridging
Total length	1,000 mm	

Pin assign of the hand input cable is shown in [Table 2-23](#).

Table 2-23 : Pin assign of hand input cable

Color	Connector ^{Note1)}	Pin number: names	Color	Connector ^{Note1)}	Pin number: names
Purple	OP1	A1: HC1	Yellow	OP3	A1: +24V
Brown		A2: HC2	Green		A2: 24G
Blue		A3: HC3	-		Reserved
Black		A4: HC4	-		Reserved
Red		B1: HC5			
White		B2: HC6			
Gray		B3: HC7			
Pink		B4: HC8			

Note1) The connector shows the connector name connected to the robot-arm side.

[Caution] The cleanliness of this option is not under warranty.

(5) Hand output cable

- Order type: 1F-GR35S-02

- Outline



The hand output cable (solenoid valve connection cable) is an option that is used when a solenoid valve other than one of the solenoid valve set options, is used. One end of the cable has a connector that connects to the input terminal inside the robot. The other end of the cable is connected.

- Configuration

Table 2-24 : Configuration equipment

Part name	Type	Qty.	Mass (kg) Note1)	Remarks
Hand output cable	1F-GR35S-02	1 cable	0.1	

Note1) Mass indicates one set.

- Specifications

Table 2-25 : Specifications

Item	Specifications	Remarks
Size x Cable core	AWG#24(0.2 mm ²) x 10 cores	One side connector and one side cable connection
Total length	500 mm	

Pin assign of the hand output cable is shown in [Table 2-26](#).

Table 2-26 : Pin assign of hand output cable


Color	Connector	Pin number: names	Color	Connector	Pin number: names
Yellow	GR1	A1: +24V	Green	GR2	A1: +24V
–		A2: Reserved	–		A2: Reserved
Purple		A3: GR1 (Hand output 1)	Red		A3: GR5 (Hand output 5)
Brown		A4: GR2 (Hand output 2)	White		A4: GR6 (Hand output 6)
Blue		B1: GR3 (Hand output 3)	Gray		B1: GR7 (Hand output 7)
Black		B2: GR4 (Hand output 4)	Pink		B2: GR8 (Hand output 8)
–		B3: Reserved	–		B3: Reserved
–		B4: Reserved	–		B4: Reserved

[Caution] The cleanliness of this option is not under warranty.

(6) Hand curl tube

- Order type: RV-4F/7F series, RV-7FLL One set: 1E-ST0402C
Two sets: 1E-ST0404C
Three sets: 1E-ST0406C
Four sets: 1E-ST0408C
- RV-13F/13FL/20F One set: 1N-ST0602C
Two sets: 1N-ST0604C
Three sets: 1N-ST0606C
Four sets: 1N-ST0608C

■ Outline



The hand curl tube is a curl tube for the pneumatic hand.

■ Configuration

Table 2-27 : Configuration equipment

Part name	Type	Qty.	Mass(kg) ^{Note1)}	Remarks
For RV-4F/7F series, RV-7FLL				
Hans curl tube (One set: 2 pcs.)	1E-ST0402C	1 pc.	0.1	φ 4 tube, 2pcs.
Hans curl tube (Two sets: 4 pcs.)	1E-ST0404C	1 pc.	0.1	φ 4 tube, 4pcs.
Hans curl tube (Three sets: 6 pcs.)	1E-ST0406C	1 pc.	0.1	φ 4 tube, 6pcs.
Hans curl tube (Four sets: 8 pcs.)	1E-ST0408C	1 pc.	0.1	φ 4 tube, 8pcs.
For RV-13F/13FL/20F				
Hans curl tube (One set: 2 pcs.)	1N-ST0602C	1 pc.	0.1	φ 6 tube, 2pcs.
Hans curl tube (Two sets: 4 pcs.)	1N-ST0604C	1 pc.	0.1	φ 6 tube, 4pcs.
Hans curl tube (Three sets: 6 pcs.)	1N-ST0606C	1 pc.	0.1	φ 6 tube, 6pcs.
Hans curl tube (Four sets: 8 pcs.)	1N-ST0608C	1 pc.	0.1	φ 6 tube, 8pcs.

Note1) Mass indicates one set.

■ Specifications

Table 2-28 : Specifications

Item	Specifications
Material	Urethane
Size	1E-ST040*C : Outside diameter φ 4 × Inside diameter φ 2.5 1N-ST060*C : Outside diameter φ 6 × Inside diameter φ 4




Fig.2-31 : Outline dimensional drawing

[Caution] The cleanliness of this option is not under warranty.

(7) Forearm external wiring set/ Base external wiring set

■ Order type


Forearm external wiring set:

- 1F-HB01S-02 (Hand input signals, force sensor and vision sensor. For SExx01)
- 1F-HB01S-01 (Hand input signals, force sensor and vision sensor. For SExx02)
- 1F-HB02S-02 (Force sensor and vision-sensor. For SExx01)
- 1F-HB02S-01 (Force sensor and vision-sensor. For SExx02)

Base external wiring set:

- 1F-HA01S-02 (Force sensor and vision-sensor. For SExx01)
- 1F-HA01S-01 (Force sensor and vision-sensor. For SExx02)
- 1F-HA02S-02 (Force sensor and vision-sensor. For SExx01)
- 1F-HA02S-01 (Force sensor and vision-sensor. For SExx02)

■ Outline



The Forearm external wiring set and the Base external wiring set are used to pull out the hand input signal cables and communication cables etc. from the underneath of the forearm and the side of the base.

This option consists of the cable clamp box and the cable for hand input signals or the cable for communication.

1) Hand input cable

The hand input cable of the option (equivalent of 1F-HC35S-02) is installed. Connect to the connectors OP1 and OP3 of the hand input cable, which is built into the forearm. Connect the user connection side of pulled-out cable to the tools etc, and input the signals.

2) Communication cable

Pulls out the cable which attached the connector for connecting with vision sensor etc.

The pulled out cables from the underneath of the forearm are connected with a vision sensor camera, or a force sensor. The pulled out cables from the side of the base are connected with a vision sensor controller, or a force sensor interface. (To connect to a force sensor, use the adaptor cable that is supplied in the force sensor option.)

■ Configuration

Table 2-29 : Configuration equipment

Part name	Type	Qty.	Remarks
Forearm external wiring set	1F-HB01S-02	Either one pc.	For SExx01
	1F-HB02S-02		
	1F-HB01S-01	Either one pc.	For SExx02
	1F-HB02S-01		
Base external wiring set	1F-HA01S-02	Either one pc.	For SExx01
	1F-HA02S-02		
	1F-HA01S-01	Either one pc.	For SExx02
	1F-HA02S-01		

■ Specification

The kind of cable which can be pulled out for each option is shown in [Table 2-30](#). Because to pull out the cable of the same purpose also as the forearm side and the base side, you should use the option in pair shown in "the pairing (recommendation)" of the table. And, each wiring system figure is shown after the following page.

Table 2-30 : Internal wiring and piping specification types

Pairing (recommendation)	Option type	Cable length (mm) Note1)	Wiring (cable for the connection to each equipment)		
			Hand input signal Note2)	Vision sensor camera	Force sensor unit
For SExx01					
1	1F-HB01S-02 (Forearm)	1,000	eight points	1	Either one unit
	1F-HA01S-02 (Base)	500	Not available	1	Either one unit
2	1F-HB02S-02 (Forearm)	1,000	Not available	1	1
	1F-HA02S-02 (Base)	500	Not available	1	1
For SExx02					
1	1F-HB01S-01 (Forearm)	1,000	eight points	1	Either one unit
	1F-HA01S-01 (Base)	500	Not available	1	Either one unit
2	1F-HB02S-01 (Forearm)	1,000	Not available	1	1
	1F-HA02S-01 (Base)	500	Not available	1	1

Note1) The length from the cable clamp box to the connector.

Note2) Although the connector is attached to the customer wiring side of hand input cable, the connector can be cut, and connect to the tool of the customer preparation. The color and signal name of the wire are shown in [Table 2-31](#).

Table 2-31 : Color of the wire and signal name (hand input cable)

Color	Signal name	Connector (HC)	Color	Signal name	Connector (HC)	Color	Signal name	Connector (HC)	Color	Signal name	Connector (HC)
Violet	HC1	A1	Brown	HC2	A2	Blue	HC3	A3	Black	HC4	A4
Red	HC5	B1	White	HC6	B2	Gray	HC7	B3	Pink	HC8	B4
Yellow	+24V	A6	Green	+24G(RG)	B6				-		

1) Wiring system diagram (1F-H*01S-01/1F-H*01S-02: Hand input signals, force sensor and vision sensor)




Fig.2-32 : Wiring system diagram (1F-H*01S-01/1F-H*01S-02)

2)Wiring system diagram (1F-H*02S-01/1F-H*02S-02: Force sensor and vision-sensor)




Fig.2-33 : Wiring system diagram (1F-H*02S-01/1F-H*02S-02)

2.8 About Overhaul

Robots which have been in operation for an extended period of time can suffer from wear and other forms of deterioration. In regard to such robots, we define overhaul as an operation to replace parts running out of specified service life or other parts which have been damaged, so that the robots may be put back in shape for continued use. As a rule of thumb, it is recommended that overhaul be carried out before the total amount of servo-on time reaches the specified time (24,000 hours for the robot arm and 36,000 hours for the controller) (See Fig. 2-34.). However, the degree of the equipment's wear and deterioration presumably varies depending on their operating conditions. Especially for operation with high load and frequency, the maintenance cycle may be shorter. For details on the part selection for replacement and the timing of overhaul, contact your dealer.




Fig.2-34 : Periodic inspection/overhaul periods

2.9 Maintenance parts

The consumable parts used in the robot arm are shown in [Table 2–32](#). Purchase these parts from the designated maker or dealer when required. Some Mitsubishi-designated parts differ from the maker's standard parts. Thus, confirm the part name, robot arm and controller serial No. and purchase the parts from the dealer.

Table 2–32 : Consumable part list

No.	Part name	Type ^{Note1)}	Usage place	Qty.	Supplier
1	Grease		Reduction gears of each axis	As needed	Mitsubishi Electric
2	Lithium battery	ER6	Inside the CONBOX cover	3 pcs.	

Note1) Confirm the robot arm serial No., and contact the dealer or service branch of Mitsubishi Electric Co., for the type.

3 Controller

3.1 Standard specifications

3.1.1 Basic specifications

Table 3-1 : Specifications of controller

Item	Unit	Specification	Remarks
Type		CR750-□ VD-1 CR751-□ VD-0 CR750-07VLD-1 CR751-07VLD-0	“ □ ” in type name shows the load (4kg: “04”, 7kg: “07”, 13kg: “13”, 20kg: “20”) of robot arm. CR750-07VLD-1 and CR751-07VLD-0 controller are for RV-7FLL only.
Number of control axis		Simultaneously 6	
Memory capacity	Programmed positions	point 39,000	
	No. of steps	step 78,000	
	Number of program		512
Robot language		MELFA-BASIC IV, V	
Teaching method		Pose teaching method, MDI method Note1)	
External input and output	Input and output	point 0/0	Max. 256/256 by option
	Dedicated input/output		Assigned with general-purpose input/output The signal number of “STOP” input signals is fixing.
	Hand open/close input/output	point 8/8	Built-in
	Emergency stop input	point 1	Dual line
	Door switch input	point 1	Dual line
	Enabling device input	point 1	Dual line
	Emergency stop output	point 1	Dual line
	Mode output	point 1	Dual line
	Robot error output	point 1	Dual line
	Addition axis synchronization	point 1	Dual line
	Mode changeover switch input	point 1	Dual line (CR751 controller only)
Interface	RS-422	port 1	Only for T/B
	Ethernet	port 1	10BASE-T/100BASE-Tx
	USB	port 1	Ver.2.0 FullSpeed Only device function
	Additional axis interface	Channel 1	SSCNET III (Connects with MR-J3-BS, MR-J4-B series)
	Tracking interface	Channel 2	
	Option slot	slot 2	For option interface
Power source	Input voltage range	V RV-4F series: Single phase AC180 to 253 RV-7F/13F series Note2) : Three phase AC180 to 253, or Single phase AC207 to 253	Refer to the table in “ ■ Introduction” for details of the robot type.
	Power capacity	kVA RV-4F series : 1.0 RV-7F series : 2.0 RV-13F series : 3.0	Does not include rush current. Note3) Refer to the table in “ ■ Introduction” for details of the robot type.
	Power supply frequency	Hz 50/60	
Outline dimensions Note4)	mm	CR750 controller 430(W) x 425(D) x 174(H)	Excluding protrusions. Refer to the table in “ ■ Introduction” for details of the robot type.
		CR751 controller RV-4F/7F series: 430(W) x 425(D) x 98(H) RV-13F series: 430(W) x 425(D) x 174(H)	
Mass	kg	CR750 controller: Approx. 18	
		CR751 controller RV-4F/7F series: Approx. 12 RV-13F series: Approx. 15	Refer to the table in “ ■ Introduction” for details of the robot type.

Item	Unit	Specification	Remarks
Construction		Self-contained floor type, Opened type. Installation vertically or horizontally	IP20 Note5)
Operating temperature range	°C	0 to 40	
Ambient humidity	%RH	45 to 85	Without dew drops
Grounding	Ω	100 or less	100Ω or less (class D grounding) Note6)
Paint color		Dark gray	Equivalent to Munsell: 3.5PB3.2/0.8

Note1) Pose teaching method: The method to register the current position of the robot arm.

MDI method: The method to register by inputting the numerical value Immediate.

Note2) Both the three phase power supply and the single phase power supply can use this product according to voltage conditions.

Note3) The power capacity is the rating value for normal operation. The power capacity does not include the rush current when the power is turned ON. The power capacity is a guideline and the actual operation is affected by the input power voltage. The short circuit breaker should use the following.

* Operate by the current leakage under the commercial frequency domain (50–60Hz). If sensitive to the high frequency ingredient, it will become the cause in which below the maximum leak current value carries out the trip.

Note4) Refer to [Page 79, "3.3.1 Outside dimensions"](#) for details.

Note5) This controller is standard specification. (Refer to [Page 73, "3.1.2 Protection specifications and operating supply"](#).)

Note6) The robot must be grounded by the customer.

3.1.2 Protection specifications and operating supply

A protection method complying with the IEC Standard IP20 (Opened type) is adopted for the controller.

The IEC IP symbols refer only to the degree of protection between the solid and the fluids, and don't indicated that any special protection has been constructed for the prevention against oil and water.

The controller is not chemical-resistant. For installing the controller, avoid places where adhesion of chemicals may occur.

【Information】

• The IEC IP20

It indicates the protective structure that prevents an iron ball $12^{+0.05}_0$ mm diameter, which is being pressed with the power of $3.1 \text{ kg} \pm 10\%$, from going through the opening in the outer sheath of the supplied equipment.


Refer to the section [Page 175, "6.2 Working environment"](#) for details on the working environment.

3.2 Names of each part


3.2.1 Controller

(1) CR750 controller


Controller (Front side)



Controller (Rear side)



<1>: ACIN terminal



There are two types (Type A and B) of terminal.
Refer to next page for details.

<20>: The operation panel






Fig.3-1 : Names of controller parts (CR750)

<1> ACIN terminal The terminal box for AC power source (single phase or three phase, AC200V) input. (Inner side of a cover)
 There are two types of the terminal and the terminal differs depending on the model.

Model	Type of the terminal
RV-4F/4FL series	<p><u>Type A:</u> For single phase</p>  <p>Connect the primary power supply to L1 and L2 terminal.</p>
RV-7F/7FL series RV-7FLL series RV-13F/13FL series RV-20F series	<p><u>Type B:</u> For single phase/three phase</p>  <p>When using the three phase primary power supply, connect to L1, L2, and L3 terminal. When using the single phase primary power supply, connect to L1 and L3 terminal.</p>


Refer to a separate manual "INSTRUCTION MANUAL/Controller setup, basic operation, and maintenance" for how to connect a power cable.

- <2> PE terminal The screw for grounding of the cable. (M4 screw x 2 place)
- <3> Power switch This turns the control power ON/OFF. (With earth leakage breaker function)
- <4> Machine cable connector (motor signal) (CN1)
 Connect with the CN1 connector of the robot arm.
- <5> Machine cable connector (motor power) (CN2)
 Connect with the CN2 connector of the robot arm.
- <6> T/B connection connector (TB) This is a dedicated connector for connecting the T/B. When not using T/B, connect the attached dummy connector.
- <7><8><9><10> CNUSR connector The connector for input/ output connection dedicated for robot. (a plug connector attached)
 <7>: CNUSR11, <8>: CNUSR12, <9>: CNUSR13, <10>: CNUSR2
 Refer to a separate manual "INSTRUCTION MANUAL/Controller setup, basic operation, and maintenance" for the connection method and the further description of pin assign.
- <11> LAN connector (LAN) For LAN connection
- <12> ExtOPT connector (ExtOPT) Connect the cable for addition axis control.
- <13> RIO connector (RIO) Connect the extension parallel input/output unit.
- <14> Option slot (SLOT1, SLOT2) Install the interface optional. (Install the cover, when not using.)
- <15> Interface cover USB interface and battery are mounted.
- <16> Mode key switch This key switch changes the robot's operation mode.
- AUTOMATIC Operations from the controller or external equipment are valid. Operations for which the operation mode must be at the external device or T/B are not possible. (Exclude the start of automatic operation.)
- MANUAL When the T/B is valid, only operations from the T/B are valid. Operations for which the operation mode must be at the external device or controller are not possible.
- <17> Emergency stop switch This switch stops the robot in an emergency state. The servo turns OFF.
- <18> Filter cover There is an air filter inside the cover.
- <19> Grounding terminal The grounding terminal for connecting cables of option card. (M3 screw x 2 places)
- <20> Operation panel The operation panel for servo ON/OFF, START/STOP the program etc.
- <21> Display panel (STATUS.NUMBER) The alarm No., program No., override value (%), etc., are displayed.
- <22> CHNGDISP button This button changes the details displayed on the display panel in the order of "Override" → "Line No." → "Program No." → "User information." → "Maker information.."
- <23> UP/DOWN button This scrolls up or down the details displayed on the "STATUS. NUMBER" display panel.

-
- <24> SVO.ON button This turns ON the servo power. (The servo turns ON.)
 - <25> SVO.OFF button..... This turns OFF the servo power. (The servo turns OFF.)
 - <26> START button..... This executes the program and operates the robot. The program is run continuously.
 - <27> STOP button This stops the robot immediately. The servo does not turn OFF.
 - <28> RESET button This resets the error. This also resets the program's halted state and resets the program.
 - <29> END button This stops the program being executed at the last line or End statement.

(2) CR751 controller

Controller (Front side)



Note) The controller is an example.

Controller (Rear side)




Fig.3-2 : Names of controller parts (CR751)

- <1> ACIN terminalThe connector for AC power source (single phase or single phase/three phase, AC200V) input. (a socket housing and a terminal are attached). Refer to a separate manual “INSTRUCTION MANUAL/Controller setup, basic operation, and maintenance” for how to connect a power cable.
- <2> PE terminalThe screw for grounding of the cable. (M4 screw x 2 place)
- <3> POWER lampLamp of control power source
- <4> Machine cable connector (motor power)
AMP1, AMP2: Motor power, BRK: Motor brake
- <5> Machine cable connector (motor signal)
CN2: Motor signal
- <6>T/B connection connector (TB)This is a dedicated connector for connecting the R33TB. When not using T/B, connect the attached dummy plug.
- <7>Filter coverThere is an air filter and battery inside this cover.
- <8>CNUSR connectorThe connector for input/ output connection dedicated for robot.
(a plug connector attached)
Refer to a separate manual “INSTRUCTION MANUAL/Controller setup, basic operation, and maintenance” for the connection method and the further description of pin assign.
- <9>Grounding terminalThe grounding terminal for connecting cables of option card. (M3 screw x 2 places)
- <10>Power supply charge lamp (CRARGE)
The lamp is to ensure safe timing (prevent electric shocks) when removing the cover (users are not normally required to remove the cover). This lamp is illuminated (red) when electrical energy accumulates on the controller’s power supply circuit board due to the robot’s servo being ON.

After turning the control power OFF and allowing a few minutes to pass,
the lamp will go out.

- <11>USB connecting connector (USB)..For USB connection
- <12>LAN connector (LAN)For LAN connection
- <13>ExtOPT connector (ExtOPT).....Connect the cable for addition axis control.
- <14>RIO connector (RIO).....Connect the extension parallel input/output unit.
- <15>Option slotInstall the interface optional. (Install the cover, when not using.)
(SLOT1、SLOT2)

Caution

Use the network equipments (personal computer, USB hub, LAN hub, etc) confirmed by manufacturer. The thing unsuitable for the FA environment (related with conformity, temperature or noise) exists in the equipments connected to USB. When using network equipment, measures against the noise, such as measures against EMI and the addition of the ferrite core, may be necessary. Please fully confirm the operation by customer. Guarantee and maintenance of the equipment on the market (usual office automation equipment) cannot be performed.

3.3 Outside dimensions/Installation dimensions

3.3.1 Outside dimensions

(1) CR750 controller




Fig.3-3 : Outside dimensions of controller (CR750)

(2) CR751 controller




Fig.3-4 : Outside dimensions of controller (CR751: RV-4F/7F series)





Fig.3-5 : Outside dimensions of controller (CR751: RV-13F series)

3.3.2 Installation dimensions

(1) CR750 controller

<Placed horizontally>



<Placed vertically>




Fig.3-6 : Installation of controller (CR750)



CAUTION Fixing installation section sure for prevention from the fall, when using the controller placing vertically. The reference figure of the metal plate for fixing is shown in [Fig. 3-7](#). You should install the metal plate for fixation to the controller with M4 x 8 or the shorter screw. The screw projection length inside the controller (side board thickness is 1.2 mm) surely makes 6.8 mm or less.



CAUTION When storing the controller in a cabinet, etc., take special care to the heat radiating properties and ventilation properties so that the ambient temperature remains within the specification values. And, don't install the controller in the position where direct rays or the heat of lighting hits. The skin temperature of the controller may rise, and the error may occur.






Fig.3-7 : Metal plate for fixation to placing vertically (Reference for CR750)

(2) CR751 controller: RV-4F/7F series

<Placed horizontally>



<Placed vertically>




Fig.3-8 : Installation of controller (CR751: RV-4F/7F series)

⚠ CAUTION

Fixing installation section sure for prevention from the fall, when using the controller placing vertically. The reference figure of the metal plate for fixing is shown in Fig. 3-9. You should install the metal plate for fixation to the controller with M4 x 8 or the shorter screw. The screw projection length inside the controller (side board thickness is 1.2mm) surely makes 6.8mm or less.

⚠ CAUTION

When storing the controller in a cabinet, etc., take special care to the heat radiating properties and ventilation properties so that the ambient temperature remains within the specification values. And, don't install the controller in the position where direct rays or the heat of lighting hits. The skin temperature of the controller may rise, and the error may occur.






Fig.3-9 : Metal plate for fixation to placing vertically (Reference for CR751: RV-4F/7F series)

(3) CR751 controller: RV-13F series

<Placed horizontally>



<Placed vertically>





Fig.3-10 : Installation of controller (CR751: RV-13F series)

CAUTION

Fixing installation section sure for prevention from the fall, when using the controller placing vertically. The reference figure of the metal plate for fixing is shown in Fig. 3-11. You should install the metal plate for fixation to the controller with M4 x 8 or the shorter screw. The screw projection length inside the controller (side board thickness is 1.2mm) surely makes 6.8mm or less.

CAUTION

When storing the controller in a cabinet, etc., take special care to the heat radiating properties and ventilation properties so that the ambient temperature remains within the specification values. And, don't install the controller in the position where direct rays or the heat of lighting hits. The skin temperature of the controller may rise, and the error may occur.




Fig.3-11 : Metal plate for fixation to placing vertically (Reference for CR751: RV-13F series)

3.4 External input/output

3.4.1 Types

- (1) Dedicated input/output.....These inputs and outputs carry out the robot remote operation and status display.
- (2) General-purpose input/output.....These are inputs and outputs that the customer can program for peripheral device control.
- (3) Hand input/output.....These are inputs and outputs related to the hand that the customer can program.
- (4)Emergency stop/Door switch input.....The wiring for the safe security of the emergency stop etc. is shown in on [Page 92, "3.6 Emergency stop input and output etc."](#) and on [Page 162, "6.1.7 Examples of safety measures"](#).

<For Reference>

Linking our GOT1000 Series (GT15) display equipment to the robot controller over the Ethernet permits you to control robot controller's input/output from a GOT (graphic operation terminal).

3.5 Dedicated input/output

Show the main function of dedicated input/output in the **Table 3-2**. Refer to attached instruction manual "Detailed explanations of functions and operations" in the product for the other functions. Each parameter indicated with the parameter name is used by designated the signal No., assigned in the order of input signal No. and output signal No.

Table 3-2 : Dedicated input/output list

Parameter name	Input			Output	
	Name	Function	Level	Name	Function
TEACHMD	None			Teaching mode output signal	Outputs that the teaching mode is entered.
ATTOPMD	None			Automatic mode output signal	Outputs that the automatic mode is entered.
ATEXTMD	None			Remote mode output signal	Outputs that the remote mode is entered.
RCREADY	None			Controller power ON complete signal	Outputs that external input signals can be received.
AUTOENA	Automatic operation enabled input signal	Allows automatic operation.	L	Automatic operation enabled output signal	Outputs the automatic operation enabled state.
START	Start input signal	Starts all slots.	E	Operating output signal	Outputs that the slot is operating.
STOP	Stop input signal	Stops all slots. The input signal No. is fixed to 0. Note) Use the emergency stop input for stop inputs related to safety.	L	Wait output signal	Outputs that the slot is temporarily stopped.
STOP2	Stop input signal	The program during operation is stopped. Unlike the STOP parameter, change of the signal number is possible. Notes) Specification is the same as the STOP parameter.	L	Wait output signal	Outputs that the slot is temporarily stopped. Notes) Specification is the same as the STOP parameter.
SLOTINIT	Program reset input signal	Resets the wait state.	E	Program selection enabled output signal	Outputs that the slot is in the program selection enabled state.
ERRRESET	Error reset input signal	Resets the error state.	E	Error occurring output signal	Outputs that an error has occurred.
CYCLE	Cycle stop input signal	Carries out cycle stop.	E	In cycle stop operation output signal	Outputs that the cycle stop is operating.
SRVOFF	Servo ON enabled input signal	Turns the servo OFF for all mechanisms.	L	Servo ON enabled output signal	Outputs servo-on disable status. (Echo back)
SRVON	Servo ON input signal	Turns the servo ON for all mechanisms.	E	In servo ON output signal	Outputs the servo ON state.
IOENA	Operation rights input signal	Requests the operation rights for the external signal control.	L	Operation rights output signal	Outputs the operation rights valid state for the external signal control.
MELOCK	Machine lock input signal	Sets/resets the machine lock state for all mechanisms.	E	In machine lock output signal	Outputs the machine lock state.
SAFEPOS	Evasion point return input signal	Requests the evasion point return operation.	E	In evasion point return output signal	Outputs that the evasion point return is taking place.
OUTRESET	General-purpose output signal reset	Resets the general-purpose output signal.	E	None	
EMGERR	None			Emergency stop output signal	Outputs that an emergency stop has occurred.
S1START : S32START	Start input	Starts each slot.	E	In operation output	Outputs the operating state for each slot.

Parameter name	Input			Output	
	Name	Function	Level	Name	Function
S1STOP : S32STOP	Stop input	Stops each slot.	L	In wait output	Outputs that each slot is temporarily stopped.
PRGSEL	Program selection input signal	Designates the setting value for the program No. with numeric value input signals.	E		None
OVRDSEL	Override selection input signal	Designates the setting value for the override with the numeric value input signals.	E		None
IODATA Note2)	Numeric value input (start No., end No.)	Used to designate the program name, override value., mechanism value.	L	Numeric value output (start No., end No.)	Used to output the program name, override value., mechanism No.
PRGOUT	Program No. output request	Requests output of the program name.	E	Program No. output signal	Outputs that the program name is being output to the numeric value output signal.
LINEOUT	Line No. output request	Requests output of the line No.	E	Line No. output signal	Outputs that the line No. is being output to the numeric value output signal.
OVRDOUT	Override value output request	Requests the override output.	E	Override value output signal	Outputs that the override value is being output to the numeric value output signal.
ERROUT	Error No. output request	Requests the error No. output.	E	Error No. output signal	Outputs that the error No. is being output to the numeric value output signal.
JOGENA	Jog valid input signal	Validates jog operation with the external signals	E	Jog valid output signal	Outputs that the jog operation with external signals is valid.
JOGM	Jog mode input 2-bit	Designates the jog mode.	L	Jog mode output 2-bit	Outputs the current jog mode.
JOG+	Jog feed + side for 8-axes	Requests the + side jog operation.	L		None
JOG-	Jog feed - side for 8-axes	Requests the - side jog operation.	L		None
HNDCTL1 : HNDCTL3	None			Mechanism 1 hand output signal status : Mechanism 3 hand output signal status	Mechanism 1: Outputs the status of general-purpose outputs 900 to 907. Mechanism 2: Outputs the status of general-purpose outputs 910 to 917. Mechanism 3: Outputs the status of general-purpose outputs 920 to 927.
HNDSTS1 : HNDSTS3	None			Mechanism 1 hand input signal status : Mechanism 3 hand input signal status	Mechanism 1: Outputs the status of hand inputs 900 to 907. Mechanism 2: Outputs the status of hand inputs 910 to 917. Mechanism 3: Outputs the status of hand inputs 920 to 927.
HNDERR1 : HNDERR3	Mechanism 1 hand error input signal : Mechanism 3 hand error input signal	Requests the hand error occurrence.	L	Mechanism 1 hand error output signal : Mechanism 3 hand error output signal	Outputs that a hand error is occurring.

Parameter name	Input			Output	
	Name	Function	Level	Name	Function
AIRERR1 : AIRERR3	Pneumatic pressure error 1 input signal : Pneumatic pressure error 3 input signal	Request the pneumatic pressure error occurrence.	L	Pneumatic pressure error 1 output signal. : Pneumatic pressure error 3 output signal.	Outputs that a pneumatic pressure error is occurring.
M1PTEXC : M3PTEXC	None		L	Maintenance parts replacement time warning signal	Outputs that the maintenance parts have reached the replacement time.
USERAREA Note3)	None			User-designated area 8-points	Outputs that the robot is in the user-designated area.

Note1) The level indicates the signal level.

L: Level signal → The designated function is validated when the signal is ON, and is invalidated when the signal is OFF.

E: Edge signal → The designated function is validated when the signal changes from the OFF to ON state, and the function maintains the original state even when the signal then turns OFF.

Note2) Four elements are set in the order of input signal start No., end No., output signal start No. and end No.

Note3) Up to eight points can be set successively in order of start output signal No. and end output signal No.

3.6 Emergency stop input and output etc.

Do wiring of the external emergency stop, the special stop input, the door switch, and the enabling device from the "special input/output" terminal connector.

Table 3-3 : Special input/output terminal

Item	Name	Function
Input	Emergency stop	Applies the emergency stop. Dual emergency line
Input	Special stop input	Applies the stop. (Refer to Page 100, "3.6.2 Special stop input (SKIP)")
Input	Door switch	Servo-off. Dual line, normal close (Page 102, "3.6.3 Door switch function")
Input	Enabling device	Servo-off. Dual line, normal close (Page 102, "3.6.4 Enabling device function")
Output	Robot error output	Contactor is opening during error occurrence.
Output	Emergency stop output	The point of contact opens under occurrence of emergency stop of external input signal, emergency stop of OP, emergency stop of T/B.
Output	Mode output	MANUAL mode: contactor is opening, AUTOMATIC mode: contactor is closing.
Output	Magnet contactor control connector output for addition axes	When an additional axis is used, the servo ON/OFF status of the additional axis can be synchronized with the robot arm. (Page 110, "3.9 Magnet contactor control connector output (AXMC) for addition axes")

*At the time of the power supply OFF, the output point of contact is always open.

[Note] The contact capacity of each input/output terminal is DC24V/10mA – 100mA. Don't connect the equipment except for this range. The use exceeding contact capacity causes failure.

In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Pin number assignment of each terminal and the circuit diagram are shown in [Fig. 3-13 \(CR750\)](#) or [Fig. 3-17 \(CR751\)](#).

3.6.1 Connection of the external emergency stop

The external emergency stop input and door switch input and enabling device input are opened at shipment as shown in [Fig. 3-13 \(CR750\)](#) or [Fig. 3-17 \(CR751\)](#).

Connect the external emergency stop switch and door switch with the following procedure.

And, the example of the connection and notes of the emergency stop are described in [Page 162, "6.1.7 Examples of safety measures"](#) Refer to it together

[Caution] The emergency stop circuit is duplicated inside the controller. The emergency stop switch uses a double contact-type switch, so please be sure to fix both of the contacts to the connector pins as shown below in order to ensure the wiring is duplicated. An error will continue to occur in the event that only one of the pins is connected.

- 1) Please prepare the emergency stop switch, door switch and enabling device.
 - a) External emergency switch
 - CR750 controller CNUSR11 connector "between 3 and 4" and CNUSR12 Connector "between 3 and 4".
 - CR751 controller CNUSR1 connector "between 2 and 27" and "between 7 and 32".
 - b) Door switch
 - CR750 controller CNUSR11 connector "between 7 and 8" and CNUSR12 connector "between 7 and 8".
 - CR751 controller CNUSR1 connector "between 4 and 29" and "between 9 and 34".
 - c) Enabling device
 - CR750 controller CNUSR11 connector "between 9 and 10" and CNUSR12 connector "between 9 and 10".
 - CR751 controller CNUSR1 connector "between 5 and 30" and "between 10 and 35".

[Caution] Be sure to use a shield cable for the emergency stop wiring cable. And when operating in an environment that is easily affected by noise, be sure to fix the attached ferrite core (model number: E04SR301334, manufacturer: Seiya Electric Mfg. Co., Ltd.). Be sure to place the ferrite core more than 30 cm from the connecting terminal section.

⚠ CAUTION

Make sure there are no mistakes in the wiring. Connecting differently to the way specified in the manual can result in errors, such as the emergency stop not being released. In order to prevent errors occurring, please be sure to check that all functions (such as the teaching box emergency stop, customer emergency stop, and door switch) are working properly after the wiring setup is completed.

⚠ CAUTION

You should always connect doubly connection of the emergency stop, the door switch, and the enabling switch. In connection of only one side, if the relay of customer use should break down, it may not function correctly.

And, the output contacts from the robot controller (robot error output, emergency stop output, mode output, addition axis contactor control output) are dual contacts (synchronizes). You should connect surely by dual line with the customer's equipment as well as connection of the emergency stop and the door switch.

⚠ CAUTION

Please make sure to wire the multiple emergency stop switches so that they each function independently. Check and make sure that the emergency stop doesn't only function under an AND condition (when multiple emergency stop switches are ON at the same time).

(1) CR750 controller




Fig.3-12 : Emergency stop cable connection (CR750)




Fig.3-13 : External emergency stop connection (CR750)

CAUTION

Place the emergency stop switch in an easily operable position, and be sure to wire it to the emergency stop correctly by referencing [Page 162, "6.1.7 Examples of safety measures"](#).

This is a necessary measure in order to ensure safe operation so that the robot can be stopped immediately by pressing the emergency stop switch in the event that the robot malfunctions.




Fig.3-14 : Method of wiring for external emergency stop connection (CR750 (CNUSR11/12))


⚠ CAUTION

Makes sure that there is no mistake when connecting to the target connectors. Connecting incorrectly will result in the robot breaking down or malfunctioning. The connector on the controller side that connects to the user wiring connector is CNUSR11 or CNUSR12. Be careful not to connect to CNUSR13 as the robot will not operate properly.

<CR750 controller>

CNUSR2 connector

* The controller is an example.

Connection procedure

Solder the pins of the user wiring connector that accompanies the product, and connect the connector to the CNUSR2 connector at the back of the controller. For the connection cables, please use AWG #30 to 24 (0.05 to 0.2mm²).

- 1) Loosen the two fixing screws on the user wiring connector that accompanies the product, and remove the connector cover.
- 2) Peel the insulation of the connecting cable to 3mm, and solder it to the appropriate connector pin number.
- 3) After the necessary cables have been soldered, re-fix the connector cover using the same fixing screws and make sure it is fastened securely.
- 4) Connect the connector to the corresponding connector (CNUSR2) on the controller. With pin number 1 facing to the upper right, insert firmly until you hear the connector's latch click in to place.

This concludes the connection procedure.

Fig.3-15 : Method of wiring for external emergency stop connection (CR750 (CNUSR2))

⚠ CAUTION

When soldering please take care to only connect to the specified pin number. Connecting to a different pin number or short-circuiting with another pin will result in the robot breaking down or malfunctioning.

(2) CR751 controller




Fig.3-16 : Emergency stop cable connection (CR751)




Fig.3-17 : External emergency stop connection (CR751)



Place the emergency stop switch in an easily operable position, and be sure to wire it to the emergency stop correctly by referencing [Page 162, "6.1.7 Examples of safety measures"](#).

This is a necessary measure in order to ensure safe operation so that the robot can be stopped immediately by pressing the emergency stop switch in the event that the robot malfunctions.




Fig.3-18 : Method of wiring for external emergency stop connection (CR751 (CNUSR1/2))



CAUTION

When soldering please take care to only connect to the specified pin number. Connecting to a different pin number or short-circuiting with another pin will result in the robot breaking down or malfunctioning.

The connectors on the controller side are CNUSR1 (upper side) and CNUSR2 (lower side). Make sure that there is no mistake when connecting to the target connectors. Connecting incorrectly will result in the robot breaking down or malfunctioning.


3.6.2 Special stop input (SKIP)

The skip is the input signal to stop the robot. The pin 9, 34 of the CNUSR2 connector shown in Fig. 3-19 (CR750) or Fig. 3-20 (CR751).

Table 3-4 : Special stop input electric specification

Item	Specifications	Internal circuit
Type	DC input	
No. of input point	1	
Insulation method	Photo-coupler insulation	
Rated input voltage	DC24V	
Rated input current	Approx. 11mA	
Working voltage range	DC 21.6 ~ 26.4V (Ripple rate within 5%)	
ON voltage/ON current	DC 8V or more / 2mA or more	
OFF voltage/OFF current	DC 4V or less / 1mA or less	
Input resistance	Approx. 2.2 k Ω	
Response time	OFF → ON 1ms or less	
	ON → OFF 1ms or less	
Common method	1 point per common	
External wire connection method	Connector	


(1) CR750 controller



Note) In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Fig.3-19 : Connection of the special-stop-input (CR750)

(2) CR751 controller



Note) In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Fig.3-20 : Connection of the special-stop-input (CR751)

3.6.3 Door switch function

This function retrieves the status of the switch installed on the door of the safety fence, etc., and stops the robot when the door is opened. This differs from an emergency stop in that the servo turns OFF when the door is opened and an error does not occur. Follow the wiring example shown in [Page 94 "Fig. 3-13: External emergency stop connection \(CR750\)"](#) or [Page 98 "Fig. 3-17: External emergency stop connection \(CR751\)"](#), and [Page 162, "6.1.7 Examples of safety measures"](#). Those figure explains the wire is contact closes when the door is closed.

Details of this function according to the robot status are shown below.

*During automatic operation When the door is opened, the servo turns OFF and the robot stops. An error occurs. The process of the restoration: Close the door, reset the alarm, turn on the servo, and restart

*During teaching..... Even when the door is opened, the servo can be turned ON and the robot moved using the teaching pendant.




Fig.3-21 : Door switch function

3.6.4 Enabling device function

When the abnormalities occur in teaching operations etc., the robot's servo power can be immediately cut only by switch operation of the enabling device^{*1)} (servo-off), and the safety increases. To use the robot safely, please be sure to connect the enabling device.

(1) When door is opening

Please do teaching by two-person operations. One person has T/B, the other has enabling device. Turn on the servo power, in the condition that both of switches are pushed. (Enable switch of T/B and enabling device) Then the jog operation will be available. You can off the servo power only by releasing the switch of the enabling device. And, care that the servo-on and releasing the brake cannot be done in the condition that the switch of the enabling device is released.

(2) When door is closing

You can turn on the servo power by operation of only T/B. In this case perform jog operation outside the safeguard sure.

*1) Recommendation products: HE1G-L20MB (IDEK)

(3) Automatic Operation/Jog Operation/Brake Release and Necessary Switch Settings

The following is a description of various operations performed on the robot and switch settings that are required.

Table 3-5 : Various operations and necessary switch settings

No	Operation	Related switch settings <small>Note1)</small>					Description
		Mode of controller	T/B enable/disable	T/B enable switch	Enabling device input terminal	Door switch input terminal	
1	Jog operation	Manual	Enable	ON	Close(ON)	—	If the enabling device input is set to Close (On), the state of door switch input does not matter.
2	Jog operation <small>Note2)</small>	Manual	Enable	ON	Open(OFF)	Close (Door Close)	If the enabling device input is set to Open (Off), door switch input must be in a state of Close
3	Brake release <small>Note3)</small>	Manual	Enable	ON	Close(ON)	—	Irrespective of the state of door switch input, enabling device input must be in a state of Close (On).
4	Automatic operation	Automatic	Disable	—	—	Close (Door Close)	Door switch input must always be in a state of Close (Door Close).

Note1) “—” in the table indicates that the state of switch concerned does not matter.

Refer to the following for operation of each switch.

- Mode of CR750 controller: [Page 74, "3.2 Names of each part"](#)
- Mode of CR751 controller: [Page 104, "3.7 Mode changeover switch input"](#)
- T/B enable/disable: [Page 113, "\(1\) Teaching pendant \(T/B\)"](#)
- T/B enable switch: [Page 113, "\(1\) Teaching pendant \(T/B\)"](#)
- Enabling device input terminal: [Page 162, "6.1.7 Examples of safety measures"](#)
- Door switch input terminal: [Page 162, "6.1.7 Examples of safety measures"](#)

Note2) Jog operation, if door switch input is set for Close (Door Close), must be performed outside the safety barrier.

Note3) It is imperative that brake release operation be carried out by two persons. One person turns on the enabling device (“Close” on the enabling device input terminal) while the other manipulates the T/B. Brake release can be effected only when both of the enabling switch device and the T/B enable switch are placed in intermediate position (lightly gripped position). At this point, the state of door switch input does not matter.




Fig.3-22 : Brake release operation

3.7 Mode changeover switch input

Connect the key switch of customer prepared and change the right of robot's operation by switch operation.

The key switch can be installed in the operation panel of customer preparation.

<Right of operation (mode)>

AUTOMATIC The operation from external equipment becomes available. Operation which needs the right of operation from T/B cannot be performed. It is necessary to set the parameter for the rights of operation to connection with external equipment. Refer to the separate volume, "Instruction Manual/Detailed Explanation of Functions and Operations" for detail.

MANUAL When T/B is available, only the operation from T/B becomes available. Operation which needs the right of operation from external equipment cannot be performed.




Fig.3-23 : Mode changeover switch image figure (CR751)

(1) Specification of the key switch interface

The function and specification of the key switch interface are shown below.

Table 3-6 : Function of the key switch interface

Pin number and Function (Connector: CNUSR1)		Change mode Note1)	
Pin number	Function	MANUAL	AUTOMATIC
49	1st line KEY input	Open	Close
24	Power supply +24V of pin number 49		
50	2nd line KEY input	Open	Close
25	Power supply +24V of pin number 50		

Note1) The mode changes by both opening or both closing between 49–24 pin and between 50–25 pin.


When input states differ between two lines, error H0044 (OP Mode key line is faulty) will occur.

[Note] In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Table 3-7 : Specification of the mode changeover switch input

Item	Specification	Remarks
Rated voltage	DC24V	Supply from the controller.
Current rating	Approx. 10mA	Select the switch or button which operates normally in 24V/10mA.
Input resistance	Approx. 2.2kΩ	
Response time (OFF→ON)	Approx. 15ms	Example: The response time the program starts, after pushing the run button.
Common method	1 point per common	
Connection method	Connector	
Conformity electric wire size	AWG#24 to #18	0.2 to 0.75mm ²
Maker/Type	-	Maker: PHOENIX CONTACT/ Type: FKC2.5/4-STF-5.0B

(2) Connection of the mode changeover switch input

Connection procedure

Solder the user wiring connector that accompanies the product to the corresponding pin, and connect it to the CNUSR1 connector at the back of the controller. For the connection cable, please use AWG #30 to 24 (0.05 to 0.2mm²).

- 1) Loosen the 2 fixing screws on the user wiring connector that accompanies the product, and remove the connector cover.
- 2) Peel the insulation of the connecting cable to 3mm, and solder it to the appropriate connector pin number.
- 3) After the necessary cable has been soldered, re-fix the connector cover using the same fixing screws and make sure it is fastened securely.
- 4) Connect the connector to the corresponding connector (CNUSR1) on the controller. With pin number 1 facing to the upper right, insert firmly until you hear the connector's latch click into place.

This concludes the connection procedure.

Fig.3-24 : Connection of the mode changeover switch input (CR751)

3.8 Additional Axis Function

This controller is equipped with an additional axis interface for controlling an additional axis when a traveling axis or rotary table is added to the robot. A maximum of eight axes of servo motors can be controlled at the same time by connecting a general-purpose servo amplifier (MR-J3-B, MR-J4-B series) that supports Mitsubishi's SSCNET III. Refer to the separate "Additional axis interface Instruction Manual" for details on the additional axis function.

3.8.1 Wiring of the Additional Axis Interface

Table 3-8 shows the connectors for additional axes inside the controller. [Fig. 3-25 \(CR750\)](#) and [Fig. 3-26 \(CR751\)](#) shows a connection example (configuration example).

Table 3-8 : Dedicated connectors inside the controller

Name	Connector name	Details
Connector for additional axes	ExtOpt	The connector for connecting the general-purpose servo amplifier.

(1) CR750 controller




Fig.3-25 : Example of addition axis connection (CR750)

(2) CR751 controller




Fig.3-26 : Example of addition axis connection (CR751)

(3) Example of the installation of the noise filter

1) EMC filter (recommended)


Please install the recommendation filter shown below according to the example of connection.

1) Combination with the servo amplifier

Servo amplifier	Recommended filter (Soshin Electric)		Mass [kg]([lb])
	Model	Leakage current [mA]	
MR-J3-10B to MR-J3-100B	(Note) HF3010A-UN	5	3 (6.61)
MR-J3-10B1 to MR-J3-40B1			5.5 (12.13)
MR-J3-250B • MR-J3-350B	(Note) HF3030A-UN	1.5	6.0 (13.23)
MR-J3-500B • MR-J3-700B			6.5
MR-J3-11KB to MR-J3-22KB	(Note) HF3100A-UN	6.5	15 (33.07)
MR-J3-60B4 • MR-J3-100B4			6(13.23)
MR-J3-200B4 to MR-J3-700B4	TF3005C-TX	5.5	
MR-J3-11KB4	TF3020C-TX	7.5(16.54)	
MR-J3-15KB4	TF3030C-TX	12.5(27.56)	12.5(27.56)
MR-J3-22KB4	TF3040C-TX		
	TF3060C-TX		

Note. A surge protector is separately required to use any of these EMC filters.

2) Connection example



Note1) For 1-phase 200V to 230VAC power supply, connect the power supply to L1, L2 and leave L3 open.

There is no L3 for 1-phase 100 to 120 VAC power supply.

Note2) The example is when a surge protector is connected.

Fig.3-27 : Example of EMC noise filter installation

2) Line noise filter

This filter is effective in suppressing noises radiated from the power supply side and output side of the servo amplifier and also in suppressing high-frequency leakage current (zero-phase current) especially within 0.5MHz to 5MHz band.

Connection diagram	Outline drawing [Unit: mm]
<p>Use the line noise filters for wires of the main power supply ($L_1 \cdot L_2 \cdot L_3$) and of the motor power supply ($U \cdot V \cdot W$). Pass each of the 3-phase wires through the line noise filter an equal number of times in the same direction. For the main power supply, the effect of the filter rises as the number of passes increases, but generally four passes would be appropriate. For the motor power supply, passes must be four times or less. Do not pass the grounding (earth) wire through the filter, or the effect of the filter will drop. Wind the wires by passing through the filter to satisfy the required number of passes as shown in Example 1. If the wires are too thick to wind, use two or more filters to have the required number of passes as shown in Example 2. Place the line noise filters as close to the servo amplifier as possible for their best performance.</p> <p>Example 1</p> <p>Example 2</p>	<p>FR-BSF01 (for wire size 3.5mm^2 (AWG12) or less)</p> <p>FR-BLF(for wire size 5.5mm^2 (AWG10) or more)</p>

Fig.3-28 : Example of noise filter installation

3.9 Magnet contactor control connector output (AXMC) for addition axes


When an additional axis is used, the servo ON/OFF status of the additional axis can be synchronized with the servo ON/OFF status of the robot itself by using the output contact (AXMC) provided on the rear or inside of the controller and configuring a circuit so that the power to the servo amplifier for the additional axis can be turned off when this output is open.

An example circuit is shown Fig. 3-29. An image of how to connect the controller connector are shown Fig. 3-30 and Fig. 3-31.

When you are using an additional axis, please perform appropriate circuit connections by referring to these drawings.

Refer to the separate "Additional axis interface Instruction Manual" for details on the additional axis function.


Note1) If you use the addition axis function as a user mechanism who became independent of the robot arm, please do not connect this output signal. Servo-on of the user mechanism may be unable.



[Note] In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Fig.3-29 : Example of circuit for addition axes of Magnet contactor control output


(1) CR750 controller



*Connects with CNUSR2 connector
with soldering. Refer to [Page 96 "Fig. 3-15: Method of wiring for external emergency stop connection \(CR750 \(CNUSR2\)\)".](#)

Fig.3-30 : AXMC terminal connector (CR750)

(2) CR751 controller



* The CNUSR2 connector is connected by soldering. Refer to [Page 99 "Fig. 3-18: Method of wiring for external emergency stop connection \(CR751 \(CNUSR1/2\)\)".](#)

Fig.3-31 : AXMC terminal connector (CR751)

3.10 Options

■ What are options?

There are a variety of options for the robot designed to make the setting up process easier for user needs.

User installation is required for the options.

Options come in two types: "set options" and "single options".

1. Set options.....A combination of single options and parts that together, form a set for serving some purpose.
2. Single options.....That are configured from the fewest number of required units of a part.
Please choose user's purpose additionally.

(1) Teaching pendant (T/B)

- Order type: CR750 controller ● R32TB: Cable length 7m
● R32TB-15: Cable length 15m
- CR751 controller ● R33TB: Cable length 7m
● R33TB-15: Cable length 15m

■ Outline



This is used to create, edit and control the program, teach the operation position and for jog feed, etc.

For safety proposes, a 3-position enable switch is mounted.*1)

■ Configuration

Table 3-9 : Configuration device

Part name	Type	Qty.	Mass (kg) Note1)	Remarks
CR750 controller				
Teaching pendant	R32TB	Either one pc.	1.7	Cable length is 7m. Hand strap is attached.
	R32TB-15		2.8	Cable length is 15m. Hand strap is attached.
CR751 controller				
Teaching pendant	R33TB	Either one pc.	1.7	Cable length is 7m. Hand strap is attached.
	R33TB-15		2.8	Cable length is 15m. Hand strap is attached.

Note1) Mass indicates one set.

■ Specifications

Table 3-10 : Specifications

Items	Specifications	Remarks
Outline dimensions	195(W) x 292(H) x 106(D) (refer to outline drawing)	
Body color	Dark gray	
Mass	Approx. 0.9kg (only arm, excluding cable)	
Connection method	Connection with controller and connector.	
Interface	RS-422	
Display method	LCD method: 24 characters x 8 lines, LCD illumination: with backlight	At 8x8 font
Operation section	36 keys	

*1) <3-position enable switch>

In ISO/10218 (1992) and JIS-B8433 (1993), this is defined as an "enable device". These standards specify that the robot operation using the teaching pendant is enabled only when the "enable device" is at a specified position. With the Mitsubishi Electric industrial robot, the above "enable device" is configured of an "Enable/Disable switch" and "Enable switch".

The 3-position enable switch has three statuses. The following modes are entered according to the switch state.

- a) "Not pressed" The robot does not operate. *)
- b) "Pressed lightly" The robot can be operated and teaching is possible.
- c) "Pressed with force" The robot does not operate. *)

*) Operations, such as program editing and status display, other than robot operation are possible.

Safety is secured as the servo power is turned OFF simultaneously with the input of the emergency stop.




Fig.3-32 : Outside dimensions of teaching pendant

■ Installation method

The teaching pendant is connected to the T/B connector on the front of the controller.

■ Key layout and main functions



Fig.3-33 : Teaching pendant key layout and main functions

(2) Parallel I/O interface

- Order type : ● 2D-TZ368 (Sink type)/2D-TZ378 (Source type)

- Outline



This is used to expand the external inputs and outputs

- The connecting cable with external equipment is not attached. Since we are preparing the external input-and-output cable (2D-CBL05 or 2D-CBL15) as the option, please use.

Notes) Although the combined use with the parallel input-and-output unit (2A-RZ361/2A-RZ371) of another option is also possible, please use the setup of the station number by the different number separately. The station number is automatically determined by the position of the option slot which installed this interface. (station number 0 to 1)

- Configuration

Table 3-11 : Configuration device

Part name	Type	Qty.	Mass (kg) Note1)	Remarks
Parallel I/O interface	2D-TZ368	Either one pc.	0.4	Input/output 32 points/32 points 2D-TZ368 is sink type. 2D-TZ378 is source type.
	2D-TZ378			

Note1) Mass indicates one set.

- Specifications

Table 3-12 : Electrical specifications of input circuits

Item	Specification		Internal circuit	
Type	DC input		<p>The table contains two detailed circuit diagrams. The first diagram, labeled <Sink type>, shows a AC input connected to a diode and a resistor (820 ohms). The output goes through a 2.7K ohm pull-up resistor to +24V/+12V (COM). The second diagram, labeled <Source type>, shows a AC input connected to a diode and a resistor (820 ohms). The output goes through a 2.7K ohm pull-down resistor to ground, with a 24G/12G connection point.</p>	
Number of input points	32			
Insulation method	Photo coupler insulation			
Rated input voltage	DC12V	DC24V		
Rated input current	Approx. 3mA	Approx.9mA		
Working voltage range	DC10.2 ~ 26.4V (Ripple factor should be less than 5%)			
ON voltage/ON current	DC8V or more/2mA or more			
OFF voltage/OFF current	DC4V or less/1mA or less			
Input resistance	Approx. 2.7k Ω			
Response time	OFF-ON	10ms or less(DC24V)		
	ON-OFF	10ms or less(DC24V)		
Common method	32 points per common			
External cable connection method	Connector			

Table 3-13 : Electrical specifications for the output circuits

Item		Specification	Internal circuit
Type		Transistor output	⟨Sink type⟩
No. of output points	32		
Insulation method		Photo-coupler insulation	
Rated load voltage		DC12V/DC24V	
Rated load voltage range		DC10.2 ~ 30V (peak voltage DC30V)	
Max. load current		0.1A/point (100%)	
Leakage current at OFF		Within 0.1mA	
Max. voltage drop at ON		DC0.9V(TYP.) Note1)	
Response time	OFF-ON	10ms or less(Resistance load) (hardware response time)	
	ON-OFF	10ms or less(Resistance load) (hardware response time)	
Fuse rating		Fuse 1.6A(one per common) Replacement possible (max. 3)	
Common method		16 points per common (common terminal: 2points)	⟨Source type⟩
External wire connection method		Connector	
External power supply	Voltage	DC12/24V(DC10.2 ~ 30V)	
	Current	60mA(TYP.DC24V per common)(base drive current)	

Note1) The maximum voltage drop value at signal ON.

Refer to it for the equipment connected to the output circuit.

Caution

The protection fuse of the output circuit prevents the failure at the time of the load short circuit and incorrect connection. The load connected of the customer should be careful not to exceed maximum rating current. The internal transistor may be damaged if maximum rating current is exceeded.

■ Installation method

The expansion parallel input/output interface is installed in the controller. Refer to separate "Instruction Manual/Controller setup, basic operation, and maintenance" for details on the installing method.

If it installs in the option SLOT of the controller, the station number will be assigned automatically.

SLOT1: station number 0 (0 to 31)

SLOT2: station number 1 (32 to 63)

Caution

If it uses together with parallel input-and-output unit 2A-RZ361/2A-RZ371, please do not overlap with the station number of the parallel input-and-output interface.

<CR750 controller>




Fig.3-34 : Parallel I/O interface installation position (CR750)




Fig.3-35 : Parallel I/O interface installation position (CR751)

■ Pin layout of connector




Fig.3-36 : Pin layout of connector

■ Connector pin No. and signal assignment

The station number is fixed by the slot to install and the allocation range of the general-purpose input-and-output signal is fixed.

Table 3-14 : The slot number and the station number

Slot number	Station number	Range of the general-purpose input-and-output signal	
		Connector <1>	Connector <2>
SLOT1	0	Input : 0 to 15 Output : 0 to 15	Input : 16 to 31 Output : 16 to 31
SLOT2	1	Input : 32 to 47 Output : 32 to 47	Input : 48 to 63 Output : 48 to 63

The connector pin number of the parallel input-and-output interface installed in SLOT1 and signal number allocation are shown in [Table 3-15](#) and [Table 3-16](#). If it installs in other slots, please interpret and utilize.

Table 3-15 : Connector<1> pin assignment list and external I/O cable (2D-CBL**) color(SLOT1)

Pin No.	Line color	Function name		Pin No.	Line color	Function name	
		General-purpose	Dedicated/power supply, common			General-purpose	Dedicated/power supply, common
1C	Orange/Red a		24G/12G: For pins 5D–20D	1D	Orange/Black a		+24V/+12V(COM): For pins 5D–20D
2C	Gray/Red a		COM : For pins 5C–20C ^{Note1)}	2D	Gray/Black a		Reserved
3C	White/Red a		Reserved	3D	White/Black a		Reserved
4C	Yellow/Red a	General-purpose input 15	Reserved	4D	Yellow/Black a		Reserved
5C	Pink/Red a			5D	Pink/Black a	General-purpose output 15	
6C	Orange/Red b	General-purpose input 14		6D	Orange/Black b	General-purpose output 14	
7C	Gray/Red b	General-purpose input 13		7D	Gray/Black b	General-purpose output 13	
8C	White/Red b	General-purpose input 12		8D	White/Black b	General-purpose output 12	
9C	Yellow/Red b	General-purpose input 11		9D	Yellow/Black b	General-purpose output 11	
10C	Pink/Red b	General-purpose input 10		10D	Pink/Black b	General-purpose output 10	
11C	Orange/Red c	General-purpose input 9		11D	Orange/Black c	General-purpose output 9	
12C	Gray/Red c	General-purpose input 8		12D	Gray/Black c	General-purpose output 8	
13C	White/Red c	General-purpose input 7		13D	White/Black c	General-purpose output 7	
14C	Yellow/Red c	General-purpose input 6		14D	Yellow/Black c	General-purpose output 6	
15C	Pink/Red c	General-purpose input 5	Operation rights input signal ^{Note2)}	15D	Pink/Black c	General-purpose output 5	
16C	Orange/Red d	General-purpose input 4	Servo ON input signal ^{Note2)}	16D	Orange/Black d	General-purpose output 4	
17C	Gray/Red d	General-purpose input 3	Start input Note2)	17D	Gray/Black d	General-purpose output 3	Operation rights output signal ^{Note2)}
18C	White/Red d	General-purpose input 2	Error reset input signal ^{Note2)}	18D	White/Black d	General-purpose output 2	Error occurring output signal ^{Note2)}
19C	Yellow/Red d	General-purpose input 1	Servo OFF input signal ^{Note2)}	19D	Yellow/Black d	General-purpose output 1	In servo ON output signal ^{Note2)}
20C	Pink/Red d	General-purpose input 0	Stop input Note3)	20D	Pink/Black d	General-purpose output 0	Operating output ^{Note2)}

Note1) Sink type: +24V/+12V(COM), Source type: 24G/12G

Note2) The dedicated signal is assigned at shipping. It can change with the parameter.

Note3) The dedicated input signal (STOP) is assigned at shipping. The signal number is fixing.

Table 3-16 : Connector<2> pin assignment list and external I/O cable (2D-CBL**) color(SLOT1)

Pin No.	Line color	Function name		Pin No.	Line color	Function name	
		General-purpose	Dedicated/power supply, common			General-purpose	Dedicated/power supply, common
1A	Orange/Red a		24G/12G: For pins 5B–20B	1B	Orange/Black a		+24V/+12V(COM): For pins 5B–20B
2A	Gray/Red a		COM : For pins 5A–20A ^{Note1)}	2B	Gray/Black a		Reserved
3A	White/Red a		Reserved	3B	White/Black a		Reserved
4A	Yellow/Red a		Reserved	4B	Yellow/Black a		Reserved
5A	Pink/Red a	General-purpose input 31		5B	Pink/Black a	General-purpose output 31	
6A	Orange/Red b	General-purpose input 30		6B	Orange/Black b	General-purpose output 30	
7A	Gray/Red b	General-purpose input 29		7B	Gray/Black b	General-purpose output 29	
8A	White/Red b	General-purpose input 28		8B	White/Black b	General-purpose output 28	
9A	Yellow/Red b	General-purpose input 27		9B	Yellow/Black b	General-purpose output 27	
10A	Pink/Red b	General-purpose input 26		10B	Pink/Black b	General-purpose output 26	
11A	Orange/Red c	General-purpose input 25		11B	Orange/Black c	General-purpose output 25	
12A	Gray/Red c	General-purpose input 24		12B	Gray/Black c	General-purpose output 24	
13A	White/Red c	General-purpose input 23		13B	White/Black c	General-purpose output 23	
14A	Yellow/Red c	General-purpose input 22		14B	Yellow/Black c	General-purpose output 22	
15A	Pink/Red c	General-purpose input 21		15B	Pink/Black c	General-purpose output 21	
16A	Orange/Red d	General-purpose input 20		16B	Orange/Black d	General-purpose output 20	
17A	Gray/Red d	General-purpose input 19		17B	Gray/Black d	General-purpose output 19	
18A	White/Red d	General-purpose input 18		18B	White/Black d	General-purpose output 18	
19A	Yellow/Red d	General-purpose input 17		19B	Yellow/Black d	General-purpose output 17	
20A	Pink/Red d	General-purpose input 16		20B	Pink/Black d	General-purpose output 16	

Note1) Sink type: +24V/+12V(COM), Source type: 24G/12G

<Reference> The example of connection with our PLC




Table 3-17 : Connection with a Mitsubishi PLC (Example of sink type)




Table 3-18 : Connection with a Mitsubishi PLC (Example of source type)

(3) External I/O cable

■ Order type : ● 2D-CBL □□ Note) The numbers in the boxes □□ refer to the length. (05: 5m, 15: 15m)

■ Outline



This is the dedicated cable used to connect an external peripheral device to the connector on the parallel I/O interface. For parallel I/O unit is another option 2A-CBL.**. One end matches the connector on the parallel input/output unit, and the other end is free. Connect the peripheral device's input/output signal using the free end. One cable correspond to the input 16 points and output 16 points. Two cables are needed to connection of (input 32 points and output 32 points) with built-in standard.

■ Configuration

Table 3-19 : Configuration device

Part name	Type	Qty.	Mass (kg) Note1)	Remarks
External I/O cable	2D-CBL □□	1 pc.	0.7(5m) 1.84(15m)	5m or 15m

Note1) Mass indicates one set.

■ Specifications

Table 3-20 : Specifications

Items	Specifications
Number of cables x cable size	AWG #28 x 20P (40 pairs)
Total length	5m, 15m

■ Connector pin numbers and cable colors

Table 3-21 : Connector pin numbers and cable colors

Pin no.	Cable colors	Pin no.	Cable colors	Pin no.	Cable colors	Pin no.	Cable colors
1A/C	Orange/Red a	11A/C	Orange/Red c	1B/D	Orange/Black a	11B/D	Orange/Black c
2A/C	Gray/Red a	12A/C	Gray/Red c	2B/D	Gray/Black a	12B/D	Gray/Black c
3A/C	White/Red a	13A/C	White/Red c	3B/D	White/Black a	13B/D	White/Black c
4A/C	Yellow/Red a	14A/C	Yellow/Red c	4B/D	Yellow/Black a	14B/D	Yellow/Black c
5A/C	Pink/Red a	15A/C	Pink/Red c	5B/D	Pink/Black a	15B/D	Pink/Black c
6A/C	Orange/Red b	16A/C	Orange/Red d	6B/D	Orange/Black b	16B/D	Orange/Black d
7A/C	Gray/Red b	17A/C	Gray/Red d	7B/D	Gray/Black b	17B/D	Gray/Black d
8A/C	White/Red b	18A/C	White/Red d	8B/D	White/Black b	18B/D	White/Black d
9A/C	Yellow/Red b	19A/C	Yellow/Red d	9B/D	Yellow/Black b	19B/D	Yellow/Black d
10A/C	Pink/Red b	20A/C	Pink/Red d	10B/D	Pink/Black b	20B/D	Pink/Black d


Notes) Pin number of connector<1> are 1C, 2C, ..., 20C, 1D, 2D, ..., 20D, connector<2> are 1A, 2A, ..., 20A, 1B, 2B, ..., 20B.

■ Connections and outside dimensions

The sheath of each signal cable (40 lines) is color indicated and marked with dots. Refer to the cable color specifications in “[Table 3-32: Connector pin numbers and cable colors](#)” when making the connections.

(Eg.) Pin number: color indication


1 : Orange / Red / a



Line color type


Pattern of the print mark

a type




One dot

b type



Two dots

c type




Three dots

d type



Four dots



Plug (Fujitsu Ltd) Connector : FCN-361J040-AU
Cover : FCN-360C040-B

Fig.3-37 : Connections and outside dimensions

(4) Parallel I/O unit

- Order type: 2A-RZ361(Sink type)
2A-RZ371(Source type)

■ Outline



This is used to expand the external inputs and outputs. One one equal with this unit is built into the control unit among controllers the standard.

- The connection cable is not included. Prepare the optional external input/output cable (2A-CBL05 or 2A-CBL15).
- Use 2A-RZ361 if the external input/output signal logic is of the sink type and 2A-RZ371 for source type signal logic.

Notes) Although the combined use with the parallel I/O interface (2D-TZ368) of another option is also possible, please use the setup of the station number by the different number separately. The station number is automatically fixed by the position of the option slot which installed the parallel I/O interface in 0-1.

■ Configuration

Table 3-22 : Configuration device

Part name	Type	Qty.	Mass (kg) Note1)	Remarks
Parallel I/O unit	2A-RZ361	Either one pc.	0.7	Input/output 32 points/32 points 2A-RZ361 is the sink type. 2A-RZ371 is the source type.
	2A-RZ371		0.7	
Robot I/O link connection connector	NETcable-1	2 sets	–	Connector with pins. The cable must be prepared and wired by the customer.
Power connection connector	DCcable-2	1 set	–	Connector with pins. The cable must be prepared and wired by the customer.
Terminator	R-TM	1 pc.	–	100Ω(1/4W)

Note1) Mass indicates one set.

■ Specifications

- 1) The parallel I/O interface (2D-TZ368) of another option, and the a maximum of eight pieces in all. (One station occupies one unit.)
- 2) The power supply (24V) must be prepared by the customer and connected with the power connection cable (DCcable-2)
A separate 24V power supply is required for the input/output circuit wiring.

Table 3-23 : Electrical specifications of input circuits

Item	Specification		Internal circuit
Type	DC input		<Sink type>
Number of input points	32		+24V/+12V (COM)
Insulation method	Photo coupler insulation		Input
Rated input voltage	12VDC	24VDC	3.3K
Rated input current	Approx 3mA	Approx 7mA	820
Working voltage range	10.2 to 26.4VDC(Ripple factor should be less than 5%).		
ON voltage/ON current	8VDC or more/ 2mA or more		
OFF voltage/ OFF current	4VDC or less/ 1mA or less		
Input resistance	Approx. 3.3kΩ		
Response time	OFF-ON	10ms or less (24VDC)	<Source type>
	ON-OFF	10ms or less (24VDC)	3.3K
Common method	8 points per common		820
External cable connection method	Connector		24G/12G

Table 3-24 : Electrical specifications for the output circuits

Item		Specification	Internal circuit
Type		Transistor output	<Sink type>
No. of output points		32	+24V/+12V Output 24G/12G Fuse
Insulation method		Photo-coupler insulation	
Rated load voltage		12VDC/24VDC	
Rated load voltage range		10.2 to 30VDC(peak voltage 30VDC)	
Max. load current		0.1A/point (100%)	
Leakage current at OFF		0.1mA or less	
Max. voltage drop at ON		0.9VDC(TYP.) Note1)	
Response time	OFF-ON	2ms or less (hardware response time)	<Source type>
	ON-OFF	2ms or less (Resistance load) (hardware response time)	Fuse +24V/+12V Output 24G/12G
Fuse rating		Fuse 3.2A (one per common) Replacement not possible	
Common method		8 points per common (common terminal: 4 points)	
External wire connection method		Connector	
External power supply	Voltage	12VDC/24VDC(10.2 to 30VDC)	
	Current	60mA (TYP. 24VDC per common) (base drive current)	

Note1) The maximum voltage drop value at signal ON.

Refer to it for the equipment connected to the output circuit.


⚠ CAUTION

The output circuit protective fuses prevent failure in case of load short-circuit and improper connections. Please do not connect loads that cause the current to exceed the maximum rated current. If the maximum rated current is exceeded, the internal transistors may be damaged.


⚠ CAUTION

Inputs the power supply for control (DCcable-2) then inputs the controller's power supply.


NETcable-1 (Network cable)



DCcable-2 (Power cable)



R-TM (Terminator)



List of parts and manufacturer

Type	Connector type	Contact type	Resistant	Manufacturer
NETcable-1	1-178288-3 (2)	1-175218-2 (6)	—	Tyco Electronics (Black connector)
	51103-0300 (1)	50351-8100 (3)	—	MOLEX (White connector)
DCcable-2	2-178288-3 (1)	1-175218-5 (3)	—	Tyco Electronics (Black connector)
R-TM	1-178288-3 (1)	1-175218-3 (2)	100Ω(1/4W) (1)	Equivalent to KOA.

Note 1) The 24V power supply is prepared by customer (The power consumption is approx. 0.3A.)

In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

Note 2) The cable for general purpose can be used to the network cable. However, use the twisted shield cable of AWG#22(0.3mm²) or more.

Fig.3-38 : Specifications for the connection cable

■ Installation method

The expansion parallel input/output unit is installed outside of the controller. Connect with the network connection cable (NETcable-1) from the RIO connector in the rear/into of the controller.(Terminator is connected at the time of shipment)

<CR750 controller>





Fig.3-39 : Installing the parallel I/O unit (CR750)

<CR751 controller>



RIO connector


Installation dimensions of 2A-RZ361/2ARZ-371 (The controller outside installation.)

Fig.3-40 : Installing the parallel I/O unit (CR751)




Fig.3-41 : Connection method of expansion parallel I/O unit (CR750)





Fig.3-42 : Connection method of expansion parallel I/O unit (CR751)

■ Pin arrangement of the connector



*2A-RZ361/2 A-RZ371 are 32/32 input-and-output units. (One-station occupancy)

Fig.3-43 : Pin arrangement of the parallel I/O unit

■ Assignment of pin number and signal

The assignment range of the general-purpose input-and-output signal is fixed by the setup of the station number.

Table 3-25 : Assignment of pin number and signal

Unit Number	Station number	CN100	CN300
1st set	0	Input : 0 to 15 Output : 0 to 15	Input : 16 to 31 Output : 16 to 31
2nd set	1	Input : 32 to 47 Output : 32 to 47	Input : 48 to 63 Output : 48 to 63
3rd set	2	Input : 64 to 79 Output : 64 to 79	Input : 80 to 95 Output : 80 to 95
4th set	3	Input : 96 to 111 Output : 96 to 111	Input : 112 to 127 Output : 112 to 127
5th set	4	Input : 128 to 143 Output : 128 to 143	Input : 144 to 159 Output : 144 to 159
6th set	5	Input : 160 to 175 Output : 160 to 175	Input : 176 to 191 Output : 176 to 191
7th set	6	Input : 192 to 207 Output : 192 to 207	Input : 208 to 223 Output : 208 to 223
8th set	7	Input : 224 to 239 Output : 224 to 239	Input : 240 to 255 Output : 240 to 255

The connector pin number of the parallel I/O unit of the station number 0 and signal number assignment are shown in [Table 3-26](#) and [Table 3-27](#). If it is set as other station number, please interpret and utilize.

■ Parallel I/O interface (First expansion unit)

Table 3-26 : Connector CN100pin No. and signal assignment list (2A-CBL □□)

Pin No.	Line color	Function name		Pin No.	Line color	Function name	
		General-purpose	Dedicated/power supply, common			General-purpose	Dedicated/power supply, common
1	Orange/Red A		FG	26	Orange/Blue A		FG
2	Gray/Red A		0V:For pins 4-7, 10-13	27	Gray/Blue A		0V:For pins 29-32, 35-38
3	White/Red A		12V/24V:For pins 4-7	28	White/Blue A		12V/24V:For pins 29-32
4	Yellow/Red A	General-purpose output 0	Operating output Note1)	29	Yellow/Blue A	General-purpose output 4	
5	Pink/Red A	General-purpose output 1	In servo ON output signal Note1)	30	Pink/Blue A	General-purpose output 5	
6	Orange/Red B	General-purpose output 2	Error occurring output signal Note1)	31	Orange/Blue B	General-purpose output 6	
7	Gray/Red B	General-purpose output 3	Operation rights output signal Note1)	32	Gray/Blue B	General-purpose output 7	
8	White/Red B		0V:For pins 4-7, 10-13	33	White/Blue B		0V:For pins 29-32, 35-38
9	Yellow/Red B		12V/24V:For pins 10-13	34	Yellow/Blue B		12V/24V:For pins 35-38
10	Pink/Red B	General-purpose output 8		35	Pink/Blue B	General-purpose output 12	
11	Orange/Red C	General-purpose output 9		36	Orange/Blue C	General-purpose output 13	
12	Gray/Red C	General-purpose output 10		37	Gray/Blue C	General-purpose output 14	
13	White/Red C	General-purpose output 11		38	White/Blue C	General-purpose output 15	
14	Yellow/Red C		COM0:For pins 15-22 Note2)	39	Yellow/Blue C		COM1:For pins 40-47 Note2)
15	Pink/Red C	General-purpose input 0	Stop input Note3)	40	Pink/Blue C	General-purpose input 8	
16	Orange/Red D	General-purpose input 1	Servo OFF input signal Note1)	41	Orange/Blue D	General-purpose input 9	
17	Gray/Red D	General-purpose input 2	Error reset input signal Note1)	42	Gray/Blue D	General-purpose input 10	
18	White/Red D	General-purpose input 3	Start input Note1)	43	White/Blue D	General-purpose input 11	
19	Yellow/Red D	General-purpose input 4	Servo ON input signal Note1)	44	Yellow/Blue D	General-purpose input 12	
20	Pink/Red D	General-purpose input 5	Operation rights input signal Note1)	45	Pink/Blue D	General-purpose input 13	
21	Orange/Red E	General-purpose input 6		46	Orange/Blue E	General-purpose input 14	
22	Gray/Red E	General-purpose input 7	Reserved	47	Gray/Blue E	General-purpose input 15	
23	White/Red E		Reserved	48	White/Blue E		Reserved
24	Yellow/Red E		Reserved	49	Yellow/Blue E		Reserved
25	Pink/Red E		Reserved	50	Pink/Blue E		Reserved

Note1) The dedicated signal is assigned at shipping. It can change with the parameter.

Note2) Sink type:12V/24V(COM),Source type:0V(COM)

Note3) The dedicated input signal (STOP) is assigned at shipping. The signal number is fixing.

Table 3-27 : Connector CN300pin No. and signal assignment list (2A-CBL □□)

Pin No.	Line color	Function name		Pin No.	Line color	Function name	
		General-purpose	Dedicated/power supply, common			General-purpose	Dedicated/power supply, common
1	Orange/Red A		FG	26	Orange/Blue A		FG
2	Gray/Red A		0V:For pins 4-7, 10-13	27	Gray/Blue A		0V:For pins 29-32, 35-38
3	White/Red A		12V/24V:For pins 4-7	28	White/Blue A		12V/24V:For pins 29-32
4	Yellow/Red A	General-purpose output 16		29	Yellow/Blue A	General-purpose output 20	
5	Pink/Red A	General-purpose output 17		30	Pink/Blue A	General-purpose output 21	
6	Orange/Red B	General-purpose output 18		31	Orange/Blue B	General-purpose output 22	
7	Gray/Red B	General-purpose output 19		32	Gray/Blue B	General-purpose output 23	
8	White/Red B		0V:For pins 4-7, 10-13	33	White/Blue B		0V:For pins 29-32, 35-38
9	Yellow/Red B		12V/24V:For pins 10-13	34	Yellow/Blue B		12V/24V:For pins 35-38
10	Pink/Red B	General-purpose output 24		35	Pink/Blue B	General-purpose output 28	
11	Orange/Red C	General-purpose output 25		36	Orange/Blue C	General-purpose output 29	
12	Gray/Red C	General-purpose output 26		37	Gray/Blue C	General-purpose output 30	
13	White/Red C	General-purpose output 27		38	White/Blue C	General-purpose output 31	
14	Yellow/Red C		COM0:For pins 15-22 ^{Note1)}	39	Yellow/Blue C		
15	Pink/Red C	General-purpose input 16		40	Pink/Blue C	General-purpose input 24	COM1:For pins 40-47 Note1)
16	Orange/Red D	General-purpose input 17		41	Orange/Blue D	General-purpose input 25	
17	Gray/Red D	General-purpose input 18		42	Gray/Blue D	General-purpose input 26	
18	White/Red D	General-purpose input 19		43	White/Blue D	General-purpose input 27	
19	Yellow/Red D	General-purpose input 20		44	Yellow/Blue D	General-purpose input 28	
20	Pink/Red D	General-purpose input 21		45	Pink/Blue D	General-purpose input 29	
21	Orange/Red E	General-purpose input 22		46	Orange/Blue E	General-purpose input 30	
22	Gray/Red E	General-purpose input 23	Reserved	47	Gray/Blue E	General-purpose input 31	Reserved
23	White/Red E		Reserved	48	White/Blue E		Reserved
24	Yellow/Red E		Reserved	49	Yellow/Blue E		Reserved
25	Pink/Red E		Reserved	50	Pink/Blue E		Reserved

Note1) Sink type:12V/24V(COM),Source type:0V(COM)

<Reference> The example of connection with our PLC




Table 3-28 : Connection with a Mitsubishi PLC (Example of sink type)




Table 3-29 : Connection with a Mitsubishi PLC (Example of source type)

(5) External I/O cable

■ Order type: 2A-CBL □□ Note) The numbers in the boxes □□ refer to the length. (05: 5m, 15: 15m)

■ Outline



This is the dedicated cable used to connect an external peripheral device to the connector on the parallel input/output unit.

One end matches the connector on the parallel input/output unit, and the other end is free. Connect the peripheral device's input/output signal using the free end.

One cable corresponds to the input 16 points and output 16 points.

Two cables are needed for connection of (input 32 points and output 32 points) with built-in standard.

■ Configuration

Table 3-30 : Configuration device

Part name	Type	Qty.	Mass(kg) ^{Note1)}	Remarks
External I/O cable	2A-CBL □□	1pc.	0.7(5m) 1.84(15m)	5m or 15m

Note1) Mass indicates one set.

■ Specifications

Table 3-31 : Specifications

Items	Specifications
Number of cables x cable size	50 pairs x AWG #28
Total length	5m or 15m

■ Connector pin numbers and cable colors

Table 3-32 : Connector pin numbers and cable colors

Pin no.	Cable colors	Pin no.	Cable colors	Pin no.	Cable colors	Pin no.	Cable colors	Pin no.	Cable colors
1	Orange/Red A	11	Orange/Red C	21	Orange/Red E	31	Orange/Blue B	41	Orange/Blue D
2	Gray/Red A	12	Gray/Red C	22	Gray/Red E	32	Gray/Blue B	42	Gray/Blue D
3	White/Red A	13	White/Red C	23	White/Red E	33	White/Blue B	43	White/Blue D
4	Yellow/Red A	14	Yellow/Red C	24	Yellow/Red E	34	Yellow/Blue B	44	Yellow/Blue D
5	Pink/Red A	15	Pink/Red C	25	Pink/Red E	35	Pink/Blue B	45	Pink/Blue D
6	Orange/Red B	16	Orange/Red D	26	Orange/Blue A	36	Orange/Blue C	46	Orange/Blue E
7	Gray/Red B	17	Gray/Red D	27	Gray/Blue A	37	Gray/Blue C	47	Gray/Blue E
8	White/Red B	18	White/Red D	28	White/Blue A	38	White/Blue C	48	White/Blue E
9	Yellow/Red B	19	Yellow/Red D	29	Yellow/Blue A	39	Yellow/Blue C	49	Yellow/Blue E
10	Pink/Red B	20	Pink/Red D	30	Pink/Blue A	40	Pink/Blue C	50	Pink/Blue E

■ Connections and outside dimensions

The sheath of each signal cable (50 lines) is color indicated and marked with dots. Refer to the cable color specifications in "Table 3-32: Connector pin numbers and cable colors" when making the connections.

(Eg.) Pin number: color indication

1 : Orange / Red / A





Fig.3-44 : Connections and outside dimensions

(6) CC-Link interface

■ Order type: ● 2D-TZ576

■ Outline



The CC-Link interface is the option interface to not only add bit data to the robot controller, but also to add CC-Link field network function that allows cyclic transmission of word data.

■ Configuration

Table 3-33 : Configuration device

Part name	Type	Qty.	Mass(kg) ^{Note1)}	Remarks
CC-Link interface	TZ576	1	0.6	
Manual	BFP-A8634	1	–	CD-ROM
Ferrite core	E04SR301334	2	–	
Cable clamp	AL4	2	–	Be sure to install this for noise countermeasure.
	AL5	2	–	
On-line connector for communication	A6CON-LJ5P	1	–	
Terminal resistor	A6CON-TR11N	1	–	Resistance value: 100Ω
One-touch connector plug for communication	A6CON-L5P	2	–	

Note1) Mass indicates one set.

Table 3-34 : Procured by the customer

Part name	Type	Qty.	Remarks
Master station	QJ61BT11(Q series)	1	FX series products are not supported.
	QJ61BT11N(Q series)		
	AJ61QBT11(QnA series)		
	A1SJ61QBT11(QnAS series)		
	AJ61BT11(A series)		
	A1SJ61BT11(AnS series)		
	A80BD-J61BT11(personal computer board)		
Communication cable	–	1	Shielded 3-core twisted cable This cable may be manufactured by the customer.




Fig.3-45 : Example of CC-Link Product Configuration

■ Specifications

Table 3-35 : Specifications

Item		Specifications				Remarks	
Communication function		Bit data and word data can be transmitted.				Word data are used by the registers.	
Station type		Intelligent device station ^{Note1)}					
Support station		Local station				No master station function	
The version corresponding to CC-Link		Ver.2				The extended cyclic setup is possible.	
Mountable option slot		Slot 1, 2					
Number of mountable CC-Link interface cards		1				Multiple CC-Link interface cards cannot be inserted.	
Number of stations		1 to 64 stations				When four stations are occupied, continuous station numbers are used. The station numbers are set by a DIP switch.	
Transmission speed		10M/5M/2.5M/625K/156K bps				This is set by the rotary SW.	
Station number		1 to 64				When two or more stations are occupied, continuous station numbers are used.	
Number of occupied stations		1/2/3/4					
Extended cyclic setup		1/2/4/8					
Maximum link point	Remote I/O (RX, RY).	Each 896 points				The two last cannot be used.	
	Remote register (RW _r , RW _w)	Each 128 register				16 bits/register	
Extended cyclic setup	-	1 fold setup	2 fold setup	3 fold setup	4 fold setup		
Link point per set	When one station is occupied	Remote I/O (RX, RY).	32 point	32 point	64 point	128 point	
		Remote register (RW _w)	4 word	8 word	16 word	32 word	
		Remote register (RW _r)	4 word	8 word	16 word	32 word	
	When two stations is occupied	Remote I/O (RX, RY).	64 point	96 point	192 point	384 point	
		Remote register (RW _w)	8 word	16 word	32 word	64 word	
		Remote register (RW _r)	8 word	16 word	32 word	64 word	
	When three stations is occupied	Remote I/O (RX, RY).	96 point	160 point	320 point	640 point	
		Remote register (RW _w)	12 word	24 word	48 word	96 word	
		Remote register (RW _r)	12 word	24 word	48 word	96 word	
	When four stations is occupied	Remote I/O (RX, RY).	128 point	224 point	448 point	896 point	
		Remote register (RW _w)	16 word	32 word	64 word	128 word	
		Remote register (RW _r)	16 word	32 word	64 word	128 word	
Number of the maximum occupancy station		4 stations					
The I/O first number of the robot controller.		No. 6000 -. The number corresponding to the station number by the setup of the parameter "CCFIX."					

Note1) The CC-Link interface supports neither the transient transmission function nor the FX series.

■ Functions**(1) Communication function**

- The number of usable points is 896 points maximum for bit control and 128 points maximum for word control.

(2) Easy setup

- The CC-Link interface card can be set by a rotary switch or DIP switch.
- No separate space is required to mount the CC-Link interface card as it is embedded in the robot controller (can only be mounted into slot 2).
- Easy wiring since only four terminals need to be connected.
- Dedicated commands have been added to MELFA-BASIC V (robot programming language); thus, no complex interface programming is required.

(3) High-speed response


- The link scan time when connecting 64 stations is approximately 7.2 ms, achieving superior high-speed response performance.
- A transmission speed can be selected from 10M, 5M, 2.5M, 625K and 156K bps according to the transmission distance.

(7) Controller protection box


- Order type: CR750 controllerCR750-MB
- CR751 controllerCR751-MB

■ Outline

<CR750-MB>



<CR751-MB>



By putting the controller in this box, the controller can be protected from oil mist environment.

Use this option, when the controller is installed where environment is oil mist such as machine shop etc.

This option is not chemical-resistant. For installing the option, avoid places where adhesion of chemicals may occur.

■ Configuration

Table 3-36 : Configuration equipment and types

Part name	Type	Qty.	Mass (Kg) ^{Note1)}	Remarks
CR750 controller				
Controller protection box	CR750-MB	1	22	
Internal power cable		3		For connection between the power supply relay terminal and controller inside this box
Internal earth cable		1		For connection between the grounding terminal and controller inside this box
Label for serial number		1		
Transparent seal		1		
Cable tie	T50L	4		
Screw for fixing of the controller mounting plate	M4x8	4		
Instruction Manual	BFP-A8896	1		-
CR751 controller				
Controller protection box	CR751-MB	1	21	
Internal power cable		2		For connection between the power supply relay terminal and controller inside this box
Internal earth cable		1		For connection between the grounding terminal and controller inside this box
Label for serial number		1		
Transparent seal		1		
Cable tie	T50L	4		
Screw for fixing of the controller mounting plate	M4x8	4		
Instruction Manual	BFP-A8997	1		-

Note1) Mass indicates one set.

■ Specifications

Table 3-37 : Specifications

Item	Unit	Specifications	Remarks
CR750 controller			
Outside dimension	mm	500(W) × 725(D) × 250(H)	Excluding protrusions
Mass	Kg	22	
Construction		Self-contained floor type	IP54
Grounding	Ω	100 or less (class D grounding)	
Paint color		Dark gray	Equivalent to Munsell: 3.5PB3.2/0.8
CR751 controller			
Outside dimension	mm	500(W) × 725(D) × 250(H)	Excluding protrusions
Mass	Kg	21	
Construction		Self-contained floor type	IP54
Grounding	Ω	100 or less (class D grounding)	
Paint color		Dark gray	Equivalent to Munsell: 3.5PB3.2/0.8

- (1) The robot must be grounded by the customer.
- (2) The cable for primary power supply connection and the grounding cable are customer preparations.

■ Outside dimension




Fig.3-46 : Outside dimension of CR750-MB




Fig.3-47 : Outside dimension of CR751-MB

■ Names of each part




Fig.3-48 : Names of each part (CR750-MB)





Fig.3-49 : Names of each part (CR751-MB)


■ Wiring system diagram

<CR750-MB>

Single phase: RV-4F series



Single phase/Three phase: RV-7F/13F series




Note1) When using the controller for the three phases with the single-phase power supply, connect the primary power supply to L1 and L2 electric terminal of the protection box so that the power supply may be supplied to the heat-exchanger AC fan of the protection box.

Connects with L1 and L3 electric terminal to the ACIN terminal block of the controller. Refer to the separate manual "Controller setup, basic operation, and maintenance" for detail of connecting the power cable and the grounding cable.


Fig.3-50 : Wiring system diagram (CR750-MB)

<CR751-MB>

Single phase: RV-4F series





Single phase/Three phase: RV-7F/13F series



Note1) When using the controller for the three phases with the single-phase power supply, connect the primary power supply to L1 and L2 electric terminal of the protection box so that the power supply may be supplied to the heat-exchanger AC fan of the protection box.
 Connects with L1 and L3 electric terminal to the ACIN terminal block of the controller. Refer to the separate manual "Controller setup, basic operation, and maintenance" for detail of connecting the power cable and the grounding cable.

Fig.3-51 : Wiring system diagram (CR751-MB)

■ Installation dimensions



(8) MELSOFT RT ToolBox2/RT ToolBox2 mini

- Order type :
 - MELSOFT RT ToolBox2
 - *For windows CD-ROM : 3D-11C-WINE
 - MELSOFT RT ToolBox2 mini
 - *For windows CD-ROM : 3D-12C-WINE

■ Outline



This is handy software that fully uses the personal computer functions. It can be used in various stages from the robot specifications study (tact study, etc.) to the design support (creation and editing of programs), start up support (execution, control and debugging of program), and maintenance.

The "personal computer support software" which supports these function fully, and the "personal computer support software mini" which does not have the simulation function are available.

■ Configuration

Table 3-38 : Product configuration

Part name	Type	Medium	Mass (kg) Note1)	Remarks
RT ToolBox2	3D-11C-WINE	CD-ROM	0.2	
RT ToolBox2 mini	3D-12C-WINE	CD-ROM	0.2	

Note1) Mass indicates one set.

■ Features

(1) Simple operation with guidance method and menu method

The Windows standard is used for windows operation, so the controller initialization and startup operations can be carried out easily by following the instructions given on the screen. Even a beginner can easily carry out the series of operations from program creation to execution.

(2) Increased work efficiency with ample support functions

The work efficiency is greatly improved with the multi-window method that carries out multiple steps and displays in parallel. The renumbering function, and copy, search, syntax check and step execution are especially sufficient, and are extremely useful when editing or debugging the program.

With the simulation function support, the program can be debugged and the tact checked before starting the machine at the site. This allows the on-site startup work efficiently to be greatly improved.

(3) The maintenance forecast function increases the efficiency of maintenance work. Analyze the load condition while the robot is actually operating. Based on this analysis, calculate the time for maintenance, such as lubrication and belt replacement. By utilizing this information, the line stop time as well as the maintenance costs can be reduced.

(4) The position recovery support function increases the recovery efficiency in the event of origin position displacement. This function compensates the origin settings and position data by just reproducing several previous teaching points when hand and/or arm displacement occurs, when replacing the motor and the belts, or when reloading the robot. This function can reduce the time required for recovery.

■ Functions

Table 3-39 : Functions

Function		Functional existence ^{Note1)}		Details
Compatible model		○	○	Personal computer running Windows XP, Windows Vista, Windows 7, Windows 8, Windows 8.1, or Windows 10. ^{Note2)}
Program editing functions	Editing functions	○	○	<ul style="list-style-type: none"> ▪ MELFA BASIC V language compatible ▪ Multiple editing screen simultaneously display ▪ Command input, comment writing ▪ Position data editing ▪ File operation (writing to controller, floppy disk, personal computer) ▪ Search and replace function (using characters, line Nos., labels) ▪ Copy, cut, paste, insert (per character, line), undo (per command statement, position conversion) ▪ Line No. automatic generation, renumbering ▪ Batch syntax check ▪ Command template ▪ Position conversion batch editing ▪ Position variable template ▪ Print, print preview
	Control functions		○	<ul style="list-style-type: none"> ▪ Program file control (list, copy, movement, delete, content comparison, name change, protect)
	Debugging functions	○	○	<ul style="list-style-type: none"> ▪ Direct editing of program in controller ▪ Confirmation of robot program operation (step execution, direct execution)
Simulation function		○	×	<ul style="list-style-type: none"> ▪ Off-line simulation of robot program operation using CG (computer graphics) ▪ Tact time calculation
Monitor functions		○	○	<ul style="list-style-type: none"> ▪ Robot operation monitor (robot operation state, stop signal, error monitor, program monitor (execution program, variables), general-purpose input/output signals (forced output possible), dedicated input/output signals, operation confirmation (operation range, current position, hand, etc.) ▪ Operation monitor (working time statistics, production information, robot version) ▪ Servo monitor (load)
Maintenance function		○	○	<ul style="list-style-type: none"> ▪ Parameter setting ▪ Batch, divided backup

RT ToolBox2 mini
(3D-12C-WINE)

RT ToolBox2
(3D-11C-WINE)

Note1) The functions included with the RT ToolBox2 and the RT ToolBox2 mini are shown below.


○ : Function provided × : Function not provided

Note2) Recommend corresponding to CE Marking, an FCC standard, and a VCCI standard.

(9) Instruction Manual (bookbinding)

- Order type: ● 5F-FF03-PE01RV-4F/7F/13F/20F-D series multiple-resistant specification

■ Outline



This is a printed version of the CD-ROM (instruction manual) supplied with this product.

■ Configuration

Table 3-40 : Product configuration

Name	Type	Mass (Kg) Note1)	Specifications
Instruction Manual	5F-FF03-PE01	2.6	The instructions manual set of RV-4F/7F/13F-D series multiple-resistant specification robot
Safety Manual	BFP-A8006	-	Items relating to safety in handling the robot
Standard Specifications	BFP-A3322	-	Specification of the robot arm and controller
Robot Arm Setup & Maintenance	BFP-A3324	-	Installation method of the robot arm, jog operation, and maintenance and inspection procedures
Controller Setup, Basic Operation and Maintenance	BFP-A8867	-	Installation method of the controller, basic operation, and maintenance and inspection procedures
Detailed Explanation of Functions and Operations	BFP-A8869	-	Functions of the controller and T/B, operation method, and explanation of MELFA-BASIC V
Troubleshooting	BFP-A8871	-	Causes of errors occurred and their countermeasures
Additional axis function	BFP-A8663	-	Function of the additional axis, operation method.
Tracking Function Manual	BFP-A8664	-	Function of the Tracking, operation method.
GOT Direct Connection Extended Function	BFP-A8849	-	Explains of data configuration of shared memory, monitoring, and operating procedures, between the GOT and controller.

Note1) Mass indicates one set.

3.11 Maintenance parts

The consumable parts used in the controller are shown in [Table 3-41](#). Purchase these parts from your dealer when required. Some Mitsubishi-designated parts differ from the maker's standard parts. Thus, confirm the part name, robot arm and controller serial No. and purchase the parts from your dealer.

Table 3-41 : Controller consumable parts list

No.	Name	Type <small>Note1)</small>	Qty.	Usage place	Supplier
1	Lithium battery	Q6BAT	1	CR750 controller: Inside of the interface cover CR751 controller: Inside of the filter cover	Mitsubishi Electric
2	Filter	CR750 controller: BK0FA0773H42 CR751 controller: BK0FA0773H41	1	Inside the filter cover	

Note1) Confirm the robot arm serial No., and contact the dealer or service branch of Mitsubishi Electric Co., for the type.

4 Software

4.1 List of commands

The available new functions in MELFA-BASIC V are given in [Table 4-1](#).

Table 4-1 : List of MELFA-BASIC V commands

Type	Class	Function	Input format (example)
Position and operation control	Joint interpolation	Moves to the designated position with joint interpolation.	Mov P1
	Linear interpolation	Moves to the designated position with linear interpolation.	Mvs P1
	Circular interpolation	Moves along a designated arc (start point → passing point → start point (end point)) with 3-dimensional circular interpolation (360 degrees).	Mvc P1,P2,P1
		Moves along a designated arc (start point → passing point → end point) with 3-dimensional circular interpolation.	Mvr P1,P2,P3
		Moves along the arc on the opposite side of a designated arc (start point → reference point → end point) with 3-dimensional circular interpolation.	Mvr2 P1,P9,P3
		Moves along a set arc (start point → end point) with 3-dimensional circular interpolation.	Mvr3 P1,P9,P3
	Speed designation	Designates the speed for various interpolation operations with a percentage (0.1% unit).	Ovrd 100
		Designate the speed for joint interpolation operation with a percentage (0.1% unit).	JOvrd 100
		Designates the speed for linear and circular interpolation with a numerical value (mm/s unit).	Spd 123.5
		Designates the acceleration/deceleration time as a percentage in respect to the predetermined maximum acceleration/deceleration. (1% unit)	Accel 50,80
		Automatically adjusts the acceleration/deceleration according to the parameter setting value.	Oadl ON
		Sets the hand and work conditions for automatic adjustment of the acceleration/deceleration.	Loadset 1,1
		Adds a process unconditionally to the operation.	Wth
Operation	Operation	Adds a process conditionally to the operation.	WthIf
		Designates smooth operation.	Cnt 1,100,200
		Performance of movement is upgraded corresponding to the application.	MvTune 4
		Designates the positioning completion conditions with a No. of pulses.	Fine 200
		Designates the positioning completion conditions with a distance in a straight line	Fine 1, P
		Designates the positioning completion conditions with a joint interpolation.	Fine 0.5, J, 2
		Turns the servo power ON/OFF for all axes.	Servo OFF
		Limits the operation of each axis so that the designated torque is not exceeded.	Torq 4,10
		Designates the base conversion data.	Base P1
Position control	Position control	Designates the tool conversion data.	Tool P1
		The robot arm rigidity is lowered and softened. (XYZ coordinate system)	Cmp Pos ,&B00000011
		The robot arm rigidity is lowered and softened. (JOINT coordinate system)	Cmp Jnt ,&B00000011
		The robot arm rigidity is lowered and softened. (TOOL coordinate system)	Cmp Tool ,&B00000011
		The robot arm rigidity is returned to the normal state.	Cmp Off
Pallet	Pallet	The robot arm rigidity is designated.	CmpG 1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0,1.0
		Defines the pallet.	Def Plt 1,P1,P2,P3,P4,5,3,1
	Singular point passage	Operates the pallet grid point position.	Plt 1,M1
	Singular point passage	Move to a specified position using linear interpolation passing through a singular point.	Mvs P1 Type 0,2

Type	Class	Function	Input format (example)
Program control	Branching	Branches unconditionally to the designated place.	GoTo 120
		Branches according to the designated conditions.	If M1=1 Then GoTo *L100 Else GoTo 20 End If
		Repeats until the designated end conditions are satisfied.	For M1=1 TO 10 Next M1
		Repeats while the designated conditions are satisfied.	While M1<10 WEnd
		Branches corresponding to the designated expression value.	On M1 GoTo *La1, *Lb2, *Lc3
		Executes program block corresponding to the designated expression value..	Select Case 1 Break Case 2 Break End Select
		Moves the program process to the next line.	Skip
	Collision detection	Set to enable/disable the collision detection.	ColChk ON/OFF
		Set the detection level of the collision detection.	ColLvl 100,80,.....
	Subroutine	Executes the designated subroutine. (Within program)	GoSub *L200
		Returns from the subroutine.	Return
		Executes the designated program.	CallP "P10",M1,P1
		Defines the program argument executed with the CALLP command.	FPrm M10,P10
		Executes the subroutine corresponding to the designated expression value.	On M1 GoSub *La1, *Lb2, *Lc3
	Interrupt	Defines the interrupt conditions and process.	Def Act 1, M1=1 GoTo *L100
		Enables/disables the interrupt.	Act 1=1
		Defines the start line of the program to be executed when an interrupt is generated from the communication line.	On Com(1) GoSub *L100
		Enables the interrupt from the communication line.	Com(1) On
		Disables the interrupt from the communication line.	Com(1) Off
		Stops the interrupt from the communication line.	Com(1) Stop
		Wait	Dly 0.5
	Stop	Designates the wait time, and the output signal pulse output time. (0.01s unit)	Wait M_In(1)=1
		Stops the program execution.	Hlt
		Generates an error. During program execution, continue, stop or servo OFF can be designated.	Error 9000
	End	Ends the program execution.	End
Hand	Hand open	Opens the designated hand.	HOpen 1
	Hand close	Closes the designated hand.	HClose 1
Input/output	Assignment	Defines the input/output variables.	Def IO PORT1=BIT,0
	Input	Retrieves the general-purpose input signal.	M1=M_In(1)
	Output	Calls out the general-purpose output signal.	M_Out(1) =0
Parallel execution	Mechanism designation	Acquires the mechanism with the designated mechanism No.	GetM 1
		Releases the mechanism with the designated mechanism No.	RelM 1
	Selection	Selects the designated program for the designated slot.	XLoad 2,"P102"
	Start/stop	Carries out parallel execution of the designated program.	XRun 3,"100",0
		Stops parallel execution of the designated program.	XStop 3
		Returns the designated program's execution line to the head and enters the program selection enabled state.	XRest 3

Type	Class	Function	Input format (example)
Others	Definition	Defines the integer type or real number type variable.	Def Inte KAISUU
		Defines the character string variable.	Def Char MESSAGE
		Defines the layout variable. (Up to 3-dimensional possible)	Dim PDATA(2,3)
		Defines the joint variable.	Def Jnt TAIHI
		Defines the position variable.	Def Pos TORU
		Defines the function.	Def FN TASU(A,B)=A+B
	Clear	Clears the general-purpose output signal, variables in program, variables between programs, etc.	Clr 1
	File	Opens a file.	Open "COM1:" AS #1
		Closes a file.	Close #1
		Inputs data from a file.	Input# 1,M1
		Outputs data to a file.	Print# 1,M1
	Comment	Describes a comment.	Rem "ABC"
	Label	Indicates the branching destination.	*SUB1

4.2 List of parameters

Show the main parameter in the [Table 4-2](#).

Table 4-2 : List of parameters

Parameter	Details	
Standard tool coordinates.	MEXTL	Set the default value for the tool data. Unit: mm or deg.
Standard base coordinates	MEXBS	Set the relation of the world coordinate system and robot coordinate system. Unit: mm or deg.
XYZ operation range	MEPAR	Designate the overrun limit value for the world coordinate system.
JOINT operation range	MEJAR	Set the overrun limit value for each joint axis.
Free plane limit	SFC1P : SFC8P	This is the overrun limit set with the free plane. Create a plane with the three coordinates x1, y1, z1 to x3, y3, z3, and set the outer side of the plane as the outside operation range (error). The following three types of parameters are used. Eight types of free plane limits can be set in SFC1P to SFC8P. There are nine elements, set in the order of x1, y1, z1, x2, y2, z2, x3, y3, z3.
	SFC1ME : SFC8ME	Designate which mechanism to use eight types of set free plane limits. The mechanism No. to use is set with 1 to 3.
	SFC1AT : SFC8AT	Set the validity of the eight types of set free plane limits. (Valid 1/Valid 2/invalid = 1/-1/0)
User-defined area	AREA1CS : AREA32CS	An area (cube) defined with two XYZ coordinate points can be designated and that area set as the outside operation range. Furthermore, a signal can be output when the axis enters that area. Up to 32 types of area can be designated. Specify the coordinate system of the user definition area *. 0: Base coordinate system (conventional compatibility) 1: Robot coordinate system
	AREA1P1 : AREA32P1	Designated the 1st point of the area. There are eight elements, set in the order of x, y, z, a, b, c, L1, L2. (L1 and L2 are the additional axes.)
	AREA1P2 : AREA32P2	Designated the 2nd point of the area. There are eight elements, set in the order of x, y, z, a, b, c, L1, L2. (L1 and L2 are the additional axes.)
	AREA1ME : AREA32ME	Designate which mechanism to use the 32 types of set area. The mechanism No. to use is set with 1 to 3.
	AREA1AT : AREA32AT	Designate the area check type. (Invalid/zone/interference = 0/1/2) Zone: The dedicated output signal USRAREA turns ON. Interference: An error occurs..
Automatic return setting	RETPATH	Set to restart the program after returning to the interrupt position when resuming operation after an interruption.
Buzzer ON/OFF	BZR	Designate whether to turn the buzzer ON or OFF.
Jog setting	JOGJSP	Designate the joint jog and step operation speed. (Set dimension H/L amount, max. override.)
	JOGPSP	Designate the linear jog and step operation speed. (Set dimension H/L amount, max. override.)
Jog speed limit value	JOGSPMX	Limit the operation speed during the teaching mode. Max. 250[mm/s]
Hand type	HANDTYPE	Set the hand type of the single/double solenoid, and the signal No. (Single/double = S/D) Set the signal No. after the hand type. Example) D900
Stop input B contact designation	INB	Change the dedicated input (stop) to either of normal open or normal close.

Parameter		Details
User-designated origin	USERORG	Designate the user-designated origin position.
Program selection memory	SLOTON	Select the program selected previously when initializing the slot. The non-selected state will be entered when not set.
Communication setting	CBAU232	Set the baud rate.
	CLEN232	Set the character length.
	CPRTY232	Set the parity.
	CSTOP232	Set the stop bit.
	CTERM232	Set the end code.
Slot table	SLT1 : SLT32	Make settings (program name, operation type, order of priority, etc.) for each slot during slot initialization.
No. of multi-tasks	TASKMAX	Designate the No. of programs to be executed simultaneously. (Max. 32)
Select the function of singular point adjacent alarm	MESNGLSW	Designate the valid/invalid of the singular point adjacent alarm. (Invalid/Valid = 0/1) When this parameter is set up "VALID", this warning sound is buzzing even if parameter: BZR (buzzer ON/OFF) is set up "OFF".
Display language.	LNG	Change the language to display on the LCD display of teaching pendant.

5 Instruction Manual

5.1 The details of each instruction manuals

The contents and purposes of the documents enclosed with this product are shown below. Use these documents according to the application.

Instruction manuals enclosed in dashed lines in the list below are for optional products.

For special specifications, a separate instruction manual describing the special section may be enclosed.

Safety Manual	Explains the common precautions and safety measures to be taken for robot handling, system design and manufacture to ensure safety of the operators involved with the robot.
Standard Specifications	Explains the product's standard specifications, factory-set special specifications, option configuration and maintenance parts, etc. Precautions for safety and technology, when incorporating the robot, are also explained.
Robot Arm Setup & Maintenance	Explains the procedures required to operate the robot arm (unpacking, transportation, installation, confirmation of operation), and the maintenance and inspection procedures.
Controller Setup, Basic Operation and Maintenance	Explains the procedures required to operate the controller (unpacking, transportation, installation, confirmation of operation), basic operation from creating the program to automatic operation, and the maintenance and inspection procedures.
Detailed Explanation of Functions and Operations	Explains details on the functions and operations such as each function and operation, commands used in the program, connection with the external input/output device, and parameters, etc.
Troubleshooting	Explains the causes and remedies to be taken when an error occurs. Explanations are given for each error No.
Additional axis function	Explains the specifications, functions and operations of the additional axis control.
Tracking Function Manual	Explains the control function and specifications of conveyor tracking
Extended Function Instruction Manual	Explains the detailed description of data configuration of shared memory, monitoring, and operating procedures, about the PLC(CR750-Q/CR751-Q controller) and the GOT(CR750-D/CR751-D controller).

6 Safety

6.1 Safety

Measures to be taken regarding safety of the industrial robot are specified in the "Labor Safety and Sanitation Rules". Always follow these rules when using the robot to ensure safety.

6.1.1 Self-diagnosis stop functions

This robot has the self-diagnosis stop functions shown in [Table 6-1](#) and the stop functions shown in [Table 6-2](#) for safe use.

Table 6-1 : Self-diagnosis stop functions

No.	Function		Details	Remarks
1	Overload protection function		Activates when the total servo current time exceeds the specified value.	The drive circuit is shut off. The robot stops, and an alarm displays.
2	Overcurrent diagnosis function		Activates when an overcurrent flows to the motor circuit.	The drive circuit is shut off. The robot stops, and an alarm displays.
3	Encoder disconnection diagnosis function		Activates when the encoder cable is disconnected.	The drive circuit is shut off. The robot stops, and an alarm displays.
4	Deflection over diagnosis function		Activates when an error occurs between the command value and actual position, and the error exceeds the specified amount.	The drive circuit is shut off. The robot stops, and an alarm displays.
5	AC power voltage drop diagnosis function		Activates when the AC power voltage drops below the specified value.	The drive circuit is shut off. The robot stops, and an alarm displays.
6	CPU error detection function		Activates when an error occurs in the CPU.	The drive circuit is shut off. The robot stops, and an alarm displays.
7	Overrun prevention function	Software limit detection	This is the limit provided by the software to enable operation only in the operation range.	The drive circuit is shut off. The robot stops, and an alarm displays.
		Mechanical stopper	This is the mechanical stopper provided outside the software.	The robot mechanically stops, and function 1 or 2 activates.

Table 6-2 : List of stop functions

Stop function	Operation panel Note1)	Teaching pendant	External input	Details
Emergency stop	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	This is the stop with the highest degree of emergency. The servo power is shut off, and the mechanical brakes (all axes) activate to stop the robot. To recover, reset the alarm, and turn the servo ON with the servo ON command.
Stop	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	This is a stop operation with a high degree of emergency. The robot immediately decelerates and stops. Note that the servo power is not shut off. Use this when using the collision evasion sensor, etc.

Note1) Only CR750 controller has operation panel.

6.1.2 External input/output signals that can be used for safety protection measures

Table 6-3 : External input/output signals that can be used for safety protection measures

	Signal	Connection point	Parameter	Functions	Usage method
Input	External emergency stop Note1)	Connector (CR750 controller: CNSUSR11/12) (CR751 controller: CNSUSR1)	–	This servo power is shut off, and the robot stops immediately.	Externally installed emergency stop switch. Door switch on safety protection fence. Stopping at high-level error occurrence.
	Door switch		–		The door switch of the safe protection fence
	Enabling device input		–		Enabling device. The safety switch during teaching work
	Stop	Parallel I/O unit or interface	STOP	The program execution is stopped, and the robot stops. The servo power is not shut off.	The robot is stopped when a peripheral device fault occurs. The servo power is not shut off.
	Servo OFF		SRVOFF	The servo power can be shut off.	The robot is stopped when a peripheral device fault occurs. The servo power is not shut off.
	Automatic operation enable		AUTOENA	Disables automatic operation when inactive.	Door switch on safety protection fence
Output	Emergency stop output	Connector (CR750 controller: CNSUSR11/12) (CR751 controller: CNSUSR1)	–	Outputs the input signal of external emergency stop or emergency stop switch of T/B turned on.	Display and warn the pilot lamp, the input signal of external emergency stop or the emergency stop switch of T/B turned on.
	In servo ON	Parallel I/O unit or interface	SRVON	The servo power ON/OFF state is output.	The servo power ON/OFF state is shown and alerted with the display lamps.
	Waiting		STOP	Outputs that the robot is temporarily stopped.	The temporary stop state is shown and alerted with the display lamps.
	In alarm	Connector (CR750/CR751 controller: CNUSR2)	ERRRESET –	Outputs when an alarm occurs in the robot.	The alarm state is shown and alerted with the display lamps.

Note1) The external emergency stop input is prepared as a normal close for safety proposes. Thus, if the emergency stop input circuit is opened when the robot is started up, the robot will not operate. Refer to [Page 162, "6.1.7 Examples of safety measures"](#) for details.

And, refer to [Page 103, "\(3\) Automatic Operation/Jog Operation/Brake Release and Necessary Switch Settings](#)" for the function of the door switch input and the enabling device input.

6.1.3 Precautions for using robot

The safety measures for using the robot are specified in the "Labor Safety and Sanitation Rules". An outline of the rules is given below.

(1) Robot installation

- Secure sufficient work space required to safely perform work such as teaching and maintenance related to the robot.
- Install the controller outside the robot's motion space. (If a safety fence is provided, install outside the fence.)
- Install the controller where the entire robot operation can be viewed.
- Install display lamps, etc., to indicate the robot's operation state.
- Securely fix the robot arm onto the fixing table with the designated bolts.

(2) Prevention of contact with operator

- Install a safety fence or enclosure so that the operator cannot easily enter the robot's motion space.
- Install an interlock function that will stop the robot if the safety fence or enclosure door is opened.

(3) Work procedures

- Create and observe work procedures for the robot teaching, operation, inspection and emergencies.
- Create hand signals to be followed when several operators are working together.
- Create displays such as "Teaching in Progress" and "Inspection in Progress" to be put up when an operator is in the robot's motion space so that other operators will not operate the operation panel (controller, control panel).

(4) Training

- Train the operators about the operations, maintenance and safety required for the robot work.

- Only trained and registered operators must operate the robot.
Participation in the "Special training for industrial robots" sponsored by the Labor Safety and Sanitation Committee, etc., is recommended for safety training.

(5) Daily inspection and periodic inspection

- Always inspect the robot before starting daily operations and confirm that there are no abnormalities.
- Set the periodic inspection standards in view of the robot's ambient environment and operation frequency, and perform periodic inspections.
- Make records when periodic inspections and repairs have been done, and store the records for three or more years.

6.1.4 Safety measures for automatic operation

- (1) Install safety fences so that operators will not enter the operation area during operation and indicate that automatic operation is in progress with lamps, etc.
- (2) Create signals to be given when starting operation, assign a person to give the signal, and make sure that the operator follows the signals.

6.1.5 Safety measures for teaching

Observe the following measures when teaching, etc., in the robot's operation range.

- (1) Specify and follow items such as procedures related to teaching work, etc.
- (2) Take measures so that operation can be stopped immediately in case of trouble, and measures so that operation can be restarted.
- (3) Take measures with the robot start switch, etc., to indicate that teaching work is being done.
- (4) Always inspect that stop functions such as the emergency stop device before starting the work.
- (5) Immediately stop the work when trouble occurs, and correct the trouble.
- (6) Take measures so that the work supervisor can immediately stop the robot operation when trouble occurs.
- (7) The teaching operator must have completed special training regarding safety. (Training regarding industrial robots and work methods, etc.)
- (8) Create signals to be used when several operators are working together.

6.1.6 Safety measures for maintenance and inspections, etc.

Turn the power OFF and take measures to prevent operators other than the relevant operator from pressing the start switch when performing inspections, repairs, adjustments, cleaning or oiling.

If operation is required, take measures to prevent hazards caused by unintentional or mistaken operations.

- (1) Specify and follow items such as procedures related to maintenance work, etc.
- (2) Take measures so that operation can be stopped immediately in case of trouble, and measures so that operation can be restarted.
- (3) Take measures with the robot start switch, etc., to indicate that work is being done.
- (4) Take measures so that the work supervisor can immediately stop the robot operation when trouble occurs.
- (5) The operator must have completed special training regarding safety. (Training regarding industrial robots and work methods, etc.)
- (6) Create signals to be used when several operators are working together.

6.1.7 Examples of safety measures

Two emergency-stop input circuits are prepared on the user wiring terminal block of the controller. Create a circuit as shown below for safety measures. In addition, the figure shows the normal state which is not in the emergency stop state.

[Caution] Since we have omitted the information in part because of explanation, there is the section different from the product. Also refer to [Page 172, "\(3\) External emergency stop connection \[supplementary explanation\]](#).

[Note] · In the emergency-stop related wiring by the customer, if the coil (is not the contact points) of the relay prepared by the customer is connected to the controller, please be sure to implement the measure against the noise by the customer in the coil section. And, please also take the lifetime of noise suppression parts into consideration.

- Electric specification of the emergency-stop-related output terminal: 100mA/24V or less
- In the customer's system, do not ground the + side of 24V power supply prepared by customer for connect to the controller. (related with emergency stop and parallel input/output) If it connects with the controller under the condition that the + side is grounded, it will lead to failure of controller.

(1) CR750 controller




Fig.6-1 : Example of safety measures (CR750 wiring example 1)





Fig.6-2 : Example of safety measures (CR750 wiring example 2)

<Wiring example 3>: Connect the emergency stop switch, door switch, and enabling device of peripheral equipment to the controller. The power supply for emergency stop input uses the power supply of peripheral equipment. Monitor the emergency stop state by the peripheral equipment side.

<Operation of the emergency stop>

If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state. And, if the emergency stop switch of OP or T/B is pushed in the state of the power of controller OFF, peripheral equipment state can be the emergency stop also.



*1) Each of the connectors, CNUSR11 and CNUSR12, are assigned with the same pin number, creating 2 systems in each terminal. It is absolutely necessary to connect the 2 systems.

*2) You can see in the diagram that connector CNUSR2 has 2 terminals and 2 systems (16/17 indicates 2 terminals at pin number 16 and pin number 17). It is absolutely necessary to connect the 2 systems.

*3) The T/B emergency stop button connected with the controller.

*4) Emergency stop input relay.

*5) Refer to the Standard specification manual or the Special specification manual for the enabling device.

*6) The emergency stop button of the robot controller.
(Only specification with the operation panel.)

*7) The emergency stop input detection relay uses the controller's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.

Fig.6-3 : Example of safety measures (CR750 wiring example 3)

<Wiring example 4>: Connect the emergency stop switch of peripheral equipment, and the door switch to two controllers, and it interlocks. Connect the enabling device to the robot controller. The power supply for emergency stop input uses the power supply of peripheral equipment. Monitor the emergency stop state by the peripheral equipment side.

<Operation of the emergency stop>

If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state. And, if the emergency stop switch of OP or T/B is pushed in the state of the power of controller OFF, peripheral equipment state can be the emergency stop also.





Fig.6-4 : Example of safety measures (CR750 wiring example 4)

<Wiring example 5>: Connect the controller to the safety relay
Use the controller's emergency stop button command as an input to the safety relay.



[Caution]

- 1) This product has category 3 functionality and therefore the robot's whole unit cannot be set to category 4.
- 2) The controller's internal circuit has polarity. Please adhere to the polarity as detailed in the wiring examples, particularly for emergency stop button output when using user equipment. Connect the positive side of the user equipment (24V DC) to the terminal 2 of CNUSR11/12, then connect the emergency stop button (or contact points) in the user equipment to across the terminals 3 and 4 of CNUSR11/12, and ultimately connect the negative side (24G).
- 3) When installing a safety relay to use it as an input point of the controller's emergency stop button command, use a safety relay that is activated by an input from one of the two systems (i.e. QS90SR2SP (Manufacture: Mitsubishi Electric Corporation)).
- 4) The emergency stop input detection relay (internal relay) uses the controller's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.
- 5) When connecting emergency stop button output to an external safety relay, please take note of the polarity and make sure that the electrical current flows in the same direction as indicated by the dotted arrows in the two places in the diagram. If the polarity is setup incorrectly, this function will not operate correctly. Please connect the terminal 13 of CNUSR11/12 to 24V.

Fig.6-5 : Example of safety measures (CR750 wiring example 5)

(2) CR751 controller





Fig.6-6 : Example of safety measures (CR751 wiring example 1)

⟨Wiring example 2⟩: Connect the emergency stop switch of peripheral equipment to the controller.

The power supply for emergency stop input uses the power supply of peripheral equipment.

⟨Operation of the emergency stop⟩

If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state.



*1) Each of the connectors, CNUSR1 and CNUSR2, are assigned with the same pin number, creating 2 systems in each terminal. It is absolutely necessary to connect the 2 systems.

*2) The T/B emergency stop button connected with the controller.

*3) Emergency stop input relay.

*4) Refer to the Standard specification manual or the Special specification manual for the enabling device.

*5) The emergency stop input detection relay uses the controller's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.


*6) Connect the 24V power supply to 26/31 terminals.

Fig.6-7 : Example of safety measures (CR751 wiring example 2)

<Wiring example 3>: Connect the emergency stop switch, door switch, and enabling device of peripheral equipment to the controller. The power supply for emergency stop input uses the power supply of peripheral equipment. Monitor the emergency stop state by the peripheral equipment side.

<Operation of the emergency stop>

If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state. And, if the emergency stop switch of OP or T/B is pushed in the state of the power of controller OFF, peripheral equipment state can be the emergency stop also.



*1) Each terminal assigned with the respectively same pin number as connector: CNUSR1 and CNUSR2 and each is dual line. Always connect the two lines.
 *2) The T/B emergency stop button connected with the controller.
 *3) Emergency stop input relay.



- *4) Refer to the Standard specification manual or the Special specification manual for the enabling device.
- *5) The emergency stop input detection relay uses the controller's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.
- *6) When using emergency stop button output function, please take note of the polarity and make sure that the electrical current flows in the same direction as indicated by the dotted arrows in the two places in the diagram. If the polarity of the circuit is wrong, the emergency stop button output may not work properly. Please connect the 24V power supply to 26/31 terminals.

Fig.6-8 : Example of safety measures (CR751 wiring example 3)

<Wiring example 4>: Connect the emergency stop switch of peripheral equipment, and the door switch to two controllers, and it interlocks. Connect the enabling device to the robot controller. The power supply for emergency stop input uses the power supply of peripheral equipment. Monitor the emergency stop state by the peripheral equipment side.

<Operation of the emergency stop>

If the emergency stop switch of peripheral equipment is pushed, the robot will also be in the emergency stop state. And, if the emergency stop switch of OP or T/B is pushed in the state of the power of controller OFF, peripheral equipment state can be the emergency stop also.




*3) Emergency stop input relay.

*4) Refer to the Standard specification manual or the Special specification manual for the enabling device.

*5) The emergency stop input detection relay uses the controller's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.

Fig.6-9 : Example of safety measures (CR751 wiring example 4)

<Wiring example 5>: Connect the controller to the safety relay
Use the controller's emergency stop button to input safety relay.



[Caution]

- 1) This product has category 3 functionality and therefore the robot's whole unit cannot be set to category 4.
- 2) The controller's internal circuit has polarity. Please adhere to the polarity as detailed in the wiring examples, particularly for emergency stop button output when using user equipment. Connect the positive side of the user equipment (24V DC) to the two terminals 26/31, then connect the emergency stop button (or contact points) in the user equipment to the 2-27 and 7-32 terminals, and ultimately connect to the negative side (24G).
- 3) Setup a safety relay on the user equipment, and when using to input the emergency stop button on the controller, please only use a safety relay that functions when connecting the input to the one end of the 2 systems (i.e. QS90SR2SP (Manufacture: Mitsubishi Electric Corporation)).
- 4) The emergency stop input detection relay (internal relay) uses the controller's internal safety relay control. If the emergency stop input detection relay is switched OFF, emergency stop is detected and the safety relay is also switched OFF.
- 5) When connecting emergency stop button output to an exterior safety relay, please take note of the polarity and make sure that the electrical current flows in the same direction as indicated by the dotted arrows in the two places in the diagram. If the polarity is setup incorrectly this function will not operate correctly. Please connect 20/19 terminal to 24V.

Fig.6-10 : Example of safety measures (CR751 wiring example 5)

(3) External emergency stop connection [supplementary explanation]

- (1) Use a 2-contact type switch for all switches.
- (2) Install a limit switch on the safety fence's door. With a constantly open contact (normal open), wire to the door switch input terminal so that the switch turns ON (is conducted) when the door is closed, and turns OFF (is opened) when the door is open.
- (3) Use a manual-return type of normal close which have two lines for the emergency stop button.
- (4) Classify the faults into minor faults (faults that are easily restored and that do not have a great effect) and major faults (faults that cause the entire system to stop immediately, and that require care in restoration), and wire accordingly.

[Caution] The emergency stop input (terminal block) on the user wiring in the controller can be used for safety measures as shown in figure above. Note that there are limits to the No. of switch contacts, capacity and cable length, so refer to the following and install.

- Switch contact Prepare a 2-contact type.*1)
- Switch contact capacity..... Use a normal open contact that operates with a switch contact capacity of approx. 1mA to 100mA/24V. *1)
If you connect the relay etc., rated current of the coil should use the relay which is 100mA/24V or less. (Refer to Fig. 6-12, Fig. 6-11)
- Cable length..... The length of the wire between the switch and terminal block must be max. 15m or less. Please use the shield line, in case of the cable may receive the noise etc. by other equipment, such as servo amplifier. And, since the ferrite core is attached as noise measures parts, please utilize.
The size of the wire that fits to use is shown below.
 - CR750 controller..... CNUSR11/12/13 connector:
AWG #26 to #16 (0.14mm² to 1.5mm²)
 - CR750 controller..... CNUSR2 connector:
AWG #30 to #24 (0.05mm² to 0.2mm²)
 - CR751 controller..... CNUSR1/2 connector:
AWG #30 to #24 (0.05mm² to 0.2mm²)

Electric specification of the emergency stop related output circuit is 100mA/24V or less. Don't connect the equipment except for this range.

*1) The minimum load electric current of the switch is more than 5mA/24V.

The electric-current value limitation when connecting the coils, such as the Relays (CR750 controller)




Fig.6-11 : Limitations when connecting the relay etc. (CR750)

The electric-current value limitation when connecting the coils, such as the Relays (CR751 controller)




Fig.6-12 : Limitations when connecting the relay etc. (CR751)

[Supplementary explanation regarding emergency stop circuit]

The controller's internal circuit is as shown in the below diagram. Be sure to build a circuit that properly shuts off the emergency stop detection relay when the emergency stop button is pressed.




Fig.6-13 : Internal circuit of controller

⚠ CAUTION

Be sure to perform wiring correctly. If there are mistakes in the wiring, the robot may not stop when the emergency stop button is pressed and there will be a risk of damage or personal injury occurring.

After wiring, be sure to press each of the installed emergency stop switches and check whether the emergency stop circuit works properly.

⚠ CAUTION

Be sure to duplicate connection of the emergency stop, door switch and enabling switch. If not duplicated, these functions may fail due to a broken relay used by customer, etc.

6.2 Working environment

Avoid installation in the following places as the equipment's life and operation will be affected by the ambient environment conditions. When using in the following conditions, the customer must pay special attention to the preventive measures.

(1) Power supply

- Where the voltage fluctuation will exceed the input voltage range.
- Where a momentary power failure exceeding 20ms may occur.
- Where the power capacity cannot be sufficiently secured.

CAUTION

Please use the controller with an input power supply voltage fluctuation rate of 10% or less. In the case of 200 VAC input, for example, if the controller is used with 180 VAC during the day and 220 VAC during the night, turn the servo off once and then on again. If this is not performed, an excessive regeneration or overvoltage error may occur.

(2) Noise

- Where a surge voltage exceeding 1000V, $1\mu\text{s}$ may be applied on the primary voltage. Near large inverters, high output frequency oscillator, large contactors and welding machines. Static noise may enter the lines when this product is used near radios or televisions. Keep the robot away from these items.

(3) Temperature and humidity

- Where the atmospheric temperature exceeds 40 degree , lower than 0 degree.
- Where the relative humidity exceeds 85%, lower than 45%, and where dew may condense.
- Where the robot will be subject to direct sunlight or near heat generating sources such as heaters.

(4) Vibration

- Where excessive vibration or impact may be applied. (Use in an environment of 34m/s^2 or less during transportation and 5m/s^2 or less during operation.)

(5) Installation environment

- Where strong electric fields or magnetic fields are generated.
- Where the installation surface is rough. (Avoid installing the robot on a bumpy or inclined floor.)
- Where there is heavy powder dust and oil mist present.

6.3 Precautions for handling

- (1) This robot has brakes on all axes. The precision of the robot may drop, looseness may occur and the reduction gears may be damaged if the robot is moved with force with the brakes applied.
- (2) Avoid moving the robot arm by hand. When unavoidable, gradually move the arm. If moved suddenly, the accuracy may drop due to an excessive backlash, or the backed up data may be destroyed.
- (3) Note that depending on the posture, even when within the movement range, the wrist section could interfere with the base section. Take care to prevent interference during jog. ^{*1)}
- (4) The robot arm consists of precision parts such as bearing. Lubricants such as grease are also applied on the moving parts to keep the mechanical accuracy. In a cold start under low temperature or in the first start after being stored for one month or longer, lubricants may not be spread enough. Such condition may lower the positioning accuracy, cause servo and overload alarms, and early wearing of the moving parts. To avoid such situation, perform warm-up operation of the machine at a low speed (at about 20% of normal operation speed). Move the robot arm from the lower to the upper limit of the movable range with the 30 degree joint angle or more for about 10 minutes. After that, speed up the operation gradually.

Please use the warm-up operation. (About the details of the warm-up operation, refer to "INSTRUCTION MANUAL/Detailed explanations of functions and operations".)

- (5) In the environment where hygiene management is required, clean the robot arm before use. Chemical-resistant specifications (SExx01) corresponds to the sterilization and cleaning by chemicals. And Food machinery grade

*1) Jog operation refers to operating the robot manually using the teaching pendant.

- H1 grease specifications (SExx02) corresponds to wiping. (Refer to [Page 20, "2.2.6 Protection specifications"](#) in detail.)
- (6) The robot arm and controller must be grounded with 100Ω or less (class D grounding) to secure the noise resistance and to prevent electric shocks.
 - (7) The items described in these specifications are conditions for carrying out the periodic maintenance and inspections described in the instruction manual.
 - (8) When using the robot arm on a mobile axis or elevating table, the machine cables enclosed as standard configuration may break due to the fixed installation specifications. In this case, use "the machine cable extension (for flexed)" factory shipment special specifications or options.
 - (9) If this robot interferes with the workpiece or peripheral devices during operation, the position may deviate, etc. Take care to prevent interference with the workpiece or peripheral devices during operation.
 - (10) The hanging installation jig can be borrowed from the maker. Order to dealer when need.
 - (11) Do not attach a tape or a label to the robot arm and the controller. If a tape or a label with strong adhesive power, such as a packaging tape, is attached to the coated surfaces of the robot arm and controller, the coated surface may be damaged when such tape or label is peeled off.
 - (12) If the robot is operated with a heavy load and at a high speed, the surface of the robot arm gets very hot. It would not result in burns, however, it may cause secondary accidents if touched carelessly.
 - (13) Do not shut down the input power supply to stop the robot. If the power supply is frequently shut down during a heavy load or high-speed operation, the speed reducer may be damaged, backlash may occur, and the program data may be destroyed.
 - (14) If the J1, J2 and J3 axes collide with the mechanical stopper during the automatic operation of the robot, it is necessary to replace the resin part of the mechanical stopper unit. For the replacement of the resin parts, please contact Mitsubishi or Mitsubishi's dealer.
If the resin part is not replaced, the mechanism unit and the speed reducer may be damaged significantly when the axes collide with the mechanical stopper next or subsequent time.
 - (15) During the robot's automatic operation, a break is applied to the robot arm when the input power supply is shut down by a power failure, for instance. When a break is applied, the arm may deviate from the operation path predetermined by automatic operation and, as a result, it may interfere with the mechanical stopper depending on the operation at shutdown. In such a case, take an appropriate measure in advance to prevent any dangerous situation from occurring due to the interference between the arm and peripheral devices.
Example) Installing a UPS (uninterruptible power supply unit) to the primary power source in order to reduce interference.
 - (16) The J1 to J3 axes of the RV-13F series generate loud noise during high-speed operation because of their reduction gear structure, but it does not affect the robot's function, performance, and a life.
 - (17) Do not conduct an insulated voltage test. If conducted by mistake, it may result in a breakdown.
 - (18) Fretting may occur on the axis which moving angle or moving distance move minutely, or not moves. Fretting is that the required oil film becomes hard to be formed if the moving angle is small, and wear occurs. The axis which not moved is moving slightly by vibration etc. To make no fretting recommends to move these axes about once every day the 30 degree or more, or the 20mm or more.
 - (19) The United Nations' Recommendations on the Transport of Dangerous Goods must be observed for trans-border transportation of lithium batteries by air, sea, and land. The lithium batteries (ER6, Q6BAT) used in Mitsubishi industrial robots contain lithium and fall under the definition.
When the lithium batteries are shipped for storage, etc., they will be classified as Class 9: Miscellaneous dangerous substances and articles. Please contact your transportation company and must provide appropriate transport safety measures as the customer's consignor.
 - (20) If the air supply temperature (primary piping) used for the tool etc. is lower than ambient air temperature, the dew condensation may occur on the coupling or the hose surface.
 - (21) When fumigants that contain halogen materials such as fluorine, chlorine, bromine, and iodine are used for disinfecting and protecting wooden packaging from insects, they cause malfunction when entering our products. Please take necessary precautions to ensure that remaining materials from fumigation do not enter our products, or treat packaging with methods other than fumigation (heat method). Additionally, disinfect and protect wood from insects before packing products.

6.4 EMC installation guideline

6.4.1 Outlines

The EMC directive is coerced from January 1, 1996, and it is necessary to attach the CE mark which shows that the product is in conformity to directive.

Since the industrial robot is the component of the automation system, it considers that the EMC directive is not the target product of the direct. However, because it is one of the main components, introduces the method and components of the measures for conforming the automation system to the EMC directive.

And also we are carrying out the qualification test about the conformity of the EMC directive under the environment based on the contents of this document. However, the noise level is changed by the kind of equipment to be used, the layout, the construction of the controlling board, the course of wiring, etc. Therefore, please confirm by the customer eventually.

6.4.2 EMC directive

The Mitsubishi Electric industrial robot follows the European EMC directive. This technical standard regulates the following two items.

- (1) Emission (EMI : Electromagnetic Interference) The capacity not to generate the disturbance noise which has a bad influence outside.
- (2) Immunity (EMS : Electromagnetic Susceptibility)..... The capacity which does not malfunction for the disturbance noise from the outside.

Each contents are shown below.

Item	Name	Contents	Testing technical-standard number
Emission (EMI)	Radiative noise disturbance	The electromagnetic noise etc. which are emitted to environs.	EN61000-6-2 : 2005 EN61000-6-4 : 2007 EN62061:2005(Annex E)
	Electrical-conduction noise disturbance	The electromagnetism noise etc. which flow out of the power-supply line.	
Immunity (EMS)	Electrostatic discharge immunity test	The noise from the electrified human body.	
	Radiated, radio-frequency, electromagnetic field immunity test susceptibility test	The electromagnetism noise from the transceiver, the broadcasting station, etc.	
	Electrical fast transient burst immunity test	The relay noise or the electromagnetism noise etc. which are caused in power-supply ON/OFF.	
	Immunity to conducted disturbances induced radio-frequency fields	The electromagnetism noise etc. which flow in through the power source wire and the grounding wire.	
	Power frequency magnetic field immunity test	The electromagnetism noise with a power supply frequency of 50/60 Hz etc.	
	Voltage dips, short interruptions and voltage variations immunity test	The noise in the variation of the source voltage of the power dispatching, etc.	
	Surge immunity test	The electromagnetism noise by the thunderbolt, etc.	

6.4.3 EMC measures

There are mainly following items in the EMC measures.

- (1) Store into the sealed metal board.
- (2) Grounding all the conductor that have floated electrically (makes the impedance low).
- (3) Wiring so that the power source wire and signal wire are separated.
- (4) Use the shield cable for the cable which wired outside of the metal board.
- (5) Install the noise filter.

To suppress the noise emitted out of the board, be careful of the following item.

- (1) Ensure grounding of the equipment.
- (2) Use the shield cable.
- (3) Separate the metal board electrically. Narrows the distance/hole.

The strength of electromagnetic noise emitted to environment is changed a lot by the shielding efficiency of cable and the distance of metal board, so it should be careful.

6.4.4 Component parts for EMC measures


(1) Ferrite core

The ferrite core is mounted by the plastics case as one. It can attach by the one-touch, without cutting the cable. This has the effect in the common-mode noise. The measures against the noise are made not influential in the quality of the signal.

There are the following as an example.


Maker: SEIWA ELECTRIC MFG. Co.,Ltd.

Type	Outside dimension (mm)				Diameter of the adaptation cable [max] (mm)
	A	B	C	D	
E04SR401938	61	38	19	40	19.0
E04SR301334	39	34	13	30	13.0




Maker: TAKACHI ELECTRONICS ENCLOSURE CO., LTD.

Type	Outside dimension (mm)				Diameter of the adaptation cable [max] (mm)
	A	B	C	D	
TFT-274015S	43.8	27.4	20.7	-	φ 26.5



(2) Line noise filter

Type : FR-BLF (Mitsubishi Electric Corp.)



7 Appendix

Appendix 1 : Specifications discussion material (RV-4F/7F series)

■ Customer information

Company name		Name	
Address		Telephone	

■ Purchased model

Item	Type ^{Note1)}				Controller ^{Note2)}
Chemical-resistant specifications (SExx01)	<input type="checkbox"/> RV-4FM-D-SExx01	<input type="checkbox"/> RV-4FLM-D-SExx01	<input type="checkbox"/> RV-7FM-D-SExx01	<input type="checkbox"/> RV-7FLM-D-SExx01	CR750-0*VD-1
	<input type="checkbox"/> RV-4FM-1D-SExx01	<input type="checkbox"/> RV-4FLM-1D-SExx01	<input type="checkbox"/> RV-7FM-1D-SExx01	<input type="checkbox"/> RV-7FLM-1D-SExx01	CR751-0*VD-0
Food machinery grade H1/grease specifications (SExx02)	<input type="checkbox"/> RV-4FM-D-SExx02	<input type="checkbox"/> RV-4FLM-D-SExx02	<input type="checkbox"/> RV-7FM-D-SExx02	<input type="checkbox"/> RV-7FLM-D-SExx02	CR750-0*VD-1
	<input type="checkbox"/> RV-4FM-1D-SExx02	<input type="checkbox"/> RV-4FLM-1D-SExx02	<input type="checkbox"/> RV-7FM-1D-SExx02	<input type="checkbox"/> RV-7FLM-1D-SExx02	CR751-0*VD-0

Note1) Refer to the [Page 2, "1.2 Model type name of robot"](#) for the details of the robot arm type name.

Note2) "*" in the controller shows the maximum load of the robot arm. (4kg: "4", 7kg: "7")

■ Shipping special specifications

Item	Standard specification	Special shipping specifications
Robot arm	CE Marking specification Not conforming with EMC directive.	<input type="checkbox"/> Not provided <input type="checkbox"/> -S15

■ Options (Installable after shipment)

Item		Type	Provision, and specifications when provided.	
J1 axis operating range change	1F-DH-06	For SExx01 of the RV-4F series:	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	1F-DH-03	For SExx02 of the RV-4F series:	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	1F-DH-07	For SExx01 of the RV-7F series:	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	1F-DH-04	For SExx02 of the RV-7F series:	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
Robot arm	1S- <input type="checkbox"/> CBL-01	Fixed type (For CR750, SExx01/02):	<input type="checkbox"/> Not provide	<input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
	1S- <input type="checkbox"/> LCB-01	Flexed type (For CR750, SExx01/02):	<input type="checkbox"/> Not provide	<input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
	1F- <input type="checkbox"/> UCBL-03	Fixed type (For CR751, SExx01):	<input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
	1F- <input type="checkbox"/> LUCBL-03	Flexed type (For CR751, SExx01):	<input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
	1F- <input type="checkbox"/> UCBL-02	Fixed type (For CR751, SExx02):	<input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
	1F- <input type="checkbox"/> LUCBL-02	Flexed type (For CR751, SExx02)	<input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
Solenoid valve set	1F-VDO <input type="checkbox"/> -04	For SExx01	<input type="checkbox"/> Not provide	
	1F-VDO <input type="checkbox"/> E-04	1F-VDO <input type="checkbox"/> -04 (Sink type):	<input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set	
	1F-VDO <input type="checkbox"/> -02	1F-VDO <input type="checkbox"/> -02 (Sink type):	<input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set	
	1F-VDO <input type="checkbox"/> E-02	1F-VDO <input type="checkbox"/> E-02 (Source type):	<input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set	
Hand input cable	1F-HC35S-02	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided	
Hand output cable	1F-GR35S-02	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided	
Hand curl tube	1E-ST040 <input type="checkbox"/> C	<input type="checkbox"/> Not provided	<input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set	
Forearm external wiring set	1F-HB0 <input type="checkbox"/> S-02	For SExx01:	<input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HB01S-02 <input type="checkbox"/> 1F-HB02S-02
	1F-HB0 <input type="checkbox"/> S-01	For SExx02:	<input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HB01S-01 <input type="checkbox"/> 1F-HB02S-01
Base external wiring set	1F-HA0 <input type="checkbox"/> S-02	For SExx01:	<input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HA01S-02 <input type="checkbox"/> 1F-HA02S-02
	1F-HA0 <input type="checkbox"/> S-01	For SExx02:	<input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HA01S-01 <input type="checkbox"/> 1F-HA02S-01
Controller	Simple teaching pendant	R32TB- <input type="checkbox"/> R33TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided	R32TB (CR750 controller): <input type="checkbox"/> 7m <input type="checkbox"/> 15m R33TB (CR751 controller): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Highly efficient teaching pendant	R56TB- <input type="checkbox"/> R57TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided	R56TB (CR750 controller): <input type="checkbox"/> 7m <input type="checkbox"/> 15m R57TB (CR751 controller): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Parallel I/O interface	2D-TZ368/ 2D-TZ378	<input type="checkbox"/> Not provided	2D-TZ368(Sink type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc. 2D-TZ378(Source type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc.
	External I/O cable (For parallel I/O interface)	2D-CBL <input type="checkbox"/> (2D-TZ368/TZ378)	<input type="checkbox"/> Not provided	<input type="checkbox"/> 5m-()pc. <input type="checkbox"/> 15m-()pc.
	Parallel I/O unit	2A-RZ361/ 2A-RZ371	<input type="checkbox"/> Not provided	<input type="checkbox"/> 2A-RZ361(Sink type)/() unit <input type="checkbox"/> 2A-RZ371(Source type)/() unit
	External I/O cable (For Parallel I/O unit)	2A-CBL <input type="checkbox"/> (2A-RZ361/RZ371)	<input type="checkbox"/> Not provided	<input type="checkbox"/> 5m-()pc. <input type="checkbox"/> 15m-()pc.
CC-Link interface	2D-TZ576		<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
Controller protection box	CR750-MB		<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	CR751-MB		<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
RT ToolBox2	3D-11C-WINE		<input type="checkbox"/> Not provided	<input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
RT ToolBox2 mini	3D-12C-WINE		<input type="checkbox"/> Not provided	<input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
Instructions manual	5F-FF03-PE01		<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided () sets

■ Maintenance parts (Consumable parts)

Maintenance parts	<input type="checkbox"/> Backup batteries ER6 () pcs.	<input type="checkbox"/> Backup batteries Q6BAT () pcs.	<input type="checkbox"/> Grease () cans
-------------------	--	--	--

■ Robot selection check list

Work description	<input type="checkbox"/> Material handling <input type="checkbox"/> Assembly <input type="checkbox"/> Machining L/UL <input type="checkbox"/> Sealing <input type="checkbox"/> Testing and inspection <input type="checkbox"/> Other ()		
Workpiece mass ()g	Hand mass ()g	Atmosphere	<input type="checkbox"/> Chemicals (Contact your dealer.) <input type="checkbox"/> Water <input type="checkbox"/> Other()
		Remarks:	

Appendix 2 : Specifications discussion material (RV-7FLL)

■ Customer information

Company name	Name
Address	Telephone

■ Purchased model

Item	Type ^{Note1)}	Controller
Chemical-resistant specifications (SExx01)	<input type="checkbox"/> RV-7FLLM-D-SExx01	CR750-07VLD-1
	<input type="checkbox"/> RV-7FLLM-1D-SExx01	CR751-07VLD-0
Food machinery grade H1 grease specifications (SExx02)	<input type="checkbox"/> RV-7FLLM-D-SExx02	CR750-07VLD-1
	<input type="checkbox"/> RV-7FLLM-1D-SExx02	CR751-07VLD-0

Note1) Refer to the [Page 2, "1.2 Model type name of robot"](#) for the details of the robot arm type name.

■ Shipping special specifications

Item	Standard specification	Special shipping specifications
Robot arm	CE Marking specification Not conforming with EMC directive.	<input type="checkbox"/> Not provided <input type="checkbox"/> -S15

■ Options (Installable after shipment)

Item		Type	Provision, and specifications when provided.
Robot arm	J1 axis operating range change	1F-DH-08 1F-DH-05J1	For SExx01: <input type="checkbox"/> Not provided <input type="checkbox"/> Provided For SExx02: <input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	Machine cable extension	1S- <input type="checkbox"/> CBL-01	Fixed type (For CR750, SExx01/02): <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
		1S- <input type="checkbox"/> LCB-01	Flexed type (For CR750, SExx01/02): <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
		1F- <input type="checkbox"/> UCBL-03	Fixed type (For CR751, SExx01): <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> LUCBL-03	Flexed type (For CR751, SExx01): <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> UCBL-02	Fixed type (For CR751, SExx02): <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> LUCBL-02	Flexed type (For CR751, SExx02): <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
	Solenoid valve set	1F-VDO <input type="checkbox"/> -04 1F-VDO <input type="checkbox"/> E-04	For SExx01 <input type="checkbox"/> Not provide 1F-VDO <input type="checkbox"/> -04 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set 1F-VDO <input type="checkbox"/> E-04 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
		1F-VDO <input type="checkbox"/> -02 1F-VDO <input type="checkbox"/> E-02	For SExx02 <input type="checkbox"/> Not provide 1F-VDO <input type="checkbox"/> -02 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set 1F-VDO <input type="checkbox"/> E-02 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
	Hand input cable	1F-HC35S-02	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided
Controller	Hand output cable	1F-GR35S-02	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	Hand curl tube	1E-ST040 <input type="checkbox"/> C	<input type="checkbox"/> Not provided <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
	Forearm external wiring set	1F-HB0 <input type="checkbox"/> S-02	For SExx01: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HB01S-02 <input type="checkbox"/> 1F-HB02S-02
		1F-HB0 <input type="checkbox"/> S-01	For SExx02: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HB01S-01 <input type="checkbox"/> 1F-HB02S-01
	Base external wiring set	1F-HA0 <input type="checkbox"/> S-02	For SExx01: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HA01S-02 <input type="checkbox"/> 1F-HA02S-02
		1F-HA0 <input type="checkbox"/> S-01	For SExx02: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HA01S-01 <input type="checkbox"/> 1F-HA02S-01
	Simple teaching pendant	R32TB- <input type="checkbox"/> R33TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided R32TB (CR750): <input type="checkbox"/> 7m <input type="checkbox"/> 15m R33TB (CR751): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Highly efficient teaching pendant	R56TB- <input type="checkbox"/> R57TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided R56TB (CR750): <input type="checkbox"/> 7m <input type="checkbox"/> 15m R57TB (CR751): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Parallel I/O interface	2D-TZ368/ 2D-TZ378	<input type="checkbox"/> Not provided 2D-TZ368(Sink type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc. 2D-TZ378(Source type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc.
	External I/O cable (For parallel I/O interface)	2D-CBL <input type="checkbox"/> (2D-TZ368/TZ378)	<input type="checkbox"/> Not provided <input type="checkbox"/> 5m-()pc. <input type="checkbox"/> 15m-()pc.
	Parallel I/O unit	2A-RZ361/ 2A-RZ371	<input type="checkbox"/> Not provided <input type="checkbox"/> 2A-RZ361(Sink type)/() unit <input type="checkbox"/> 2A-RZ371(Source type)/() unit
	External I/O cable (For Parallel I/O unit)	2A-CBL <input type="checkbox"/> (2A-RZ361/RZ371)	<input type="checkbox"/> Not provided <input type="checkbox"/> 5m-()pc. <input type="checkbox"/> 15m-()pc.
	CC-Link interface	2D-TZ576	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	Controller protection box	CR750-MB	CR750 : <input type="checkbox"/> Not provided <input type="checkbox"/> Provided
		CR751-MB	CR751 : <input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	RT ToolBox2	3D-11C-WINE	<input type="checkbox"/> Not provided <input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
	RT ToolBox2 mini	3D-12C-WINE	<input type="checkbox"/> Not provided <input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
	Instructions manual	5F-FF03-PE01	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided () sets

■ Maintenance parts (Consumable parts)

Maintenance parts	<input type="checkbox"/> Backup batteries ER6 () pcs.	<input type="checkbox"/> Backup batteries Q6BAT () pcs.	<input type="checkbox"/> Grease () cans
-------------------	--	--	--

■ Robot selection check list

Work description	<input type="checkbox"/> Material handling <input type="checkbox"/> Assembly <input type="checkbox"/> Machining L/UL <input type="checkbox"/> Sealing <input type="checkbox"/> Testing and inspection <input type="checkbox"/> Other ()					
Workpiece mass ()g	Hand mass ()g	Atmosphere	<input type="checkbox"/> Chemicals (Contact your dealer.) <input type="checkbox"/> Water <input type="checkbox"/> Other()			
Remarks:						

Appendix 3 : Specifications discussion material (RV-13F/13FL)

■ Customer information

Company name	Name
Address	Telephone

■ Purchased model

Item	Type Note1)	Controller
Chemical-resistant specifications (SExx01)	<input type="checkbox"/> RV-13FM-D-SExx01	<input type="checkbox"/> RV-13FLM-D-SExx01
	<input type="checkbox"/> RV-13FM-1D-SExx01	<input type="checkbox"/> RV-13FLM-1D-SExx01
Food machinery grade H1 grease specifications (SExx02)	<input type="checkbox"/> RV-13FM-D-SExx02	<input type="checkbox"/> RV-13FLM-D-SExx02
	<input type="checkbox"/> RV-13FM-1D-SExx02	<input type="checkbox"/> RV-13FLM-1D-SExx02

Note1) Refer to the [Page 2, "1.2 Model type name of robot"](#) for the details of the robot arm type name.

■ Shipping special specifications

Item	Standard specification	Special shipping specifications
Robot arm	CE Marking specification Not conforming with EMC directive.	<input type="checkbox"/> Not provided <input type="checkbox"/> -S15

■ Options (Installable after shipment)

Item		Type	Provision, and specifications when provided.	
Robot arm	J1 axis operating range change	1F-DH-08	For SExx01: <input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
		1F-DH-05J1	For SExx02: <input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	Machine cable extension	1S- <input type="checkbox"/> CBL-01	Fixed type (For CR750, SExx01/02): <input type="checkbox"/> Not provide	<input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
		1S- <input type="checkbox"/> LCB-01	Flexed type (For CR750, SExx01/02): <input type="checkbox"/> Not provide	<input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
		1F- <input type="checkbox"/> UCBL-03	Fixed type (For CR751, SExx01): <input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> LUCBL-03	Flexed type (For CR751, SExx01): <input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> UCBL-02	Fixed type (For CR751, SExx02): <input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> LUCBL-02	Flexed type (For CR751, SExx02): <input type="checkbox"/> Not provide	<input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
	Solenoid valve set	1F-VDO <input type="checkbox"/> -05	For SExx01: <input type="checkbox"/> Not provide	<input type="checkbox"/>
		1F-VDO <input type="checkbox"/> E-05	1F-VDO <input type="checkbox"/> -05 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set	<input type="checkbox"/> 1F-VDO <input type="checkbox"/> E-05 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
		1F-VDO <input type="checkbox"/> -03	For SExx02: <input type="checkbox"/> Not provide	<input type="checkbox"/>
		1F-VDO <input type="checkbox"/> E-03	1F-VDO <input type="checkbox"/> -03 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set	<input type="checkbox"/> 1F-VDO <input type="checkbox"/> E-03 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
Controller	Hand input cable	1F-HC35S-02	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	Hand output cable	1F-GR35S-02	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	Hand curl tube	1N-ST060 <input type="checkbox"/> C	<input type="checkbox"/> Not provided	<input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
	Forearm external wiring set	1F-HB0 <input type="checkbox"/> S-02	For SExx01: <input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HB01S-02 <input type="checkbox"/> 1F-HB02S-02
		1F-HB0 <input type="checkbox"/> S-01	For SExx02: <input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HB01S-01 <input type="checkbox"/> 1F-HB02S-01
	Base external wiring set	1F-HA0 <input type="checkbox"/> S-02	For SExx01: <input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HA01S-02 <input type="checkbox"/> 1F-HA02S-02
		1F-HA0 <input type="checkbox"/> S-01	For SExx02: <input type="checkbox"/> Not provided	<input type="checkbox"/> 1F-HA01S-01 <input type="checkbox"/> 1F-HA02S-01
	Simple teaching pendant	R32TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided	R32TB (CR750): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
		R33TB- <input type="checkbox"/>		R33TB (CR751): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Highly efficient teaching pendant	R56TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided	R56TB (CR750): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
		R57TB- <input type="checkbox"/>		R57TB (CR751): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Parallel I/O interface	2D-TZ368/ 2D-TZ378	<input type="checkbox"/> Not provided	2D-TZ368(Sink type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc. 2D-TZ378(Source type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc.
	External I/O cable (For parallel I/O interface)	2D-CBL <input type="checkbox"/>	<input type="checkbox"/> Not provided	5m-()pc. <input type="checkbox"/> 15m-()pc.
	Parallel I/O unit	2A-RZ361/ 2A-RZ371	<input type="checkbox"/> Not provided	2A-RZ361(Sink type)/() unit 2A-RZ371(Source type)/() unit
	External I/O cable (For Parallel I/O unit)	2A-CBL <input type="checkbox"/>	<input type="checkbox"/> Not provided	5m-()pc. <input type="checkbox"/> 15m-()pc.
	CC-Link interface	2D-TZ576	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	Controller protection box	CR750-MB	CR750: <input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
		CR751-MB	CR751: <input type="checkbox"/> Not provided	<input type="checkbox"/> Provided
	RT ToolBox2	3D-11C-WINE	<input type="checkbox"/> Not provided	<input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
	RT ToolBox2 mini	3D-12C-WINE	<input type="checkbox"/> Not provided	<input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
	Instructions manual	5F-FF03-PE01	<input type="checkbox"/> Not provided	<input type="checkbox"/> Provided () sets

■ Maintenance parts (Consumable parts)

Maintenance parts	<input type="checkbox"/> Backup batteries ER6 () pcs.	<input type="checkbox"/> Backup batteries Q6BAT () pcs.	<input type="checkbox"/> Grease () cans
-------------------	--	--	--

■ Robot selection check list

Work description	<input type="checkbox"/> Material handling <input type="checkbox"/> Assembly <input type="checkbox"/> Machining L/UL <input type="checkbox"/> Sealing <input type="checkbox"/> Testing and inspection <input type="checkbox"/> Other ()					
Workpiece mass ()g	Hand mass ()g	Atmosphere	<input type="checkbox"/> Chemicals (Contact your dealer.) <input type="checkbox"/> Water <input type="checkbox"/> Other()			
Remarks:						

Appendix 4 : Specifications discussion material (RV-20F)

■ Customer information

Company name		Name	
Address		Telephone	

■ Purchased model

Item	Type ^{Note1)}	Controller
Chemical-resistant specifications (SExx01)	<input type="checkbox"/> RV-20FM-D-SExx01	CR750-20VD-1
	<input type="checkbox"/> RV-20FM-1D-SExx01	CR751-20VD-0
Food machinery grade H1 grease specifications (SExx02)	<input type="checkbox"/> RV-20FM-D-SExx02	CR750-20VD-1
	<input type="checkbox"/> RV-20FM-1D-SExx02	CR751-20VD-0

Note1) Refer to the [Page 2, "1.2 Model type name of robot"](#) for the details of the robot arm type name.

■ Shipping special specifications

Item	Standard specification	Special shipping specifications
Robot arm	CE Marking specification Not conforming with EMC directive.	<input type="checkbox"/> Not provided <input type="checkbox"/> -S15

■ Options (Installable after shipment)

Item		Type	Provision, and specifications when provided.
Robot arm	J1 axis operating range change	1F-DH-08	For SExx01: <input type="checkbox"/> Not provided <input type="checkbox"/> Provided
		1F-DH-05J1	For SExx02: <input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	Machine cable extension	1S- <input type="checkbox"/> CBL-01	Fixed type (For CR750, SExx01/02): <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
		1S- <input type="checkbox"/> LCB-01	Flexed type (For CR750, SExx01/02): <input type="checkbox"/> Not provide <input type="checkbox"/> 5m <input type="checkbox"/> 10m <input type="checkbox"/> 15m
		1F- <input type="checkbox"/> UCBL-03	Fixed type (For CR751, SExx01): <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> LUCBL-03	Flexed type (For CR751, SExx01): <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> UCBL-02	Fixed type (For CR751, SExx02): <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
		1F- <input type="checkbox"/> LUCBL-02	Flexed type (For CR751, SExx02) <input type="checkbox"/> Not provide <input type="checkbox"/> 10m <input type="checkbox"/> 15m <input type="checkbox"/> 20m
	Solenoid valve set	1F-VDO <input type="checkbox"/> -05	For SExx01 <input type="checkbox"/> Not provide
		1F-VDO <input type="checkbox"/> E-05	1F-VDO <input type="checkbox"/> -05 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set 1F-VDO <input type="checkbox"/> E-05 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
		1F-VDO <input type="checkbox"/> -03	For SExx02 <input type="checkbox"/> Not provide
		1F-VDO <input type="checkbox"/> E-03	1F-VDO <input type="checkbox"/> -03 (Sink type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set 1F-VDO <input type="checkbox"/> E-03 (Source type): <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
	Hand input cable	1F-HC35S-02	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	Hand output cable	1F-GR35S-02	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	Hand curl tube	1N-ST060 <input type="checkbox"/> C	<input type="checkbox"/> Not provided <input type="checkbox"/> 1set <input type="checkbox"/> 2set <input type="checkbox"/> 3set <input type="checkbox"/> 4set
	Forearm external wiring set	1F-HB0 <input type="checkbox"/> S-02	For SExx01: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HB01S-02 <input type="checkbox"/> 1F-HB02S-02
		1F-HB0 <input type="checkbox"/> S-01	For SExx02: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HB01S-01 <input type="checkbox"/> 1F-HB02S-01
	Base external wiring set	1F-HA0 <input type="checkbox"/> S-02	For SExx01: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HA01S-02 <input type="checkbox"/> 1F-HA02S-02
		1F-HA0 <input type="checkbox"/> S-01	For SExx02: <input type="checkbox"/> Not provided <input type="checkbox"/> 1F-HA01S-01 <input type="checkbox"/> 1F-HA02S-01
Controller	Simple teaching pendant	R32TB- <input type="checkbox"/> R33TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided R32TB (CR750): <input type="checkbox"/> 7m <input type="checkbox"/> 15m R33TB (CR751): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Highly efficient teaching pendant	R56TB- <input type="checkbox"/> R57TB- <input type="checkbox"/>	<input type="checkbox"/> Not provided R56TB (CR750): <input type="checkbox"/> 7m <input type="checkbox"/> 15m R57TB (CR751): <input type="checkbox"/> 7m <input type="checkbox"/> 15m
	Parallel I/O interface	2D-TZ368/ 2D-TZ378	<input type="checkbox"/> Not provided 2D-TZ368(Sink type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc. 2D-TZ378(Source type)/ <input type="checkbox"/> -1pc. <input type="checkbox"/> -2pc.
	External I/O cable (For parallel I/O interface)	2D-CBL <input type="checkbox"/> (2D-TZ368/TZ378)	<input type="checkbox"/> Not provided <input type="checkbox"/> 5m-()pc. <input type="checkbox"/> 15m-()pc.
	Parallel I/O unit	2A-RZ361/ 2A-RZ371	<input type="checkbox"/> Not provided <input type="checkbox"/> 2A-RZ361(Sink type)/() unit <input type="checkbox"/> 2A-RZ371(Source type)/() unit
	External I/O cable (For Parallel I/O unit)	2A-CBL <input type="checkbox"/> (2A-RZ361/RZ371)	<input type="checkbox"/> Not provided <input type="checkbox"/> 5m-()pc. <input type="checkbox"/> 15m-()pc.
	CC-Link interface	2D-TZ576	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	Controller protection box	CR750-MB	CR750: <input type="checkbox"/> Not provided <input type="checkbox"/> Provided
		CR751-MB	CR751: <input type="checkbox"/> Not provided <input type="checkbox"/> Provided
	RT ToolBox2	3D-11C-WINE	<input type="checkbox"/> Not provided <input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
	RT ToolBox2 mini	3D-12C-WINE	<input type="checkbox"/> Not provided <input type="checkbox"/> Windows XP/Vista/7/8/8.1/10 English CD-ROM
	Instructions manual	5F-FF03-PE01	<input type="checkbox"/> Not provided <input type="checkbox"/> Provided () sets

■ Maintenance parts (Consumable parts)

Maintenance parts	<input type="checkbox"/> Backup batteries ER6 () pcs.	<input type="checkbox"/> Backup batteries Q6BAT () pcs.	<input type="checkbox"/> Grease () cans
-------------------	--	--	--

■ Robot selection check list

Work description	<input type="checkbox"/> Material handling <input type="checkbox"/> Assembly <input type="checkbox"/> Machining L/UL <input type="checkbox"/> Sealing <input type="checkbox"/> Testing and inspection <input type="checkbox"/> Other ()					
Workpiece mass ()g	Hand mass ()g	Atmosphere	<input type="checkbox"/> Chemicals (Contact your dealer.) <input type="checkbox"/> Water <input type="checkbox"/> Other()			
Remarks:						



Product Service

EC-Statement of Compliance

No. E6 15 02 25554 053

Holder of Certificate: Mitsubishi Electric Corporation

Tokyo BILD., 2-7-3 Marunouchi,
Chiyoda-ku
Tokyo
100-8310 JAPAN

Name of Object: Industrial, Scientific and Medical equipment
Industrial Robot**Model(s):** F series
(See Attachment for Nomenclature)**Description of Object:** Rated Voltage: 230 VAC
Rated Power: 1.7 kW
Protection Class: I**Tested according to:** EN 61000-6-4/A1:2011
EN 61000-6-2:2005

This EC-Statement of Compliance is issued according to the Directive 2004/108/EC relating to electromagnetic compatibility. It confirms that the listed apparatus complies with such aspects of the essential requirements of the EMC directive as specified by the manufacturer or his authorized representative in the European Community and applies only to the sample and its technical documentation submitted to TÜV SÜD Product Service GmbH for testing and certification. See also notes overleaf.

Technical report no.: 73552066

Date, 2015-02-10

(Johann Roidt)



TÜV SÜD Product Service GmbH is Notified Body to the Directive 2004/108/EC of the European Parliament and of the council with the identification number 0123.

Page 1 of 8



Product Service

Attachment

Statement No.

E6 15 02 25554 053A: Model name of **F** series Robot description is shown as follows.

A1:RH-3FH,RH6FH,RH-2FH series 1.7kW

RH-x FH xx xx x - x x x-Sxx

(1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11)

(1)**RH**: Horizontal Robot

(2) Maximum Payload specification:

3 : 3kg **2** : 2kg**6** : 6kg(3) **F** : **F** series robot(4) **H** : 4 joints

(5) Robot Arm length(No1 and No2 arm) specification:

35 : 350 mm arm **15** : 150 mm arm**45** : 450 mm arm**55** : 550 mm arm

(6) Z stroke length specification:

12 : 120 mm arm **25** : 250 mm arm**15** : 150 mm arm**20** : 200 mm arm**34** : 340 mm arm

(7) Dimension and Ambient specification:

M : Oil mist model(IP65)**C** : Clean room model(ISO5)

[none] : Basic model(IP54)

(8) Type of Robot controller cabinet

[none] : CR750 controller

1 : CR751 controller

(9) Robot controller type:

D : Stand alone type**Q** : iQ platform type

(10) Standard:

0: normal type

1: CE marking model

2: CE marking and UL model

(11) Optional Specification:

1 : normal type

SM : added cabinet box over Robot controller for oil mist resist

Sxx : Mechanical option

Attachment

Statement No.

E6 15 02 25554 053



Product Service

A2:RH-12FH,RH-20FHseries 1.7kW

RH-x FH xx xx x - x x x-Sxx

(1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11)

(1)**RH**: Horizontal Robot

(2) Maximum Payload specification:

12 : 12kg

20 : 20kg

(3) **F** : F series robot

(4) **H** : 4 joints

(5) Robot Arm length(No1 and No2 arm) specification:

55 : 550 mm arm

70 : 700 mm arm

85 : 850 mm arm

100 : 1000 mm arm

(6) Z stroke length specification:

35 : 350 mm arm

45 : 450 mm arm

(7) Dimension and Ambient specification:

M : Oil mist model(IP65)

C : Clean room model(ISO3)

N : Special spec. For EU(IP54)

[none]: Basic model(IP20)

(8) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(9) Robot controller type:

D :Stand alone type

Q :iQ platform type

(10) Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(11) Optional Specification:

1 :normal type

SM :added cabinet box over Robot controller for oil mist resist

Sxx :Mechanical option



Product Service

Attachment

Statement No.

E6 15 02 25554 053

A3:RV-2Fseries 1.7kW

RV-x F x x - x x x-Sxx

(1) (2) (3) (4)(5) (6)(7) (8) (9)

(1)**RV**: Vertical Robot

(2) Maximum Payload specification:

2 : 2kg(3) **F** : F series robot

(4)Robot Joint type

B :All axes have brake units.

[none] :J4 axis doesn't have brake unit.

(5)Robot Arm length

L : Long Arm model

[none] : normal model

(6) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(7)Robot controller type:

D :Stand alone type**Q** :iQ platform type

(8)Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(9)Optional Specification:

1 :normal type

SM :added cabinet box over Robot controller for oil mist resist

Sxx :Mechanical option



Product Service

Attachment

Statement No.

E6 15 02 25554 053

A4:RV-4F,7Fseries 1.7kW

RV-x F x x x - x x x-Sxx

(1) (2) (3) (4)(5) (6) (7) (8) (9) (10)

(1)**RV**: Vertical Robot

(2) Maximum Payload specification:

4 : 4kg**7** : 7kg(3) **F** : F series robot

(4) Robot axes:

J : 5 axes model

[none]: normal model

(5) Robot arm length:

L : Long arm model

[none]: normal model

(6) Dimension and Ambient specification:

M : Oil mist model(IP67)**C** : Clean room model(ISO3)

[none] : Basic model(IP40)

(7) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(8) Robot controller type:

D :Stand alone type**Q** :iQ platform type

(9) Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(10) Optional Specification:

1 :normal type**SM** :added cabinet box over Robot controller for oil mist resist**SH** :Internal tube and wires are extended to J6 axis.**Sxx** :Mechanical option



Product Service

Attachment

Statement No.

E6 15 02 25554 053

A5:RV-13F,20F,7FLLseries 1.7kW

RV-x F x x - x x x-Sxx

(1) (2) (3) (4) (5) (6) (7) (8) (9)

(1)**RV**: Vertical Robot

(2) Maximum Payload specification:

13 : 13kg **20** : 20kg
7 : 7kg(3) **F** : F series robot

(4) Robot arm length:

L : Long arm model**LL** : Long reach(1503mm) model (for only RV-7FLL series)

[none]: normal model

(5) Dimension and Ambient specification:

M : Oil mist model(IP67)**C** : Clean room model(ISO3)

[none] : Basic model(IP40)

(6) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(7) Robot controller type:

D : Stand alone type**Q** : iQ platform type

(8) Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(9) Optional Specification:

1 :normal type

SM : added cabinet box over Robot controller for oil mist resist

SH : Internal tube and wires are extended to J6 axis.

Sxx : Mechanical option



Product Service

Attachment

Statement No.

E6 15 02 25554 053

A6:RH-1FHR,RH-3FHR series 1.7kW

RH-x F HR xx xx x - x x x-Sxx

(1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11)

(1)**RH**: Horizontal Robot

(2) Maximum Payload specification:

1 : 1kg**3** : 3kg(3) **F** : F series robot(4)**HR** :4 joints ,reverse mount model

(5) Robot Arm length(No1 and No2 arm) specification:

35 : 350 mm arm **75** : 750 mm arm**55** : 550 mm arm

(6) Z stroke length specification:

12 : 120 mm arm**15** : 150 mm arm

(7) Dimension and Ambient specification:

W : Water proof model**M** : Oil mist model**C** : Clean room model(ISO5)

[none] : Basic model(IP54)

(8) Type of Robot controller cabinet

[none] :CR750 controller

1 :CR751 controller

(9)Robot controller type:

D :Stand alone type**Q** :iQ platform type

(10)Standard:

0: normal type

1:CE marking model

2:CE marking and UL model

(11)Optional Specification:

1 :normal type**SM** :added cabinet box over Robot controller for oil mist resist**Sxx** :Mechanical option



Product Service

Attachment

Statement No.

E6 15 02 25554 053B: Model name of **F** series Robot controller description is shown as follows.

CR750- xx x x x - x - x - Sxx
 (1) (2) (3) (4) (5) (6) (7) (8)

(1)**CR750**: CR750 controller**CR751**: CR751 controller

(2) Maximum Payload specification:

01 : 1kg**03** : 3kg**06** : 6kg**12** : 12kg**20** : 20kg**02** : 2kg**04** : 4kg**07** : 7kg**13** : 13kg

(3) Robot type

H : Horizontal robot**HR** : Horizontal robot(reverse mount)**V** : Vertical robot**VJ** : 5 axes Vertical robot**VL** : for only RV-7FLL series

(4) Robot controller type

D : stand alone**Q** : iQ platform type

(5) Standard

1 : CE marking model

2 : CE marking and UL model

(6) Operation Panel

[none] : No panel type

1 : Panel type

(7) Power input connector type

[none] : normal type

P2 : Added cable with a connector and a terminal

P3 : Added cable with a connector and a terminal block

(8) Optional Specification

[none] : normal

SM : Added Cabinet box over robot controller for oil mist resist

Sxx : mechanical option

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

NAGOYA WORKS: 5-1-14, YADA-MINAMI, HIGASHI-KU NAGOYA 461-8670, JAPAN

Authorised representative:

Mitsubishi Electric Europe B.V. FA - European Business Group
Mitsubishi-Electric-Platz 1, D-40882 Ratingen, Germany
Tel: +49(0)2102-4860