AB Power Meter Monitor 1.6.2 - Deployment and Integration Guide

William W. Wallace, NRAO/GBO

2026-10-26

Contents

AB Power Meter Monitor — Deployment & Integration Guide **1**
Contents . . . 1
What changed in 1.6.2 . . . 2
What changed in 1.6.1 . . . 2
What changed in 1.6.0 . . . 3
Components & versions . . . 4
Deployment modes . . . 4
Requirements & environment setup . . . 5
Configuration switches . . . 5
Memory protection (RAM flush) . . . 7
Outputs and persistence . . . 8
Veusz `.vszh5` output . . . 8
Mode A — headless monitor under systemd . . . 9
Mode B — Prometheus exporter . . . 9
Mode C — driving the monitor from Python . . . 10
GUI . . . 10
Graceful stop . . . 10
Testing offline . . . 10
Windows test kit . . . 11
Python version compatibility . . . 11
Restart behaviour & log access . . . 12
Uninstall . . . 12
Troubleshooting . . . 12
Change log . . . 12

AB Power Meter Monitor — Deployment & Integration Guide

Allen-Bradley (Rockwell 1403) site power-meter poller, data logger, GUI and Prometheus exporter for NRAO / Green Bank Observatory site infrastructure monitoring. **Release 1.6.2 (2026-10-26)** — Python 3.12 primary target (Linux and Windows).

The toolset polls AB power meters over HTTP (each meter strictly one page at a time, meters in parallel), parses the 11 HTML table pages, keeps a columnar time series in memory, and writes any combination of CSV, Markdown, **native Veusz `.vszh5` (appended in place)**, FITS and XLSX — or serves the live values to Prometheus. A full manual (LuaLaTeX source and bookmarked PDF) ships in `docs/`.

Contents

- What changed in 1.6.2

- What changed in 1.6.1
- What changed in 1.6.0
- Components & versions
- Deployment modes
- Requirements & environment setup
- Configuration switches
- Memory protection (RAM flush)
- Outputs and persistence
- Veusz `.vszh5` output
- Mode A — headless monitor under systemd
- Mode B — Prometheus exporter
- Mode C — driving the monitor from Python
- GUI
- Graceful stop
- Testing offline
- Windows test kit
- Python version compatibility
- Restart behaviour & log access
- Uninstall
- Troubleshooting
- Change log

What changed in 1.6.2

Area	1.6.1	1.6.2
CSV / Markdown file **open in Excel** (Windows)	Excel blocks writes to an open file; the monitor logged an ERROR for every table on every poll, and a flush could not drop those rows while the file stayed open	one WARNING per file per 10 min; rows stay in memory and are written when the file is closed; a flush / Save Now / stop writes them to `<file>_<stamp>_rescue.csv` / `.md`, merged back in order on the next write (as FITS, XLSX and `.vszh5` already did)
Stopping on Windows	Ctrl+Break (`CTRL_BREAK_EVENT`) killed the headless monitor and the exporter without the final writes	handled like Ctrl+C / SIGTERM: graceful stop with the final writes (monitor 1.6.2, exporter 0.1.1)
Windows testing	—	`windows/` test kit: one-click setup, all suites, Task Manager check, GUI and headless checklists, results zip (below)

What changed in 1.6.1

Area	1.6.0	1.6.1
RAM flush on **Windows**	rows were dropped, but only `gc.collect()` ran: the process kept the freed memory and Task Manager showed no drop	after every flush `return_memory_to_os()` decommits free heap memory (`HeapSetInformation(NULL, HeapOptimizeResources)`) and trims the working set (`EmptyWorkingSet`), so Task Manager's **Memory** column drops at once

Area	1.6.0	1.6.1
Duplicate-row race	a flush / Save Now / stop that waited for a busy writer could read its cursor before it advanced and send the same rows again (seen as extra XLSX rows on Windows Python, possible on any OS)	cursors advance inside the writer task; re-read after the previous write is confirmed done; a writer still running is never started twice on one file
Reporting	—	flush log and GUI show the release steps, RSS (working set) and, on Windows, commit charge; GUI check boxes for both new switches

New switches `MEM_RETURN_TO_OS = 1`, `MEM_TRIM_WORKING_SET = 1`; new API `return_memory_to_os()`, `describe_memory_release()`, `process_commit_mb()`.

What changed in 1.6.0

Defects found and fixed (all reproduced first against the meter emulator in `tests/`):

Area	1.5.5 behaviour	1.6.0
GUI memory	`QTabWidget.clear()` does not delete pages, so every poll leaked the preview tabs and pixmaps: **+1,440 widgets / +255 MB in ~45 s** at a 2 s period	tabs created once and updated in place; 140-poll soak: widget count constant (445)
GUI log console	`QTextEdit` grew forever, DEBUG level	`QPlainTextEdit` capped at `GUI_LOG_MAX_LINES`, INFO level
GUI responsiveness	~40 PNGs rendered on the GUI thread every poll; Poll Now blocked the GUI	only the visible tab is rendered (min/max decimated); polling, writing and flushing run in a worker thread
FITS	`EXTNAME = tname[:8]` collided (two pairs of tables); rows **doubled on every rewrite** (6 polls → 54–59 rows)	full table names; old files separated by `TBLNAME`; atomic writes
CSV / Markdown	in append mode across runs, writing stopped after the first poll	per-row sequence cursors; files never re-read to count rows
Store-size flush	wrote files, never cleared the store; GUI never checked it	one flush path for GUI/headless/caller; always persists, then clears
RAM-% flush	fired on every poll once *other* processes used the RAM	minimum interval + minimum store size; process-RSS trigger added
Freed memory	`gc.collect()` only; RSS stayed high	`malloc_trim(0)` on Linux after a flush
Exporter	re-exported a dead meter's last values indefinitely; `samples_total` was not monotonic	per-table latest snapshot; down/stale tables not exported; real counters
Concurrency	`ALL_DEVICE_DATA` rebuilt while the GUI iterated it	swapped under a lock
Duplicates	duplicate IPs polled one meter from two threads; duplicate parameter names overwrote each other	IP list de-duplicated; duplicate names kept as `Name [#N]`
Python 3.12	`datetime.utcnow()` deprecation warnings	timezone-aware UTC; test suite runs with `-W error::DeprecationWarning`
Service wrapper	`POLL_INTERVAL` was read but never passed to the monitor	passed as `--interval`

Veusz output is now written natively with `vszh5_writer.py` (h5py) — the `veusz` package is **not** needed to

write files, only to view them.

Components & versions

File	Version	Role
`ab_power_meter_monitor.py`	**1.6.2**	Poller, store, persistence engine, RAM flush, GUI, CLI
`vszh5_writer.py`	**0.0.18**	Native Veusz `.vszh5` writer + in-place appender (h5py)
`ab_prometheus_exporter.py`	**0.1.1**	Prometheus exporter (uses the monitor as a library)
`ab_meter_caller.py`	**1.3.0**	Drive the monitor one poll at a time from Python
`ab_caller_Example.py`	1.2.0	Usage examples (Spyder cells)
`ab_ramflush_off_Example.py`	1.1.0	Caller + Prometheus with RAM flush off
`ab_stop.py`	1.1.0	Graceful stop (writes `STOP_COLLECTION`)
`install.sh`	1.1.0	systemd installer (monitor and/or exporter; system or user)
`install-mamba.sh`	1.1.0	Pure conda-forge environment (Python 3.12 default)
`abmeter_wrapper.sh`	1.1.0	Single-instance service wrapper (flock + PID)
`abmeter.service`, `ab-exporter.service`	1.1.0	systemd unit templates
`abmeter_logrotate.conf`	—	logrotate policy (system mode)
`requirements-py312.txt`	1.6.0	**pip deps, Python 3.12 (primary, tested)**
`requirements.txt`	1.6.0	pip deps, Python 3.8 – 3.12
`requirements-py37.txt`	1.6.0	pinned pip deps, Python 3.7.x
`environment.yml`	1.6.0	mamba interpreter 3.12 + pip
`environment-conda.yml`	1.6.0	pure conda-forge, Python 3.12
`environment-py37.yml`	—	mamba 3.7.11 + pinned pip
`tests/`	0.0.1 – 0.0.2	meter emulator, offline / memory / file-lock / exporter tests, GUI and headless soaks, Windows memory check, test runner
`windows/`	1.0.0	Windows test kit: setup and run scripts, pinned conda-forge specs, `START_HERE.md`
`docs/`	1.6.2	LuaLaTeX manual source + bookmarked PDF

Deployment modes

Mode	Use when	Entry point
A. Headless monitor	files written on a schedule under systemd	`ab_power_meter_monitor.py --headless`
B. Prometheus exporter	live metrics for Prometheus/Grafana	`ab_prometheus_exporter.py`
C. Python caller	polling driven from your own Python code	`import ab_meter_caller`
GUI	interactive monitoring, previews, Save/Flush buttons	`ab_power_meter_monitor.py --gui`

Modes A and B are independent services and can run side by side.

Requirements & environment setup

Python **3.12** is the primary, tested target (test suite on 3.12.3). The source keeps the Python 3.7 language level, so one code base serves 3.7.11 through 3.12+; only dependency versions differ.

Preferred: mamba (interpreter) + pip (packages)

```
mamba env create -f environment.yml        # env "abmeter", Python 3.12
mamba activate abmeter
```

Equivalent explicit form:

```
mamba create -n abmeter -c conda-forge python=3.12 pip
mamba run -n abmeter pip install -r requirements-py312.txt
```

Pure conda-forge (no pip)

```
mamba env create -f environment-conda.yml
./install-mamba.sh                          # same, scripted; ABMETER_MINIMAL=1 for exporter-only
ABMETER_WITH_VEUSZ=1 ./install-mamba.sh     # also install Veusz as a viewer
```

Python 3.7.11 hosts

```
mamba env create -f environment-py37.yml    # pins from requirements-py37.txt
```

What each dependency is for

Package	Needed for
requests, beautifulsoup4, lxml	always (HTTP + HTML)
psutil	memory protection (RAM %, free RAM, process RSS)
numpy, h5py	Veusz `.vszh5` output (with `vszh5_writer.py` next to the monitor)
astropy	FITS output
openpyxl	XLSX output
PySide6, qtpy, matplotlib	GUI (qtpy is the Qt abstraction layer; it was missing from the 1.5.x requirement files)
prometheus_client	exporter
pypdf (optional)	PDF bookmarks when rendering documents with `vszh5_writer.render_pages()`
Veusz (optional)	viewing `.vszh5` files; “Open in Veusz” button

Configuration switches

All behaviour is set by module-level constants near the top of `ab_power_meter_monitor.py`. They are read at call time, so a caller may override them by assignment (`abm.ENABLE_CSV = 1`).

Outputs

Switch	Default	Meaning
`ENABLE_GUI`	1	PySide6 window; 0 = headless
`ENABLE_CSV`	0	CSV per device per table, appended every poll
`ENABLE_LOG_APPEND`	0	Markdown table log per device per table, appended
`ENABLE_VEUSZ`	0	Veusz `.vszh5` per device, appended in place (native)

Switch	Default	Meaning
VEUSZ_APPEND_EVERY_CYCLE	1	1 = every poll; 0 = only at flush / Save Now / stop
ENABLE_FITS	0	FITS per device (rewritten on a cadence, atomically)
ENABLE_XLSX	0	Excel workbook per device (streamed rewrite on a cadence)
ENABLE_LOG_FILE	0	ab_monitor.log
FULL_WRITE_EVERY_N_CYCLES	10	FITS/XLSX every N polls (0 = only flush/stop)
APPEND_OUTPUT_FILES	1	0 = start every file afresh once per run
FSYNC_OUTPUTS	1	fsync appended CSV/MD (survives power loss)
VEUSZ_WRITE_ON_FLUSH	0	**deprecated, no effect** (document is appended continuously)

Memory protection

Switch	De-fault	Meaning
ENABLE_RAM_FLUSH	1	master enable for automatic flushes
MEM_FLUSH_THRESHOLD_MB	256	flush when the store estimate exceeds N MB
MEM_PROC_RSS_LIMIT_MB	0	flush when this process's RSS exceeds N MB (0 = off)
MEM_RAM_PCT_LIMIT	60	flush when system RAM use ≥ N % (store must be ≥ MEM_MIN_STORE_MB_FOR_CLEAR)
MEM_FREE_MIN_MB	512	flush when system free RAM < N MB (same condition)
MEM_MIN_STORE_MB_FOR_CLEAR	1.0	system-wide triggers only clear a store at least this big
MEM_FLUSH_MIN_INTERVAL_SEC	120	minimum time between automatic flushes
RAM_FLUSH_KEEP_SAMPLES	0	newest rows per table kept after a flush (GUI default 120)
RAM_FLUSH_SPILL_PICKLE	0	pickle the store before clearing when no file output is enabled
MEM_RETURN_TO_OS	1	after a flush, hand the freed memory back to the OS (Linux malloc_trim; Windows heap decommit)
MEM_TRIM_WORKING_SET	1	Windows: also trim the working set after a flush (Task Manager "Memory" drops at once)

Devices, timing, paths, file sizes

Switch	Default	Meaning
IP_LIST	[…]	meter IPs (duplicates removed)
METER_URL_TEMPLATE	http://{ip}/{page}	page URL (proxy, port forward, emulator)
SAMPLE_PERIOD_SEC	30	seconds between poll starts
HTTP_TIMEOUT_SEC / HTTP_RETRY_COUNT / HTTP_RETRY_DELAY_SEC	8 / 2 / 2.0	per page
HEADLESS_LOOP_COUNT	1	headless polls (0 = until stopped)
HEADLESS_MAX_CONSEC_FAILS	3	stop after N all-failed polls (0 = never)
OUTPUT_BASE_DIR	./ab_meter_output	output root; env ABMETER_OUTPUT_DIR overrides
VSZH5_MAX_FILE_MB	256	.vszh5 rollover size (0 = never)
VSZH5_TIME_AXIS	local	local (DST-aware) or utc date axis
FITS_MAX_ROWS_PER_FILE	100000	FITS rollover (0 = never)
XLSX_MAX_ROWS_PER_FILE	50000	XLSX rollover (Excel limit 1,048,576 rows)
PREVIEW_MAX_POINTS	2000	GUI preview points per series (min/max decimation)

Switch	Default	Meaning
`ENABLE_SIGNAL_HANDLERS`	1	0 when embedded in a host that owns SIGINT/SIGTERM

CLI overrides (script use only): `--headless | --gui --count N --interval S --ips a,b --ram-pct P --no-ram-flush --output-dir DIR --url-template T`.

Memory protection (RAM flush)

A **flush** first persists every enabled output and waits for the writes, then drops only the rows that **every** enabled output has confirmed, optionally keeps the newest `RAM_FLUSH_KEEP_SAMPLES` rows, removes empty tables, and hands the freed memory back to the operating system (`MEM_RETURN_TO_OS`, see below). Rows an output failed to write stay in memory and are retried — a flush never loses data that was not written. With no data output enabled the rows are dropped (or pickled to `spill/` when `RAM_FLUSH_SPILL_PICKLE = 1`; read them with `abm.load_spill(path)`).

Triggers (any one, with `ENABLE_RAM_FLUSH = 1` and at least `MEM_FLUSH_MIN_INTERVAL_SEC` since the last flush): store estimate > `MEM_FLUSH_THRESHOLD_MB`; process RSS > `MEM_PROC_RSS_LIMIT_MB`; system RAM ≥ `MEM_RAM_PCT_LIMIT`; free RAM < `MEM_FREE_MIN_MB`. The two system-wide triggers only act when the store holds at least `MEM_MIN_STORE_MB_FOR_CLEAR`, because clearing a tiny store cannot relieve RAM used by other processes (1.5.x then cleared the store on every poll).

The store estimate is computed in $O(\text{tables})$ every poll. For a table with n rows and k parameters (CPython 64-bit):

$$B \approx n\,(32\,k + 144) \text{ bytes},$$

where 32 B is one float object (24 B) plus its list slot (8 B), and 144 B per row covers the timestamp string, sequence number and Unix time. For example, 2 meters × 11 tables × 12 parameters at one poll per 30 s for a day ($n = 2880$) gives

$$B \approx 22 \times 2880 \times (32 \cdot 12 + 144) = 33\,454\,080 \text{ B} \approx 31.9 \text{ MiB}.$$

Returning memory to the operating system

Dropping rows frees Python objects, but the allocators underneath keep freed memory for re-use: CPython's pymalloc returns a 1 MiB arena only when every object in it is free, the C heap keeps freed blocks committed, and on Windows even released pages stay in the process's *working set* (Task Manager's "Memory" column) until Windows trims it. After every flush, with `MEM_RETURN_TO_OS = 1`, the monitor therefore calls:

OS	Call	Effect
Linux (glibc)	`malloc_trim(0)`	returns free heap pages to the kernel
Windows 8.1+	`HeapSetInformation(NULL, HeapOptimizeResources, {1, 0})`	every heap with a low-fragmentation heap: caches optimised, free memory decommitted where possible (the call Firefox makes under memory pressure)
Windows	`EmptyWorkingSet(GetCurrentProcess())` (`MEM_TRIM_WORKING_SET`)	removes as many pages as possible from the working set; the RAM goes back to Windows at once, pages still in use fault back in on first access

OS	Call	Effect
macOS, other	—	`gc.collect()` only

`_heapmin()` is deliberately **not** called: in the Universal CRT used by python.exe it is just `HeapCompact()`, which Microsoft documents as not compacting anything further on a normal system. On Windows, watch two numbers: **RSS** (= working set, Task Manager "Memory") drops right after a flush; **commit** (private bytes, Task Manager "Commit size") drops by what the heaps could decommit. Both are shown in the flush log and in the GUI status line.

(The monitor reports "MB" as MiB, 2^{20} bytes.)

GUI: **Flush RAM Now** and **Save Now** buttons, a memory line (store, values, rows, RSS, system RAM, flush count), and a "Keep after flush" spin box.

Outputs and persistence

Every stored row receives a process-wide sequence number. Each output keeps, per folder and per (device, table), the last sequence number it persisted, so a poll writes only rows that are new to that output — $O(\text{new rows})$, never $O(\text{file size})$ — and nothing is written twice or skipped across flushes, trims and restarts.

Output	When written	How
CSV	every poll	appended; new parameters add columns (one streamed rewrite)
Markdown	every poll	appended; changed columns start a new section
`.vszh5`	every poll (or flush/stop)	appended in place, see below
FITS	every `FULL_WRITE_EVERY_N_CYCLES` polls, flush, Save Now, stop	merged and replaced atomically; `EPOCH_UTC` column
XLSX	same as FITS	read-only → write-only streaming copy, replaced atomically

A file locked by another program (Excel, a FITS viewer, Veusz loading) is retried on the next poll; when data must land now (flush, Save Now, stop) the rows go to a timestamped `*_rescue.*` file, which FITS/XLSX merge back later. Unreadable files are moved aside (`*_unreadable.csv`, `*.corrupt_<stamp>`).

Veusz `.vszh5` output

One document per meter, `veusz/ABMeter_<ip>.vszh5`, written with `vszh5_writer.VeuszAppender` (h5py, no Veusz needed):

- per table a date dataset `<octet>_dt_<table>` and one dataset per parameter `<octet>_<table>_<param>` (collision-free, never truncated; 1.5.x cut names at 64 characters);
- rows are appended each poll; datasets are chunked, resizable, uncompressed (no file bloat from re-compressed chunks), fill value NaN;
- a parameter that appears later is back-filled with NaN; the Veusz page script is rewritten only when datasets are added: per-table grid pages (`VSZH5_PANELS_PER_PAGE`, 2 columns) and per-unit overlay pages;
- the table→dataset index is stored under `/VszAppend` (Veusz reads only `/Veusz`), so appending resumes after a restart;

- rollover to `ABMeter_<ip>_<stamp>_closed.vszh5` at `VSZH5_MAX_FILE_MB`.

Verified by loading and rendering the appended documents in real Veusz 4.2.1 (23 pages + PDF). **Open in Veusz** in the GUI brings the documents up to date and launches the Veusz program (`VEUSZ_EXE` or PATH).

Mode A — headless monitor under systemd

```
sudo ./install.sh                    # system mode (abmeter user, /opt/abmeter)
./install.sh --user                  # per-user mode, no sudo
sudo journalctl -u abmeter -f
```

The wrapper passes `POLL_COUNT`, `POLL_INTERVAL` and optional `RAM_PCT_LIMIT` from the unit's `Environment=` lines; `ABMETER_OUTPUT_DIR` moves the output.

Variable	Default	Description
`POLL_COUNT`	0	polls (0 = until stopped)
`POLL_INTERVAL`	30	seconds between polls (passed as `--interval` since 1.1.0)
`RAM_PCT_LIMIT`	—	optional `--ram-pct`
`INSTALL_DIR`	`/opt/abmeter`	installation root

Single instance: systemd PID tracking, `flock --nonblock` in the wrapper, PID file in `/run/abmeter/`. Installer flags: `--user`, `--exporter`, `--only-exporter`, `--python PATH`, `--mamba` (Python 3.12), `--py37`, `--ips`, `--port`, `--interval`, `--max-history`. The installer now also installs `vszh5_writer.py` and picks `requirements-py312.txt` on Python ≥ 3.12.

Mode B — Prometheus exporter

```
python ab_prometheus_exporter.py --ips 10.16.130.50,10.16.130.54 --interval 30
sudo ./install.sh --only-exporter --ips 10.16.130.50,10.16.130.54 --port 9184
```

Data model (0.1.0): a background thread polls; each table is stored in the exporter's own latest snapshot (`ip → table → {parameter: (value, unit)}`), replaced whole on a good fetch and **removed** on a failed fetch or when its meter is down — dead meters are no longer exported with their last values. `--stale-after` (default 2.5 × interval) drops anything older. A scrape only reads that snapshot (no network I/O).

Flag	Default	Meaning
`--port` / `--bind`	9184 / 0.0.0.0	listen address
`--interval`	30	seconds between polls
`--ips`	monitor `IP_LIST`	meters
`--retries` / `--retry-delay` / `--timeout`	2 / 2.0 / 8	per page
`--stale-after`	2.5 × interval	freshness window (0 = never stale)
`--timestamps`	off	expose each value with its fetch time
`--url-template`	`http://{ip}/{page}`	page URL
`--max-history`	—	accepted for old unit files, ignored

```
ab_meter_value{ip,table,parameter,unit}         latest value
ab_meter_up{ip}                                 meter answered the last poll
ab_meter_table_up{ip,table}                     table fetched and fresh
ab_meter_last_fetch_timestamp_seconds{ip,table} last good fetch (Unix s)
ab_meter_samples_total{ip,table}                successful fetches (monotonic)
ab_meter_table_fetch_errors_total{ip,table}     failed fetches
```

```
ab_meter_poll_duration_seconds                 last poll duration
ab_meter_last_poll_timestamp_seconds           last poll time
ab_meter_polls_total / ab_meter_poll_errors_total
ab_meter_build_info{version,monitor_version}
```

One sample per meter reading. Prometheus stores one sample per scrape, so scraping faster than `--interval` records each reading more than once. Either set `scrape_interval` equal to `--interval`, or run with `--timestamps` (repeated scrapes of one reading then collapse to one sample). Prometheus discourages exporter timestamps in general, so this is opt-in.

```yaml
scrape_configs:
  - job_name: ab_power_meter
    scrape_interval: 30s
    static_configs:
      - targets: ["exporter-host:9184"]
```

Mode C — driving the monitor from Python

```python
import ab_meter_caller as abc
data = abc.run(count=3, interval=30)                          # 3 polls
data = abc.run(count=0, interval=30, enable_ram_flush=False)  # until ab_stop.py

import ab_power_meter_monitor as abm                          # run API (1.6.0)
cfg = abm.begin_run(); status = abm.poll_cycle(cfg); abm.end_run(cfg)
```

`run()` returns `abm.TIME_SERIES_STORE` (`data[ip][table]["timestamps_local" | "columns" | "units"]`, unchanged). Use `abm.store_snapshot()` for an independent copy and `abm.trim_store(n)` instead of slicing the lists by hand.

GUI

Light/dark theme (View menu; previews follow it); output and memory controls; Poll Now, Start Auto, Stop, **Save Now**, **Flush RAM Now**, **Open in Veusz**; a preview tab per table and per unit overlay (only the visible tab is rendered; an interactive zoom/pan window per plot). Closing the window waits for the final writes (no thread is terminated mid-write).

Graceful stop

```
sudo systemctl stop abmeter          # SIGTERM -> clean stop
python ab_stop.py                    # STOP_COLLECTION file (monitor, caller, exporter)
python ab_stop.py --output-dir /srv/abmeter
```

All paths write every enabled output before exiting.

Testing offline

```
python tests/test_vszh5_appender.py       # writer/appender (+ real Veusz if VEUSZ_EXE set)
python tests/test_monitor_offline.py      # no loss / no duplicates / locks / triggers
python tests/test_exporter_offline.py     # exporter data model + process
python tests/test_memory_release.py       # flush returns memory to the OS (Linux + Windows)
python tests/test_windows_file_locks.py   # outputs held open by another program (Excel)
python tests/windows_memory_check.py      # working set / commit before and after a flush
python tests/headless_soak_test.py --minutes 10   # real CLI, every output, stop, leaks
```

```
python tests/run_all_tests.py --quick     # all of the above + report + results zip
QT_QPA_PLATFORM=offscreen python tests/gui_soak_test.py 150
python tests/ab_meter_emulator.py --hosts 127.0.0.2,127.0.0.3 --port 8080   # manual
```

The emulator serves the 11 pages per host with drifting values, string cells, a duplicated parameter name and optional faults (`--fail-pages`, `--down-after`, `--slow-ms`). Point the monitor at it with `--url-template "http://{ip}:8080/{page}" --ips 127.0.0.2,127.0.0.3`.

Windows test kit

`windows/` holds everything needed to test on a Windows 10/11 PC without meters (the emulator serves two meters on 127.0.0.2/.3). Extract the kit (or this repository) to a path without spaces, e.g. `C:\ABTest`, then run:

Step	Script	What it does
1	`1_setup_environment.bat`	creates `env\` from `environment-windows-test.txt` (conda-forge, exact versions) with mamba / conda / micromamba, or a venv from `py -3.12`; optional `env_veusz\` with Veusz 4.2.1
2	`2_run_all_tests.bat [--quick]`	`tests/run_all_tests.py`: system report + eight suites + `results\AB_TestResults_<computer>_<time>.zip`
3	`3_task_manager_check.bat`	flush runs that pause 20 s each, to watch the working set fall in Task Manager
4	`4_gui_with_emulator.bat`	the GUI against the emulator, with a hands-on checklist (Excel lock, Flush RAM Now, Open in Veusz)
5	`5_headless_with_emulator.bat`	visible headless run; stop with Ctrl+C / Ctrl+Break

Details, the GUI checklist and troubleshooting: `windows/START_HERE.md`. The scripts avoid `||` / `&&` after `call` (explicit `if errorlevel` checks instead), so they behave the same under every `cmd` implementation.

Python version compatibility

Python	Status	Requirements
3.12	**primary, tested** (3.12.3; DeprecationWarnings as errors)	`requirements-py312.txt` / `environment*.yml`
3.8 – 3.11	supported	`requirements.txt`
3.7.11	language level kept (syntax-checked)	`requirements-py37.txt` (h5py 3.8.0, qtpy 2.4.3 added)
3.12 on **Windows**	offline, memory-release, appender and exporter suites pass on the Windows build (conda-forge win-64, Python 3.12.15) run under Wine 9.0; Wine runs the Windows code paths but not the Windows memory manager, so the Task Manager drop itself is documented, not measured	`environment-conda.yml`

Tested package versions (3.12): numpy 2.5.4, h5py 3.16.0, astropy 8.0.2, openpyxl 3.1.5, PySide6 6.12.0, qtpy 2.4.3, matplotlib 3.11.2, lxml 6.1.3, psutil 7.2.2, prometheus-client 0.26.0, requests 2.34.2, beautifulsoup4 4.15.0; Veusz 4.2.1 (conda-forge) as viewer.

Restart behaviour & log access

`Restart=on-failure  RestartSec=15  StartLimitBurst=5  StartLimitIntervalSec=120`

A clean exit (code 0, e.g. via `ab_stop.py`) does not restart.

```
sudo journalctl -u abmeter -f
journalctl --user -u abmeter -f
```

Uninstall

```
sudo systemctl disable --now abmeter
sudo rm /etc/systemd/system/abmeter.service /etc/logrotate.d/abmeter
sudo systemctl daemon-reload
sudo userdel abmeter; sudo rm -rf /opt/abmeter        # optional
```

Troubleshooting

Symptom	Check
RSS still high after a flush (Windows)	check `MEM_RETURN_TO_OS = 1` / `MEM_TRIM_WORKING_SET = 1` and the flush log line `OS release [heap_optimize ok, working_set_trim ok]`; commit can stay higher than RSS when the heap is fragmented — it is re-used, and RSS stops growing
“store holds only X MB — a flush would not help”	system RAM is used by other processes; raise `MEM_RAM_PCT_LIMIT` or find the consumer
`.vszh5 is open in another program`	Veusz is loading the file; rows are kept and written on the next poll
`*_rescue.*` files	the main file was locked during a flush/stop; FITS/XLSX merge them back automatically; `.vszh5` rescue files are complete standalone documents
`vszh5_writer.py not importable`	put `vszh5_writer.py` next to the monitor; install numpy + h5py
Exporter shows no values for a meter	expected while it is down (`ab_meter_up 0`); see `ab_meter_table_fetch_errors_total`
Prometheus shows each reading twice	set `scrape_interval` = `--interval`, or run with `--timestamps`
Old FITS files with mixed rows	written by 1.5.x (EXTNAME collision); start a new file — 1.6.0 separates tables by `TBLNAME` but cannot unmix old rows
Service ignores the interval	update `abmeter_wrapper.sh` to 1.1.0

Change log

Component	Version	Change
monitor	1.6.2	See What changed: Excel-locked CSV/MD handled with rescue files; Ctrl+Break graceful stop.
exporter	0.1.1	Ctrl+Break (SIGBREAK) stops cleanly on Windows.
windows kit	1.0.0	Setup / run scripts, test runner, Windows memory check, file-lock and headless soak tests.

Component	Version	Change
monitor	1.6.1	See What changed: RAM flush returns memory to Windows; duplicate-row race in forced persists fixed.
monitor	1.6.0	See What changed: GUI leak, FITS row multiplication, append-mode CSV/MD, functional RAM flush, native appended `.vszh5`, run API, Python 3.12.
vszh5_writer	0.0.18	`VeuszAppender`, `VeuszWriter(resizable=True)`; revision history renumbered (0.0.16).
exporter	0.1.0	Latest-snapshot data model; no stale re-export; monotonic counters; `--timestamps`, `--stale-after`, `--bind`.
caller	1.3.0	Uses `begin_run/poll_cycle/end_run`.
examples / stop	1.2.0 / 1.1.0 / 1.1.0	House headers; `trim_store`; `ABMETER_OUTPUT_DIR`.
kit	1.1.0	Installer installs `vszh5_writer.py`, picks 3.12 requirements; wrapper passes `--interval`.
monitor	1.5.5	Restore stdout/stderr on unexpected loop errors.
monitor	1.5.4	CLI front-end.
monitor	1.5.2	`ENABLE_RAM_FLUSH`.
monitor	1.5.1	`ENABLE_SIGNAL_HANDLERS`.

Author: W. Wallace — NRAO / Green Bank Observatory · `wwallace@nrao.edu` · +1 (304) 456-2216