

# **PowerFlex 40 Programming and Setup Guide**

## **General Precautions**

Important safety guidelines including capacitor discharge times, ESD handling, and qualified personnel requirements.

## **Mounting and Installation**

Mount the drive upright on a flat surface. Maintain clearances based on enclosure type. Protect from dust, corrosion, and direct sunlight.

## **Electrical Connections**

Proper wiring for input power (single-phase/three-phase), motor connections (U/T1, V/T2, W/T3), grounding, and MOV jumper removal for ungrounded systems.

## **Specifications and Ratings**

Covers input/output ratings, protection features, fuses, circuit breakers, dynamic braking, and efficiency.

## **Terminal Blocks**

Power terminal block wiring, torque requirements, I/O terminal descriptions, and analog/digital input/output configuration.

## **Control and Keypad**

Keypad functions including Start, Stop, Reverse, Escape, parameter navigation, and integral potentiometer usage. LED indicators explained.

## **Start-Up Procedure**

Checklist before applying power, applying power steps, and verifying DIP switch settings. Ensures drive is safe to run.

## **Programming Parameters - Basic Group**

Motor nameplate settings (voltage, frequency, overload current), min/max frequency, start/stop sources, accel/decel times, and factory reset option.

## **Programming Parameters - Advanced Group**

Covers digital inputs/outputs, relay options, analog scaling, jog frequency, braking, boost settings, auto restart, PID control, autotune, and communication settings.

## **Fault Codes**

Common faults such as undervoltage, overvoltage, motor overload, ground fault, communication loss, and corrective actions.

## **Dimensions and Frames**

Drive frame sizes, mounting clearances, and enclosure options.