



BimmerStein Bin Analyzer

User Manual

ECU Binary Analysis and Map Editing

Version 0.2.18 | Windows x64 | September 2026

This manual covers the 0.2.18 application. Check the version of your installed release if a control described here is missing. Screenshots use synthetic demonstration data; they are not tuning recommendations or real ECU calibrations.

[Printable PDF](#) | [Downloads](#) | [Issues and feedback](#)

Contents

1. What the app does
2. Install and start
3. First session
4. Workspace and navigation
5. Detection and reviewing a found table
6. Definitions and addresses
7. Conversion factors and table properties
8. Axes and the axis library
9. Table, curve and switch views
10. 3D surfaces and preview
11. Editing and undo
12. Saving BINs and reading checksum reports
13. Projects, closing and replacing files
14. Exports and map packs
15. Family modules and session sharing
16. Keyboard reference
17. Troubleshooting and support

1. What the app does

BimmerStein Bin Analyzer opens a saved ECU firmware image, searches for potential calibration tables, and lets you inspect their layout, axes and values. You can import RomRaider definitions, refine detected tables, edit values, save a separate BIN, and export definitions or map packs.

The primary validated family is **BMW Siemens MS41**, including stock and community variants. Other images can be inspected with the generic detector, but a plausible shape does not establish a table's function or correct scaling. Detection does not guarantee every map, scalar, switch or runtime-dependent structure has been found. A high confidence score is not a tuning approval.

This is an offline Windows application. It does not connect to, read, write or flash an ECU. There is no Android version. Use your separate flashing tool for ECU transfers after independently reviewing the output.

Keep an unchanged source BIN and the matching definitions. A checksum result describes the regions the app checked; it does not establish mechanical safety, firmware compatibility or the suitability of a calibration for an engine.

The three files you may save

File	What it contains	Main command
BIN	Firmware bytes, including your value edits and supported checksum corrections	Save Bin / Save Bin As
Project (.binproj.json)	Map definitions, axes, potential maps, format defaults and the referenced BIN identity	Save Project
Definition or map list	Descriptions of tables for another editor or analysis tool	Export

A project does **not** contain the BIN bytes or an unsaved edit history. Save the BIN first, then the project, when keeping an edited calibration.

2. Install and start


1. Open the project's **Downloads** link and choose the intended version.
2. Download the Windows x64 -[setup.exe](#) or [.msi](#) installer. Choose one installer format for your installation.
3. Run the installer and follow its prompts, then launch **BimmerStein Bin Analyzer**.
4. If the app cannot start because WebView2 is unavailable, install the Microsoft Edge WebView2 Runtime, then try again.

Installers are unsigned. Windows may display a SmartScreen warning. Verify the download source and release filename before choosing to proceed. Source build instructions are in the repository README.

Updating the application does not replace your separately saved BINs, projects or exported definitions. Keep backups of those files before updating.

3. First session

1. Click **Open Bin** and select a firmware file, or drop it onto the app window.
2. Check the file name, byte size and abbreviated SHA-256 in the bottom status bar. File identity matters more than its name.
3. Wait for **scan done**. **Cancel scan** stops a running scan; **Rescan** starts another scan of the current working bytes.
4. If you have the matching RomRaider definition, click **Import Def**, choose its XML file and select the correct ROM entry when prompted.
5. Select a map in the left sidebar, then click **map** for its values or **3d** for a surface. Use **preview** to keep a small surface visible beside another view.
6. Review the address, dimensions, byte format, axes and scaling before editing.
7. Save a project to preserve your table definitions. If you edited values, save the BIN to a separate file first.



Workspace with synthetic maps and a rotatable preview

The sidebar lists confirmed/imported maps separately from unconfirmed potential maps. The right-hand area follows the selected view. The bottom bar reports the loaded image, selection, changed-byte count, scan state and available checksum or save reports.

4. Workspace and navigation

Resize the map list

Drag the narrow vertical divider at the right edge of the sidebar. Widen it to read longer names, addresses and filter choices. The divider can also receive keyboard focus with **Tab**: **Left/Right Arrow** changes its width, and **Home** restores the default. Double-clicking the divider also resets it.

The width is limited so the main view remains available. It lasts for the current app window and is not stored in a project. Scroll the sidebar to reach additional maps. Hover a truncated map name to read its full name.

View controls

Control	Use
hex	Inspect addresses, raw values, selections and detected regions
2d	View a trace of the selected data/range
3d	View the selected grid as a labeled surface
map	View a table, a curve with its values, or named switch states
preview	Show or hide the small 3D surface
Swap X/Y	Transpose a selected two-dimensional map for display

width is the number of bytes per raw value: 1, 2 or 4. **LoHi (LE)** means little-endian; **HiLo (BE)** means big-endian. **signed** changes the interpretation of raw values. These toolbar controls frame raw browsing and new manual selections; existing maps retain their own stored format.

Use **M/W** to increase/decrease the raw view's column count and **Ctrl+Left/Right** to move the origin by a byte. These are inspection controls, not instructions to move bytes inside the BIN.

5. Detection and reviewing a found table

Search and filters

Use **Search maps** for a name, hexadecimal address or shape such as **20x16**. Combine it with **All shapes** and **All methods**, or use **Clear filters** to restore the complete lists. When filtered, the heading shows visible/total counts.

Click a potential map to inspect it and read its **Detection evidence** text above the lists. Badges describe how it was found:

Method	Meaning
FAMILY	ECU-family analysis, which can include firmware references and structural fallbacks
STRUCT	Structure inferred from stored headers and axis lengths
POOL	Byte candidate associated with shared axes
Generic / byte patterns	Shape and byte-pattern evidence without a family-specific identification

The badge alone does not prove a firmware caller, a table name or an exact address. Read the selected candidate's explanation and compare it with the BIN and a definition known to match that firmware.

Confirm or define a map

Double-click a potential map, or select it and press **K**, to promote it to **Maps**. Promotion records a table definition; it does not rewrite its values. For a manual map, select a byte range in the raw view, choose a suitable width and column framing, then press **K**. Check the resulting dimensions and range.

Confirmed maps have a **Properties** pencil button. The remove button removes the map definition, not its bytes. Undo can restore a removed definition.

Review suspicious boundaries or axes

In **Map properties**, use **Review table layout** to inspect alternative addresses, dimensions and formats. Compare the candidate preview before **Apply table layout**. This changes how the bytes are described; it does not move or rewrite the underlying data. An applied layout can be undone.

Use **Review detected axes** to compare proposed axis bindings and their breakpoint previews. Apply a pair only when its meaning and lengths fit the table. Undo restores both previous axes together. A layout or axis proposal is evidence for review, not confirmation that it belongs to the selected function.

6. Definitions and addresses

Import Def accepts RomRaider ECU XML. If the file describes more than one ROM, select the entry corresponding to the loaded firmware. Import messages report skipped or unsupported content; read them before relying on the result.

Imported definitions are not guaranteed to match an arbitrary BIN with the same ECU family name. A partial calibration and a full ROM can also use different address frames. For recognized MS41 full reads, the app can map calibration storage addresses into the full image. Answer the address-frame prompt according to how the definition was authored, not according to which answer imports more maps.

Addresses in map properties identify **byte offsets in the loaded file**. A 24 KB calibration-only file and a 256 KB full read do not share a universal additive offset. The app's MS41 mapping accounts for the full-read layout. RomRaider exports reverse a supported full-read mapping where possible.

Out-of-range definitions are skipped rather than extending the image. An axis with malformed or nonnumeric labels can fall back to indices with a warning. Numeric static labels, including complete scientific-notation values, can be used as breakpoints. Text such as a descriptive label is not silently interpreted as a numeric prefix.

7. Conversion factors and table properties

To add a conversion factor to a found table:

1. Promote the potential map to **Maps** by double-clicking it or pressing **K**.
2. Click its **Properties** pencil button.
3. Set **factor**, **offset**, **units**, and **digits** under **Scaling**.
4. Click **Save** and inspect the displayed values. Save the project to retain the conversion for a later session.


The conversion is:

physical value = raw value × factor + offset

For example, with raw value **100**, factor **0.5**, offset **-10**, units **deg** and digits **1**, the displayed result is **40.0 deg**. This is only an arithmetic example; it is not a prescribed MS41 conversion.

Field	Effect
Name / Category	Identify and organize the map
factor	Multiply the stored raw value
offset	Add a constant after multiplication
units	Describe the physical quantity, such as rpm or V
digits	Number of decimal places displayed

Changing scaling describes the same existing bytes differently. Typing a new cell value performs the inverse conversion and changes bytes. Do not substitute a guessed factor for a verified definition or firmware measurement.



Scaling (physical = raw × factor + offset)

factor 0.5

offset -10

units deg

digits 1

Map properties scaling controls

Each axis has its **own** scaling. Changing the map factor does not change the X or Y breakpoint conversion. Use the axis controls for that.

Unsupported imported nonlinear expressions remain preserved and are shown as raw values with a warning. Changing factor/offset does not remove such an expression. Use a correctly supported definition rather than assuming the warning has been resolved. A zero factor cannot be inverted for value editing.

8. Axes and the axis library


An axis can be **referenced** (breakpoints stored in the BIN), **literal** (static values supplied by a definition), or **index** (0, 1, 2 and so on). An index axis supplies positions, not an inferred physical quantity.

In Map properties, **Edit locally** lets you define or revise a referenced axis's address, count, format, name and scaling. Its count must fit the table dimension. Literal axes cannot be edited with the referenced-axis form.

Remove removes the binding and allows an index fallback.

Save to library adds the current referenced or literal axis to the reusable axis library. **Pick from library** lists compatible entries for the selected slot. **Detach** removes its library link while preserving the map's inline axis definition.

Click **Axes** in the toolbar to open the library. You can create a referenced axis, inspect its attached maps, attach it to compatible slots, edit its metadata, or detach/remove it. After editing a library entry, choose whether to update its attached slots; existing copies are not silently changed.



Axis library with a synthetic shared load axis

Editing an axis definition changes metadata. Editing a referenced breakpoint in the table changes BIN bytes. Multiple maps can share those exact bytes, so a breakpoint edit can affect all of them. Review the shared-axis notice before changing a value. Literal/index headers have no editable storage bytes.

9. Table, curve and switch views

map adapts to the selected definition:


- A two-dimensional table shows a spreadsheet with X headers across columns and Y headers down rows. The header identifies its data address, dimensions, value width and units.
- A curve shows a line plot and its value grid. Use this for single-axis calibrations and inspect the corresponding breakpoint values.
- A scalar shows its single value.
- A switch shows the stored byte pattern and the matching named state, or **Custom** when no supplied state matches. The switch view is read-only.

Swap X/Y transposes a two-dimensional map's display in the table, full 3D view and preview. It also keeps breakpoint labels paired with the corresponding data dimension. It does not rewrite the BIN, change storage orientation, or transpose exported definitions. Curves and scalars do not use this toggle.

A definition may legitimately place RPM across columns and load down rows, or the opposite. Use the display toggle for your preferred presentation. If the labels or values themselves are wrong, review the actual definition and axis bindings instead of trying to fix them through display transposition.

10. 3D surfaces and preview

Select a table with at least two rows and two columns, then click **3d**. The surface shows colored cells, a base grid, breakpoint tick labels and axis names/units from the selected definition. The title identifies the map and its value units. Vertical ticks use the scaled physical values; blue represents lower values and red higher values within this surface.



Full 3D surface with named axes, units and value ticks

Drag with the left mouse button to rotate. Scroll over the canvas to zoom. **Reset view** restores the initial camera angle and zoom. The surface updates when data or scaling changes while retaining its current camera orientation.

preview opens the same surface in a smaller panel while you use another view. Drag directly inside that panel to rotate it; scroll there to zoom. Its **Reset** button affects only the preview camera. Press **P** or click **preview** again to hide it when it covers information you need.



Compact 3D preview

Cell spacing follows the table's row and column indices, even when physical breakpoints are unevenly spaced. Labels show the actual breakpoint values. The height and color ranges are normalized for each selection, so visual height alone cannot compare absolute values between different maps. Read the ticks. Only representative ticks are printed to keep the plot readable.

Missing axes are labeled **X (index)** or **Y (index)**. Unknown value units are shown as **raw**. Unsupported conversions are explicitly identified as raw. Raw range selections have no definition-based scaling. Curves, scalars, empty selections and non-finite data do not produce a valid 3D surface.

11. Editing and undo

Double-click a table cell, type the desired **displayed physical value**, then press **Enter** or move focus to commit. **Escape** cancels the active editor. The app converts back to the stored format and redisplay the representable result. Rounding can change the last displayed digit; a format-limit clamp is reported. Invalid or empty numeric input is rejected.

Click a cell to select it; Shift-click another to form a rectangular selection. **+ / -** changes selected values by one raw storage step, which need not be one physical unit. For factor **0.5**, one raw step corresponds to **0.5** physical units. Check the selection before using these shortcuts.

Double-click a referenced axis header to edit a stored breakpoint. Axis changes use that axis's format and scaling. A shared breakpoint is shared data, even if it is visible through several table definitions.

Changed cells/axis headers are highlighted. The status bar counts changed **bytes**, not table cells: changing a word may affect one or two bytes. The journal is relative to the file as opened, so its changed-byte count can remain after a successful save to a separate output.

Use **Ctrl+Z** for undo and **Ctrl+Shift+Z** for redo. **F11** toggles original values in the table/curve display for comparison; the original-value badge identifies that mode. The 3D surfaces continue to show working data.

Revert selection restores the selected region from the originally opened image. **Revert all changes** restores all byte edits to that original. Revert is itself undoable. These commands target original bytes, not the last saved output, so a revert after saving may create new unsaved differences.

12. Saving BINs and reading checksum reports

1. Click **Save Bin As** to choose a new output filename. **Save Bin** also asks for a destination the first time; later it uses that session's saved target.
2. Choose a path different from the file you originally opened. The app refuses to overwrite that source path, including when opened through a project.
3. Review the save result. The app applies supported checksum corrections, writes the file, then reads it back and compares its SHA-256.
4. If there is a warning or failed verification, resolve it before using the output for a transfer. A written file and a fully checked image are distinct.

The status bar's saved-file button reopens the last save report. The checksum button opens details for the current image when a family module recognizes it. Read individual blocks and the reasons for any skipped checks.

Result	What to do
Corrected and verified	Review the reported coverage and your edits before using the file
Unrecognized image / checksum not checked	Obtain the appropriate checksum validation for this exact firmware
Edits touch an uncorrected region	Use an appropriate external correction/verification path
Existing uncorrectable mismatch	Investigate the input image and its applicable checksum rules
Structure no longer recognized	Review edits to identity or structural bytes
Read-back mismatch or save failure	Do not use that output; choose a working destination and save again

MS41 program checksums are reported but never rewritten by this application. A partial image cannot contain checksums for absent full-ROM regions. Some community firmware also requires variant-specific interpretation. Do not assume every checksum is corrected merely because saving completed.

If newer edits arrive while a save is in progress, the saved snapshot can be valid while those newer edits remain unsaved. The app reports this; save again to include them.

13. Projects, closing and replacing files

Save Project writes a `.binproj.json` containing confirmed maps, potential maps, axes, value defaults and the identity of the associated BIN. After saving an edited BIN, save its project beside that output so reopening can locate it. Projects can retain the original source identity as lineage for an edited file.

Open Project first looks for the recorded BIN beside the project. If it is missing, select its location. A SHA-256 mismatch produces a separate warning because the map addresses might describe different bytes. Cancel if you cannot establish that the files belong together. Incompatible out-of-range definitions are reported and dropped. Rescan after opening a project if you need fresh detection results and region shading.

Close the current BIN

Click **Close Bin**. The confirmation reminds you to save both byte edits and project metadata as appropriate. Cancel to return to your work, or continue to clear the loaded session and stop its running scan. The application remains open. Closing a BIN does not delete its file.

Open a different BIN or project

This version works with **one BIN at a time**. Open Bin, dropping another BIN, and Open Project warn before replacing an existing session, including when its bytes are unchanged. Definitions or axis metadata may still need a project save. Cancel retains the existing session; accepting replaces it after the new file can be read. There is no automatic save and no multiple-BIN tab system.

The window-close button also warns about unsaved byte edits. It does not track unsaved project metadata separately, so save the project before quitting even if you have not changed a BIN value.

14. Exports and map packs

Choose a format next to **Export**, then choose a destination.

Format	Intended use
CSV	A map inventory for inspection or a spreadsheet
JSON	A structured map inventory, including available metadata
RomRaider XML	Confirmed table definitions for a compatible editor
TunerPro XDF	Confirmed definitions in TunerPro's format

CSV/JSON are map lists, not a replacement for a saved edited BIN. Definition exports describe confirmed maps; review format warnings and unsupported items. The Export button requires at least one confirmed map. Display-only Swap X/Y does not alter exported definitions.

Export Pack creates a reusable map pack from edited confirmed tables. A pack records its base-image identity and expected bytes so the receiving app can check compatibility. It is not a complete firmware image.

Apply Pack opens a review panel. Inspect its image match, each table's byte comparison, available details and any conflict/mismatch explanation. Select only eligible rows you intend to apply, then apply them. Incompatible rows are blocked; do not treat a pack as a general cross-firmware conversion tool. Applying changes the working buffer; save the BIN separately when satisfied. Cancel applies nothing.

15. Family modules and session sharing

Families

Families lists built-in and loaded family modules. A family module can recognize an image and provide byte/checksum semantics. Use **Add module** to select a module file, **Reload** to reload configured modules, and the remove control for an added module. The dialog identifies the configured folder.

These are executable extensions, not ordinary definition files. Load only modules you trust and that support the exact intended family. A checksum family module does not automatically add a new detection algorithm or prove that all tables in that ECU can be found.

Optional co-pilot connection

Share session with co-pilot is off by default. Enabling it permits a configured external tool to inspect the session and submit proposals. The status bar shows whether it is waiting, connected or reconnecting. Disable sharing when the session should no longer be exposed.

Review proposed changes in the app before accepting them. Check their target map, addresses and before/after values. Accepting a proposal applies the chosen change to the working session; saving to disk remains a separate operation. Connection setup and the command reference are in the repository's **apps/mcp/README.md**. No external connection is required for ordinary offline use.

16. Keyboard reference

These shortcuts work when focus is outside text inputs and no modal dialog is open. Finish or cancel a numeric edit before using workspace shortcuts.

Shortcut	Action
M / W	Increase / decrease raw-view columns
Ctrl+Left / Ctrl+Right	Shift raw-view origin by a byte
K	Define the selection as a map, or promote the selected potential map
F / Shift+F	Next / previous potential map
T / Shift+T	Next / previous main view
P	Toggle the 3D preview
Ctrl+B	Optimize the visible raw-value range
Ctrl+Z	Undo
Ctrl+Shift+Z	Redo
+ / -	Increase / decrease the selected values by a raw storage step
F11	Toggle original-value comparison in table/curve view
Enter / Escape	Commit / cancel the active numeric editor
Left / Right on the sidebar divider	Narrow / widen the sidebar
Home on the sidebar divider	Restore its default width

Use the mouse wheel to scroll lists/grids, or to zoom when the pointer is over a 3D canvas. Left-drag a 3D canvas to rotate it. Tab navigates focusable controls.

17. Troubleshooting and support

Symptom	Check
A map name is truncated	Widen the sidebar or hover the name for its full text
A known map is missing	Clear filters; check the file identity and matching definition; review detection evidence
Too many potential maps	Filter by shape/method and promote only reviewed candidates
Values appear unrealistic	Check data address, width, endian, signedness, factor and offset
The table starts a byte or word early	Review table layout and actual data boundaries; do not compensate with a guessed scaling
RPM and load look swapped	Try Swap X/Y for display; review axis bindings if the headers themselves are incorrect
Axis headers are 0, 1, 2...	Check whether the axis is absent/index-based or an import reported unsupported labels
Editing factor has no effect	Look for an imported unsupported-expression warning; it preserves raw display
A breakpoint cannot be edited	Literal and index axes have no editable BIN storage
A 3D view is blank	Select at least a 2x2 table; check for invalid values and use Reset view
3D preview obscures a control	Toggle preview off with P or the toolbar button
Project cannot find its BIN	Place the recorded BIN beside it or locate the exact file when prompted
Project reports a different hash	Verify you selected the correct source or saved output; do not accept solely because names match
Save refuses the destination	Choose a different path from the originally opened BIN
Changed-byte count remains after saving	The journal compares against the opened source; inspect the save report for the saved snapshot
Checksum warning persists	Open the checksum report and inspect uncorrectable or unchecked blocks
A shared-axis edit changed another map	Both definitions reference the same stored bytes; use Undo and review the shared-axis notice
A switch has no editing control	Named switch states are currently displayed read-only

Before closing a session

1. Review changed values and any shared axes.
2. Save the BIN under the intended output name and inspect its report.
3. Save the project beside that BIN.
4. Keep the original and matching definitions separately.
5. Close the BIN or application when the required files are saved.

Report a problem

Include the application version, Windows version, exact steps, expected result, observed result and relevant error text. For a table issue, include the file size, address, dimensions, format and whether it is a partial or full read. A synthetic reproduction or an appropriately redacted screenshot is useful.

Use [Issues and feedback](#). Do not post proprietary firmware, private definitions, personal identifiers or information you do not have permission to share. Security reports should follow the repository's **SECURITY.md** instructions.

Copyright 2026 Cristian Ayon. BimmerStein Bin Analyzer is licensed under GPL-3.0-or-later. Independent software; not affiliated with a vehicle or ECU manufacturer. Third-party notices are included with the application.