

Dishwasher Maintenance Guide

Follow these steps to maintain your dishwasher and troubleshoot common issues:

- 1 Check and clean the filter at the bottom of the dishwasher once a month. Remove any food debris or buildup.
- 2 Inspect the spray arms for clogs. Use a toothpick to clear any blocked holes.
- 3 Run an empty cycle with white vinegar once a month to remove grease and odors.
- 4 Wipe down the door gasket with a damp cloth to prevent mold and mildew buildup.
- 5 Make sure the drain hose is not kinked or clogged. Check the connection under the sink.
- 6 Use the correct amount of detergent. Too much detergent can cause residue and poor cleaning.
- 7 Load dishes properly (do not block the spray arms or overcrowd the racks).
- 8 Check water temperature. Hot water should be at least 120°F for optimal cleaning.
- 9 If the dishwasher is not draining, check the garbage disposal connection and air gap.
- 10 Contact maintenance if you notice leaking, unusual noises, or error codes on the display.