For kernel;

1. Copy the kernel package 2.6.34.1 to the system storage,

   ```
   # dpkg -i xxx.deb
   # update-initramfs –k 2.6.34.1-vortex86-sg -c
   # update-grub
   ```

PS: must complete it as above, and be sure all procedure completed and no error or fail.

File: ftp://vxmx:gc301@ftp.dmp.com.tw/Linux/Source/linux-image-2.6.34.1-vortex86-sg_1.0_i386.deb

2. If your system used the GRUB2 as the boot loader, then you have to revise the file /boot/grub/grub.cfg. To add 16 behind two parts of instruction of 2.6.34.1,

   Menuentry ‘Ubuntu, with Linux 2.6.34.1-vortex86-sg’ –class……
   ……
   ……
   Linux16 /boot/vmlinuz-……..
   Echo ‘Loading init……
   Initrd16 /boot/initrd.img……

PS: it would fix the APM can’t automatic shutdown issue.

For VGA driver,

Copy the rdc_drv.so inside the folder of 1.7.5 of VGA driver folder to the /usr/lib/xor/modules/drivers/

```
#/etc/init.d/gdm stop
#X –configure
#/etc/init.d/gdm start
```

Please follow the procedure that I provided as above,
If you encountered some problem, please tell me which steps you are doing, and what the error appear?

File: ftp://vxmx:gc301@ftp.dmp.com.tw/Linux/Source/RDC Xorg Driver R0.0.9.zip