



OWNER'S CARD • START HERE

The whole instrument, front and back

Four rows of keys, played like four strings. Turn it over for your first ten minutes, quick fixes, and every guide.

READ THIS
FIRST

To charge it, the side switch must be ON.

Plug in a switched-off Cardputer and nothing happens: no light, no charge, and it looks broken. It isn't. Switch it on first, then plug in. The left top trigger, **BTN RST**, restarts the device and loses nothing.

THE FOUR ROWS ARE FOUR STRINGS

STRING 3 • HIGH	1	2	3	4	5	6	7	8	9	0
STRING 2	q	w	e	r	t	y	u	i	o	p
STRING 1	a	s	d	f	g	h	j	k	l	;
STRING 0 • LOW	z	x	c	v	b	n	m	,	.	/

← the chord row: tap chords here

Left to right walks up the scale, and every key is a note of it (A minor pentatonic out of the box), so there are no dead keys and nothing to avoid. Each row behaves like a string: one voice, gliding between whatever you press on it.

THE SLIDING IS THE INSTRUMENT

HOLD ONE KEY • PRESS ANOTHER ON THE SAME ROW

Hammer-on

The voice **glides** to the new note instead of restarting. No new attack, no click: one continuous line, like sliding a finger up a string.

THEN LET THE SECOND ONE GO

Pull-off

It glides back down to the key you're still holding. Together they give you trills, grace notes, and the scoops that make a line sound played rather than typed.

HOLD A SHAPE ACROSS ROWS • RE-FINGER IT ELSEWHERE

Slide a chord. This is the thing.

Hold two or three keys across different rows, then move that shape while the old notes still ring. Every voice glides to its new home at once: the gesture no keyboard can make, and why the instrument exists.

TAP THE BOTTOM ROW

One hand backs, one solos

Each tap adds a chord, and they loop one per bar, in key. Solo on the three rows above. **bks** clears them and starts over.

EVERYTHING ELSE, AT A GLANCE

shift (<i>hold</i>)	the notes between: off-scale semitones, only while held
- / =	octave down / up
[/]	bend down / up
space	sustain
bks	panic: silences everything
fn + q..p	switch between the ten sounds, live
fn + shift + q..p	save the live sound over that slot
fn + k / fn + s	step the key / the scale (add shift to go back)
fn + k (<i>hold</i>)	listen: retune to the song in the room
fn + a	arpeggiate the chords
fn + c / fn + h	Advanced: chord mode / harmony
\ / fn + \	tap the tempo / metronome on, off
alt	loop pedal: counts you in, loops on the bar line; hold clears
enter	tilt on / off: lean to blend into your last sound
00 (<i>right trigger</i>)	the performance button: a wah out of the box
tab	settings: Mode, How to play, and more
ctrl / opt	volume down / up
` (<i>hold</i>)	restart, saving your work first

01 • TWO MINUTES

Solo over any song

1. Play a song out loud nearby: a speaker, a phone, the car.
2. Hold **fn + k**. GLIDE goes quiet, listens for a few seconds, and retunes itself to the song's key.
3. Play anything on the top three rows. It fits.
4. Not quite right? Tap **space** while the result is showing to try its next guess.

03 • THE ONE OF ONE PART

Roll a sound nobody else has

1. Slots **o** and **p** were rolled on your device's first boot. No other unit has them.
2. **tab** opens settings. **Randomize** rolls a new sound and plays it for you; **Mutate** nudges the one you have.
3. Like it? Back out and press **fn + shift** + a top-row letter **q..p** to keep it in that slot.

02 • TEN SECONDS

Build a backing, then play over it

1. Tap three or four keys on the bottom row. Each one is a chord, and they loop one per bar.
2. Solo on the rows above. Tap **** in time to set the tempo.
3. **fn + a** turns the chords into an arpeggio. **fn + ** adds a click.
4. **bksp** clears it all and starts over.

04 • USE YOUR HANDS

Blend two sounds by leaning

1. Press **fn + w** (ACID), then **fn + q** (GLIDE).
2. Tilt is already on. Hold a note and tilt the device toward you: GLIDE melts into ACID, the sound you were just on.
3. Lean left and right for vibrato. **enter** turns tilt off when you want it still.

WHEN SOMETHING LOOKS WRONG

► It won't charge or turn on

Slide the side switch ON first, then plug in. A switched-off Cardputer shows no light and takes no charge.

► Stuck in a mode

bksp silences everything and clears the chords. Holding **`** restarts; your sounds and settings stay.

► Keep the SD card in

Your saved sounds live on it. Without a card everything still plays, but saving needs one.

► No sound

opt turns the volume up. Headphones in the jack mute the speaker. **bksp** clears anything stuck.

► Getting to your other apps

Press **BTN RST** (left top trigger) and tap any key as it starts up. That opens the Launcher.

► Updating

New versions are free and your sounds survive them. Scan **updating glide** below for the ten-minute walkthrough.

What the screen says

The trace is your pitch over time. Top left: the sound (* means unsaved), then key and scale. Top right: **OCT**, with **CHORD**, **WAH** or **SOLO** beside it when on. Underneath: tilt, the loop, the chords.

The loop pedal

alt: tap, and four clicks count you in. Tap again and it loops from the bar line. Tap to layer, hold to clear.

Your sounds are safe

Slots, settings and card files live outside the program, so an update never touches them. The whole manual is on the device: **tab** → **How to play**.

Two modes

A new GLIDE starts in Basic: the essentials. **tab** → **Mode** opens Advanced: chord mode, harmony, the sound knobs. Switching loses nothing.

Every guide, a scan away no typing, no app



EVERY GUIDE
AND HELP



PLAYING
GLIDE



PLAY ALONG
WITH ANY SONG



THE SOUND
LIBRARY



UPDATING
GLIDE



THE
DISCORD