Gust envelope diagram per CS-VLA - TecnamP92 4 3 LOAD FACTOR n [g] Point S Point S inverted 10 20 30 50 60 AIRSPEED V [m/s]