

26 Network Management



26.1 Device Discovery with CDP




- Cisco提供的专有的命令
- 获得直接连接的设备的信息摘要
- 运行在数据链路层
- CDP默认自动启动
- CDP默认更新周期60秒
- CDP默认过期周期180秒




CDP CDP概述

- 用CDP发现邻居信息摘要包括:
- 设备ID (Device ID)
- 本地接口(Local Interface)
- 保持时间(Holdtime)
- 功能 (Capability)
- 平台 (Platform)
- 端口ID(Port ID)
- VTP域名(VTP Management Domain Name (CDPv2 only))
- 本征VLAN (Native VLAN (CDPv2 only))
- 全双工/半双工 (Full/Half-Duplex (CDPv2 only))



CDP概述 配置和验证 CDP




CDP概述 配置和验证 CDP



Rl#show cdp neighbors detail Device ID: R2 Entry address(es): IP address : 172.16.12.2 Platform: cisco C2900, Capabilities: Router Interface: SerialO/O/O, Port ID (outgoing port): SerialO/O/O Holdtime: 155 Version : Cisco IOS Software, C2900 Software (C2900-UNIVERSALK9-M), Version 15.1(4)M4, RELEASE SOFTWARE (fc2) Technical Support: http://www.cisco.com/techsupport Copyright (c) 1986-2012 by Cisco Systems, Inc. Compiled Thurs 5-Jan-12 15:41 by pt team advertisement version: 2 Duplex: full Device ID: S1 Entry address(es): IP address : 172.16.1.100 Platform: cisco 3560, Capabilities: Router Interface: GigabitEthernetO/O, Port ID (outgoing port): FastEthernetO/1 Holdtime: 169 Version : Cisco IOS Software, C3560 Software (C3560-ADVIPSERVICESK9-M), Version 12.2(37)SE1, RELEASE SOFTWARE (fcl) Copyright (c) 1986-2007 by Cisco Systems, Inc. Compiled Thu 05-Jul-07 22:22 by pt team advertisement version: 2 Duplex: full

6

CDP概述 配置和验证 CDP



1. 在全局配置模式下使用(no)cdp run 命令开启或关闭所由接口的 CDP功能。默认情况下, CDP被全局开启。

```
Rl(config)#cdp run
Rl(config)#no cdp run
```

2.在接口模式下使用(no) cdp enable 命令可以开启或关闭某个特定接口的CDP功能。


```
Rl(config)#interface serial 0/0/0
Rl(config-if)#no cdp enable
Rl(config-if)#cdp enable
```

26.2 Device Discovery with LLDP



供应商中立的第 2 层邻居发现协议, 类似于 CDP

- 拓扑信息
- 设备的主要能力
- 管理地址
- 设备标识
- 接口标识



- DA: LLDP帧的目的地址,组播地址其值:01-80-C2-00-00-0E
- SA:与设备相邻连接设备的桥MAC
- LLDP Ethertype: 帧类型,它的值为0x88CC
- LLDPDU: LLDP Data Unit, LLDP数据单元,它是LLDP信息交换的主体

0

■ FCS: 帧校验






LLDP概述 配置和验证 LLDP

```
Switch# conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)# lldp run
Switch(config)# interface gigabitethernet 0/1
Switch(config-if)# lldp transmit
Switch(config-if)# lldp receive
Switch(config-if)# end
Switch# show lldp
Global LLDP Information:
    Status: ACTIVE
    LLDP advertisements are sent every 30 seconds
    LLDP hold time advertised is 120 seconds
    LLDP interface reinitialisation delay is 2 seconds
```

```
S1# show lldp neighbors
Capability codes:
    (R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
    (W) WLAN Access Point, (P) Repeater, (S) Station, (O) Other
Device ID
                    Local Intf
                                        Hold-time
                                                            Capability
                                                                                Port ID
                    Fa0/5
                                        117
R1
                                                                      R
                    Gi0/0/1
S2
                    Fa0/1
                                        112
                                                                      В
                    Fa0/1
Total entries displayed: 2
```

LLDP概述 配置和验证 LLDP



Rl#show lldp

Global LLDP Information:

Status: ACTIVE

LLDP advertisements are sent every 30 seconds

LLDP hold time advertised is 120 seconds

LLDP interface reinitialisation delay is 2 seconds

Sl#show lldp neighbors

Capability codes:

- (R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
- (W) WLAN Access Point, (P) Repeater, (S) Station, (0) Other

Device ID Local Intf Hold-time Capability Port ID Rl Fa0/l 120 R Giq0/0

LLDP概述 配置和验证 LLDP




```
Sl#show lldp neighbors detail
Chassis id: 00D0.972D.B101
Port id: GigO/O
Port Description: GigabitEthernet0/0
System Name: Rl
System Description:
Cisco IOS Software, C2900 Software (C2900-UNIVERSALK9-M), Version 15.1(4)M4, RELEASE SOFTWARE (fc2)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2012 by Cisco Systems, Inc.
Compiled Thurs 5-Jan-12 15:41 by pt team
Time remaining: 90 seconds
System Capabilities: R
Enabled Capabilities: R
Management Addresses - not advertised
Auto Negotiation - supported, enabled
Physical media capabilities:
   100baseT(FD)
   1000baseT(HD)
    lbaseT(FD)
Media Attachment Unit type: 10
Vlan ID: 1
Total entries displayed: 1
```

10

26.3 NTP




- NTP 是一种用于同步计算机系统数据网络时钟的协议
- NTP 可以从内部或外部时间来源获得正确的时间
- 时间来源可以是:
 - 本地主时钟
 - 网络上的主时钟
 - GPS 或原子钟
- 可将网络设备配置为 NTP 服务器或 NTP 客户端



NTP简介 **实施 NTP**

- 设置系统时钟
 - 手动配置日期和时间
 - 配置网络时间协议 (NTP)
- NTP 操作
 - 时间源分层系统(stratum)
 - 第0层-权威时间源
 - 第16层(最低层级)表示设备不同步
 - 层数表示服务器距离时间源的远近
- 配置和验证 NTP
 - ntp server ip-address
 - show ntp associations
 - show ntp status
 - show clock






第0层







R1# show clock detail

20:55:10.207 UTC Fri Nov 15 2019

Time source is user configuration

R1(config)# ntp server 209.165.200.225
R1(config)# end
R1# show clock detail
21:01:34.563 UTC Fri Nov 15 2019
Time source is NTP



NTP简介 验证网络时间协议 (NTP)

```
R1# show ntp associations
  address
                 ref clock
                                  st
                                       when
                                              poll reach delay offset
*~209. 165. 200. 225 . GPS.
                                        61
                                               64
                                                    377 0.481
                                                                7.480 4.261
* sys.peer, # selected, + candidate, - outlyer, x falseticker, ~ configured
R1# show ntp status
Clock is synchronized, stratum 2, reference is 209.165.200.225
nominal freq is 250.0000 Hz, actual freq is 249.9995 Hz, precision is 2**19
ntp uptime is 589900 (1/100 \text{ of seconds}), resolution is 4016
reference time is DA088DD3. C4E659D3 (13:21:23.769 PST Fri Nov 15 2019)
clock offset is 7.0883 msec, root delay is 99.77 msec
```

loopfilter state is 'CTRL' (Normal Controlled Loop), drift is 0.000001803 s/s

root dispersion is 13.43 msec, peer dispersion is 2.48 msec


system poll interval is 64, last update was 169 sec ago.

17

26.4 Syslog

系统日志简介 **系统日志功能**


- 系统日志的日志记录服务提供了以下三个主要功能:
- 能够收集日志记录信息来用于监控和故障排除
- 能够选择捕获的日志记录信息的类型
- 能够指定捕获的系统日志消息发送目的地



系统日志简介 系统日志操作

- 支持设备发送消息至系统日志服务器
- 大部分网络设备都可支持
- 系统消息的常见目的地如下:
 - ✓ 日志记录缓冲区(路由器或交换机内部的 RAM)
 - ✓ 控制台线路
 - ✓ 终端线路
 - ✓ 系统日志服务器系统(Syslog服务器)
- 日志消息格式
- 严重性级别 0-7 级
- 设备 服务标识符
- 服务时间戳
 - 增强了实时调试和管理。
 - service timestamps log datetime

严重名称	严重级别	说明
紧急	第 0 级	系统不可用
提醒	第 1 级	需要立即采取操作
重要	第 2 级	关键条件
错误	第 3 级	错误条件
警告	第 4 级	警告条件
通知	第 5 级	正常、但比较重要的情况
信息性	第 6 级	信息性消息
调试	第 7 级	调试消息



系统消息格式

*Dec 18 17:10:15.079: %LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state to down

- 时间戳: *Dec 18 17:10:15.079
- ■路由器上生成消息的设施: %LINEPROTO
- ■严重性级别:5
- ■消息的助记符: UPDOWN
- ■消息说明: Line protocol on Interface FastEthernet0/0, changed state to down

修改系统消息

```
R1(config) # no service timestamps
R1(config) # service sequence-numbers
R1(config) # end
R1#

000011: %SYS-5-CONFIG_I: Configured from console by console
```


配置和检验 Syslog

- R1(config)#logging 192.168.1.101
- R1(config)#logging trap 4
- ■默认情况下,思科路由器和交换机会向控制台发送所有严重性级别的日志消息。在某些 IOS 版本中,默认情况下设备还会缓冲这些 syslog 消息
 - R1(config)# logging console
 - R1(config)# logging buffered
- R1# show logging

系统日志简介

路由器和交换机作为syslog客户端配置命令

```
R1 (config) # logging 192.168.1.3
R1(config) # logging trap 4
R1(config) # logging source-interface g0/0
R1(config) # interface loopback 0
R1(config-if)#
*Jun 12 22:06:02.902: %LINK-3-UPDOWN: Interface Loopback0,
changed state to up
*Jun 12 22:06:03.902: %LINEPROTO-5-UPDOWN: Line protocol on
Interface LoopbackO, changed state to up
*Jun 12 22:06:03.902: %SYS-6-LOGGINGHOST STARTSTOP: Logging to
host 192.168.1.3 port 514 started - CLI initiated
R1(config-if)# shutdown
R1(config-if)#
*Jun 12 22:06:49.642: %LINK-5-CHANGED: Interface Loopback0,
changed state to administratively down
*Jun 12 22:06:50.642: %LINEPROTO-5-UPDOWN: Line protocol on
Interface LoopbackO, changed state to down
R1(config-if) # no shutdown
R1(config-if)#
*Jun 12 22:09:18.210: %LINK-3-UPDOWN: Interface Loopback0,
changed state to up
*Jun 12 22:09:19.210: %LINEPROTO-5-UPDOWN: Line protocol on
Interface LoopbackO, changed state to up
R1(config-if)#
```





R1# show logging | include changed state to up *Jun 12 17:46:26.143: %LINK-3-UPDOWN: Interface GigabitEthernet0/1, changed state to up *Jun 12 17:46:26.143: %LINK-3-UPDOWN: Interface Serial0/0/1, changed state to up *Jun 12 17:46:27.263: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/1, changed state to up *Jun 12 17:46:27.263: %LINEPROTO-5-UPDOWN: Line protocol on Interface SerialO/O/1, changed state to up *Jun 12 20:28:43.427: %LINK-3-UPDOWN: Interface GigabitEthernet0/0, changed state to up *Jun 12 20:28:44.427: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0, changed state to up *Jun 12 22:04:11.862: %LINEPROTO-5-UPDOWN: Line protocol on Interface LoopbackO, changed state to up *Jun 12 22:06:02.902: %LINK-3-UPDOWN: Interface Loopback0, changed state to up *Jun 12 22:06:03.902: %LINEPROTO-5-UPDOWN: Line protocol on Interface LoopbackO, changed state to up *Jun 12 22:09:18.210: %LINK-3-UPDOWN: Interface Loopback0, changed state to up

R1# show logging | begin Jun 12 22:35 *Jun 12 22:35:46.206: %LINK-5-CHANGED: Interface LoopbackO, changed state to administratively down *Jun 12 22:35:47.206: %LINEPROTO-5-UPDOWN: Line protocol on Interface LoopbackO, changed state to down *Jun 12 22:35:55.926: %LINK-3-UPDOWN: Interface LoopbackO, changed state to up *Jun 12 22:35:56.926: %LINEPROTO-5-UPDOWN: Line protocol on Interface LoopbackO, changed state to up *Jun 12 22:49:52.122: %SYS-5-CONFIG_I: Configured from console by console *Jun 12 23:15:48.418: %SYS-5-CONFIG_I: Configured from console by console R1#

26.5 Router and Switch File Maintenance 路由器和交换机文件维护



- 路由器文件系统
 - show file systems 列出所有可用的文件系统
 - dir 列出文件系统的内容
 - pwd 检验当前工作目录
 - · cd 更改当前目录

可以看到总内存和空闲内存、文件系统的类型及其权限。权限包括只读(ro)、只写(wo)和读写(rw)。命令输出的 Flags(标志)列中显示的就是权限。

闪存文件系统前面还标有一个星号。这表示闪存是当前默认文件系统。

可启动的 IOS 位于闪存中; 因此闪存列表附加的井号(#)表示它是可启动磁盘。

Ro	outer# show fi	le systems							
File Systems:									
	Size(b)	Free(b)	Type	Flags	Prefixes				
			opaque	rw	system:				
			opaque	rw	tmpsys:				
*	7194652672	6294822912	disk	rw	bootflash: flash:#				
	256589824	256573440	disk	rw	usb0:				
	1804468224	1723789312	disk	ro	webui:				
			opaque	rw	null:				
			opaque	ro	tar:				
			network	rw	tftp:				
			opaque	wo	syslog:				
	33554432	33539983	nvram	rw	nvram:				
			network	rw	rcp:				
			network	rw	ftp:				
			network	rw	http:				
			network	rw	scp:				
			network	rw	sftp:				
			network	rw	https:				
			opaque	ro	cns:				
	·	·							



路由器和交换机文件维护路由器文件系统

- 路由器文件系统
 - · dir 列出文件系统的内容

```
Router# dir
Directory of bootflash:/
   11 drwx
                              Aug 2 2019 04:15:13 +00:00 lost+found
                      16384
                             Oct 3 2019 15:12:10 +00:00 .installer
370945 drwx
                        4096
                        4096
                               Aug 2 2019 04:15:55 +00:00
338689 drwx
217729 drwx
                        4096
                              Aug 2 2019 04:17:59 +00:00 core
379009
                        4096 Sep 26 2019 15:54:10 +00:00 .prst sync
       drwx
80641 drwx
                              Aug 2 2019 04:16:09 +00:00 .rollback timer
                       4096
161281 drwx
                        4096
                             Aug 2 2019 04:16:11 +00:00 gs_script
                      102400
                             Oct 3 2019 15:23:07 +00:00 tracelogs
112897 drwx
                             Aug 23 2019 17:19:54 +00:00
                                                          .dbpersist
362881 drwx
                        4096
298369 drwx
                        4096
                             Aug 2 2019 04:16:41 +00:00 virtual-instance
                              Oct 3 2019 15:14:11 +00:00 throughput_monitor_params
   12 -rw-
                              Aug 2 2019 04:17:55 +00:00 onep
 8065 drwx
                       4096
   13 -rw-
                              Oct 3 2019 15:19:30 +00:00 pnp-tech-time
                             Aug 20 2019 17:40:11 +00:00 Archives
249985 drwx
                              Oct 3 2019 15:19:42 +00:00 pnp-tech-discovery-summary
   14 -rw-
                      65037
   17 -rw-
                    5032908 Sep 19 2019 14:16:23 +00:00
isr4200_4300_rommon_1612_1r_SPA.pkg
                  517153193 Sep 21 2019 04:24:04 +00:00 isr4200-
   18 -rw-
universalk9_ias.16.09.04.SPA.bin
7194652672 bytes total (6294822912 bytes free)
Router#
```



路由器和交换机文件维护路由器文件系统

- 路由器文件系统
 - dir 列出文件系统的内容
 - pwd 检验当前工作目录
 - cd 更改当前目录

```
Router#
Router# cd nvram:
Router# pwd
nvram:/
Router# dir
Directory of nvram:/
32769
                         1024
                                                    startup-config
32770
                           61
                                                    private-config
32771
                         1024
                                                    underlying-config
       -rw-
                                                    private-KS1
                         2945
                                                    cwmp inventory
       -rw-
                          447
                                                    persistent-data
                         1237
                                                    ISR4221-2x1GE 0 0 0
       -rw-
                           17
                                                    ecfm_ieee_mib
       -rw-
                                                    ifIndex-table
                            0
       -rw-
   10
       -rw-
                         1431
                                                    NIM-2T 0 1 0
                          820
                                                    IOS-Self-Sig#1.cer
       -rw-
                          820
                                                    IOS-Self-Sig#2.cer
       -rw-
33554432 bytes total (33539983 bytes free)
Router#
```



路由器和交换机文件维护 **交换机文件系统**

Switch# show file systems											
File Systems:											
	Size(b)	Free(b)	Type	Flags	Prefixes						
*	32514048	20887552	flash	rw	flash:#						
			opaque	rw	vb:						
			opaque	ro	bs:						
	-	-	opaque	rw	system:						
	-	-	opaque	rw	tmpsys:						
	65536	48897	nvram	rw	nvram:						
			opaque	ro	xmodem:						
			opaque	ro	ymodem:						
			opaque	rw	null:						
			opaque	ro	tar:						
			network	rw	tftp:						
			network	rw	rcp:						
			network	rw	http:						
			network	rw	ftp:						
			network	rw	scp:						
	-	-	network	rw	https:						
	-	-	opaque	ro	cns:						

路由器和交换机文件维护使用文本文件备份配置


步骤 1. 在File(文件)菜单中点击 Log。

步骤 2. 选择保存文件的位置。Tera Term 将开始捕获文本。

步骤 3. 在开始捕获后,在特权 EXEC模式下使用 show running-config 或 show startup-config 命令。在终端窗口中显示的文本将指向选定文件。

步骤 4. 当捕获完成后,在终端日志窗口选择关闭。

步骤 5. 查看文件验证其未损坏。





- 使用 TFTP 进行备份和恢复
 - copy running-config tftp
 - copy startup-config tftp
 - · 步骤 1. 输入 copy running-config tftp 命令。
 - 步骤 2. 输入要存储配置文件的主机的 IP 地址。
 - 步骤 3. 输入要为配置文件指定的名称。
 - 步骤 4. 按 Enter 确认每次选择。

```
R1# copy running-config tftp
Remote host []?192.168.10.254
Name of the configuration file to write[R1-config]? R1-Jan-2019
Write file R1-Jan-2019 to 192.168.10.254? [confirm]
Writing R1-Jan-2019 !!!!!! [OK]
```



路由器和交换机文件维护 路由器和交换机文件备份

- 使用 USB 端口进行备份和恢复
 - show file systems
 - dir usbflash0:
 - copy run usbflash0://

```
R1# dir usbflash0:/
Directory of usbflash0:/
                0 Oct 15 2010 16:28:30 +00:00 Cisco
   16 -rw- 5024 Jan 7 2013 20:26:50 +00:00 R1-Config
4050042880 bytes total (3774144512 bytes free)
R1#
R1# more usbflash0:/R1-Config
! Last configuration change at 20:19:54 UTC Mon Jan 7 2013 by
admin version 15.2
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
hostname R1
boot-start-marker
boot-end-marker
logging buffered 51200 warnings
no aaa new-model
no ipv6 cef
```





路由器冷启动,1分钟内按住【Ctrl】+【Break】

步骤 1. 进入 ROMMON 模式。

步骤 2. 更改配置寄存器值。

步骤 3. 把启动配置复制到运行配置。

步骤 4. 更改密码。

步骤 5. 把运行配置保存为新的启动配置。


步骤 6. 重启设备。

```
rommon 1 > confreg 0x2142
rommon 2 > reset
Router# copy startup-config running-config
R1(config)# enable secret cisco
R1(config)# config-register 0x2102
R1(config)# end
R1# copy running-config startup-config
```

26.6 IOS Image Management IOS 映像管理

IOS 映像管理 IOS 备份

- TFTP 服务器作为备份位置
 - IOS 映像和配置文件的备份位置
- 将 IOS 映像备份到 TFTP 服务器的步骤
 - · 验证 TFTP 服务器的访问权
 - 确认有足够的磁盘空间
 - 将 IOS 映像复制到 TFTP 服务器
 - copy source-ur/tftp:
- 将 IOS 映像复制到设备的步骤
 - 从 Cisco.com 下载 IOS 映像并将其传输到 TFTP 服务器
 - 验证设备到 TFTP 服务器的访问权
 - 确认设备上有足够的磁盘空间
 - 从 TFTP 服务器上复制映像
 - copy tftp: destination-url
- boot system 命令
 - 在启动过程中,使用命令加载新映像
 - boot system file-url




isr4200-universalk9_ias.16.09.04.SPA.bin

TFTP 服务器

172.16.1.100

IOS 映像管理 创建Cisco IOS映像文件备份




```
R1# ping 172.16.1.100
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 172.16.1.100, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5),
round-trip min/avg/max = 56/56/56 ms
```

备份IOS 映像到TFTP 服务器, 需要以下几个步骤:

- ■步骤1. 确保本地能够访问到TFTP服务器
- 步骤2. 检查TFTP服务器是否有充分的磁盘空间来 存放IOS映像文件
- ■步骤3. 使用 copy source-url destination-url 命令复制IOS文件到TFTP服务器。

```
R1# show flash0:
-# - --length-- -----date/time----- path
8 68831808 Apr 2 2013 21:29:58 +00:00
c1900-universalk9-mz.SPA.152-4.M3.bin
<output omitted>
```

IOS 映像管理 复制一个 IOS 映像文件



TFTP server 2001:DB8:AC10:100::64

下列几个步骤可以在Cisco 路由器上升级IOS映像:

- <mark>步骤 1</mark>. 从 cisco. com下载需要的 IOS 文件并传输到 TFTP 服务器
- 步骤 2. 验证本机到TFTP 服务器的连接是否正常
- <mark>步骤 3</mark>. 确保路由器有足够的flash**存储空间**升级到新的 映像
- <mark>步骤 4</mark>. 使用 copy tftp: flash0: 命令从TFTP服务 器复制 IOS 映像文件到本地路由器

```
R1# ping 2001:DB8:CAFE:100::99

Type escape sequence to abort.

Sending 5, 100-byte ICMP Echos to 2001:DB8:CAFE:100::99,
timeout is 2 seconds:
!!!!!

Success rate is 100 percent (5/5),
round-trip min/avg/max = 56/56/56 ms
```

```
R1# show flash0:
-# - --length-- -----date/time----- path
<output omitted>

182394880 bytes available (74092544 bytes used)

R1#
```



IOS 映像管理 系统引导

■使用boot system命令指定准备加载的Cisco IOS 文件的名字和位置。

Router(config)# boot system flash0:// flash0:isr4200-universalk9_ias.16.09.04.SPA.bin

Router(config)# boot system tftp://flash0:isr4200-universalk9_ias.16.09.04.SPA.bin

Router(config)# boot system rom

```
R1# show version
Cisco IOS XE Software, Version 16.09.04
Cisco IOS Software [Fuji], ISR Software (X86 64 LINUX IOSD-UNIVERSALK9 IAS-M), Version 16.9.4, RELEASE
SOFTWARE (fc2)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2019 by Cisco Systems, Inc.
Compiled Thu 22-Aug-19 18:09 by mcpre
Cisco IOS-XE software, Copyright (c) 2005-2019 by cisco Systems, Inc.
All rights reserved. Certain components of Cisco IOS-XE software are
licensed under the GNU General Public License ("GPL") Version 2.0. The
software code licensed under GPL Version 2.0 is free software that comes
with ABSOLUTELY NO WARRANTY. You can redistribute and/or modify such
GPL code under the terms of GPL Version 2.0. For more details, see the
documentation or "License Notice" file accompanying the IOS-XE software,
or the applicable URL provided on the flyer accompanying the IOS-XE
software.
ROM: IOS-XE ROMMON
Router uptime is 2 hours, 19 minutes
Uptime for this control processor is 2 hours, 22 minutes
System returned to ROM by PowerOn
System image file is "flash:isr4200-universalk9 ias. 16.09.04. SPA. bin"
```

cisco