Copyright Notice

The content in this Tutorial / Document has been used for private use only and any other use of the whole or any part of the material (including Adapting, Copying, Issuing Copies, Lending, Public Performance, Broad Casting or making the same available to or via the internet or wireless technology or authorising of the forgoing) is strictly prohibited

If found anyone of the above notice then the consequence will be met with respective person who leaked out & falls under the risk of copyrights respect to this contents

This material content are completely created as Non-Plagiarised or Non-Copied of any document (Except Titles). This material only for the purpose of spreading knowledge & not to disobey copyrights.

Note: The content in this Tutorial / Document has been used for private use only


Bootloader


Different formats to use any application or firmware file, Majorly converting and using formats is

- 1. Hex format &
- 2. SRE format for the standards such as Intel and Motorola.

- The Request Download (0x34) service is used by the tester to initiate the data transfer from the client to ECU
- The above mode of transferring data is called Download
- Once the ECU receives the Request Download message request then the ECU should expect process to receive data before it sends a positive response message.

Assumption Scenario





Hex Data

01 4D 13 DE 01 21 01 10 10 01 01
02 4D 12 DE 01 41 01 10 10 01 01
03 4D 15 DE 01 21 01 05 10 01 01
04 4D 17 DE 01 27 01 10 10 01 01
05 4D 18 DE 01 61 01 10 10 01 01
06 4D 12 DE 01 21 01 10 10 01 01
07 4D 1B DE 01 81 01 10 10 01 01

Data Format Identifier

- Data format Identifier is a Data parameter which is represented as onebyte value with each nibble encoded separately. The high nibble specifies the Compression Method & the low nibble specifies the Encrypting Method.
- The value 00 hex specifies that no Compression Method nor Encrypting Method is used.
- Values other than 00 hex are vehiclemanufacturer-specific.

Address and Length Format Identifier

- The number of bytes used for the Memory Address and Memory Size parameters is defined by Address and Length Format Identifier (low and high nibble).
- It is also possible to use a fixed Address and Length Format Identifier & unused bytes within the Memory Address or Memory Size parameter are padded with the value 00 hex in the higher range address locations.
 - Bit 7-4 : length of memory size parameter
 - Bit 3-0 : length of memory address parameter

Memory Size (Un Compressed)

- During the Transfer Data service the size of memory used by the server is compared with amount of data transferred & uncompressed memory size.
- This increases the programming security.
- The number of bytes used for this <u>size</u> is defined by the high nibble (bit 7 - 4) of the Address Format Identifier.

Memory Address

- The parameter Memory address is the starting address of server memory to which data is to be written.
- After recognizing the starting address server will keep on transfer a data to consecutive address till the end byte of data
- The number of bytes used for this address is defined by the low nibble (bit 3 - 0) of the Address Format Identifier.
- Byte #m in the Memory Address parameter is always the least significant byte of the address being referenced in the server.
- The most significant byte of the address can be used as a memory Identifier.

Length Format Identifier

- This parameter is a one-byte value with each nibble encoded separately:
 - bit 7 4: length (number of bytes) of the Max Number Of Block Length parameter.
 - bit 3 0: reserved by standard to be set to 0 hex.
- The format of this parameter is compatible to the format of the address and Length format Identifier parameter contained in the request message, except that the lower nibble has to be set to 0 hex.

Max Number of Block Length


- This parameter is used by the Request Download positive response message to inform the client how many data bytes shall be included in each Transfer Data request message from the client.
- This length reflects the complete message length.

Block Sequence Counter

- The Block Sequence Counter parameter value starts at 01 hex with the first Transfer Data request that follows the
- Request Download (34 hex) or Request Upload (35 hex) service. Its value is incremented by one for each subsequent
- Transfer Data request. At the value one-byte value with each nibble encoded separately

Checksum

- To compare the uncompressed data and compressed data check sum is used at the end.
- Once the process gets started check sum will note down the end value address and which compare before the entire data transfer done.
- If the check sum matches then it is considered as data transferred successfully



- The Request Download (0x34) service is used by the tester to initiate the data transfer from the client to ECU
- The above mode of transferring data is called Download
- Once the ECU receives the Request Download message request then the ECU should expect process to receive data before it sends a positive response message.



Positive Response



34 - Service Id


11 - Data Format Id

11 - Address & Length

format Id

20 - Memory Address

01 - Memory Size



045 - PCI Length

74 - Response Sid

30 - Length Format Id

02 10 11 - Max Number

of block length



<u>List of NRCs Supported – 0x22</u>

- 0x13 Incorrect Message Length
- 0x22 Conditions Not Correct
- 0x31 Request Out of Range
- 0x33 Security Access Denied
- 0x70 Upload Download Not Accepted