CHAPTER

4

INERT GAS SYSTEM



CHAPTER 47 INERT GAS SYSTEM

Subject/Page	Date	COC	Subject/Page	Date	COC	Subject/Page	Date	COC
47-EFFECTIVE	E PAGES		47-31 TASKS	(cont)		47-31 TASKS	(cont)	
1 thru 2	Oct 15/2024		R 221	Oct 15/2024		R 257	Oct 15/2024	
47-HOW TO U	SE THE FIM		R 222	Oct 15/2024		R 258	Oct 15/2024	
R 1	Oct 15/2024		R 223	Oct 15/2024		R 259	Oct 15/2024	
R 2	Oct 15/2024		R 224	Oct 15/2024		R 260	Oct 15/2024	
R 3	Oct 15/2024		R 225	Oct 15/2024		R 261	Oct 15/2024	
R 4	Oct 15/2024		R 226	Oct 15/2024		R 262	Oct 15/2024	
R 5	Oct 15/2024		R 227	Oct 15/2024		R 263	Oct 15/2024	
R 6	Oct 15/2024		R 228	Oct 15/2024		R 264	Oct 15/2024	
47-FAULT CO	DE INDEX		R 229	Oct 15/2024		R 265	Oct 15/2024	
R 101	Oct 15/2024		R 230	Oct 15/2024		R 266	Oct 15/2024	
R 102	BLANK		R 231	Oct 15/2024		R 267	Oct 15/2024	
47-MAINT MS			R 232	Oct 15/2024		R 268	Oct 15/2024	
R 101	Oct 15/2024		R 233	Oct 15/2024		R 269	Oct 15/2024	
R 102	Oct 15/2024		R 234	Oct 15/2024		R 270	Oct 15/2024	
R 103	Oct 15/2024		R 235	Oct 15/2024		R 271	Oct 15/2024	
R 104	BLANK		R 236	Oct 15/2024		R 272	Oct 15/2024	
47-31 TASKS R 201	Oct 15/2024		R 237	Oct 15/2024		R 273	Oct 15/2024	
R 202	Oct 15/2024 Oct 15/2024		R 238	Oct 15/2024		R 274	Oct 15/2024	
R 203	Oct 15/2024		R 239	Oct 15/2024		R 275	Oct 15/2024	
R 204	Oct 15/2024		R 240	Oct 15/2024		R 276	Oct 15/2024	
R 205	Oct 15/2024		R 241	Oct 15/2024		R 277	Oct 15/2024	
R 206	Oct 15/2024		R 242	Oct 15/2024		R 278	Oct 15/2024	
R 207	Oct 15/2024		R 243	Oct 15/2024		R 279	Oct 15/2024	
R 208	Oct 15/2024		R 244	Oct 15/2024		R 280	Oct 15/2024	
R 209	Oct 15/2024		R 245	Oct 15/2024		R 281	Oct 15/2024	
R 210	Oct 15/2024		R 246	Oct 15/2024		R 282	Oct 15/2024	
R 211	Oct 15/2024		R 247	Oct 15/2024		R 283	Oct 15/2024	
R 212	Oct 15/2024		R 248	Oct 15/2024		R 284	Oct 15/2024	
R 213	Oct 15/2024		R 249	Oct 15/2024		R 285	Oct 15/2024	
R 214	Oct 15/2024		R 250	Oct 15/2024		R 286	Oct 15/2024	
R 215	Oct 15/2024		R 251	Oct 15/2024		R 287	Oct 15/2024	
R 216	Oct 15/2024		R 252	Oct 15/2024		288	BLANK	
R 217	Oct 15/2024		R 253	Oct 15/2024		47-31 TASK S		
R 218	Oct 15/2024		R 254	Oct 15/2024		R 301	Oct 15/2024	
R 219	Oct 15/2024		R 255	Oct 15/2024		R 302	Oct 15/2024	
R 220	Oct 15/2024		R 256	Oct 15/2024		R 303	Oct 15/2024	

A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change

47-EFFECTIVE PAGES



CHAPTER 47 INERT GAS SYSTEM

Subject/Page Date	COC	Subject/Page	Date	COC	Subject/Page	Date	COC
47-31 TASK SUPPORT (cont)							
R 304 Oct 15/2024							

 $\mbox{A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change} \label{eq:added}$

47-EFFECTIVE PAGES



YOU FIND A FAULT WITH AN AIRPLANE SYSTEM

These are the possible types of faults:

- 1. Observed Fault
- 2. Cabin Fault

USE BITE TO GET MORE INFORMATION

If you did a BITE test already, then you can go directly to the fault isolation procedure for the maintenance message.

For details, see Figure 2 —

GO TO THE FAULT ISOLATION TASK IN THE FIM

Use the fault code or description to find the task in the FIM. There is a numerical list of fault codes in each chapter. There are lists of fault descriptions at the front of the FIM.

For details, see Figure 3 ----

FOLLOW THE STEPS OF THE FAULT ISOLATION TASK

The fault isolation task explains how to find the cause of the fault. When the task says "You corrected the fault" you know that the fault is gone.

For details, see Figure 4 ──►

G04902 S0000148576_V1

Basic Fault Isolation Process Figure 1

- EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-HOW TO USE THE FIM

Page 1 Oct 15/2024



Some airplane systems have built-in test equipment (BITE). If the system finds a fault when you do a BITE test, it will give you a maintenance message.

A maintenance message can be any of these:

- a code
- a text message
- a light
- an indication.

To find the fault isolation task for a maintenance message, go to the Maintenance Message Index in the chapter for the applicable system.

If you do not know which chapter is the correct one, look at the list at the front of any Maintenance Message Index. For each system or component (LRU) that has BITE, this list gives the chapter number where you can find the Index that you need.

Find the maintenance message for the applicable LRU or system in the Index. Then find the task number on the same line as the maintenance message. Go to the task in the FIM and do the steps of the task (see Figure 4).

G04950 S0000148578 V1

Getting Fault Information from BITE Figure 2

EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-HOW TO USE THE FIM

Page 2 Oct 15/2024



IF YOU HAVE:

THEN DO THIS TO FIND THE TASK IN THE FIM:

FAULT CODE

- 1. The first two digits of the fault code are the FIM chapter that you need. Go to the Fault Code Index in that chapter and find the fault code. If the fault code starts with a letter, then go to the Cabin Fault Code Index at the front of the FIM.
- 2. Find the task number on the same line as the fault code. Go to the task in the FIM and do the steps in the task (see Figure 4).

OBSERVED FAULT
DESCRIPTION

- 1. Go to the Observed Fault List at the front of the FIM and find the best description for the fault.
- 2. Find the task number on the same line as the fault description. Go to the task in the FIM and do the steps of the task (see Figure 4).

CABIN FAULT DESCRIPTION

- Go to the Cabin Fault List at the front of the FIM and find the best description for the fault.
- 2. Find the task number on the same line as the fault description. Go to the task in the FIM and do the steps of the task (see Figure 4).

MAINTENANCE MESSAGE (FROM BITE)

- Go to the Maintenance Message Index in the chapter for the LRU (the front of each Index gives you the chapter number for all LRUs). Find the maintenance message in the Index.
- 2. Find the task number on the same line as the maintenance message. Go to the task in the FIM and do the steps in the task (see Figure 4).

G04979 S0000148579_V2

Finding the Fault Isolation Task in the FIM Figure 3

- EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-HOW TO USE THE FIM

Page 3 Oct 15/2024



ASSUMED CONDITIONS AT START OF TASK

- External electrical power is ON
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- No equipment in the system is deactivated

POSSIBLE CAUSES

- The list of possible causes has the most likely cause first and the least likely cause last.
- You can use the maintenance records of your airline to determine if the fault occurred before. Compare the list of possible causes to the past maintenance actions. This will help prevent repetition of the same maintenance actions.

INITIAL EVALUATION PARAGRAPH

- The primary purpose of the Initial Evaluation paragraph at the start of the task is to help you find out if you can detect the fault right now:
 - If you cannot detect the fault right now, then the task cannot isolate the fault and the Initial Evaluation paragraph will say that there was an intermittent fault.
 - If you have an intermittent fault, you must use your judgement (and follow your airline's policy) to decide which maintenance action to take. Then monitor the airplane to see if the fault happens again on subsequent flights.
- The Initial Evaluation paragraph can also help you find out which Fault Isolation Procedure to use to isolate and correct the fault.

FAULT ISOLATION STEPS

- The FIM task steps are presented in a specified order. The "If... then" statements will guide you along a logical path. But if you do not plan to follow the FIM task exactly, make sure that you read it before you start to isolate the fault. Some FIM procedures start with important steps that have an effect on the other steps in the procedure.
- When you are at the endpoint of the path, the step says "...you corrected the fault." Complete the step and exit the procedure.

G05009 S0000148580_V3

Doing the Fault Isolation Task Figure 4

- EFFECTIVITY


47-HOW TO USE THE FIM

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

Page 4 Oct 15/2024



FAULT ISOLATION MANUAL



Subjects at Front of FIM Figure 5


EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-HOW TO USE THE FIM

Page 5 Oct 15/2024





Fault isolation procedures for the chapter. Each procedure is identified by a chapter-section number and a 3-digit task number.

G05102 S0000148582_V1

Subjects in Each FIM Chapter Figure 6

- EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-HOW TO USE THE FIM

Page 6 Oct 15/2024



FAULT CODE	FAULT DESCRIPTION	GO TO FIM TASK
470 811 00	Nitrogen generation system: operability indicator INOPERATIVE (amber) light is on.	47-31 TASK 801
470 812 00	Nitrogen generation system: operability indicator has all lights off.	47-31 TASK 801
470 813 00	Nitrogen generation system: operability indicator DEGRADED (blue) light is on.	47-31 TASK 840

EFFECTIVITY -

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-FAULT CODE INDEX

Page 101 Oct 15/2024



LRU/SYSTEM	SHORT NAME	CHAPTER
Air Data Inertial Reference System	ADIRS	34
Air Traffic Controller Transponder - 1 (Left)	ATC XPDR - 1 (L)	34
Air Traffic Controller Transponder - 2 (Right)	ATC XPDR - 2 (R)	34
Airborne Vibration Monitor System Signal Conditioner	AVM SIG COND	77
Antiskid Control Unit	ANTISKID	32
Attendant Control Panel	ACP	23
Automatic Direction Finder Receiver - 1	ADF RECVR - 1	34
Automatic Direction Finder Receiver - 2	ADF RECVR - 2	34
Autothrottle Computer	A/T COMPUTER	22
Auxiliary Power Unit	APU	49
Auxiliary Power Unit Generator Control Unit	APU GCU	24
Bus Power Control Unit	BPCU	24
Cabin Pressure Controller	CAB PRESS CON	21
Cabin Temperature Controller	CAB TEMP CONT	21
Cargo Electronic Unit - Lower Aft	CEU - LWR AFT	26
Cargo Electronic Unit - Lower Forward	CEU - LWR FWD	26
Cargo Electronic Unit - Main Aft	CEU - MAIN AFT	26
Cargo Fire Control Panel	CFCP	26
Common Display System	CDS	31
Compartment Overheat Detection Control Module	WING/BODY OHT	26
Digital Flight Control System	DFCS	22
Distance Measurement Equipment Interrogator	DME INTRROGTR	34
Electrical Meters, Battery, and Galley Power Module	P5-13	24
Electronic Engine Controller - 1	ENGINE - 1	73
Electronic Engine Controller - 2	ENGINE - 2	73
Emergency Locator Transmitter	ELT	23
Engine Accessory Unit	EAU	78
Engine Accessory Unit/TR DEPLOY ENG 1	EAU/TR DPLOY-ENG 1	78
Engine Accessory Unit/TR DEPLOY ENG 2	EAU/TR DPLOY-ENG 2	78
Engine Accessory Unit/TR STOW ENG 1	EAU/TR STOW-ENG 1	78
Engine Accessory Unit/TR STOW ENG 2	EAU/TR STOW-ENG 2	78
Engine and Auxiliary Power Unit Fire Detection Control Module	ENG/APU FIRE	26
Enhanced Digital Flight Control Computer-A	EDFCC-A	22
Enhanced Digital Flight Control System	EDFCS	22
Flap/Slat Electronics Unit	FSEU	27

EFFECTIVITY -

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-MAINT MSG INDEX

Page 101 Oct 15/2024



LRU/SYSTEM	SHORT NAME	CHAPTER
Flight Data Acquisition Unit	FDAU	31
Flight Management Computer System	FMCS	34
Fuel Quantity Indicating System	FQIS	28
Generator Control Unit - 1	GCU - 1	24
Generator Control Unit - 2	GCU - 2	24
Ground Proximity Computer	GROUND PROX	34
High Frequency Transceiver	HF XCVR	23
Low Limit (35 Degree F) Controller - Left	35 DEG CONT L	21
Low Limit (35 Degree F) Controller - Right	35 DEG CONT R	21
Multi-Mode Receiver	MMR	34
Nitrogen Generation System BITE Display Unit	NGS	47
Pack Flow Temperature Controller	PFTC	21
Pack/Zone Temperature Controller - Left	PACK/ZN CON - L	21
Pack/Zone Temperature Controller - Right	PACK/ZN CON - R	21
Proximity Switch Electronics Unit	PSEU	32
Radio Altimeter Receiver/Transmitter	RADIO ALTIMTR	34
Stall Management Yaw Damper Computer - 1	SMYD - 1	27
Stall Management Yaw Damper Computer - 2	SMYD - 2	27
Traffic Alert and Collision Avoidance System Computer	TCAS COMPUTER	34
VHF Omnidirectional Ranging Marker Beacon Receiver	VOR/MKR RCVR	34
Very High Frequency Transceiver	VHF XCVR	23
Waste Tank Logic Control Module	WASTE TANK	38
Weather Radar Receiver/Transmitter	WEATHER RADAR	34
Window Heat Control Unit - Left Forward	WHCU - L FWD	30
Window Heat Control Unit - Left Side	WHCU - L SIDE	30
Window Heat Control Unit - Right Forward	WHCU - R FWD	30
Window Heat Control Unit - Right Side	WHCU - R SIDE	30
Window Heat Control Unit 1 - Left Forward and Right Side	WHCU1 - L FWD/R SIDE	30
Window Heat Control Unit 2 - Right Forward and Left Side	WHCU2 - R FWD/L SIDE	30

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-MAINT MSG INDEX



LRU/SYSTEM	MAINTENANCE MESSAGE	GO TO FIM TASK
NGS	47-30001 NGS CONTROLLER	47-31 TASK 802
NGS	47-30002 NGS CONTROLLER INOP	47-31 TASK 803
NGS	47-30010 NGS BLD PRESS SENSOR	47-31 TASK 804
NGS	47-30011 NGS TEMP SENSOR ELEC	47-31 TASK 805
NGS	47-30012 NGS TEMP SENSOR DRIFT	47-31 TASK 806
NGS	47-30013 DP SENSOR HI ELEC	47-31 TASK 807
NGS	47-30014 DP SENSOR HI DRIFT	47-31 TASK 808
NGS	47-30017 NGS ALT SENSOR ELEC	47-31 TASK 809
NGS	47-30018 BLD PRESS SENSOR DRIFT	47-31 TASK 811
NGS	47-30019 NGS ALT SENSOR DRIFT	47-31 TASK 810
NGS	47-30020 NGSSOV ELEC FAIL	47-31 TASK 812
NGS	47-30021 NGSSOV FAIL OPEN	47-31 TASK 813
NGS	47-30023 NGSSOV/OTSOV/HFV CLOSED	47-31 TASK 814
NGS	47-30024 OTSOV ELEC FAIL	47-31 TASK 815
NGS	47-30025 OTSOV FAIL OPEN	47-31 TASK 816
NGS	47-30026 NGSRAV ELEC FAIL	47-31 TASK 817
NGS	47-30027 NGSRAV FAIL OPEN	47-31 TASK 818
NGS	47-30028 NGSRAV FAIL CL/HX BLKD	47-31 TASK 819
NGS	47-30029 FILTER BLOCKED	47-31 TASK 820
NGS	47-30030 HFV ELEC FAIL	47-31 TASK 821
NGS	47-30031 HFV FAIL CLOSED	47-31 TASK 837
NGS	47-30032 HFV FAIL OPEN	47-31 TASK 823
NGS	47-30040 WOW SIG FAIL IN AIR	47-31 TASK 824
NGS	47-30041 WOW SIG FAIL ON GROUND	47-31 TASK 825
NGS	47-30042 FWD CGO FIRE SIG FAIL ON	47-31 TASK 826
NGS	47-30043 MN CGO FIRE SIG FAIL ON	47-31 TASK 827
NGS	47-30044 AFT CGO FIRE SIG FAIL ON	47-31 TASK 828
NGS	47-30045 FD SMK EVAC SIG FAIL ON	47-31 TASK 829
NGS	47-30050 ENG1 SIG FAIL	47-31 TASK 830
NGS	47-30051 ENG2 SIG FAIL	47-31 TASK 831
NGS	47-30054 PACK SIG FAIL OFF	47-31 TASK 832
NGS	47-30056 AIRCRAFT ID INVALID	47-31 TASK 833
NGS	47-30059 REFUEL SIG1 FAIL OPEN	47-31 TASK 834
NGS	47-30062 NGS OXYGEN SENS FAIL	47-31 TASK 838
NGS	47-30063 NGS ASM FAIL	47-31 TASK 839

EFFECTIVITY -

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-MAINT MSG INDEX

Page 103 Oct 15/2024



801. NGS BITE - Procedure

A. General

- (1) The ASM performance is measured by the purity of the Nitrogen Enriched Air (NEA) delivered to the center tank. To do a test of the purity of the NEA, it is necessary to do a check of the Nitrogen Generation System (NGS) operational temperature, pressure and the oxygen percentage in the NEA stream. The NGS temperature and pressure measurements are calculated by the NGS controller and shown on the BITE Display Unit (BDU).
- (2) To do a test of the oxygen percentage, (AMM TASK 47-00-00-720-801), an oxygen analyzer, COM-7456, is connected to the Ground Support Equipment (GSE) test port on the Nitrogen-Enriched Air Distribution System (NEADS) line. The percent oxygen (shown on the oxygen analyzer) and NGS inlet pressure (shown on the BDU) are plotted on a go-no-go graph (Figure 201).
- (3) You do the NGS BITE test from the BDU found in the forward air conditioning area.
- (4) The NGS BITE procedure uses these functions from the GROUND TESTS menu
 - (a) ELECTRICAL TEST?
 - (b) SYSTEM TEST?
- (5) ELECTRICAL TEST
 - (a) The BDU ELECTRICAL TEST? is a manually initiated test done by the NGS controller to test the controller valve drivers (on and off conditions), sensor interfaces, sensor open/short conditions, solenoid or torque motor open/short conditions and airplane discrete inputs. The electrical test can be done with the NGS system in a pressurized or non-pressurized condition. The electrical test opens and closes the NGS shutoff and overtemperature shutoff valves in a timed sequence to stop the pressurization of the NGS system.
 - (b) The electrical test displays any faults which are currently present in the BDU system.
- (6) SYSTEM TEST
 - (a) The BDU SYSTEM TEST? is a manually initiated test done by the NGS controller when the NGS system is pressurized. To do the system test, it is necessary to pressurize the NGS with bleed air pressure and operate the left air conditioning pack. The system test is a timed sequence test that does a check of the open and closed position of all of the electrically controlled valves.
 - (b) The system tests displays any faults which are currently present in the BDU system.

B. NGS BITE Procedure

- (1) Do these steps to do the BDU electrical test:
 - (a) Make sure that the BDU is in the main menu mode.
 - (b) The BDU will show one of these functions:

NOTE: If the BDU does not show one of these functions, then push the MENU button until one of the following menu item shows.

- 1) EXISTING FAULTS?
- 2) FAULT HISTORY?
- 3) GROUND TESTS?
- 4) OTHER FUNCTIONS?
- (c) Push the up or down arrow until the BDU shows GROUND TESTS?
 - 1) Push the YES button on the BDU.



(d) Make sure the BDU display shows ELECTRICAL TEST?.

NOTE: If the BDU does not show "ELECTRICAL TEST?", push the up or down arrow until "ELECTRICAL TEST?" shows.

- (e) Push the YES button on the BDU to start the electrical test.
- (f) The BITE test will start.

NOTE: TEST IN PROGRESS XXX% COMPLETE will show on the display during the test.

The electrical test does an IBIT check of the operability indicator lights at 40 to 50 seconds after the test starts. You must witness that the 3 colored lights come on in this sequence:

Light Color	System Indication	Time Light is On
Blue	Degraded Temporarily Serviceable	12 seconds
Green	Operational	15 seconds
Amber	Inoperative - Unserviceable	21 seconds

- (g) Make sure that the BITE Display Unit shows ELECTRICAL TEST PASS at the end of the test.
 - 1) Make sure that the green OPERATIONAL light on the operability indicator is on.
- (h) If the test fails, look at the BDU test results for the list of fault messages.
- (2) Do these steps to do the BDU system test:
 - (a) Do these steps to pressurize the Environmental Control System (ECS) Air Supply System:
 - 1) To supply conditioned air, do this task: AMM TASK 21-00-00-800-803.
 - Pressurize the pneumatic system (AMM TASK 36-00-00-860-801).

NOTE: Use of engine(s) air to supply pneumatic pressure for this task is not recommended. All areas around operating engines are dangerous. If you must use the engine(s) to supply pneumatic power, make sure that you obey all applicable WARNINGS.

a) Make sure that these switches on the P5–10 panel are in the positions shown:

Table 201

14410 = 0			
SWITCH	POSITION		
APU Bleed	ON (if APU is running) if not, OFF		
L PACK	HIGH		
R PACK	OFF		
Engine BLEED 1	ON (if engine is running) if not, OFF		
Engine BLEED 2	ON (if engine is running) if not, OFF		
Cabin Temp	AUTO		
ISOLATION VALVE	OPEN		
SHZ 002, 009-699, 706, 721-799 POST SB 737-47-1003			
RECIRC FAN	AUTO		

EFFECTIVITY



SHZ 002, 009-699, 706, 721-799 POST SB 737-47-1003 (Continued)

Table 201 (Continued)

SWITCH	POSITION	
SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 860-863, 865, 866, 871-874 POST SB 737-47-10		
L RECIRC FAN	AUTO	
R RECIRC FAN	AUTO	

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

- Do a check of the manifold duct pressure.
 - a) Look at the dual duct pressure gage on the P5 panel.
 - b) Make sure that the L and R duct pressure is 20 psig (138 kPa) or more.
- (b) Make sure the BDU display shows SYSTEM TEST?.

NOTE: If the BDU does not show "SYSTEM TEST?", push the up or down arrow until "SYSTEM TEST?" shows.

- (c) Push the YES button on the BDU to start the system test.
- (d) The BITE test will start.

NOTE: TEST IN PROGRESS XXX% COMPLETE will show on the display during the test.

(e) Wait until the test is complete.

NOTE: The test will take two to three minutes.

- (f) If the test is satisfactory, "SYSTEM TEST PASS" shows on the display.
- (g) If the test fails, look at the BDU test results for the list of fault messages.
- (3) Refer to the table at the end of this task to find the fault isolation task for the applicable maintenance message.

LRU/SYSTEM	MAINTENANCE MESSAGE	GO TO FIM TASK
NGS	47-30001 NGS CONTROLLER	47-31 TASK 802
NGS	47-30002 NGS CONTROLLER INOP	47-31 TASK 803
NGS	47-30010 NGS BLD PRESS SENSOR	47-31 TASK 804
NGS	47-30011 NGS TEMP SENSOR ELEC	47-31 TASK 805
NGS	47-30012 NGS TEMP SENSOR DRIFT	47-31 TASK 806
NGS	47-30013 DP SENSOR HI ELEC	47-31 TASK 807
NGS	47-30014 DP SENSOR HI DRIFT	47-31 TASK 808
NGS	47-30017 NGS ALT SENSOR ELEC	47-31 TASK 809
NGS	47-30018 BLD PRESS SENSOR DRIFT	47-31 TASK 811
NGS	47-30019 NGS ALT SENSOR DRIFT	47-31 TASK 810
NGS	47-30020 NGSSOV ELEC FAIL	47-31 TASK 812
NGS	47-30021 NGSSOV FAIL OPEN	47-31 TASK 813
NGS	47-30023 NGSSOV/OTSOV/HFV CLOSED	47-31 TASK 814

EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003




LRU/SYSTEM	MAINTENANCE MESSAGE	GO TO FIM TASK
NGS	47-30024 OTSOV ELEC FAIL	47-31 TASK 815
NGS	47-30025 OTSOV FAIL OPEN	47-31 TASK 816
NGS	47-30026 NGSRAV ELEC FAIL	47-31 TASK 817
NGS	47-30027 NGSRAV FAIL OPEN	47-31 TASK 818
NGS	47-30028 NGSRAV FAIL CL/HX BLKD	47-31 TASK 819
NGS	47-30029 FILTER BLOCKED	47-31 TASK 820
NGS	47-30030 HFV ELEC FAIL	47-31 TASK 821
NGS	47-30031 HFV FAIL CLOSED	47-31 TASK 837
NGS	47-30032 HFV FAIL OPEN	47-31 TASK 823
NGS	47-30040 WOW SIG FAIL IN AIR	47-31 TASK 824
NGS	47-30041 WOW SIG FAIL ON GROUND	47-31 TASK 825
NGS	47-30042 FWD CGO FIRE SIG FAIL ON	47-31 TASK 826
NGS	47-30043 MN CGO FIRE SIG FAIL ON	47-31 TASK 827
NGS	47-30044 AFT CGO FIRE SIG FAIL ON	47-31 TASK 828
NGS	47-30045 FD SMK EVAC SIG FAIL ON	47-31 TASK 829
NGS	47-30050 ENG1 SIG FAIL	47-31 TASK 830
NGS	47-30051 ENG2 SIG FAIL	47-31 TASK 831
NGS	47-30054 PACK SIG FAIL OFF	47-31 TASK 832
NGS	47-30056 AIRCRAFT ID INVALID	47-31 TASK 833
NGS	47-30059 REFUEL SIG1 FAIL OPEN	47-31 TASK 834
NGS	47-30062 NGS OXYGEN SENS FAIL	47-31 TASK 838
NGS	47-30063 NGS ASM FAIL	47-31 TASK 839

— END OF TASK ——

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



FAULT ISOLATION MANUAL



GSE GO-NO-GO CRITERIA AT LOW FLOW

LEGEND:

NEA PURITY SATISFACTORY (GO ZONE)

NEA PURITY NOT SATISFACTORY (NO-GO ZONE)


1495949 S0000271687_V1

GSE Go-No-Go Criteria Figure 201/47-31-00-990-801 (Sheet 1 of 2)

EFFECTIVITY SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



FAULT ISOLATION MANUAL



GSE GO-NO-GO CRITERIA AT HIGH FLOW

LEGEND:

MEA PURITY SATISFACTORY (GO ZONE)

_ ⊓NEA PURITY NOT SATISFACTORY (NO-GO ZONE)

1495996 S0000271691_V1

GSE Go-No-Go Criteria Figure 201/47-31-00-990-801 (Sheet 2 of 2)

EFFECTIVITY SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003 47-31 TASK 801

Page 206 Oct 15/2024



802. NGS BITE Message NGS CONTROLLER - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30001 NGS CONTROLLER
 - (b) NVM Fault Shop Code 18, 20, 28, 31, 33, 53, 59, 61, 62, 71, 72, 73, 75, 76, 78, 100, 101, 230, 231, 232.
- (2) The operability indicator shows NGS DEGRADED (blue light). The NGS is operating below normal.
- (3) This fault message shows when the NGS controller internal self-test detects a controller problem.
- (4) The BDU will show the NGS CONTROLLER fault message when one or more of these conditions are true:
 - (a) Ram air valve driver temperature out of range, value cannot be calculated.
 - (b) Flow bypass valve driver fault.
 - (c) High-flow valve driver fault.
 - (d) NGS bleed pressure sensor interface fault.
 - (e) NGS temperature sensor element 1 or 2 interface fault.
 - (f) NGS altitude sensor interface fault.
 - (g) ASM differential pressure sensor (high-flow) interface fault.
 - (h) ASM differential pressure sensor (high-flow) interface fault.
 - (i) Non Volatile Memory (NVM) fault.
 - (j) BDU power supply driver fault.
 - (k) Test mode fault.
 - (I) Mux 4, 5, 6, 7, or 8 fault.
- (5) To find more data about this fault message, do this task: AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) NGS Controller, M02559
- (2) Oxygen Sensor, M02692

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message, ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, NGS CONTROLLER 47-30001 shows, then do the Fault Isolation Procedure for the NGS Controller below.
 - (c) If the Electrical Test on the BDU fails and shop code 0232 shows, then do the Fault Isolation Procedure for the NGS Controller and the Oxygen Sensor below.

F. Fault Isolation Procedure for the NGS Controller

(1) Replace the NGS controller, M02559.

(Nitrogen Generation System Controller Removal, AMM TASK 47-31-01-000-801)

(Nitrogen Generation System Controller Installation, AMM TASK 47-31-01-400-801)

- (a) If the replacement of the controller does not work, then do this task, BDU Fault History Menu, AMM TASK 47-31-02-740-803 to retrieve fault history and shop code information.
 - 1) Shop Code 18, 20, Replace Temperature Sensor and Check Wiring.
 - 2) Shop Code 28, Replace Delta P Sensor and Check Wiring.
 - 3) Shop Code 31, Replace Altitude Sensor and Check Wiring.
 - 4) Shop Code 33, Replace High Flow Valve and Check Wiring.
 - 5) Shop Code 62, Replace Inlet Pressure Sensor and Check Wiring.
 - 6) Shop Code 71, Replace BDU and Check Wiring.
 - 7) Shop Code 78, Replace RAV and Check Wiring.
 - 8) Shop Code 230-232, Replace Oxygen Sensor and Check Wiring.

G. Fault Isolation Procedure for the Oxygen Sensor

(1) Replace the Oxygen Sensor, M02692.

(NGS Oxygen Sensor - Removal, AMM TASK 47-42-03-020-801)

(NGS Oxygen Sensor - Installation, AMM TASK 47-42-03-420-801).

H. Repair Confirmation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the fault.

----- END OF TASK -----

803. NGS BITE Message NGS CONTROLLER INOP - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30002 NGS CONTROLLER INOP.
 - (b) NVM Fault Shop Code 5, 6, 7, 9, 10, 11, 12, 13, 14, 16, 36, 74, 99, 108.
- (2) The operability indicator shows INOPERATIVE (amber light). The NGS is offline.

47-31 TASKS 802-803



- (3) The NGS controller will show NGS CONTROLLER INOP when one or more of these conditions are true:
 - (a) NGS shutoff valve driver fault.
 - (b) Over temperature shutoff valve driver fault.
 - (c) NGS controller critical fault affects the reliability of the Central Processing Unit (CPU). NGS controller software incompatibility is a critical fault.
 - 1) If the controller finds a critical fault, it will re-configure the system to the system fail-safe mode.
 - 2) The fail-safe mode will cause these system conditions:
 - a) The NGS controller software will be disabled.
 - b) The NGS controller will set all outputs to the OFF (fail-safe) condition.
 - c) Communication between the NGS controller and BDU may be disabled.
 - 3) The recovery condition to unlatch the fault is to cycle the system power. The system fail-safe mode will continue until the NGS controller passes the power-up self-test.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

(1) NGS Controller, M02559.

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

(1) Open and close these circuit breakers:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

47-31 TASK 803

Page 209 Oct 15/2024



SHZ 802-825, 827-847, 850-852, 855-859, 880-899 (Continued)

(Continued)

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

(a) The NGS controller will start the power-up self-test.

NOTE: The power-up self-test will be complete in 5 seconds.

- (2) If the BDU messages are available and NGS CONTROLLER INOP 47-30002 does not show, then there was an intermittent fault.
- (3) Do the fault isolation procedure if one of these conditions exist:
 - (a) NGS CONTROLLER INOP 47-30002 shows.
 - (b) No BDU menu items show.

F. Fault Isolation Procedure

Replace the NGS controller, M02559.

(Nitrogen Generation System Controller Removal, AMM TASK 47-31-01-000-801)

(Nitrogen Generation System Controller Installation, AMM TASK 47-31-01-400-801)

- (a) If the replacement of the controller does not work, then do this task, BDU Fault History Menu, AMM TASK 47-31-02-740-803 to retrieve fault history and shop code information.
 - 1) Shop Code 16, Replace NGS Shutoff Valve and Check Wiring.
 - 2) Shop Code 36, Replace OTSOV and Check Wiring.
 - 3) Shop Code 108, Controller software settings are incompatible with aircraft.

G. Repair Confirmation

Open and close these circuit breakers:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

(a) The NGS controller will start the power-up self-test.

NOTE: The power-up self-test will be complete in 5 seconds.

(2) If the BDU menu items are available, and NGS CONTROLLER INOP 47-30002 does not show, then you corrected the fault.

----- END OF TASK -----

901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



804. NGS BITE Message NGS BLD PRESS SENSOR - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30010 NGS BLD PRESS SENSOR
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) NGS BLD PRESS SENSOR shows on the display when the NGS Controller finds an open or short circuit condition for the NGS Pressure Sensor, M02565.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- NGS Pressure Sensor, M02565
- (2) NGS Wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message 47-30010 NGS BLD PRESS SENSOR shows, do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Disconnect connector D13830 from the NGS Pressure Sensor, M02565.
- (2) Disconnect connector D13804 from the NGS Controller, M02559.
- (3) Do the continuity checks that follow in the related wiring between the NGS Pressure Sensor and the NGS Controller (WDM 47-30-11):



NGS PRESS NGS

SNSR CONTROLLER

 D13830
 D13804

 pin 1
 pin 26

 pin 3
 pin 25

NGS PRESS SNSR D13830

pin 5 GD2318-ST

- (a) If you find problems in the wiring, repair as necessary.
 - 1) Re-connect connector D13830 to the NGS Pressure Sensor.
 - 2) Re-connect connector D13804 to the NGS Controller.
 - Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (4) Replace the NGS Pressure Sensor, M02565. These are the tasks:
 - NGS Pressure Sensor Removal, AMM TASK 47-43-04-000-801
 - NGS Pressure Sensor Installation, AMM TASK 47-43-04-400-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- 1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the problem.
 - (b) If the NGS BLD PRESS SENSOR message still shows, continue the Fault Isolation Procedure at the subsequent step.

----- END OF TASK -----

805. NGS BITE Message NGS TEMP SENSOR ELEC - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30011 NGS TEMP SENSOR ELEC
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) NGS TEMP SENSOR ELEC shows when the controller finds an open or short circuit condition for the Temperature Sensor, T03020.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Temperature Sensor, T03020
- (2) NGS Wiring

47-31 TASKS 804-805



C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
- (3) If the fault message 47–30011 NGS TEMP SENSOR ELEC shows, do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- Disconnect connector D13828 on the Temperature Sensor, T03020.
- (2) Disconnect the connector D13804 on the NGS Controller, M02559.
- (3) Do the continuity checks that follow in the related wiring between the NGS Temperature Sensor and the NGS Controller (WDM 47-30-11):

NGS TEMP	NGS
SNSR	CONTROLLER
D13828	D13804
pin A	pin 8
pin D	pin 7
pin B	pin 3
pin C	pin 2

NGS TEMP SNSR D13828

pin E GD109-ST

- (a) If you find problems in the wiring, repair as necessary.
 - 1) Re-connect connector D13828 to the NGS Temperature Sensor.
 - 2) Re-connect connector D13804 to the NGS Controller.
 - Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.



- (4) Replace the Temperature Sensor, T03020. These are the tasks:
 - Temperature Sensor Removal, AMM TASK 47-43-03-000-801
 - Temperature Sensor Installation, AMM TASK 47-43-03-400-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

— END OF TASK —

806. NGS BITE Message NGS TEMP SENSOR DRIFT - Fault Isolation

Description

- (1) This task is for fault message:
 - (a) 47-30012 NGS TEMP SENSOR DRIFT
- The operability indicator shows DEGRADED (blue light). The NGS is operating below normal. (2)
- The NGS controller compares the temperature sensor 1 signal and the temperature sensor 2 signal. If the difference is more than ±16°F (-8.9°C) and lasts for more than 2 minutes 30 seconds, then the NGS TEMP SENSOR DRIFT fault message is set. If the NGS TEMP SENSOR DRIFT fault message is set, then the NGS controller will use the higher of the two temperature signals.
- To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

(1) NGS Temperature Sensor, T03020

Circuit Breakers

These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Col Number Row Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D C01657 NITROGEN GEN CONT 17

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

NITROGEN GENERATION CONTROL C01657

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

Ε C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801
- If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.

47-31 TASKS 805-806



(3) If the fault message, NGS TEMP SENSOR DRIFT 47-30012 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Disconnect connector D13828 from the NGS Temperature Sensor.
- Disconnect connector D13804 from the NGS Controller.
- (3) Do the continuity checks that follow in the related wiring between the NGS Temperature Sensor and the NGS Controller (WDM 47-30-11):

NGS TEMP SNSR D13828	NGS CONTROLLER D13804
pin A	pin 8
pin D	pin 7
pin B	pin 3
pin C	pin 2
NGS TEMP	

NGS TEMP SNSR D13828

pin E GD109-ST

(4) Add a jumper between pins A and D and between pins B and C on D13828. Do the resistance checks that follow in the related pins of the NGS Controller (WDM 47-30-11):

NOTE: Resistance between pins 8 and 7 and pins 3 and 2 should be within one Ohm of each other.

NGS	NGS
CONTROLLER	CONTROLLER
D13828	D13828
pin 8	pin 7
pin 3	pin 2

- (a) If you find problems in the wiring, repair as necessary.
 - 1) Re-connect connector D13828 to the NGS Temperature Sensor.
 - 2) Re-connect connector D13804 to the NGS Controller.
 - 3) Do the Repair Confirmation at the end of this task.
- (5) Replace the NGS Temperature Sensor, T03020. These are the tasks:
 - Temperature Sensor Removal, AMM TASK 47-43-03-000-801
 - Temperature Sensor Installation, AMM TASK 47-43-03-400-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

----- END OF TASK -----



807. NGS BITE Message DP SENSOR HI ELEC - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30013 DP SENSOR HI ELEC
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) DP SENSOR HI ELEC shows when the NGS Controller finds an open or short circuit condition for the High-Flow Differential Pressure Sensor (M02564).
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- High-Flow Valve Differential Pressure (DP) Sensor, M02564
- (2) NGS Wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message 47–30013 DP SENSOR HI ELEC shows, do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- Disconnect connector D13824 from the High-Flow Valve DP Sensor, M02564.
- (2) Do the 16 VDC check that follows in the related wiring of the DP Sensor:

 DP SNSR
 DP SNSR

 D13824
 D13824

 pin 1
 pin 5

(3) Disconnect connector D13804 from the NGS Controller, M02559.

— EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



(4) Do the continuity check that follows in the related wiring between the DP Sensor and the NGS Controller:

NGS

DP SNSR CONTROLLER D13824 D13804

pin 3 pin 23

- (a) If you find problems in the wiring, repair as necessary.
 - 1) Re-connect connector D13824 to the DP Sensor.
 - 2) Re-connect connector D13804 to the NGS Controller.
 - 3) Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (5) Replace the high-flow valve DP sensor, M02564. These are the tasks:
 - High Flow Valve Differential Pressure Sensor Removal, AMM TASK 47-42-02-020-801
 - High Flow Valve Differential Pressure Sensor Installation, AMM TASK 47-42-02-400-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

——— END OF TASK ———

808. NGS BITE Message DP SENSOR HI DRIFT - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30014 DP SENSOR HI DRIFT
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) DP SENSOR HI DRIFT shows on the display when there is a pressure drift for the high-flow differential pressure sensor. The fault message is set when the NGS controller does a zero pressure test of the high-flow DP sensor when the NGS system is commanded off.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

(1) High-flow DP Sensor, M02564

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

47-31 TASKS 807-808



SHZ 802-825, 827-847, 850-852, 855-859, 880-899 (Continued)

(Continued)

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, DP SENSOR HI DRIFT 47-30014 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- Disconnect connector D13824 from the High-Flow Valve DP Sensor, M02564.
- (2) Do the 16 VDC check that follows in the related wiring of the DP Sensor:

DP SNSR	DP SNSR
D13824	D13824
pin 1	pin 5

- (3) Disconnect connector D13804 from the NGS Controller, M02559.
- (4) Do the continuity check that follows in the related wiring between the DP Sensor and the NGS Controller:

	NGS
DP SNSR	CONTROLLER
D13824	D13804
pin 3	pin 23

- (a) If you find problems with the wiring, repair as necessary.
 - 1) Re-connect connector D13824 to the DP Sensor.
 - 2) Re-connect connector D13804 to the NGS Controller.
 - Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (5) Replace the High-flow DP Sensor, M02564. These are the tasks:
 - High Flow Valve Differential Pressure Sensor Removal, AMM TASK 47-42-02-020-801
 - High Flow Valve Differential Pressure Sensor Installation, AMM TASK 47-42-02-400-801
 - (a) Do the Repair Confirmation below.



G. Repair Confirmation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

----- END OF TASK -----

809. NGS BITE Message NGS ALT SENSOR ELEC - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30017 NGS ALT SENSOR ELEC
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) NGS ALT SENSOR ELEC shows on the display when the NGS Controller finds an open or a short circuit condition with the NGS Altitude Sensor.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) NGS Altitude Sensor, M02562
- (2) NGS Wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, NGS ALT SENSOR ELEC 47-30017 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- Disconnect connector D13818 from the NGS Altitude Sensor, M02562.
- (2) Do the 16 VDC check that follows in the related wiring of the NGS Altitude Sensor:

— EFFECTIVITY —

47-31 TASKS 808-809

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



NGS ALT SNSR	NGS ALT SNSR
D13818	D13818
pin 1	pin 5

- (3) Disconnect connector D13804 from the NGS Controller, M02559.
- (4) Do the continuity check that follows in the related wiring between the NGS Altitude Sensor and the NGS Controller:

	NGS
NGS ALT SNSR	CONTROLLER
D13818	D13804
pin 3	pin 24

- (a) If you find problems in the wiring, repair as necessary.
 - 1) Re-connect connector D13818 to the NGS Altitude Sensor.
 - Re-connect connector D13804 to the NGS Controller.
 - 3) Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (5) Replace the NGS Altitude Sensor, M02562. These are the tasks:
 - Altitude Sensor Removal, AMM TASK 47-42-01-000-801
 - Altitude Sensor Installation, AMM TASK 47-42-01-400-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

------ END OF TASK ------

810. NGS BITE Message NGS ALT SENSOR DRIFT - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30019 NGS ALT SENSOR DRIFT
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) NGS ALT SENSOR DRIFT shows when the NGS Controller finds an altitude sensor range fault. If the fault occurs in flight, the system defaults to the low flow mode.
- (4) The fault confirmation time for this fault exceeds both the electrical test time and the system test time. The NGS ALT SENSOR DRIFT fault will never be validated in IBIT. The result is that the fault message will be cleared by selecting either IBIT. The fault is redetected in CBIT if the fault is still present.
- (5) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

(1) NGS Altitude Sensor, M02562

47-31 TASKS 809-810



C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
- (3) If the fault message 47–30019 NGS ALT SENSOR DRIFT shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do the following steps to compare the altitude reading from the BDU with the barometric altimeter in the flight compartment:
 - (a) Push the ON/OFF pushbutton on the BDU.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (b) Select the OTHER FUNCTION? menu.
 - 1) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.
 - Push the YES pushbutton.
- (c) Select the I/O MONITOR? menu.
 - 1) Push the up or down arrow pushbutton until I/O MONITOR? shows.
 - 2) Push the YES pushbutton.
- (d) Select the ANALOG INPUTS? menu.
 - 1) Push the up or down arrow pushbutton until ANALOG INPUTS? shows.
 - 2) Push the YES pushbutton.
- (e) Select the PALT.
 - Push the up or down arrow pushbutton until PALT: XXXX.X FT/ PB: YYY.Y PSIG shows on the display.
 - a) Make a note of the altitude shown.





TO STOP THE GROUND TEST, PUSH THE MENU BUTTON THEN THE NO BUTTON ON THE BDU. IF THE SHUTOFF VALVE STAYS OPEN, DAMAGE TO EQUIPMENT CAN OCCUR.

- (f) Push the MENU pushbutton to stop the test.
- (2) In the flight compartment, make sure that the barometric altimeter has the correct altimeter setting in the baro window.
 - (a) Make a note of the barometric altitude.
- (3) Compare the barometric altitude with the altitude shown on the BDU.
 - (a) If the altitude readings are the same, do the Repair Confirmation at the end of this task.
 - (b) If the altitude readings differ by 100 ft (30 m) or more, then continue.
- (4) Disconnect connector D13818 from the NGS Altitude Sensor, M02562.
- (5) Do the 16 VDC check that follows in the related wiring of the NGS Altitude Sensor:

NGS ALT SNSR	NGS ALT SNSR	
D13818	D13818	
pin 1	pin 5	

- (6) Disconnect connector D13804 from the NGS Controller, M02559.
- (7) Do the continuity check that follows in the related wiring between the NGS Altitude Sensor and the NGS Controller:

	NGS	
NGS ALT SNSR	CONTROLLER	
D13818	D13804	
pin 3	pin 24	

- (a) If you find problems in the wiring, repair as necessary.
 - 1) Re-connect connector D13818 to the NGS Altitude Sensor.

1100

- Re-connect connector D13804 to the NGS Controller.
- 3) Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (8) Replace the NGS Altitude Sensor, M02562. These are the tasks:
 - Altitude Sensor Removal, AMM TASK 47-42-01-000-801
 - Altitude Sensor Installation, AMM TASK 47-42-01-400-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

——— END OF TASK ———

811. NGS BITE Message BLD PRESS SENSOR DRIFT - Fault Isolation

A. Description

(1) This task is for fault message:

EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASKS 810-811



- (a) 47-30018 BLD PRESS SENSOR DRIFT
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) BLD PRESS SENSOR DRIFT shows when NGS bleed pressure exceeded 67 psig (462 kPa) for more than 60 seconds during descent or cruising altitude. The fault message can show if the NGS bleed pressure is more than the overpressure limit for 60 seconds during the BDU system test.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Bleed air system over-pressurization (ATA 36)
- (2) NGS Pressure Sensor, M02565

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) ATA 36
- (2) SSM 47-30-11
- (3) WDM 47-30-11

E. Initial Evaluation

- (1) Do the SYSTEM TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the BDU message SYSTEM TEST PASS shows, then there was an intermittent fault.
- (3) If the fault message 47–30018 BLD PRESS SENSOR DRIFT shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Look for over-pressure condition(s) in the bleed air system (ATA 36).
 - (a) If the bleed air system is satisfactory, then continue.
- (2) Do the following steps to compare the bleed pressure reading from the BDU with the duct pressure reading on the flight compartment.
 - (a) Push the ON/OFF pushbutton on the BDU.
 - NOTE: The BDU automatically shutdowns after five minutes of inactivity.
 - (b) Select the OTHER FUNCTION? menu.
 - 1) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.

EFFECTIVITY -----

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



- 2) Push the YES pushbutton.
- (c) Select the I/O MONITOR? menu.
 - 1) Push the up or down arrow pushbutton until I/O MONITOR? shows.
 - 2) Push the YES pushbutton.
- (d) Select the ANALOG INPUTS? menu.
 - 1) Push the up or down arrow pushbutton until ANALOG INPUTS? shows
 - 2) Push the YES pushbutton.
- (e) Select the PALT.
 - 1) Push the up or down arrow pushbutton until PALT: XXXX.X FT/ PB: YYY.Y PSIG shows on the display.
 - a) Make a note of the bleed pressure (PB).



TO STOP THE GROUND TEST, PUSH THE MENU BUTTON THEN THE NO BUTTON ON THE BDU. IF THE SHUTOFF VALVE STAYS OPEN, DAMAGE TO EQUIPMENT CAN OCCUR.

- (f) Push the MENU pushbutton to stop the test.
- (3) In the flight compartment, locate the dual duct pressure gauge.
 - (a) Make a note of the duct pressure.
- (4) Compare the dual duct pressure gage reading with the bleed pressure (PB) reading on the BDU.
 - (a) If the pressure readings are the same, do the Repair Confirmation at the end of this task.
 - (b) If the pressure readings differ by ±2 psig (14 kPa) or more, then continue.
- (5) Disconnect connector D13830 from the NGS Pressure Sensor, M02565.
- (6) Disconnect connector D13804 from the NGS Controller, M02559.
- (7) Do the continuity check that follows in the related wiring between the NGS Pressure Sensor and the NGS Controller.

NGS PRESSURE SNSR D13830

pin 5 GD2318-ST

NGS

PRESSURE NGS

SNSR CONTROLLER

 D13830
 D13804

 pin 1
 pin 26

 pin 3
 pin 25

- (a) If you find problems with the wiring, repair as necessary.
 - 1) Re-connect connector D13830 to the NGS Pressure Sensor.
 - 2) Re-connect connector D13804 to the NGS Controller.



- 3) Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (8) Replace the NGS Pressure Sensor, M02565. These are the tasks:
 - NGS Pressure Sensor Removal, AMM TASK 47-43-04-000-801
 - NGS Pressure Sensor Installation, AMM TASK 47-43-04-400-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the SYSTEM TEST PASS shows on the BDU display, then you corrected the fault.

——— END OF TASK ———

812. NGS BITE Message NGSSOV ELEC FAIL - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30020 NGSSOV ELEC FAIL
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) NGSSOV ELEC FAIL shows when the NGS controller finds an open or a short circuit condition with the NGS shutoff valve.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- NGS Shutoff Valve, V00172
- (2) NGS Wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

47-31 TASKS 811-812



E. Initial Evaluation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, NGSSOV ELEC FAIL 47-30020 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the NGS shutoff valve:
 - (a) Disconnect connector D13810 from the NGS shutoff valve, V00172.
 - (b) Do a check for 28 VDC between pins A and D (ground) of D13810.
 - (c) If there is 28 VDC between pins A and D of D13810, then do these steps:
 - Replace the NGS shutoff valve, V00172.
 (NGS Shutoff Valve Removal, AMM TASK 47-32-01-000-801)
 (NGS Shutoff Valve Installation, AMM TASK 47-32-01-400-801)
 - 2) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
 - (d) If there is not 28 VDC between pins A and D of D13810, then do these steps:
 - Make sure that pin D of D13810 goes to ground.
 - 2) If pin D of D13810 does not go to ground, then do these steps:
 - a) Repair the wiring from pin D to GD2318-ST.
 - b) Re-connect connector D13810 to the NGS shutoff valve.
 - c) Do the Repair Confirmation at the end of this task.
 - <1> If the Repair Confirmation is not satisfactory, then continue.
 - 3) If pin D of D13810 goes to ground, then do these steps:
 - Repair the wiring between pin A of D13810 and this circuit breaker, C01657.
 - <1> Circuit Breaker List

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

- b) Re-connect connector D13810 to the NGS shutoff valve.
- c) Do the Repair Confirmation at the end of this task.
 - <1> If the Repair Confirmation is not satisfactory, then continue.
- (2) Do this check of the wiring:
 - (a) Disconnect connector D13810 from the NGS shutoff valve, V00172.
 - (b) Disconnect connector D13806 from the NGS controller, M02559.



(c) Do a check for an open circuit between these pins:

D13810 D13806 pin B pin 31

- (d) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D13810 to the NGS shutoff valve.
 - 3) Re-connect connector D13806 to the NGS controller.
 - 4) Do the Repair Confirmation at the end of this task.
- (e) If there is continuity between pin B of D13810 and pin 31 of D13806, then do these steps.
 - 1) Replace the NGS shutoff valve, V00172.

(NGS Shutoff Valve Removal, AMM TASK 47-32-01-000-801) (NGS Shutoff Valve Installation, AMM TASK 47-32-01-400-801)

- 2) Re-connect connector D13810 to the NGS shutoff valve.
- Re-connect connector D13806 to the NGS controller.
- 4) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the fault.

----- END OF TASK -----

813. NGS BITE Message NGSSOV FAIL OPEN - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30021 NGSSOV FAIL OPEN
- (2) The operability indicator shows INOPERATIVE (amber light). The NGS is offline.
- (3) The BDU display shows NGSSOV FAIL OPEN fault message when the NGS shutoff valve does not close in 10 seconds when commanded closed.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

(1) NGS Shutoff Valve, V00172

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASKS 812-813



SHZ 802-825, 827-847, 850-852, 855-859, 880-899 (Continued)

(Continued)

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the BDU message SYSTEM TEST PASS shows, then there was an intermittent fault.
- (3) If the fault message NGSSOV FAIL OPEN 47-30021 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

(1) Do the system test in this task: NGS BITE - Procedure, 47-31 TASK 801.

NOTE: The system test operates for 4 minutes.

- (a) While the system test operates, have a second person monitor the position indicator on the NGS shutoff valve.
 - 1) Make sure that the NGS shutoff valve opens, then closes, during the system test.
- (b) If the position indicator is stuck in the open position during the system test, then do these steps:
 - 1) Replace the NGS shutoff valve, V00172.

(NGS Shutoff Valve Removal, AMM TASK 47-32-01-000-801)

(NGS Shutoff Valve Installation, AMM TASK 47-32-01-400-801)

- 2) Do the Repair Confirmation at the end of this task.
- (c) If the NGS shutoff valve opens, then closes, during the system test, the NGS shutoff valve is serviceable.

NOTE: If the valve moves to the closed position slowly, this can be the cause of the fault. The system only allows 10 seconds for the valve to close after the command is given.

G. Repair Confirmation

- (1) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the SYSTEM TEST PASS shows on the BDU display, then you corrected the fault.

——— END OF TASK ———

814. NGS BITE Message NGSSOV / OTSOV / HFV CLOSED - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30023 NGSSOV/OTSOV/HFV CLOSED

901-999; SHŹ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASKS 813-814

Page 228 Oct 15/2024



- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) NGSSOV/OTSOV/HFV CLOSED shows when the NGS is on. The NGS shutoff valve (SOV), overtemperature (OT) SOV, and high flow valve (HFV) are commanded open, but a no-flow condition is sensed by the NGS controller for 30 seconds.
 - (a) The controller logic includes these five components: NGS SOV, OT SOV, HFV, ASM differential pressure sensor (Hi-Flow), and the NGS pressure sensor.

NOTE: Fault detection logic:

[(NGS SOV CMD = ON) AND (OTSOV CMD = ON) AND (ASM HFV CMD = ON) AND (DPHI < 5 psid) AND (PB > 15 psig) AND (DPHI_INVALID = FALSE) AND (PB INVALID = FALSE)] for 30 seconds

(4) To find more data about this maintenance message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) NGS shutoff valve, V00172
- (2) Overtemperature shutoff valve, V00175
- (3) High flow valve, V00174
- (4) Backflow prevention check valves (primary, secondary)
- (5) Tubes have blockage or are bent.

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

(1) Push the ON/OFF pushbutton on the BDU.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (2) Select the EXISTING FAULTS? menu.
 - (a) Push the up or down arrow pushbutton until EXISTING FAULTS? shows.
 - (b) Push the YES pushbutton.



(3) If the fault message NGSSOV/OTSOV/HFV CLOSED shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

(1) Do the system test in this task: NGS BITE - Procedure, 47-31 TASK 801.

NOTE: The system test operates for 4 minutes.

- (a) While the system test operates, have a second person monitor the position indicator on the NGS shutoff valve and the high flow valve.
 - Make sure that the NGS shutoff valve and high flow valve opens, then closes, during the system test.
- (2) Do this check of the NGS shutoff valve:
 - (a) If the NGS shutoff valve does not open during the system test, then do these steps:
 - Replace the NGS shutoff valve, V00172.
 (NGS Shutoff Valve Removal, AMM TASK 47-32-01-000-801)
 (NGS Shutoff Valve Installation, AMM TASK 47-32-01-400-801)
 - Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
 NOTE: The system test operates for 4 minutes.
 - If the SYSTEM TEST PASS shows on the BDU display, then you corrected the fault.
 - 4) If the fault message NGSSOV/OTSOV/HFV CLOSED 47-30023 shows, then continue.
 - (b) If the NGS shutoff valve opens, then closes, during the system test, the NGS shutoff valve is serviceable.
- (3) Do this check of the high flow valve, V00174:
 - (a) If the high flow valve does not open during the system test, then do these steps:
 - Replace the high flow valve, V00174.
 (High Flow Valve Removal, AMM TASK 47-11-02-000-801)
 (High Flow Valve Installation, AMM TASK 47-11-02-420-801)
 - 2) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.

NOTE: The system test operates for 4 minutes.

- a) Make sure that the high flow valve opens, then closes, during the system test.
- 3) If the SYSTEM TEST PASS shows on the BDU display, then you corrected the fault.
- 4) If the fault message NGSSOV/OTSOV/HFV CLOSED 47-30023 shows, then continue.
- (b) If the high flow valve opens, then closes, during the system test, the high flow valve is serviceable.
- (4) Do this check of the overtemperature shutoff valve, V00175:
 - (a) Replace the overtemperature shutoff valve, V00175.
 (Overtemperature Shutoff Valve Removal, AMM TASK 47-11-04-000-801)
 (Overtemperature Shutoff Valve Installation, AMM TASK 47-11-04-400-801)
 - (b) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.NOTE: The system test runs for 4 minutes.
 - 1) If the SYSTEM TEST PASS shows on the BDU display, then you corrected the fault.



- If the fault message NGSSOV/OTSOV/HFV CLOSED 47-30023 shows, then continue.
- (5) Do this check of the backflow prevention check valve:
 - (a) Replace the primary prevention check valve.
 (Primary Backflow Prevention Check Valve Removal, AMM TASK 47-21-04-000-801)
 (Primary Backflow Prevention Check Valve Installation, AMM TASK 47-21-04-400-801)
 - (b) Replace the secondary prevention check valve.
 (Secondary Backflow Prevention Check Valve Removal, AMM TASK 47-21-04-000-803)
 (Secondary Backflow Prevention Check Valve Installation, AMM TASK 47-21-04-400-803)
 - (c) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.

NOTE: The system test runs for 4 minutes.

- If the BDU message SYSTEM TEST PASS shows, then you corrected the fault.
- (6) Do an air pressure test check:
 - (a) Do these steps to prepare the airplane:
 - 1) Install the downlock pins at the main landing gears: Landing Gear Downlock Pins Installation, AMM TASK 32-00-01-480-801.
 - 2) Do the static grounding of the airplane: Static Grounding, AMM TASK 20-40-11-910-801.
 - Remove fuel from the fuel tanks: DEFUELING MAINTENANCE PRACTICES, AMM 28-26-00/201.
 - 4) Remove electrical power from the airplane: Remove Electrical Power, AMM TASK 24-22-00-860-812.
 - 5) Prepare for fuel tank entry into the center fuel tank: FUEL TANKS MAINTENANCE PRACTICES, AMM 28-11-00/201
 - 6) Open this access panel:

Number Name/Location
192CL ECS Access Door

- (b) Make sure that the air pressure source can supply pressure at 7.0 psig (48.3 kPa) and 30 ft³ (850 l) per minute with an in-line shutoff valve.
- (c) Use a pressure gauge that shows changes in air pressure of 0.25 psig (1.72 kPa).
- (d) Use a flow meter that can show air flow from 0.0 to 30 ft³ (850 I) per minute.
- (e) Use an air inlet adapter for connection to the flame arrestor fitting or bulkhead fitting on the rear spar.

NOTE: If it is necessary to connect a hose between the flame arrestor fitting or bulkhead fitting and pressure gauge, the hose's minimum inside diameter is 0.5 in. (1.3 cm) and maximum hose length is 18 in. (46 cm)inches.





TOO MUCH PRESSURE CAN CAUSE DAMAGE TO THE NGS TUBES. YOU MUST USE AN APPLICABLE PRESSURE LIMIT DEVICE TO PREVENT TOO MUCH PRESSURE INSIDE THE NGS TUBES. THE MAXIMUM PRESSURE PUT INTO THE NGS TUBES DURING THE PRESSURE TEST IS +5.2 PSIG OR +144.2 INCHES OF WATER. ADJUST THE AIR PRESSURE IF NECESSARY BEFORE CONNECT THE TEST EQUIPMENT TO THE AIRPLANE.

- (f) Connect it to the air pressure supply and keep the shutoff valve in the Open position to allow air to go into the NGS tubes.
- (g) Turn on the air pressure source and apply positive air pressure of 1.0 psig (6.9 kPa) to 2.0 psig (13.8 kPa) through the Nitrogen Enriched Air Distribution System (NEADS) tubes. Wait between 30 seconds and one minute to allow the air flow to stabilize.
 - 1) If the air flow meter shows at or more than 10 ft³ (283 l) per minute, do these steps:
 - a) Make sure that the air pressure is less than 5 psig (34 kPa).

NOTE: Do not put more than 5 psig (34 kPa) air pressure into the Nitrogen Enriched Air (NEA) tubes. If air pressure of 5 psig (34 kPa) gives a reading on the flow meter of less than 10 ft³ (283 l) per minute, then the in-tank NEA tubes possibly have a blockage or bent tubing. Repair any blockage or bent tubing as necessary and then do this pressure test again.

- b) Turn off the air pressure supply source.
- 2) If the air flow meter shows less than 10 ft³ (283 I) per minute, do these steps.
 - a) Increase the air pressure in increments of 1.0 psig (6.9 kPa) to 1.5 psig (10.3 kPa) again and wait between 30 seconds and one minute between each air pressure increase until the flow meter shows a minimum of 10 ft³ (283 l) per minute. Maximum air pressure put into the NEA tubes is 5 psig (34 kPa).

NOTE: Do not put more than 5 psig (34 kPa) air pressure into the NEA tubes. If air pressure of 5 psig (34 kPa) gives a reading on the flow meter of less than 10 ft³ (283 l) per minute, then the in-tank NEA tubes possibly have a blockage or bent tubing. Repair any blockage or bent tubing as necessary and then do this pressure test again.

- b) When the flow meter shows at or more than 10 ft³ (283 I) per minute, make sure that the air pressure is less than 5 psig (34 kPa).
- c) Turn off the air pressure supply source.
- 3) Release any air pressure from the NEA tubes and air flow meter.
- (h) Disconnect the air source, shutoff valve, flow meter, and pressure gauge from the inlet adapter.
- (i) On the rear spar, remove the inlet adapter from the flame arrestor fitting or bulkhead fitting.
- (j) At the flame arrestor fitting or bulkhead fitting, install the kept protective cap if it was removed.
- (k) Put the Airplane back to a serviceable condition:
 - 1) Put fuel into the fuel tank: FUEL SERVICING, AMM 12-11-00/301
 - 2) Make sure there are no fuel leaks: FUEL TANKS INSPECTION/CHECK, AMM 28-11-00/601



- If necessary apply electrical power to the airplane: Supply Electrical Power, AMM TASK 24-22-00-860-811
- 4) Make sure that this access panel is closed:

Number Name/Location

192CL ECS Access Door

------ END OF TASK ------

815. NGS BITE Message OTSOV ELEC FAIL - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30024 OTSOV ELEC FAIL
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) OTSOV ELEC FAIL shows on the display if the NGS controller finds one of these problems:
 - (a) NGS thermal switch does not operate.
 - (b) The overtemperature shutoff valve (OTSOV) does not operate.
 - (c) There is a short circuit.
 - (d) There is an open circuit.
 - (e) Temperature sensor does not operate.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) NGS Thermal Switch, S01129
- (2) OTSOV, V00175
- (3) NGS Wiring
- (4) NGS Temperature Sensor, T03020

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

47-31 TASKS 814-815



E. Initial Evaluation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, OTSOV ELEC FAIL 47-30024 shows, do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the NGS thermal switch:
 - (a) Disconnect connector D13816 from the NGS thermal switch, S01129.
 - (b) Do a check for 28 VDC between pins A and C (ground) of D13816.
 - (c) If there is 28 VDC between pins A and C of D13816, then do these steps:
 - Replace the NGS thermal switch, S01129.
 (Thermal Switch Removal, AMM TASK 47-43-02-000-801)
 (Thermal Switch Installation, AMM TASK 47-43-02-400-801)
 - 2) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
 - (d) If there is not 28 VDC between pins A and C of D13816, then do these steps:
 - 1) Make sure that pin C of D13816 goes to ground.
 - 2) If pin C of D13816 does not go to ground, then do these steps:
 - a) Repair the wiring from pin C to GD109-ST.
 - b) Re-connect connector D13816 to the NGS thermal switch.
 - c) Do the Repair Confirmation at the end of this task.
 - <1> If the Repair Confirmation is not satisfactory, then continue.
 - 3) If pin C of D13816 goes to ground, then do these steps:
 - a) Repair the wiring between pin A of D13816 and circuit breaker C01657:
 - <1> Circuit Breaker List

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

- b) Re-connect connector D13816 to the NGS thermal switch.
- Do the Repair Confirmation at the end of this task.
 - <1> If the Repair Confirmation is not satisfactory, then continue.
- (2) Do this check of the overtemperature shutoff valve (OTSOV):
 - (a) Disconnect connector D13826 from the OTSOV, V00175.
 - (b) Do a check for 28 VDC between pins A and B (ground) of D13826.

901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



- (c) If there is 28 VDC between pins A and B of D13826, then do these steps:
 - 1) Replace the OTSOV, V00175.

(Overtemperature Shutoff Valve Removal, AMM TASK 47-11-04-000-801) (Overtemperature Shutoff Valve Installation, AMM TASK 47-11-04-400-801)

- Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (d) If there is not 28 VDC between pins A and B of D13826, then do these steps:
 - 1) Make sure that pin B of D13826 goes to ground.
 - 2) If pin B of D13826 does not go to ground, then do these steps:
 - a) Repair the wiring from pin B to GD109-ST.
 - b) Re-connect connector D13826 to the OTSOV.
 - c) Do the Repair Confirmation at the end of this task.<1> If the Repair Confirmation is not satisfactory, then continue.
 - 3) If pin B of D13826 goes to ground, then do this step and continue:
 - a) Re-connect connector D13826 to the OTSOV.
- (3) Do this check of the wiring:
 - (a) Disconnect connector D13816 from the NGS thermal switch, S01129.
 - (b) Disconnect connector D13826 from the OTSOV, V00175.
 - (c) Disconnect connector D13806 from the NGS controller, M02559.
 - (d) Do a check for an open circuit between these pins:

D13826	D13816
pin A	pin B
F	P
D13826	D13806
pin C	nin 20
DIII C	טנווט

- (e) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D13826 to the OTSOV.
 - 3) Re-connect connector D13806 to the NGS controller.
 - 4) Re-connect connector D13816 to the NGS thermal switch.
 - 5) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (f) If there is continuity, then do these steps and continue.
 - 1) Re-connect connector D13826 to the OTSOV.
 - 2) Re-connect connector D13806 to the NGS controller.
 - 3) Re-connect connector D13816 to the NGS thermal switch.
 - Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (4) Replace the NGS temperature sensor, T03020:



(Temperature Sensor Removal, AMM TASK 47-43-03-000-801) (Temperature Sensor Installation, AMM TASK 47-43-03-400-801)

(5) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the fault.

------ END OF TASK ------

816. NGS BITE Message OTSOV FAIL OPEN - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30025 OTSOV FAIL OPEN
- (2) The operability indicator shows INOPERATIVE (amber light). The NGS is offline.
- (3) OTSOV FAIL OPEN shows when the NGS controller finds that the Overtemperature Shutoff Valve is in the incorrect open position.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

(1) Overtemperature Shutoff Valve - OTSOV, V00175

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message SYSTEM TEST PASS shows, then there was an intermittent problem.
 - (b) If the fault message, OTSOV FAIL OPEN 47-30025 shows, then do the Fault Isolation Procedure below.

EFFECTIVITY ----

47-31 TASKS 815-816

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



F. Fault Isolation Procedure

- (1) Replace the Overtemperature Shutoff Valve, V00175. These are the tasks:
 - Overtemperature Shutoff Valve Removal, AMM TASK 47-11-04-000-801
 - Overtemperature Shutoff Valve Installation, AMM TASK 47-11-04-400-801

G. Repair Confirmation

- (1) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the SYSTEM TEST PASS shows on the display, then you corrected the problem.

----- END OF TASK -----

817. NGS BITE Message NGSRAV ELEC FAIL - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30026 NGSRAV ELEC FAIL
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) NGSRAV ELEC FAIL shows when the NGS Controller finds an open or short circuit condition for the NGS Ram Air Valve.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) NGS Ram Air Valve, V00173
- (2) NGS Wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.

47-31 TASKS 816-817



If the fault message, NGSRAV ELEC FAIL 47-30026 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- Disconnect connector D13812 from the NGS Ram Air Valve, V00173.
- Disconnect connector D13806 from the NGS Controller, M02559.
- Do the continuity check that follows in the related wiring between the NGS Ram Air Valve and the NGS Controller:

NGS RAM AIR

VALVE

D13812

pin C GD113-ST

NGS RAM AIR NGS

VALVE CONTROLLER

D13812 D13806 pin B pin 34 pin 35

- If you find problems with the wiring, repair as necessary.
 - Re-connect connector D13812 to the NGS Ram Air Valve.
 - Re-connect connector D13806 to the NGS Controller. 2)
 - Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (4) Replace the NGS Ram Air Valve, V00173. These are the tasks:
 - Ram Air Valve Removal, AMM TASK 47-32-05-000-801
 - Ram Air Valve Installation, AMM TASK 47-32-05-400-801
 - (a) Do the Repair Confirmation below.

Repair Confirmation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

— END OF TASK —

818. NGS BITE Message NGSRAV FAIL OPEN - Fault Isolation

Description

- (1) This task is for fault message:
 - (a) 47-30027 NGSRAV FAIL OPEN
- The operability indicator shows DEGRADED (blue light). The NGS is operating below normal. (2)
- The NGS Controller detected that the bleed air temperature went below 110°F (43°C) and the bleed pressure was more than 15 psig (103 kPa). If these conditions last for more than 20 minutes during flight, the NGSRAV FAIL OPEN fault message is set.
- To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

47-31 TASKS 817-818

EFFECTIVITY SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



B. Possible Causes

- (1) Air leak in the muscle air line on the NGS Ram Air Valve
- NGS Ram Air Valve, V00173
- (3) Precooler Control Valve stuck open

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
- (3) If the fault message NGSRAV FAIL OPEN 47-30027 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

SHZ 886-899

- (1) If the maintenance message 21-51255 FLOW CTRL VALVE for the left pack shows on the Pack Flow Temperature Controller (PFTC), do the Flow Control Valve Overpressure Fault Isolation, 21-62 TASK 902.
 - (a) Do the Repair Confirmation at the end of this task.

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

(2) Do the system test in this task: NGS BITE - Procedure, 47-31 TASK 801.

NOTE: The system test operates for 4 minutes.

- (a) Have a second person examine the NGS Ram Air Valve during the system test.
 - 1) Make sure that the NGS Ram Air Valve opens, then closes, during the system test.
- (b) If the position indicator on the NGS Ram Air Valve is stuck in the open position during the system test, then do these steps:
 - 1) Replace the NGS Ram Air Valve, V00173. These are the tasks:
 - Ram Air Valve Removal, AMM TASK 47-32-05-000-801
 - Ram Air Valve Installation, AMM TASK 47-32-05-400-801

47-31 TASK 818

865, 866, 871-874 POST SB 737-47-1003



- 2) Do the Repair Confirmation at the end of this task.
- (c) If the NGS Ram Air Valve opens, then closes, during the system test, the NGS Ram Air Valve is serviceable.
- (3) Do the leak check in this task: Leak Check of the Nitrogen Generation System, AMM TASK 47-00-00-790-801.
 - (a) If there is a leak, then repair the leaks that you find.
 - 1) Do the Repair Confirmation at the end of this task.
 - If you do not find an air leak in the NGS Ram Air Valve muscle air line, then continue.
- (4) Do this task: Precooler Control Valve System Health Check, AMM TASK 36-12-00-700-801.
 - (a) Do the Repair Confirmation at the end of this task.

G. Repair Confirmation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the problem.
 - (b) If the fault message NGSRAV FAIL OPEN 47-30027 shows, then continue the Fault Isolation Procedure at the subsequent step.



819. NGS BITE Message NGSRAV FAIL CL/HX BLKD - Fault Isolation

A. Description

- (1) This task is for this maintenance message:
 - (a) 47-30028 NGSRAV FAIL CL/HX BLKD
 - (b) NVM Download Shop Code 77
- (2) The Operability Indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) The BDU shows NGSRAV FAIL CL/HX BLKD maintenance message when there is an Overtemperature condition.
 - (a) An Overtemperature condition occurs when the System Temperature stays above 175°F (79.4°C) for a given period of time.
- (4) To find more information about this maintenance message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

EFFECTIVITY

- (1) NGS Air Separation Module (ASM)
- (2) Ram Air Valve, V00173 (failed in the CLOSED position)
- (3) Heat Exchanger Blockage
- (4) High Bleed Air Temperature
- (5) Ambient Temperature more than 120°F (48.9°C)

SHZ 801-825, 827, 828, 876-880, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

(6) Left Ram Air Inlet Actuator

901-999; SHZ 002, 009-699, 706, 721-799, 860-863,

865, 866, 871-874 POST SB 737-47-1003

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

(7) Left Flow Control and Shutoff Valve

SHZ 801-825, 827-847, 850-852, 855-859, 876-899,

47-31 TASKS 818-819



- (8) Flap Switch, S1051
- (9) Duct Leakage

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the BDU ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the maintenance message 47-30028 NGSRAV FAIL CL/HX BLKD does not show, then there was an intermittent fault.
 - (b) If the maintenance message 47-30028 NGSRAV FAIL CL/HX BLKD shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) If the maintenance message 47-30028 NGSRAV FAIL CL/HX BLKD showed during descent, do a check of the Flap Switch, S1051:
 - (a) Lower the flaps to the one degree position (AMM TASK 27-51-00-860-801).
 - (b) Do this task: Put the Airplane in the Air Mode, AMM TASK 32-09-00-860-801.
 - (c) Make sure that the Left Ram Air Inlet Deflector Door moves to the stowed position.
 - (d) Make sure that the Left Ram Air Inlet Modulation Panels move to a more closed position and the RAM DOOR FULL OPEN lights on the P5-10 Air Conditioning Panel are ON.

NOTE: Movement of the Left Ram Air Inlet Modulation Panels may not be easily noticed.

- If the Modulation Panels move to a more closed position and the RAM DOOR FULL OPEN lights on the P5-10 Air Conditioning Panel are OFF, then replace the Flap Switch, S1051. These are the tasks:
 - Flap Limit Switch Removal, AMM TASK 27-51-63-000-801
 - Flap Limit Switch Installation, AMM TASK 27-51-63-400-801
 - a) Do the Repair Confirmation at the end of this task.
- (e) Do this task: Return the Airplane to the Ground Mode, AMM TASK 32-09-00-860-802.
- (f) Retract the flaps to the FULL UP position (AMM TASK 27-51-00-860-801).



SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 860-863, 865, 866, 871-874 POST SB 737-47-1003

- (2) If the maintenance message 47-30028 NGSRAV FAIL CL/HX BLKD showed in the air, do the Pack Temperature Control BITE Procedure, 21-62 TASK 801 on the #1 Controller.
 - (a) After you push the VERIFY button, do a visual check to make sure that the Left Ram Air Doors move to the CLOSED position and then back to the OPEN position.
 - (b) If the Controller finds a problem in the Left Ram Air Inlet Actuator or the Left Ram Air Inlet Doors, replace the Left Ram Air Inlet Actuator. These are the tasks:
 - Ram Air Inlet Actuator Removal, AMM TASK 21-51-21-000-801
 - Ram Air Inlet Actuator Installation, AMM TASK 21-51-21-400-801
 - 1) Do the Repair Confirmation at the end of this task.

SHZ 002, 009-699, 706, 721-799 POST SB 737-47-1003

- (3) If the maintenance message 47-30028 NGSRAV FAIL CL/HX BLKD showed in the air, do the Post-Installation Test of the Ram Air Inlet Controller #1 (AMM TASK 21-51-20-400-801).
 - (a) After you push the VERIFY button, do a visual check to make sure that the Left Ram Air Doors move to the CLOSED position and then back to the OPEN position.
 - (b) If there is a problem in the Left Ram Air Inlet Actuator or the Left Ram Air Inlet Doors, replace the Left Ram Air Inlet Actuator. These are the tasks:
 - Ram Air Inlet Actuator Removal, AMM TASK 21-51-21-000-801
 - Ram Air Inlet Actuator Installation, AMM TASK 21-51-21-400-801
 - 1) Do the Repair Confirmation at the end of this task.

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

- (4) If the maintenance message 47-30028 NGSRAV FAIL CL/HX BLKD shows on the ground, do the "Test of Pack Valves" in this task: Flight Management Computer System - System Test, AMM TASK 34-61-00-730-801.
 - (a) If the "Test of Pack Valves" is not satisfactory, then replace the Left Flow Control and Shutoff Valve Control Valve. These are the tasks:
 - Flow Control and Shutoff Valve Removal, AMM TASK 21-51-01-000-801-001 or Left Flow Control and Shutoff Valve - Removal, AMM TASK 21-51-01-000-802-002 or Left Flow Control and Shutoff Valve Removal, AMM TASK 21-51-01-000-806-003
 - Flow Control and Shutoff Valve Installation, AMM TASK 21-51-01-400-801-001 or Left Flow Control and Shutoff Valve - Installation, AMM TASK 21-51-01-400-805-002 or Left Flow Control and Shutoff Valve Installation, AMM TASK 21-51-01-400-807-003
 - 1) Do the Repair Confirmation at the end of this task.
- (5) Do this check of the Ram Air Valve:
 - (a) Do the NGS BITE Procedure, 47-31 TASK 801.
 - 1) Have a second person examine the NGS Ram Air Valve during the System Test.
 - (b) If the Ram Air Valve does not open during the BITE Task, then do these steps:
 - 1) Replace the Ram Air Valve, V00173. These are the tasks:
 - Ram Air Valve Removal, AMM TASK 47-32-05-000-801
 - Ram Air Valve Installation, AMM TASK 47-32-05-400-801
 - 2) Do the Repair Confirmation at the end of this task.



- (c) If the NGS Ram Air Valve opens during the BITE Task, then do these steps:
 - 1) Replace the ASM. These are the tasks:
 - Air Separation Module (ASM) Removal, AMM TASK 47-11-01-000-801
 - Air Separation Module (ASM) Installation, AMM TASK 47-11-01-420-801
 - a) Do the Repair Confirmation at the end of this task.
 - Do this task: Precooler Control Valve System Health Check, AMM TASK 36-12-00-700-801.

NOTE: Sensors cannot be tested on-wing. It is recommended to replace the 390 Degree Sensor if the Health Check is good.

- a) Do the Repair Confirmation at the end of this task.
- 3) Replace the Heat Exchanger. These are the tasks:
 - · Heat Exchanger Removal, AMM TASK 47-32-03-000-801
 - Heat Exchanger Installation, AMM TASK 47-32-03-400-801
 - a) Do the Repair Confirmation at the end of this task.
- (6) Do a Leak Check of the Nitrogen Generation System, downstream of the Temperature Sensor. This is the task Leak Check of the Nitrogen Generation System, AMM TASK 47-00-00-790-801.
 - (a) Do the Repair Confirmation at the end of this task.

G. Repair Confirmation

- Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If ELECTRICAL TEST PASS shows on the BDU, then you corrected the problem.
 - (b) If ELECTRICAL TEST PASS does not show on the BDU, then continue the fault Isolation Procedure at the subsequent step.



820. NGS BITE Message FILTER BLOCKED - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30029 FILTER BLOCKED
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) The NGS controller does a filter Built-In-Test (BIT) to find a blocked or defective filter. The filter BIT sets the FILTER BLOCKED message when all of these conditions are true:
 - (a) The filter differential pressure switch senses high pressure
 - (b) The NGS system is on
 - (c) The airplane is in the climb condition, or the IBIT System Test is in progress.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Air Separation Module
- (2) Filter DP switch, M02561
- (3) NGS filter

47-31 TASKS 819-820



(4) Airplane wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Review the BDU Fault History Menu, AMM TASK 47-31-02-740-803.
 - (a) If the fault message NGS ASM FAIL 47-30063 and FILTER BLOCKED 47-30029 have occurred within the last 10 flights then the ASM is likely failed.
- (2) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801
 - (a) If the BDU message SYSTEM TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, FILTER BLOCKED 47-30029 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the filter DP switch:
 - (a) Disconnect connector D13814 from the filter DP switch, M02561.
 - (b) Do a check for 18.0 29.5 VDC between pins A and B (ground) of D13814.
 - c) If there is 18.0 29.5 VDC between pins A and B of D13814, then do these steps:
 - Replace the filter DP switch, M02561.
 (Filter Differential Pressure Switch Removal, AMM TASK 47-43-01-000-801)
 (Filter Differential Pressure Switch Installation, AMM TASK 47-43-01-400-801)
 - 2) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
 - (d) If there is not 18.0 29.5 VDC at pin A of D13814, then do these steps:
 - 1) Make sure that pin B of D13814 goes to ground.
 - 2) If pin B of D13814 does not go to ground, then do these steps:
 - a) Repair the wiring from pin B to GD121-DC.
 - b) Re-connect connector D13814 to the filter DP switch.
 - c) Do the Repair Confirmation at the end of this task.



<1> If the Repair Confirmation is not satisfactory, then continue.

- 3) If pin B of D13814 does go to ground, then do these steps:
 - a) Disconnect connector D13806 from the NGS controller, M02559.
 - b) Repair the wiring from pin A of D13814 to pin 6 of D13806.
 - c) Re-connect connector D13814 to the filter DP switch.
 - d) Re-connect connector D13806 to the NGS controller.
 - e) Do the Repair Confirmation at the end of this task.
 - <1> If the Repair Confirmation is not satisfactory, then continue.
- Replace the NGS filter.

NGS Filter Element - Removal, AMM TASK 47-32-04-000-802

NGS Filter Element - Installation, AMM TASK 47-32-04-400-802

(a) Do the Repair Confirmation at the end of this task.

G. Repair Confirmation

- (1) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the SYSTEM TEST PASS shows on the BDU display, then you corrected the fault.



821. NGS BITE Message HFV ELEC FAIL - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30030 HFV ELEC FAIL
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) HFV ELEC FAIL shows on the display when the NGS controller finds a problem with high-flow valve, an open circuit, or a short circuit in the high-flow valve circuit.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) High-flow valve, V00174
- (2) Airplane wiring
- (3) Circuit breaker Nitrogen Generation Control (C01657).

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

47-31 TASKS 820-821



SHZ 802-825, 827-847, 850-852, 855-859, 880-899 (Continued)

(Continued)

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message HFV ELEC FAIL 47-30030 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the high flow shutoff valve:
 - (a) Disconnect connector D13820 from the high-flow valve, V00174.
 - (b) Do a check for 28 VDC between pins 1 and 3 (ground) of D13820.
 - (c) If there is 28 VDC between pins 1 and 3 of D13820, then do these steps:
 - 1) Replace the high-flow valve.

(High Flow Valve Removal, AMM TASK 47-11-02-000-801)
(High Flow Valve Installation, AMM TASK 47-11-02-420-801)

- 2) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (d) If there is not 28 VDC between pins 1 and 3 of D13820, then do these steps:
 - 1) Make sure that pin 3 of D13820 goes to ground.
 - 2) If pin 3 of D13820 does not go to ground, then do these steps:
 - a) Repair the wiring from pin 3 to GD111-ST.
 - b) Re-connect connector D13820 to the high-flow valve.
 - c) Do the Repair Confirmation at the end of this task.

<1> If the Repair Confirmation is not satisfactory, then continue.

- 3) If pin 3 of D13820 does go to ground, then do these steps:
 - Repair the wiring between pin 1 of D13820 and circuit breaker C01657:
 Circuit Breaker List

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003 (Continued)

(Continued)

CAPT Electrical System Panel, P18-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	17	C01657	NITROGEN GEN CONT
SHZ 802-825, 827-847, 850-852, 855-859, 880-899			
D	17	C01657	NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

- b) Re-connect connector D13820 to the high-flow valve.
- c) Do the Repair Confirmation at the end of this task.

<1> If the Repair Confirmation is not satisfactory, then continue.

- (2) Do this check of the wiring:
 - (a) Disconnect connector D13820 from the high-flow valve V00174.
 - (b) Disconnect connector D13806 from the NGS controller, M02559.
 - (c) Do a check for an open circuit between these pins:

D13820	D13806
pin 2 .	 pin 14

- (d) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D13820 to the high-flow valve.
 - Re-connect connector D13806 to the NGS controller.
 - 4) Do the Repair Confirmation at the end of this task.
- (e) If there is continuity, then do these steps:
 - Replace the high-flow valve.

(High Flow Valve Removal, AMM TASK 47-11-02-000-801) (High Flow Valve Installation, AMM TASK 47-11-02-420-801)

- 2) Re-connect connector D13820 to the high-flow valve.
- 3) Re-connect connector D13806 to the NGS controller.
- 4) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the fault.

——— END OF TASK ———

823. NGS BITE Message HFV FAIL OPEN - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30032 HFV FAIL OPEN

47-31 TASKS 821-823



- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) The BDU display shows HFV FAIL OPEN when the NGS controller finds that the hardware for the ASM high-flow valve is failed in the open position.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

(1) High-flow valve, V00174

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the BDU message SYSTEM TEST PASS shows, then there was an intermittent fault.
- (3) If the fault message HFV FAIL OPEN 47-30032 shows, then do the Fault Isolation Procedure.

F. Fault Isolation Procedure

- (1) Have a person check the position indicator on the high flow valve.
- (2) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.

NOTE: The system test operates for 4 minutes.

- (a) While the system test operates, have a second person monitor the position indicator on the high flow valve.
 - 1) Make sure that the high flow valve opens, then closes, during the system test.
- (3) If the position indicator is stuck in the open position during the system test, then do these steps:
 - (a) Replace the high flow valve, V00174.

(High Flow Valve Removal, AMM TASK 47-11-02-000-801)

(High Flow Valve Installation, AMM TASK 47-11-02-420-801)

(4) If the high flow valve opens, then closes, during the system test, the valve is serviceable.

EFFECTIVITY 47-31 TASK 823



G. Repair Confirmation

- (1) Do the system test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the SYSTEM TEST PASS shows on the BDU display, then you corrected the fault.

----- END OF TASK -----

824. NGS BITE Message WOW SIG FAIL IN AIR - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30040 WOW SIG FAIL IN AIR
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) WOW SIG FAIL IN AIR shows on the display when the NGS controller senses that the AIR/GROUND relay system is in the incorrect air condition for more than 10 seconds.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Primary air/ground relay system
- (2) Airplane wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 32-09-11
- (2) SSM 32-09-12
- (3) SSM 47-30-11
- (4) WDM 32-09-11
- (5) WDM 32-09-12
- (6) WDM 47-30-11

E. Initial Evaluation

- (1) Make sure that the airplane is in the ground mode (AMM TASK 32-09-00-860-802).
- (2) Push the ON/OFF pushbutton on the BDU.
 - (a) The BDU will show IN AIR for one second then go off.
- (3) If the message IN AIR shows, then do the Fault Isolation Procedure below.

- EFFECTIVITY

47-31 TASKS 823-824

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

Page 249 Oct 15/2024



- (4) If the BDU menu is available, then do these steps:
 - (a) Select the EXISTING FAULTS? menu.
 - 1) Push the up or down arrow pushbutton until EXISTING FAULTS? shows.
 - 2) Push the YES pushbutton.
 - (b) If the fault message WOW SIG FAIL IN AIR 47-30040 does not show, then there was an intermittent fault.
 - (c) If the fault message WOW SIG FAIL IN AIR 47-30040 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the proximity switch electronics unit:
 - (a) Do this task: Proximity Switch Electronics Unit (PSEU) BITE Procedure, 32-09 TASK 801. NOTE: Look for maintenance message 32–06001 AIR/GND R584 FLT on the PSEU.
 - (b) If the maintenance message 32–06001 AIR/GND R584 FLT shows on the PSEU display, then do these steps:
 - 1) Do the applicable fault isolation procedure(s) for this fault.
 - Make sure that the messages related to the AIR / GROUND relay system are corrected.
 - (c) After you repair the problem, do these steps to make sure that you repaired the problem:
 - 1) Make sure that the airplane is in the ground mode (AMM TASK 32-09-00-860-802).
 - 2) Push the ON/OFF pushbutton on the BDU.
 - a) If the BDU menu is available, then you repaired the problem.
 - b) If the BDU shows IN AIR for one second then goes off, continue with the fault isolation procedure.
- (2) Do this check of the wiring:
 - (a) Disconnect connector D13806 on the NGS controller, M02559.
 - (b) Disconnect connector D11002 on the AIR/GND relay, R584, in the J22 Panel.
 - (c) Do a check for an open circuit between these pins:

D11002	D13806
pin D3	 pin 12

- (d) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - Make sure that pin D2 of D11002 goes to ground.
 - If pin D2 of D11002 does not go to ground, then do the next step and continue.
 - a) Repair the wiring from pin D2 to GD532-DC.
 - If pin D2 of D11002 goes to ground, then continue.
 - 5) Re-connect connector D11002 to the AIR/GND relay.
 - 6) Re-connect connector D13806 to the NGS controller.
 - 7) Do the Repair Confirmation at the end of this task.
- (e) If there is continuity between each pin, then do these steps:
 - 1) Replace the AIR/GND relay, R584.



- 2) Re-connect connector D11002 to the AIR/GND relay.
- 3) Re-connect connector D13806 to the NGS controller.
- 4) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Make sure that the airplane is in the ground mode (AMM TASK 32-09-00-860-802).
- (2) Push the ON/OFF pushbutton on the BDU.
 - (a) If the BDU menu is available, then you repaired the problem.

------ END OF TASK ------

825. NGS BITE Message WOW SIG FAIL ON GROUND - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30041 WOW SIG FAIL ON GROUND
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) WOW SIG FAIL ON GROUND shows on the display when the NGS controller senses that the AIR/GROUND relay system is in the incorrect ground state for more than 10 seconds.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Primary air/ground relay system
- (2) Airplane Wiring.

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) WDM 32-09-11
- (2) WDM 32-09-12
- (3) WDM 47-30-11

E. Initial Evaluation

- Do this task: Prepare to Put the Airplane in the Air Mode, AMM TASK 32-09-00-840-801.
- (2) Do this task: Put the Airplane in the Air Mode, AMM TASK 32-09-00-860-801.
- (3) Do these steps to navigate to the DIGITAL INPUTS? menu:

47-31 TASKS 824-825

Page 251 Oct 15/2024



- (a) Push the ON/OFF pushbutton on the BDU.
 - NOTE: The BDU automatically shutdowns after five minutes of inactivity.
- (b) Select the OTHER FUNCTION? menu.
 - 1) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.
 - 2) Push the YES pushbutton.
- (c) Select the I/O MONITOR? menu.
 - 1) Push the up or down arrow pushbutton until I/O MONITOR? shows.
 - 2) Push the YES pushbutton.
- (d) Select the DIGITAL INPUTS? menu.
 - 1) Push the up or down arrow pushbutton until DIGITAL INPUTS? shows.
 - 2) Push the YES pushbutton.
- (e) Select WOW:
- (f) If the message WOW: ON GROUND shows, then do the Fault Isolation Procedure below.
- (g) If the message WOW: IN AIR shows, then there was an intermittent fault.
 - 1) Put the airplane in the ground mode (Return the Airplane to the Ground Mode, AMM TASK 32-09-00-860-802).

F. Fault Isolation Procedure

- (1) Do this check of the proximity switch electronics unit:
 - (a) Do this task: Proximity Switch Electronics Unit (PSEU) BITE Procedure, 32-09 TASK 801.
 NOTE: Look for maintenance message 32–06001 AIR/GND R584 FLT on the PSEU.
 - (b) If the maintenance message 32–06001 AIR/GND R584 FLT shows on the PSEU display, then do these steps:
 - 1) Do the applicable fault isolation procedure(s) for this fault.
 - 2) Make sure that the messages related to the AIR/GND relay system are corrected.
 - 3) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
 - (c) If maintenance message 32-06001 AIR/GND R584 FLT does not show on the PSEU display, then continue.
- (2) Do this check of the wiring:

Do these steps to do a check for a short circuit between the NGS controller (M02559) and the R584 System 1 AIR/GND relay:

- (a) Disconnect connector D13806 from the NGS controller, M02559.
- (b) Disconnect connector D11002 from the AIR/GND relay, R584, in the J22 Panel.
- (c) Do a check for an open circuit between these pins:

D11002 D13806 pin D3 pin 12

- (d) If there is an open circuit, then do these steps:
 - Repair the wiring.
 - 2) Make sure that pin D2 of D11002 goes to ground.



- 3) If pin D2 of D11002 does not go to ground, then do the next step and continue.
 - a) Repair the wiring from pin D2 to GD532-DC.
- 4) If pin D2 of D11002 goes to ground, then continue.
- 5) Re-connect connector D11002 to the AIR/GND relay.
- 6) Re-connect connector D13806 to the NGS controller.
- Do the Repair Confirmation at the end of this task.
- (e) If there is continuity between each pin, then do these steps:
 - 1) Replace the AIR/GND relay, R584.
 - 2) Re-connect connector D11002 to the AIR/GND relay.
 - 3) Re-connect connector D13806 to the NGS controller.
 - 4) Do the Repair Confirmation below.

G. Repair Confirmation

(1) After you repair the problem, do this task: Return the Airplane to the Ground Mode, AMM TASK 32-09-00-860-802.

NOTE: Make sure that the airplane is in the ground mode for ten minutes to reset the air/ground mode signal.

- (2) Do this task: Prepare to Put the Airplane in the Air Mode, AMM TASK 32-09-00-840-801.
- (3) Do these steps to make sure that you repaired the problem:
 - (a) Push the ON/OFF button on the BDU.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (b) Select the OTHER FUNCTION? menu.
 - 1) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.
 - 2) Push the YES pushbutton.
- (c) Select the I/O MONITOR? menu.
 - 1) Push the up or down arrow pushbutton until I/O MONITOR? shows.
 - 2) Push the YES pushbutton.
- (d) Select the DIGITAL INPUTS? menu.
 - 1) Push the up or down arrow pushbutton until DIGITAL INPUTS? shows.
 - 2) Push the YES pushbutton.
- (e) Select WOW:
- (f) If WOW: IN AIR shows on the display, then you repaired the problem.
- (4) Do this task: Return the Airplane to the Ground Mode, AMM TASK 32-09-00-860-802.

------ END OF TASK ------

826. NGS BITE Message FWD CGO FIRE SIG FAIL ON - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30042 FWD CGO FIRE SIG FAIL ON
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.

47-31 TASKS 825-826



- (3) FWD CGO FIRE SIG FAIL ON shows on the display when the NGS controller senses that the forward cargo fire signal is in the incorrect ON state.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Forward cargo fire signal system
- (2) Airplane wiring.

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) WDM 21-31-23
- (2) WDM 26-11-21
- (3) WDM 26-16-21
- (4) WDM 47-30-11

E. Initial Evaluation

- Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, FWD CGO FIRE SIG FAIL ON 47-30042 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the cargo electronic unit:
 - (a) Do the BITE procedure:

(Cargo Electronic Unit (CEU) BITE Procedure, 26-16 TASK 801)

- (b) If the test fails then do the applicable fault isolation procedure.
 - 1) Repair the problems that you find.
 - Make sure that the BITE messages related to the forward cargo fire signal system are corrected.
 - 2) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (c) If the test passes, then continue.



- (2) Do this check of the wiring:
 - (a) Disconnect connector D13806 from the NGS controller, M02559.
 - (b) Disconnect connector D40426P from the E3-2 shelf.
 - (c) Do a check for an open circuit between these pins:

D13806 D40426P Pin 3 Pin 15

- (d) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D40426P to the E3-2 shelf.
 - 3) Re-connect connector D13806 to the NGS controller.
 - Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (e) If there is continuity between each pin, then do these steps and continue.
 - 1) Re-connect connector D40426P to the E3-2 shelf.
 - 2) Re-connect connector D13806 to the NGS controller.
- (3) Do this check of the wiring:
 - (a) Disconnect connector D40426P from the E3-2 shelf.
 - (b) Do a check for wire W0321-0499-20 from pin 15 of D40426J and wire splice SM48.
 - (c) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D40426P to the E3-2 shelf.
 - 3) Do the Repair Confirmation at the end of this task.
 - (d) If there is continuity between each pin, then do these steps.
 - Re-connect connector D40426P to the E3-2 shelf.
 - 2) Re-connect connector D13806 to the NGS controller.

G. Repair Confirmation

- (1) Do the electrical test in this task: Ground Operation of the Nitrogen Generation System, AMM TASK 47-00-00-800-801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the fault.

------ END OF TASK ------

827. NGS BITE Message MN CGO FIRE SIG FAIL ON - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30043 MN CGO FIRE SIG FAIL ON
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) MN CGO FIRE SIG FAIL ON shows on the display when the NGS controller senses that the main deck cargo fire signal is in the incorrect ON state.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

EFFECTIVITY ----

47-31 TASKS 826-827

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



B. Possible Causes

- Main deck fire signal system
- (2) Airplane wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) WDM 21-31-23
- (2) WDM 26-11-21
- (3) WDM 26-16-21
- (4) WDM 47-30-11

E. Initial Evaluation

- Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message MN CGO FIRE SIG FAIL ON 47-30043 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the cargo electronic unit:
 - (a) Do the cargo electronic unit BITE task.

(Cargo Electronic Unit (CEU) BITE Procedure, 26-16 TASK 801)

- (b) If the test fails then do the applicable fault isolation procedure.
 - 1) Repair the problems that you find.
 - Make sure that the BITE messages related to the main cargo fire signal system are corrected.
 - Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (c) If the test passes, then continue.
- (2) Do this check of the wiring:
 - (a) Disconnect connector D13806 from the NGS controller, M02559.
 - (b) Disconnect connector D40426P from the E3-2 shelf.
 - (c) Do a check for an open circuit between these pins:



D1380	16	D40426P
Pin 8		Pin 15

- (d) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D40426P to the E3-2 shelf.
 - 3) Re-connect connector D13806 to the NGS controller.
 - 4) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (e) If there is continuity between each pin, then do these steps and continue.
 - 1) Re-connect connector D40426P to the E3-2 shelf.
 - 2) Re-connect connector D13806 to the NGS controller.
- (3) Do this check of the wiring:
 - (a) Disconnect connector D40426P from the E3-2 shelf.
 - (b) Do a check for wire W0321-0499-20 from pin 15 of D40426J and wire splice SM48.
 - (c) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D40426P to the E3-2 shelf.
 - 3) Do the Repair Confirmation at the end of this task.
 - (d) If there is continuity between each pin, then do these steps.
 - 1) Re-connect connector D40426P to the E3-2 shelf.
 - 2) Re-connect connector D13806 to the NGS controller.

G. Repair Confirmation

- (1) Do the electrical test in this task: Ground Operation of the Nitrogen Generation System, AMM TASK 47-00-00-800-801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the fault.

------ END OF TASK ------

828. NGS BITE Message AFT CGO FIRE SIG FAIL ON - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30044 AFT CGO FIRE SIG FAIL ON
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) AFT CGO FIRE SIG FAIL ON shows on the display when the NGS controller senses that the aft cargo fire signal is in the incorrect ON state.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Main deck fire signal system
- (2) Airplane wiring.

47-31 TASKS 827-828



C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) WDM 21-31-23
- (2) WDM 26-11-21
- (3) WDM 26-16-21
- (4) WDM 47-30-11

E. Initial Evaluation

- (1) Do the electrical test in this task: Ground Operation of the Nitrogen Generation System, AMM TASK 47-00-00-800-801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message, AFT CGO FIRE SIG FAIL ON 47-30044 shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the cargo electronic unit:
 - (a) Do the cargo electronic unit BITE task.

(Cargo Electronic Unit (CEU) BITE Procedure, 26-16 TASK 801)

- (b) If the test fails then do the applicable fault isolation procedure.
 - Repair the problems that you find.
 - a) Make sure that the BITE messages related to the aft cargo fire signal system are corrected.
 - 2) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (c) If the test passes, then continue.
- (2) Do this check of the wiring:
 - (a) Disconnect connector D13806 from the NGS controller, M02559.
 - (b) Disconnect connector D40426P from the E3-2 shelf.
 - (c) Do a check for an open circuit between these pins:

D13806 D40426P Pin 27 Pin 15

47-31 TASK 828

Page 258 Oct 15/2024



- (d) If there is an open circuit, then do these steps:
 - Repair the wiring.
 - 2) Re-connect connector D40426P to the E3-2 shelf.
 - 3) Re-connect connector D13806 to the NGS controller.
 - 4) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
- (e) If there is continuity between each pin, then do these steps and continue:
 - 1) Re-connect connector D40426P to the E3-2 shelf.
 - 2) Re-connect connector D13806 to the NGS controller.
- (3) Do this check of the wiring:
 - (a) Disconnect connector D40426J from the E3-2 shelf.
 - (b) Do a check for wire W0321-0499-20 from pin 15 of D40426J and wire splice SM48.
 - (c) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D40426P to the E3-2 shelf.
 - 3) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
 - (d) If there is continuity between each pin, then do these steps and continue:
 - 1) Re-connect connector D40426P to the E3-2 shelf.
 - 2) Re-connect connector D13806 to the NGS controller.

G. Repair Confirmation

- (1) Do the electrical test in this task: Ground Operation of the Nitrogen Generation System, AMM TASK 47-00-00-800-801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU display, then you corrected the fault.



829. NGS BITE Message FD SMK EVAC SIG1 FAIL ON - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30045 FD SMK EVAC SIG1 FAIL ON
- (2) The Operability Indicator shows DEGRADED (Blue Light). The NGS is operating below normal.
- (3) FD SMK EVAC SIG1 FAIL ON shows on the display when the NGS Controller finds that the Forward Smoke Evacuation Signal is in the incorrect ON condition.
- (4) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- Flight Deck Smoke Evacuation System
- (2) Airplane wiring

47-31 TASKS 828-829



C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) WDM 21-43-21
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault
 - (b) If the fault message, 47-30045 FD SMK EVAC SIG1 FAIL ON shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- Do a check of the Overboard Evacuation Valve.
 - (a) If the Overboard Evacuation Valve is in the SMOKE position, then do this task: Equipment Cooling Overboard Exhaust Valve - Functional Test, AMM TASK 21-27-00-700-803.
 - (b) If the test fails, then do the applicable Fault Isolation Procedure.
- Do the Repair Confirmation at the end of this task.
 - (a) If the Repair Confirmation is not satisfactory, then continue.
- (3) Make sure that the Overboard Evacuation Valve is in the NORMAL position.
- (4) Do these steps to do a check for a short to ground between the NGS Controller and the Overboard Exhaust Valve Relay:
 - (a) Open these circuit breakers and install safety tags:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



- (b) Disconnect the electrical connector D13806 at the NGS Controller.
- Disconnect the electrical connector D11880 at the Overboard Exhaust Valve (V157).
- Do a check of the wire from connector D13806 pin 41 to the airplane structure.

NOTE: If pin 41 and the airplane structure are connected, then there is a short circuit to ground.

- Repair the problems that you find. 1)
- (e) Connect the connectors D13806 and D11880.
- (5) Remove the safety tags and close these circuit breakers:

CAPT Electrical System Panel, P18-3

Row <u>Col</u> Number

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D C01657 NITROGEN GEN CONT 17

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

NITROGEN GENERATION CONTROL 17 C01657

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

C01680 NGS ALT PWR

G. Repair Confirmation

- (1) Do the Electrical Test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the BDU Display, then you corrected the fault.

– END OF TASK –

830. NGS BITE Message ENG1 SIG FAIL - Fault Isolation

Description

- This task is for fault 47-30050.
- The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- ENG1 SIG FAIL shows on the display when the NGS controller detects an incorrect engine 1 running relay open circuit.

Possible Causes

- Engine 1 Running Relay (R564)
- (2) Airplane wiring

C. Circuit Breakers

These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	1	C00458	ENGINE 1 IGNITION RIGHT
Α	3	C00153	ENGINE 1 IGNITION LEFT
В	3	C01312	ENGINE 1 RUN/PWR

47-31 TASKS 829-830



CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11
- (3) SSM 73-22-31
- (4) WDM 73-22-31

E. Initial Evaluation

- Do the electrical test (47-31 TASK 801).
- (2) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent problem.
- (3) If the fault message, ENG1 SIG FAIL 47-30050 shows, then continue:
 - (a) Do these steps to simulate the engine running:
 - 1) Make sure that there is no pneumatic power to the engine starters.
 - Do this task: Remove Pressure from the Pneumatic System, AMM TASK 36-00-00-860-806.
 - 2) Open these circuit breakers and install safety tags:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	1	C00458	ENGINE 1 IGNITION RIGHT
Α	3	C00153	ENGINE 1 IGNITION LEFT

F/O Electrical System Panel, P6-1

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-3

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	4	C00359	FUEL SPAR VALVE ENG 1

- Make sure that the ENGINE START 1 switch, on the P5 panel, is in the OFF position.
- 4) Set the engine 1 start lever, on the Control Stand, to the IDLE position.



a) Wait a minimum of 5 minutes before proceeding.

<u>NOTE</u>: The engine running controls and relays require 5 minutes to change state.

- (b) Make sure that the fire handles are in the NORMAL position.
- (c) Navigate to the DISCRETE INPUTS? menu on the BDU:
 - 1) Push the ON/OFF pushbutton.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- 2) Select the OTHER FUNCTION? menu.
 - a) Push the (\uparrow) up or (\downarrow) down arrow pushbutton or the NO pushbutton until OTHER FUNCTIONS? shows.
 - b) Push the YES pushbutton.
- 3) Select the I/O MONITOR? menu.
 - a) Push the (↑) up or (↓) down arrow pushbutton or the NO pushbutton until I/O MONITOR? shows.
 - b) Push the YES pushbutton.
- 4) Select the DISCRETE INPUTS? menu.
 - a) Push the (↑) up or (↓) down arrow pushbutton until ENGINE 1 SIG: XXX shows on the display.
- If the message ENGINE 1 SIG: ON shows, there was an intermittent problem and continue.
- If the message ENGINE 1 SIG: OFF shows, then do the Fault Isolation Procedure below.
- (d) Do these steps to return the engine running relays back to the not running condition:
 - 1) Set the engine 1 start lever to the CUTOFF position.
 - 2) Remove the safety tags and close these circuit breakers:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	1	C00458	ENGINE 1 IGNITION RIGHT
Α	3	C00153	ENGINE 1 IGNITION LEFT

F/O Electrical System Panel, P6-1

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-3

Row	Col	<u>Number</u>	<u>Name</u>
В	4	C00359	FUEL SPAR VALVE ENG 1

F. Fault Isolation Procedure

(1) Do these steps to replace the Engine 1 Running Relay, R564:

NOTE: Engine 1 running relay is in junction box, J22.



(a) Open these circuit breakers and install safety tags:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	1	C00458	ENGINE 1 IGNITION RIGHT
Α	3	C00153	ENGINE 1 IGNITION LEFT
В	3	C01312	ENGINE 1 RUN/PWR

- (b) Replace the Engine 1 Running Relay, R564 (WDM 47-30-11).
- (c) Remove the safety tags and close these circuit breakers:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	1	C00458	ENGINE 1 IGNITION RIGHT
Α	3	C00153	ENGINE 1 IGNITION LEFT
В	3	C01312	ENGINE 1 RUN/PWR

- (d) Do the Repair Confirmation at the end of this task.
 - 1) If the Repair Confirmation is not satisfactory, then continue.
- (2) Do this check of the wiring:
 - (a) Set the engine 1 start lever, on the Control Stand, to the CUTOFF position.
 - (b) Open these circuit breakers and install safety tags:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	3	C01312	ENGINE 1 RUN/PWR

CAPT Electrical System Panel, P18-3

Row	Col	Number	Name
-----	-----	--------	------

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

- (c) Disconnect the connector, D13806, from the NGS Controller, M2559.
- (d) Disconnect the connector, D10918, from the Engine 1 Running Relay, R564.
- (e) Do a continuity check from the NGS Controller connector D13806, to the panel connector D10918: pin 52 to pin D1 (WDM 47-30-11).
- (f) If there is an open circuit, then do these steps:
 - Repair the wiring.
 - 2) Re-connect the connector, D10918, to the Engine 1 Running Relay, R564.
 - 3) Re-connect the connector, D13806, to the NGS Controller, M2559.
- (g) If there is continuity between pin 52 and pin D1, then continue.
 - 1) Re-connect the connector, D10918, to the Engine 1 Running Relay, R564.

SHZ 801-825, 827-847, 850-852, 855-859, 876-899.

901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



- 2) Re-connect the connector, D13806, to the NGS Controller, M2559.
- (3) Remove the safety tags and close these circuit breakers:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	3	C01312	ENGINE 1 RUN/PWR

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

(4) Set the engine 1 start lever to the IDLE position.

NOTE: You must wait five minutes or more for the engine running controls and relays to change state.

G. Repair Confirmation

- (1) Do these steps to simulate the engine running:
 - (a) Make sure that there is no pneumatic power to the engine starters.
 - 1) Do this task: (Remove Pressure from the Pneumatic System, AMM TASK 36-00-00-860-806)
 - (b) Open these circuit breakers and install safety tags:

CAPT Electrical System Panel, P18-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	1	C00458	ENGINE 1 IGNITION RIGHT
Α	3	C00153	ENGINE 1 IGNITION LEFT

F/O Electrical System Panel, P6-1

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-3

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	4	C00359	FUEL SPAR VALVE ENG 1

- (c) Make sure that the ENGINE START 1 switch, on the P5 panel, is in the OFF position.
- (d) Set the engine 1 start lever, on the Control Stand, to the IDLE position.
 - 1) Wait a minimum of 5 minutes before proceeding.

NOTE: The engine running controls and relays require 5 minutes to change state.

- (2) Make sure that the fire handles are in the NORMAL position.
- (3) Navigate to the DISCRETE INPUTS? menu on the BDU:



(a) Push the ON/OFF pushbutton.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (b) Select the OTHER FUNCTION? menu.
 - Push the (↑) up or (↓) down arrow pushbutton or the NO pushbutton until OTHER FUNCTIONS? shows.
 - 2) Push the YES pushbutton.
- (c) Select the I/O MONITOR? menu.
 - Push the (↑) up or (↓) down arrow pushbutton or the NO pushbutton until I/O MONITOR? shows.
 - 2) Push the YES pushbutton.
- (d) Select the DISCRETE INPUTS? menu.
 - 1) Push the (↑) up or (↓) down arrow pushbutton until ENGINE 1 SIG: XXX shows on the display.
- (e) If message ENGINE 1 SIG: ON shows, then you corrected the fault.
- (4) Do these steps to return the engine running relays back to the not running condition:
 - (a) Set the engine 1 start lever to the CUTOFF position.
 - (b) Remove the safety tags and close these circuit breakers:

CAPT Electrical System Panel, P18-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	1	C00458	ENGINE 1 IGNITION RIGHT
Α	3	C00153	ENGINE 1 IGNITION LEFT

F/O Electrical System Panel, P6-1

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	4	C00359	FUEL SPAR VALVE ENG 1

------ END OF TASK ------

831. NGS BITE Message ENG2 SIG FAIL - Fault Isolation

A. Description

- This task is for fault 47-30051.
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) ENG2 SIG FAIL shows on the display when the NGS controller detects an incorrect engine 2 running relay open circuit.

B. Possible Causes

- (1) Engine 2 running relay (R563)
- (2) Airplane wiring

47-31 TASKS 830-831



C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	5	C01313	ENGINE 2 RUN/PWR
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	6	C00151	ENGINE 2 IGNITION LEFT

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11
- (3) SSM 73-22-31
- (4) WDM 73-22-31

E. Initial Evaluation

- Do the electrical test (47-31 TASK 801).
- (2) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent problem.
- (3) If the fault message, ENG2 SIG FAIL 47-30051 shows, then continue:
 - (a) Do these steps to simulate the engine running:
 - 1) Make sure that there is no pneumatic power to the engine starters.
 - Do this task: Remove Pressure from the Pneumatic System, AMM TASK 36-00-00-860-806
 - 2) Open these circuit breakers and install safety tags:

F/O Electrical System Panel. P6-1

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	6	C00151	ENGINE 2 IGNITION LEFT

EFFECTIVITY ————

47-31 TASK 831

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	3	C00360	FUEL SPAR VALVE ENG 2

- 3) Make sure that the ENGINE START 2 switch, on the P5 panel, is in the OFF position.
- 4) Set the engine 2 start lever, on the Control Stand, to the IDLE position.
 - a) Wait a minimum of 5 minutes before proceeding.

NOTE: The engine running controls and relays require 5 minutes to change state.

- (b) Make sure that the fire handles are in the NORMAL position.
- (c) Navigate to the DISCRETE INPUTS? menu on the BDU:
 - 1) Push the ON/OFF pushbutton.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- 2) Select the OTHER FUNCTION? menu.
 - a) Push the (\uparrow) up or (\downarrow) down arrow pushbutton or the NO pushbutton until OTHER FUNCTIONS? shows.
 - b) Push the YES pushbutton.
- 3) Select the I/O MONITOR? menu.
 - a) Push the (↑) up or (↓) down arrow pushbutton or the NO pushbutton until I/O MONITOR? shows.
 - b) Push the YES pushbutton.
- 4) Select the DISCRETE INPUTS? menu.
 - a) Push the (↑) up or (↓) down arrow pushbutton until ENGINE 2 SIG: XXX shows on the display.
- If the message ENGINE 2 SIG: ON shows, there was an intermittent problem and continue.
- If the message ENGINE 2 SIG: OFF shows, then do the Fault Isolation Procedure below.
- (d) Do these steps to return the engine running relays back to the not running condition:
 - 1) Set the engine 2 start lever to the CUTOFF position.
 - Remove the safety tags and close these circuit breakers:

F/O Electrical System Panel, P6-1

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	6	C00151	ENGINE 2 IGNITION LEFT



F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	3	C00360	FUEL SPAR VALVE ENG 2

F. Fault Isolation Procedure

(1) Do these steps to replace the Engine 2 Running Relay, R563:

NOTE: Engine 2 running relay is in junction box, J24.

(a) Open these circuit breakers and install safety tags:

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	5	C01313	ENGINE 2 RUN/PWR
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	6	C00151	ENGINE 2 IGNITION LEFT

- (b) Replace the Engine 2 Running Relay, R563 (WDM 47-30-11).
- (c) Remove the safety tags and close these circuit breakers:

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	5	C01313	ENGINE 2 RUN/PWR
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	6	C00151	ENGINE 2 IGNITION LEFT

- (d) Do the Repair Confirmation at the end of this task.
 - 1) If the Repair Confirmation is not satisfactory, then continue.
- (2) Do this check of the wiring:
 - (a) Set the engine 2 start lever, on the Control Stand, to the CUTOFF position.
 - (b) Open these circuit breakers and install safety tags:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	5	C01313	ENGINE 2 RUN/PWR

- (c) Disconnect the connector, D13806, from the NGS controller, M2559.
- (d) Disconnect the connector, D10916, from the Engine 2 Running Relay, R563.

EFFECTIVITY —

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



- (e) Do a continuity check from the NGS Controller connector D13806, to the panel connector D10916: pin 16 to pin D1 (WDM 47-30-11).
- (f) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect the connector, D10916, to the Engine 2 Running Relay, R563.
 - 3) Re-connect the connector, D13806, to the NGS Controller, M2559.
- (g) If there is continuity between pin 16 and pin D1, then continue.
 - 1) Re-connect the connector, D10916, to the Engine 2 Running Relay, R563.
 - 2) Re-connect the connector, D13806, to the NGS Controller, M2559.
- (3) Remove the safety tags and close these circuit breakers:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	5	C01313	ENGINE 2 RUN/PWR

(4) Set the engine 2 start lever to the IDLE position.

<u>NOTE</u>: You must wait five minutes or more for the engine running controls and relays to change state.

G. Repair Confirmation

- (1) Do these steps to simulate the engine running:
 - (a) Make sure that there is no pneumatic power to the engine starters.
 - Do this task: Remove Pressure from the Pneumatic System, AMM TASK 36-00-00-860-806
 - (b) Open these circuit breakers and install safety tags:

F/O Electrical System Panel, P6-1

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-2

<u>Row</u>	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	6	C00151	ENGINE 2 IGNITION LEFT

EFFECTIVITY _____



F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	3	C00360	FUEL SPAR VALVE ENG 2

- (c) Make sure that the ENGINE START 2 switch, on the P5 panel, is in the OFF position.
- (d) Set the engine 2 start lever, on the Control Stand, to the IDLE position.
 - Wait a minimum of 5 minutes before proceeding.
 NOTE: The engine running controls and relays require 5 minutes to change state.
- (2) Make sure that the fire handles are in the NORMAL position.
- (3) Navigate to the DISCRETE INPUTS? menu on the BDU:
 - (a) Push the ON/OFF pushbutton.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (b) Select the OTHER FUNCTION? menu.
 - Push the (↑) up or (↓) down arrow pushbutton or the NO pushbutton until OTHER FUNCTIONS? shows.
 - 2) Push the YES pushbutton.
- (c) Select the I/O MONITOR? menu.
 - Push the (↑) up or (↓) down arrow pushbutton or the NO pushbutton until I/O MONITOR? shows.
 - 2) Push the YES pushbutton.
- (d) Select the DISCRETE INPUTS? menu.
 - Push the (↑) up or (↓) down arrow pushbutton until ENGINE 2 SIG: XXX shows on the display.
- (e) If message ENGINE 2 SIG: ON shows, then you corrected the fault.
- (4) Do these steps to return the engine running relays back to the not running condition:
 - (a) Set the engine 2 start lever to the CUTOFF position.
 - (b) Remove the safety tags and close these circuit breakers:

F/O Electrical System Panel, P6-1

Row	<u>Col</u>	Number	<u>Name</u>
D	13	C00120	WEATHER RADAR RT

F/O Electrical System Panel, P6-2

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
D	4	C00459	ENGINE 2 IGNITION RIGHT
D	6	C00151	ENGINE 2 IGNITION LEFT

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
В	3	C00360	FUEL SPAR VALVE ENG 2

------ END OF TASK ------



832. NGS BITE Message PACK SIG FAIL OFF - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30054 PACK SIG FAIL OFF
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) PACK SIG FAIL OFF shows on the display when the controller finds that the PACK signal is failed OFF.
- (4) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Air conditioning pack signal
- (2) Airplane wiring.

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

F/O Electrical System Panel, P6-4

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
С	6	C00262	AIR CONDITIONING PACK CONT VALVES L

D. Related Data

- (1) WDM 21-51-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
- If the fault message PACK SIG FAIL OFF 47-30054 shows, then do these steps:
 - (a) Put the L PACK switch on the P-5 panel to the HIGH or AUTO position.
 - Make sure that the R PACK switch is OFF.
 - (b) Navigate to the DISCRETE INPUTS? menu on the BDU:
 - 1) Push the ON/OFF pushbutton.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- 2) Select the OTHER FUNCTIONS? menu.
 - a) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.

— EFFECTIVITY —

47-31 TASK 832

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



- b) Push the YES pushbutton.
- 3) Select the I/O MONITOR? menu.
 - a) Push the up or down arrow pushbutton until I/O MONITOR? shows.
 - b) Push the YES pushbutton.
- 4) Select the DISCRETE INPUTS? menu.
 - a) Push the up or down arrow pushbutton until PACK SIG 1: shows on the display.
- (c) If the message PACK SIG 1: ON shows, there was an intermittent problem.
- (d) If the message PACK SIG 1: OFF shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check of the left pack flow control and shutoff valve:
 - (a) Do this task: Pack Flow Control Valve Operational Test, AMM TASK 21-51-00-700-802 or Pack Flow Control Valve Operational Test, AMM TASK 21-51-00-710-801.
 - (b) If a FAIL indication for the pack flow control valve operational test shows, then do these steps:
 - 1) Do the applicable fault isolation procedures.
 - 2) Repair the problems that you find.
 - 3) Do the Repair Confirmation at the end of this task.
 - a) If the Repair Confirmation is not satisfactory, then continue.
 - (c) If the FAIL indication does not show, then continue.
- (2) Do these steps to do a check of the airplane wiring:
 - (a) Open these circuit breakers and install safety tags:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

F/O Electrical System Panel, P6-4

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
С	6	C00262	AIR CONDITIONING PACK CONT VALVES I

- (b) Disconnect the connector D13806 from the NGS controller.
- (c) Disconnect the connector D458B from the air conditioning relay 1 (M00324).
- (d) Do a check of the wiring between connector D13806 pin 23 and connector D458B, pin 43.
- (e) Repair the problems that you find.
- (f) Connect the connector D13806 to the NGS controller.

EFFECTIVITY

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



- (g) Connect the connector D458B to the air conditioning relay 1.
- (3) Remove the safety tags and close these circuit breakers:

CAPT Electrical System Panel, P18-3

Number Row Col **Name**

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

C01680 NGS ALT PWR

F/O Electrical System Panel, P6-4

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
С	6	C00262	AIR CONDITIONING PACK CONT VALVES L

Repair Confirmation

- Navigate to the I/O Monitor DISCRETE/ inputs screen on the BDU.
 - (a) Push the ON/OFF pushbutton.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (b) Select the OTHER FUNCTIONS? menu.
 - 1) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.
 - 2) Push the YES pushbutton.
- (c) Select the I/O MONITOR? menu.
 - 1) Push the up or down arrow pushbutton until I/O MONITOR? shows.
 - 2) Push the YES pushbutton.
- (d) Select the DISCRETE INPUTS? menu.
 - 1) Push the up or down arrow pushbutton until PACK SIG 1: shows on the display.
- (e) Push the up or down arrow until PACK SIG 1: XXX shows on the display.
 - If PACK SIG 1: ON shows on the display, then you repaired the problem.

– END OF TASK –

833. NGS BITE Message AIRCRAFT ID INVALID - Fault Isolation

Description

- (1) This task is for fault message:
 - (a) 47-30056 AIRCRAFT ID INVALID
- The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- AIRCRAFT ID INVALID shows on the display when the NGS controller detects an incorrect aircraft ID signal.
- To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

47-31 TASKS 832-833

EFFECTIVITY SHZ 801-825, 827-847, 850-852, 855-859, 876-899 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

Page 274 Oct 15/2024



- B. Possible Causes
 - (1) Airplane wiring
 - (2) NGS Controller, M02559
- C. Circuit Breakers
 - (1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

- D. Related Data
 - (1) WDM 47-30-11
- E. Initial Evaluation
 - (1) Open and close these circuit breakers:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

(2) Push the ON/OFF pushbutton on the BDU.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (3) Select the EXISING FAULTS? menu.
 - (a) Push the up or down arrow pushbutton until EXISTING FAULTS? shows.
 - (b) Push the YES button.
- (4) If the fault message AIRCRAFT ID INVALID 47-30056 does not show, then there was an intermittent fault.
- (5) If the fault message AIRCRAFT ID INVALID 47-30056 shows, then do these steps:
 - (a) Push the ON/OFF pushbutton on the BDU.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (b) Select the OTHER FUNCTION? menu.
 - 1) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.



- 2) Push the YES pushbutton.
- (c) Select the SYSTEM CONFIG? menu.
 - Push the up or down arrow pushbutton until SYSTEM CONFIG? shows.
 - 2) Push the YES pushbutton.
- (d) Select AIRCRAFT ID:
- (e) If the message AIRCRAFT ID: 737 shows, there was an intermittent problem.
- (f) If the message AIRCRAFT ID: NOT ENABLED shows, then do the Fault Isolation Procedure below.
- (g) If the message AIRCRAFT ID: UNDEFINED shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

Replace the NGS controller, M02559.

(Nitrogen Generation System Controller Removal, AMM TASK 47-31-01-000-801) (Nitrogen Generation System Controller Installation, AMM TASK 47-31-01-400-801)

- (2) Do the Repair Confirmation at the end of this task.
 - (a) If the Repair Confirmation is not satisfactory, then continue.
- (3) Do this check of the wiring:
 - (a) Disconnect connector D13804 from the NGS controller, M02559.
 - (b) Do a check for an open circuit between these pins:

D13804	D13804
pin 30	pin 47
pin 29	pin 47
pin 46	pin 47

- (c) If there is an open circuit, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-connect connector D13804 to the NGS controller.
 - 3) Do the Repair Confirmation at the end of this task.
- (d) If there is continuity between pin 47 of D13804 and pins 29, 30, 46 of D13804, then do this step:
 - 1) Re-connect connector D11740 to the NGS controller.

G. Repair Confirmation

(1) Open and close these circuit breakers:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



SHZ 802-825, 827-847, 850-852, 855-859, 880-899 (Continued)

(Continued)

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

(2) Push the ON/OFF pushbutton on the BDU.

NOTE: The BDU automatically shutdowns after five minutes of inactivity.

- (3) Select the OTHER FUNCTION? menu.
 - (a) Push the up or down arrow pushbutton until OTHER FUNCTIONS? shows.
 - (b) Push the YES pushbutton.
- (4) Select the SYSTEM CONFIG? menu.
 - (a) Push the up or down arrow pushbutton until SYSTEM CONFIG? shows.
 - (b) Push the YES pushbutton.
- (5) Select AIRCRAFT ID:
- (6) If the message AIRCRAFT ID: 737 shows, then you corrected the fault.

----- END OF TASK -----

834. NGS BITE Message REFUEL SIG1 FAIL OPEN - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30059 REFUEL SIG1 FAIL OPEN
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) REFUEL SIG1 FAIL OPEN 47-30059 shows on the display when the controller senses that the Center Tank Refuel Valve is in the incorrect open position.

B. Possible Causes

- NGS Center Tank Refuel Valve Relay, R951
- Refuel Power Control Switch, S156
- (3) Wiring

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

EFFECTIVITY —

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASKS 833-834



SHZ 802-825, 827-847, 850-852, 855-859, 880-899 (Continued)

(Continued)

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	3	C00032	FUEL FUELING CONT

D. Related Data

- (1) WDM 28-44-11
- (2) WDM 47-30-11
- (3) SSM 28-44-11
- (4) SSM 47-30-11

E. Initial Evaluation

(1) Push the ON/OFF Push-Button on the BDU.

NOTE: The BDU automatically shuts down after five minutes of inactivity.

- (2) Select the EXISTING FAULTS? Menu.
 - (a) Push the up or down Arrow Push-Button until EXISTING FAULTS? shows.
 - (b) Push the YES Push-Button.
- (3) If the fault message REFUEL SIG1 FAIL 47-30059 does not show, then there was an intermittent fault.
 - l) If the fault message REFUEL SIG1 FAIL 47-30059 shows, then do these steps:
 - (a) Open this circuit breaker and install safety tag:

F/O Electrical System Panel, P6-3

Row	Col	<u>Number</u>	<u>Name</u>
Α	3	C00032	FUEL FUELING CONT

- (b) Push the ON/OFF Push-Button.
- (c) Select the OTHER FUNCTION? Menu.
 - 1) Push the up or down Arrow Push-Button until OTHER FUNCTIONS? shows.
 - 2) Push the YES Push-Button.
- (d) Select the I/O MONITOR? Menu.
 - 1) Push the up or down Arrow Push-Button until I/O MONITOR? shows.
 - Push the YES Push-Button.
- (e) Select the DISCRETE INPUTS OR ARINC INPUTS? Menu.
 - Push the up or down Arrow Push-Button until DISCRETE INPUTS OR ARINC INPUTS? shows.
 - 2) Push the YES Push-Button.

____ 47-31 TASK 834

EFFECTIVITY



- (f) Select the REFUEL VLV SIG1:
 - 1) If the message REFUEL VLV SIG1: VALVE CLOSED shows, there was an intermittent problem.
 - 2) If the message REFUEL VLV SIG1: VALVE OPEN shows, then do the Fault Isolation Procedure below.
- (5) Remove the safety tag and close this circuit breaker:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	3	C00032	FUEL FUELING CONT

F. Fault Isolation Procedure

- Do a check of the NGS Center Tank Refuel Valve Relay, R951 in the Junction Box, J20 (WDM 28-44-11, WDM 47-30-11).
 - (a) If you find a problem with the relay, then do these steps:
 - 1) Replace the NGS Center Tank Refuel Valve Relay, R951.
 - 2) Do the Repair Confirmation at the end of this task.
 - (b) If you do not find a problem with the relay, then continue.
- (2) Do this check of the wiring (WDM 47-30-11):
 - (a) Disconnect connector D13806 from the NGS Controller, M2559.
 - (b) Remove the NGS Center Tank Refuel Valve Relay, R951.
 - (c) Do a wiring check as follows:

CTR TANK	NGS
REFUEL VALVE	CONTROLLER,
RLY, R951	M2559
D13842	D13806
pin 2	pin 33
D13842	

..... GD3704-DC

- 1) If you find a problem with the wiring, then do these steps:
 - a) Repair the wiring.
 - b) Re-connect connector D13806 to the NGS Controller, M2559.
 - c) Re-install the NGS Center Tank Refuel Valve Relay, R951.
 - d) Do the Repair Confirmation at the end of this task.
- If you do not find a problem with the wiring, then do these steps and continue:
 - a) Re-connect connector D13806 to the NGS Controller, M2559.
 - b) Re-install the NGS Center Tank Refuel Valve Relay, R951.
- (3) Replace the Refuel Power Control Switch, S156. These are the tasks:
 - Fueling Power Control Switch Sensor Magnet Removal, AMM TASK 28-21-81-000-801
 - Fueling Power Control Switch Sensor Magnet Installation, AMM TASK 28-21-81-400-801

47-31 TASK 834

pin 5



- Actuator Switch for the Fueling Power Control Switch Removal, AMM TASK 28-21-81-350-801
- Actuator Switch for the Fueling Power Control Switch Installation, AMM TASK 28-21-81-350-802
- (a) Do the Repair Confirmation at the end of this task.

G. Repair Confirmation

(1) Open this circuit breaker and install safety tag:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	3	C00032	FUEL FUELING CONT

(2) Push the ON/OFF Push-Button on the BDU.

NOTE: The BDU automatically shuts down after five minutes of inactivity.

- (3) Select the OTHER FUNCTION? Menu.
 - (a) Push the up or down Arrow Push-Button until OTHER FUNCTIONS? shows.
 - (b) Push the YES Push-Button.
- (4) Select the I/O MONITOR? Menu.
 - (a) Push the up or down Arrow Push-Button until I/O MONITOR? shows.
 - (b) Push the YES Push-Button.
- (5) Select the DISCRETE INPUTS OR ARINC INPUTS? Menu.
 - (a) Push the up or down Arrow Push-Button until DISCRETE INPUTS OR ARINC INPUTS? shows.
 - (b) Push the YES Push-Button.
- (6) Select the REFUEL VLV SIG1:
 - (a) If the message REFUEL VLV SIG1: VALVE CLOSED shows, then you corrected the problem.
 - (b) If the message REFUEL VLV SIG1: VALVE OPEN shows, then continue the Fault Isolation Procedure at the subsequent step.
- (7) Remove the safety tag and close this circuit breaker:

F/O Electrical System Panel, P6-3

Row	<u>Col</u>	<u>Number</u>	<u>Name</u>
Α	3	C00032	FUEL FUELING CONT

——— END OF TASK ———

837. NGS BITE Message HFV FAIL CLOSED - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30031 HFV FAIL CLOSED
- (2) The BDU display shows HFV FAIL CLOSED fault message when the NGS Controller finds that the hardware for the ASM High Flow Valve is failed in the closed position.

I D633A103-SHZ

(3) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803

- EFFECTIVITY

47-31 TASKS 834-837

Page 280 Oct 15/2024



B. Possible Causes

(1) High Flow Valve (V00174)

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- (1) Do the SYSTEM TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
- (2) If the BDU message SYSTEM TEST PASS shows, then there was an intermittent fault.
- (3) If the fault message 47–30031 HFV FAIL CLOSED shows, then do the Fault Isolation Procedure.

F. Fault Isolation Procedure

(1) Do the SYSTEM TEST in this task: NGS BITE - Procedure, 47-31 TASK 801.

NOTE: The system test operates for 4 minutes.

- (a) While the SYSTEM TEST operates, have a person monitor the position indicator on the High Flow Valve.
 - 1) Make sure that the High Flow Valve opens, then closes, during the SYSTEM TEST.
 - If the High Flow Valve opens, then closes, during the SYSTEM TEST, the valve is serviceable.
 - 3) If the High Flow Valve does not open during the SYSTEM TEST, then continue.
- Disconnect connector D13820 from the ASM High Flow Valve, V00174.
- (3) Do the 28VDC check that follows in the related wiring of the ASM High Flow Valve:

 ASM HIGH
 ASM HIGH

 FLOW VALVE
 FLOW VALVE

 D13820
 D13820

 pin 1
 pin 3

- (4) Disconnect connector D13806 from the NGS Controller, M02559.
- (5) Do the continuity check that follows in the related wiring between the ASM High Flow Valve and the NGS Controller:

EFFECTIVITY

47-31 TASK 837

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



ASM HIGH NGS

FLOW VALVE CONTROLLER

D13820 D13806 pin 2 pin 14

- (a) If you find problems with the wiring, repair as necessary.
 - 1) Re-connect connector D13820 to the ASM High Flow Valve.
 - 2) Re-connect connector D13806 to the NGS Controller.
 - 3) Do the Repair Confirmation at the end of this task.
- (b) If the wiring is OK, then continue.
- (6) Replace the High Flow Valve, V00174. These are the tasks:
 - High Flow Valve Removal, AMM TASK 47-11-02-000-801
 - High Flow Valve Installation, AMM TASK 47-11-02-420-801
 - (a) Do the Repair Confirmation below.

G. Repair Confirmation

- (1) Do the SYSTEM TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the SYSTEM TEST PASS shows on the display, then you corrected the fault.



838. NGS BITE Message NGS OXYGEN SENS FAIL - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30062 NGS OXYGEN SENS FAIL
- (2) The Operability Indicator shows DEGRADED (Blue Light).
 - (a) The NGS is operating below normal.
- (3) NGS OXYGEN SENS FAIL shows when the controller finds an open or short circuit condition for the NGS Oxygen Sensor, M2692.
- (4) NGS OXYGEN SENS FAIL shows when there is fuel contamination.
- (5) To find more data about this fault message, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) Primary Backflow Prevention Check Valve
- (2) Secondary Backflow Prevention Check Valve
- (3) NGS Oxygen Sensor, M2692
- (4) NGS Wiring

47-31 TASKS 837-838



C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) WDM 47-30-11
- (2) SSM 47-30-11

E. Initial Evaluation

- (1) Do this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If ELECTRICAL TEST PASS and SYSTEM TEST PASS shows on the BDU, then there was an intermittent fault.
 - (b) If the fault message 47-30062 NGS OXYGEN SENSOR ELEC shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do the fuel leak check. This is the task: Drain Cap Fuel Leak Check, AMM TASK 47-21-00-700-802.
 - (a) If the backflow prevention check valves are replaced, do the Repair Confirmation at the end of the task.
 - (b) If you do not find evidence of fuel contamination, then continue.
- Disconnect connector D14200 from the NGS Oxygen Sensor, M2692 (WDM 47-30-11).
- (3) Do a check for 28V DC at pin F of connector D14200.
 - (a) If you find 28V DC, replace the NGS Oxygen Sensor, M02692. These are the tasks:
 - NGS Oxygen Sensor Removal, AMM TASK 47-42-03-020-801
 - NGS Oxygen Sensor Installation, AMM TASK 47-42-03-420-801
 - 1) Do the Repair Confirmation at the end of this task.
 - (b) If you do not find 28V DC at pin F, disconnect connector D40830P at the Load Control Center - Left (LCC-L) Panel, P18 and examine the wiring between the LCC-L and the NGS Oxygen Sensor as follows:

NGS OXYGEN
LCC-L, P18 SNSR
D40830P D14200
pin 13 pin F

EFFECTIVITY



NGS OXYGEN SNSR D14200

pin C GD129-ST

- 1) If you find problems with the wiring, do these steps:
 - a) Repair the wiring.
 - b) Re-connect connector D40830P to the LCC-L Panel, P18.
 - c) Re-connect connector D14200 to the NGS Oxygen Sensor.
 - d) Do the Repair Confirmation at the end of this task.
- 2) If you do not find problems with the wiring, continue.
- (4) Do this wiring check (WDM 47-30-11).
 - (a) Disconnect connector D14200 from the NGS Oxygen Sensor, M2692.
 - (b) Disconnect connectors D13804 and D13806 from the NGS Controller.
 - (c) Examine the wiring between the NGS Oxygen Sensor, M2692 and the NGS Controller, M2559 as follows:

NGS OXYGEN SNSR	NGS CONTROLLER	
D14200 pin E	•	
D14200 pin G	D13806 pin 15	

- 1) If you find problems with the wiring, repair it as necessary.
 - a) Re-connect connector D40830P to the LCC-L Panel, P18.
 - b) Re-connect connector D14200 to the NGS Oxygen Sensor.
 - c) Do the Repair Confirmation at the end of this task.
- (5) If you find problems with the wiring, repair as necessary.
 - (a) Re-connect connector D14200 to the NGS Oxygen Sensor.
 - (b) Re-connect connectors D13804 and D13806 to the NGS Controller.
 - (c) Do the Repair Confirmation at the end of this task.

G. Repair Confirmation

- (1) Do this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If ELECTRICAL TEST PASS and SYSTEM TEST PASS shows on the BDU Display, then you correct the problem.
 - (b) If the 47-30062 NGS OXYGEN SENS FAIL maintenance message still shows, then continue the Fault isolation Procedure at the subsequent step.

----- END OF TASK -----



839. NGS BITE Message NGS ASM FAIL - Fault Isolation

A. Description

- (1) This task is for fault message:
 - (a) 47-30063 NGS ASM FAIL
 - (b) NVM Fault Shop Code 239 or 245.
- (2) The operability indicator shows DEGRADED (blue light). The NGS is operating below normal.
- (3) The fault message, NGS ASM FAIL, shows when the oxygen level is too high or an overtemperature occurs.
- (4) If there is not enough time to complete the ASM performance test on five or more flights in a row, because of short flight lengths, a nuisance fault message, NGS ASM FAIL, can show. The operability indicator shows NGS DEGRADED (blue light).
- (5) To find more data about this fault, do this task: BDU Fault History Menu, AMM TASK 47-31-02-740-803.

B. Possible Causes

- (1) NGS ASM
- (2) NGS Oxygen Sensor, M02692
- (3) Short flight durations (5 or more flights in a row)

C. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

D. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

E. Initial Evaluation

- Review the BDU Fault History Menu, AMM TASK 47-31-02-740-803.
 - (a) If the fault message 47–30063 NGS ASM FAIL and 47–30029 FILTER BLOCKED have occurred within the last 10 flights then the ASM is likely failed.
- (2) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If the fault message 47–30063 NGS ASM FAIL shows, then do the Fault Isolation Procedure.

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003



F. Fault Isolation Procedure

- (1) Do this check of the Air Separation Module:
 - (a) Do this task: Functional Test of the Nitrogen Generation System, AMM TASK 47-00-00-720-801 NGS PERF HI FLOW.
 - 1) If available use both the BDU and oxygen analyzer, COM-7456.
 - 2) If the oxygen analyzer, COM-7456 is not available then use the reading from BDU only.
 - (b) If the NGS inlet pressure/NEA purity data point is in the go-zone area, and the oxygen analyzer is in the go-zone area then the problem is corrected.
 - (c) If the NGS inlet pressure/NEA purity data point is in the no-go-zone area, and the oxygen analyzer is in the go-zone area, replace the oxygen sensor. These are the tasks:
 - NGS Oxygen Sensor Removal, AMM TASK 47-42-03-020-801.
 - NGS Oxygen Sensor Installation, AMM TASK 47-42-03-420-801.
 - (d) If the NGS inlet pressure/NEA purity data point is in the no-go-zone area, and the oxygen analyzer is in the no-go-zone area, replace the ASM. These are the tasks:
 - Air Separation Module (ASM) Removal, AMM TASK 47-11-01-000-801.
 - Air Separation Module (ASM) Installation, AMM TASK 47-11-01-420-801.
 - 1) Do the Repair Confirmation at the end of this task.

G. Repair Confirmation

- (1) Do the ELECTRICAL TEST in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the ELECTRICAL TEST PASS shows on the display, then you corrected the fault.



840. Operability Indicator DEGRADED (Blue) Light is On - Fault Isolation

A. Description

(1) The operability indicator shows DEGRADED (blue light). The nitrogen generation system (NGS) is operating below normal.

B. Circuit Breakers

(1) These are the primary circuit breakers related to the fault:

CAPT Electrical System Panel, P18-3

Row Col Number Name

SHZ 801, 876-879, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

D 17 C01657 NITROGEN GEN CONT

SHZ 802-825, 827-847, 850-852, 855-859, 880-899

D 17 C01657 NITROGEN GENERATION CONTROL

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

E 15 C01680 NGS ALT PWR

C. Related Data

- (1) SSM 47-30-11
- (2) WDM 47-30-11

47-31 TASKS 839-840



D. Initial Evaluation

- (1) Do the electrical test in this task: NGS BITE Procedure, 47-31 TASK 801.
 - (a) If the BDU message ELECTRICAL TEST PASS shows, then there was an intermittent fault.
 - (b) If a fault message shows, do the Fault Isolation procedure for the applicable fault message.

E. Fault Isolation Procedure

(1) No additional maintenance action is necessary.

----- END OF TASK -----



The table below shows maintenance message to NVM Shop Code Cross Reference. Each maintenance message is followed by shop code and description.

Maintenance Message to NVM Shop Code Cross Reference

Maintenance Message	Shop Code	Description
NGSRAV FAIL OPEN 47-30027	4	UNDER TEMP FAULT (RAV failed open for cold side control)
NGS CONTROLLER INOP 47-30002	5	PROGRAM MEMORY FAULT
NGS CONTROLLER INOP 47-30002	6	RAM FAULT
NGS CONTROLLER INOP 47-30002	7	POWER SUPPLY FAULT
NGS CONTROLLER INOP 47-30002	9	FOREGROUND FRAME OVERRUN FAULT
NGS CONTROLLER INOP 47-30002	10	CSCI3 CHECKSUM FAULT
NGS CONTROLLER INOP 47-30002	11	CONFIGURATION FAULT
NGS CONTROLLER INOP 47-30002	12	UNEXPECTED RESET FAULT
NGS CONTROLLER INOP 47-30002	13	WATCHDOG FAULT
NGS CONTROLLER INOP 47-30002	14	BACKGROUND FRAME OVERRUN FAULT
NGSSOV ELEC FAIL 47-30020	15	SOV SOL OPEN/SHORT FAULT
NGS CONTROLLER INOP 47-30002	16	SOV SOL DRIVER FAULT
NGS TEMP SENSOR ELEC 47-30011	17	TASMI 1 OPEN/SHORT FAULT
NGS CONTROLLER 47-30001	18	TASMI 1 IF FAULT
NGS TEMP SENSOR ELEC 47-30011	19	TASMI 2 OPEN/SHORT FAULT
NGS CONTROLLER 47-30001	20	TASMI 2 IF FAULT
NGS TEMP SENSOR DRIFT 47-30012	21	TASMI DRIFT FAULT
NGSRAV ELEC FAIL 47-30026	22	TM1 OPEN/SHORT FAULT
DP SENSOR HI ELEC 47-30013	27	DPHI OPEN/SHORT FAULT

· EFFECTIVITY -

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASK SUPPORT

Page 301 Oct 15/2024



Maintenance Message to NVM Shop Code Cross Reference (Continued)

Maintenance Message	Shop Code	Description
NGS CONTROLLER 47-30001	28	DPHI IF FAULT
DP SENSOR HI DRIFT 47-30014	29	DPHI ZERO PRESSURE FAULT
NGS ALT SENSOR ELEC 47-30017	30	PALT OPEN/SHORT FAULT
NGS CONTROLLER 47-30001	31	PALT IF FAULT
HFV ELEC FAIL 47-30030	32	HFV SOL OPEN/SHORT FAULT
NGS CONTROLLER 47-30001	33	HFV SOL DRIVER FAULT
NGS CONTROLLER INOP 47-30002	36	OTSOV SOL DRIVER FAULT
OTSOV ELEC FAIL 47-30024	37	OTSOV SOL OPEN/SHORT FAULT
NGSSOV FAIL OPEN 47-30021	43	SOV FAILED OPEN FAULT
WOW SIG FAIL IN AIR 47-30040	44	WOW STUCK AIR FAULT
WOW SIG FAIL ON GROUND 47-30041	45	WOW STUCK GROUND FAULT
NGS BLD PRESS SENSOR 47-30010	47	PB OPEN/SHORT FAULT
MN CGO FIRE SIG FAIL ON 47-30043	49	MAIN CARGO FIRE INDICATION ARMED STUCK ARMED FAULT
FD SMK EVAC SIG1 FAIL ON 47-30045	50	FLIGHT DECK SMOKE 1 EVAC STUCK EVAC FAULT
ENG1 SIG FAIL 47-30050	51	ENGINE 1 ON STUCK ON FAULT
PACK SIG FAIL OFF 47-30054	52	PACK OFF STUCK OFF FAULT
NGS CONTROLLER 47-30001	53	NGS INOP LAMP DRIVER FAULT
NGS CONTROLLER 47-30001	59	NVM FAULT
AIRCRAFT ID INVALID 47-30056	60	AIRCRAFT ID FAULT
NGS CONTROLLER 47-30001	61	TEST MODE FAULT
NGS CONTROLLER 47-30001	62	PB IF FAULT
NGS CONTROLLER 47-30001	71	BDU PS DRIVER FAULT
NGS CONTROLLER 47-30001	72	MUX 4 FAULT
NGS CONTROLLER 47-30001	73	MUX 5 FAULT
NGS CONTROLLER INOP 47-30002	74	MUX 6 FAULT
NGS CONTROLLER 47-30001	75	MUX 7 FAULT
NGS CONTROLLER 47-30001	76	MUX 8 FAULT
NGSRAV FAIL CL/HX BLKD 47-30028	77	TM1 FAILED CLOSED FAULT

- EFFECTIVITY -

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASK SUPPORT

Page 302 Oct 15/2024



Maintenance Message to NVM Shop Code Cross Reference (Continued)

Maintenance Message	Shop Code	Description
NGS CONTROLLER 47-30001	78	TM1 DRIVER FAILED TEMP OUT OF RANGE FAULT
OTSOV FAIL OPEN 47-30025	80	OTSOV FAILED OPEN FAULT
HFV FAIL OPEN 47-30032	82	ASM HFV FAILED OPEN FAULT
NGSSOV/OTSOV/HFV CLOSED 47-30023	84	SOV/OTSOV/HFV FAILED CLOSED FAULT
AFT CGO FIRE SIG FAIL ON 47-30044	89	AFT CARGO FIRE INDICATION ARMED STUCK ARMED FAULT
FWD CGO FIRE SIG FAIL ON 47-30042	90	FWD CARGO FIRE INDICATION ARMED STUCK ARMED FAULT
ENG2 SIG FAIL 47-30051	92	ENGINE 2 ON STUCK ON FAULT
FILTER BLOCKED 47-30029	96	FILTER BLOCKAGE FAULT
REFUEL SIG1 FAIL OPEN 47-30059	97	REFUEL 1 INDICATION STUCK OPEN FAULT
NGS CONTROLLER INOP 47-30002	99	EXT_WATCHDOG_FAULT
NGS CONTROLLER 47-30001	100	NGS OPERABLE LAMP DRIVER FAULT
NGS CONTROLLER 47-30001	101	NGS DEGRADED LAMP DRIVER FAULT
ENG1 SIG FAIL 47-30050	104	ENGINE 1 ON STUCK OFF FAULT
ENG2 SIG FAIL 47-30051	105	ENGINE 2 ON STUCK OFF FAULT
NGS CONTROLLER INOP 47-30002	108	NGSC_COMPATIBILITY_FAULT
BLD PRESS SENSOR DRIFT 47-30018	109	PB SHIFT HIGH FAULT
NGS ALT SENSOR DRIFT 47-30019	110	PALT SHIFT FAULT
NGS CONTROLLER 47-30001	230	O2 IF FAULT
NGS CONTROLLER 47-30001	231	PO2 IF FAULT
NGS CONTROLLER 47-30001	232	O2 SENSOR DRIVER FAULT
NGS OXYGEN SENS FAIL 47-30062	233	O2 SENSOR INTERNAL FAULT
NGS OXYGEN SENS FAIL 47-30062	234	O2 SENSOR EXCITATION OPEN/SHORT FAULT
NGS OXYGEN SENS FAIL 47-30062	235	O2 SIGNAL OPEN/SHORT FAULT
NGS OXYGEN SENS FAIL 47-30062	236	PO2 SIGNAL OPEN/SHORT FAULT

EFFECTIVITY -

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASK SUPPORT

Page 303 Oct 15/2024



Maintenance Message to NVM Shop Code Cross Reference (Continued)

Maintenance Message	Shop Code	Description
NGS OXYGEN SENS FAIL 47-30062	237	O2 SENSOR STUCK ON FAULT
NGS OXYGEN SENS FAIL 47-30062	238	O2 SENSOR STUCK WARMING FAULT
NGS ASM FAIL 47-30063	239	ASM PERF FAULT
NGS ASM FAIL 47-30063	245	ASM OVERTEMP FAULT

· EFFECTIVITY -

SHZ 801-825, 827-847, 850-852, 855-859, 876-899, 901-999; SHZ 002, 009-699, 706, 721-799, 860-863, 865, 866, 871-874 POST SB 737-47-1003

47-31 TASK SUPPORT

Page 304 Oct 15/2024