
## ENGINE MOUNTING/DISMOUNTING

id011000507000


### Mounting

1. Install the **SST** (arms) to the four positions as shown in the figure and temporarily tighten the bolts (Part No. **9YA20-1003** or **M10 × 1.5 length 90 mm {3.55 in}**).





bes3ze00000116

2. Install the **SSTs** (bolts and nuts) to the four positions of the **SST** (plate) as shown in the figure.




bes2ze00000111

3. Install the **SST** (bolts, nuts and plate) set in Step 2 to the **SST** (arms) set in Step 1 using the **SSTs** (hook and nuts).
4. Adjust the bolts so that **approx. 20 mm {0.79 in}** of thread is exposed from the side of the plate.
5. Adjust the bolts and nuts so that the plate and arms are parallel.
6. Tighten the **SSTs** (bolts and nuts) to affix the **SST** firmly.
7. Install the engine to the **SST** (engine stand).
8. Remove the oil drain plug and drain the engine oil.
9. Replace the gasket with a new one and install the oil pan drain plug.




bpe2ue00000089

**Tightening torque**
**30—41 N·m {3.1—4.1 kgf·m, 23—30 ft·lbf}**

### Dismounting

1. Dismount in the reverse order of mounting.