
OIL SEAL (PARKING SHIFT LEVER) REPLACEMENT [EW6A-EL/EW6AX-EL]

id05170066051l4

Note
- Perform the following servicing only if the oil seal is replaced due to ATF leakage from the oil seal (parking shift lever).


1. Clean the outside of the transaxle. (See AUTOMATIC TRANSAXLE CLEANING.)
2. Remove the electric AT oil pump using the following procedure (only vehicles with i-stop).

Caution
- **Do not drop or apply an impact to the electric AT oil pump. Replace the electric AT oil pump with a new one if it was dropped or received an impact.**
- **Do not disassemble the electric AT oil pump. Replace the electric AT oil pump if it has been disassembled.**
- **To prevent a malfunction, be careful not to allow sealant or foreign matter to penetrate the electric AT oil pump and the interior of the transaxle.**
- **Be careful not to scratch or damage the aligning surfaces of the electric AT oil pump and end cover and the O-ring assembly area so as not to cause ATF leakage.**



bfw2za00000308


(1) Remove the bolts shown in the figure.




azzjjw00001452

(2) Remove the electric AT oil pump.

Note
- Shake the electric AT oil pump by hand as shown in the figure and remove it.




azzjjw00001453



azzjjw00001454


(3) Remove the O-rings.

1	3 bolts
2	Electric AT oil pump
3	O-ring




bfw2za00000309

3. Remove the stud bolts.



azzjjw00000304

4. Remove the torque converter.



azzjjw00000305

5. Install the transaxle to the SST (engine stand) using the following procedure:


Caution

- **When installing the transaxle to the SST (engine stand) using chain hoists, be careful not to allow the transaxle (oil cooler in particular) to contact the SST (engine stand). If the transaxle contacts the SST, check the areas that made contact and replace damaged parts with new ones.**

(1) Install the SSTs to the transaxle using the following procedure.

Note
- When installing the SST (49 L010 1A0) to the transaxle (stud bolt holes), use part number: 9YA02 1440 or M14×1.5 bolts, length to 100 mm {3.94 in}.
- When installing the SST (49 UN30 3050) to the transaxle, use part number: 9YA02 1015, or M10×1.5 bolts, length to 35 mm {1.4 in}.


1) Temporarily install the arms (49 L010 102) using part number: 9YA02 1440, or M14×1.5 bolts, length to 100 mm {3.94 in}.



bfw2za00000310

Note
- To adjust the installation position of the SST in Step 3), temporarily tighten the bolts.

A : Part number: 9YA02 1440, or M14×1.5 bolt, length to 100 mm {3.94 in}




bfw2za00000311

2) Assemble the SST (49 L010 1A0).

Note
- Use bolts (49 L010 105) with a length of 138 mm {5.43 in}.

A : Washer
B : Approx. 20 mm {0.79 in}
C : Approx. 26 mm {1.0 in}
D : Approx. 47 mm {1.9 in}



bfw2za00000312

3) Install the SST assembled in Step 2).

Note
- Adjust so that the plate (49 L010 101) and arms (49 L010 102) are level, and install.


A : Washer
B : Level out

4) Verify that nothing other than the SST arms (49 L010 102) installation area contacts the transaxle.

Caution
- **If something other than the SST arms (49 L010 102) installation area contacts the transaxle, readjust the SST to prevent damaging the part.**

5) Tighten the nuts and bolts.

Tightening torque
- **Bolt: Part number: 9YA02 1440, or M14×1.5 bolt, length to 100 mm {3.94 in}**
  40—52 N·m {4.1—5.3 kgf·m, 30—38 ft·lbf}
- **Nut: 49 L010 104**
  140—160 N·m {15—16 kgf·m, 104—118 ft·lbf}




bfw2za00000313

6) Assemble the SSTs using part number: 9YA02 1015, or M10×1.5 bolts, length to 35 mm {1.4 in}.

A : Part number: 9YA02 1015, or M10×1.5 bolt, length to 35 mm {1.4 in}

Tightening torque
38—52 N·m {3.9—5.3 kgf·m, 29—38 ft·lbf}



bfw2za00000314


(2) Using chain hoists, install the transaxle to the SST (engine stand) using part number: 9YA02 A220, or M12×1.75 bolts, length to 40 mm {1.6 in}.

Caution
- **When installing the transaxle to the SST (engine stand) using chain hoists, be careful not to allow the transaxle (oil cooler in particular) to contact the SST (engine stand). If the transaxle contacts the SST, check the areas that made contact and replace damaged parts with new ones.**

Note
- Tighten the four locations with bolts and securely install the transaxle to the SST (engine stand).


A : Part number: 9YA02 A220, or M12×1.75 bolt, length to 40 mm {1.6 in}

Tightening torque
88—118 N·m {9.0—12 kgf·m, 65—87 ft·lbf}




bfw2za00000315

(3) Remove the SSTs.
A : Part number: 9YA02 1015, or M10×1.5 bolt, length to 35 mm {1.4 in}



bfw2za00000316


6. Remove the converter housing using the following procedure:




bfw2za00000317

(1) Remove the bolts shown in the figure.


Caution
- **Sealant has been applied to the removed bolts. If the bolts are reused it could cause ATF leakage, therefore when performing assembly use new bolts.**


bfw2za00000075


(2) Remove the bolts shown in the figure.


bfw2za00000076

(3) Lightly tap the converter housing using a plastic hammer to remove it.




bfw2za00000318



bfw2za00000319


(4) Remove the O-rings.

1	25 bolts
2	Converter housing
3	O-ring (oil pump)
4	O-ring (oil cooler oil passage)




bfw2za00000320

7. Remove the baffle plate.




bfw2za00000321

8. Remove the oil pump using the following procedure:



azzjjw00000348


(1) Remove the bolts shown in the figure.



azzjjw00000349


(2) Remove the oil pump.

1	7 bolts
2	Oil pump




azzjjw00000350

9. Remove the thrust needle bearing.




bfw2za00000322

10. Remove the high clutch component and low clutch component.



azzjjw00000352


11. Remove the turbine shaft.



azzjjw00000353


12. Remove the D-ring and seal rings from the turbine shaft using the procedure in the figure:

1	D-ring
2	Seal ring




bfw2za00000323


13. Remove the thrust needle bearing.


azzjjw00000355


14. Remove the high clutch hub.


azzjjw00000356


15. Remove the thrust needle bearing.


azzjjw00000357

16. Remove the low clutch hub.



azzjjw00000358

17. Remove the thrust needle bearing.




azzjjw00000359

18. Remove the ring gear and differential.




bfw2za00000077

19. Remove the oil pipe.



azzjjw00000361

20. Remove the secondary gear and output gear.




azzjjw00000362

21. Remove the roll pin using the following procedure:
    (1) Verify that the parking shift lever component is in the P position.

Caution
- **If the parking shift lever component is at a position other than P, shift the parking shift lever component to the P position.**


A : Parking shift lever component
B : Manual plate component
C : Detent bracket component




azzjjw00001376

(2) Remove the roll pin shown in the figure using a pin punch.


Note
- Use a pin punch with an end outer diameter of 3 mm {0.119 in} or more, and within 4 mm {0.157 in}.


azzjjw00001370




bfw2za00000324

22. Remove the parking shift lever component.



azzjjw00000367

23. Remove the oil seal.



bfw2za00000325

Caution
- **If the washer comes off together when the oil seal is removed, clean the washer and assemble it.**
  A: Washer




azzjjw00001372

24. Assemble a new oil seal using the following procedure:


Caution
- **If an oil seal is reused it could cause ATF leakage, therefore use a new oil seal.**

(1) Apply ATF (ATF FZ) to the engagement area of the new oil seal and transaxle case.
(2) Apply ATF (ATF FZ) to the lip of the new oil seal.
(3) Assemble the new oil seal to the position shown in the figure using the SSTs.



bfw2za00000326


A : –0.3—0.3 mm {–0.01—0.01 in}




bfw2za00000327

25. Assemble the parking shift lever component.

Note
- Pass the end of the parking shift lever component through the assembly hole (radial needle bearing) of the transaxle case, and assemble it to the manual plate component.




azzjjw00000367



bfw2za00000328

26. Assemble a new roll pin using the following procedure:
    (1) Set the manual plate component and parking shift lever component as shown in the figure and align with the roll pin hole.


A : Roll pin hole
B : Manual plate component
C : Parking shift lever component
D : Detent bracket component



bfw2za00000329


    (2) Assemble the new roll pin to the position shown in the figure using a pin punch.

Note
- Use a pin punch with an end outer diameter of 5 mm {0.197 in} or more.




bfw2za00000330

A : 0—1 mm {0—0.03 in}




bfw2za00000331

27. Assemble the secondary gear and output gear.



azzjjw00000362




bfw2za00000332

28. Assemble the oil pipe.


Caution

- **Do not assemble the oil pipe using a tool such as a hammer to prevent damaging the part. For the oil pipe assembly, it is better to only use your hands to put the oil pipe into the output gear.**




azzjjw00000361

29. Assemble the ring gear and differential.




bfw2za00000077



bfw2za00000333

30. Assemble the thrust needle bearing.

Note
- Thrust needle bearing size: Outer diameter approx. 80.3 mm {3.16 in}



azzjjw00000385


31. Assemble a new D-ring and new seal rings to the turbine shaft using the following procedure:

Caution
- **If a D-ring is reused it could cause ATF leakage, therefore use a new D-ring.**
- **If a seal ring is reused it could cause ATF leakage, therefore use a new seal ring.**

(1) Apply ATF (ATF FZ) to the new D-ring and new seal rings.


(2) Assemble the new D-ring and new seal rings to the turbine shaft using the procedure shown in the figure:

1	Seal ring (outer diameter approx. 24.4 mm {0.961 in}, thickness approx. 1.5 mm {0.059 in})
2	D-ring (outer diameter approx. 16.4 mm {0.646 in}, thickness approx. 2.4 mm {0.094 in})




bfw2za00000334

32. Assemble together the high clutch component and low clutch component, turbine shaft, high clutch hub, low clutch hub, and thrust needle bearing using the following procedure:
(1) Assemble the parts using the procedure shown in the figure:



azzjjw00001415


Note
- For the high clutch hub and low clutch hub assembly, assembly is easier if the work is performed using the following procedure:
  — High clutch hub
    1. Place the assembled parts on the workbench with the high clutch component and low clutch component situated sideways.


azzjjw00000389


2. While rotating the high clutch hub, engage the splines of each of the high clutch drive plates one by one, and assemble.

— Low clutch hub

1. Place the assembled parts on the workbench with the high clutch component and low clutch component situated sideways.




bfw2za00000335



bfw2za00000336

2. While rotating the low clutch hub, engage the splines of each of the low clutch drive plates one by one, and assemble.



bfw2za00000337

1	High clutch component and low clutch component
2	Turbine shaft
3	Thrust needle bearing (outer diameter approx. 37.3 mm {1.47 in})
4	High clutch hub
5	Thrust needle bearing (outer diameter approx. 51.3 mm {2.02 in})
6	Low clutch hub

(2) To verify that the parts are securely assembled together, measure the distance shown in the figure.


Note

- Recommended measuring instrument: Vernier caliper

Specification

63.9—66.0 mm {2.52—2.59 in}


- If not within the specification, disassemble the assembled parts and reassemble.



azzjjw00000388

33. Assemble the parts which were assembled together in Step 32 using the following procedure:

(1) Assemble the parts assembled together in Step 32.




azzjjw00000393

(2) To verify that the parts are securely assembled, measure the distance shown in the figure.

Note
- Recommended measuring instrument: Depth gauge, straight edge ruler

A : Transaxle case end (alignment surface with converter housing)
B : High clutch component and low clutch component end




bfw2za00000338

Specification
11.6—14.8 mm {0.457—0.582 in}

- If not within the specification, remove the parts and perform re-assembly from Step 32.

Note
- Measurement method

1) Set two straight edge rulers along the alignment surface of the transaxle case with the converter housing as shown in the figure.
2) Measure the positions (2 locations) shown in the figure using a depth gauge and calculate the average value.




A : Straight edge ruler

3) Subtract the thickness of the straight edge ruler from the average value.

bfw2za00000339


34. Assemble the thrust needle bearing.

Note
- Thrust needle bearing size: Outer diameter approx. 72.7 mm {2.86 in}




azzjjw00000396

35. Assemble the oil pump using the following procedure:



azzjjw00000397

(1) Assemble the oil pump.




azzjjw00000350

(2) Assemble and tighten the bolts shown in the figure.

Note
- Bolt size: M8×1.25 bolt, length to approx. 31 mm {1.2 in}


Tightening torque
19—25 N·m {2.0—2.5 kgf·m, 15—18 ft·lbf}




azzjjw00000398

1	Oil pump
2	7 bolts (M8×1.25 bolt, length to approx. 31 mm {1.2 in})

36. Assemble the baffle plate.



bfw2za00000321



bfw2za00000340

37. Assemble the converter housing using the following procedure:

* : Of the 25 bolts, 6 are applied with sealant


(1) Assemble new O-rings using the following procedure:

Caution


- **If an O-ring is reused it could cause ATF leakage, therefore use a new O-ring.**

1) Apply ATF (ATF FZ) to the new O-rings.

2) Assemble the new O-rings.




bfw2za00000341



bfw2za00000342

1	O-ring (outer diameter approx. 15.6 mm {0.614 in}, thickness approx. 2.4 mm {0.094 in})
2	O-ring (outer diameter approx. 73.3 mm {2.89 in}, thickness approx. 3.0 mm {0.12 in})

(2) Remove any remaining old sealant on the contact surfaces of the transaxle case and converter housing, and degrease the contact surfaces.




bfw2za00000343

Caution
- **When degreasing and if degreaser is used, use a rag saturated with degreaser and be careful not to allow degreaser to penetrate the interior of the transaxle.**
  In addition, after degreasing, visually verify that there is no foreign matter (such as old sealant, cloth fibers) which has penetrated the interior of the transaxle.

(3) Apply sealant (silicone sealant TB1217E or equivalent) to the transaxle case.


Caution
- **If sealant is applied excessively or applied to a part other than the indicated part, the O-ring could deform and the sealant could penetrate the oil passage. Apply an appropriate amount of sealant to the indicated part.**

Note
- Sealant application amount (bead thickness): φ 1.8—2.5 mm {0.071—0.098 in}




azzjjw00000331

(4) Assemble the converter housing before the applied sealant starts to harden.


bfw2za00000319

(5) Assemble and temporarily tighten the bolts to the positions shown in the figure.


Note
- Bolt size: M8×1.25 bolt, length to approx. 28 mm {1.1 in}


bfw2za00000078

(6) Assemble and temporarily tighten the new bolts to the positions shown in the figure.


Caution
- **The bolts for the assembly are applied with sealant. If the bolts are reused it could cause ATF leakage, therefore use new bolts.**

Note
- Bolt size: M8×1.25 bolt, length to approx. 28 mm {1.1 in} (with sealant applied)


bfw2za00000079

(7) Tighten the bolts shown in the figure.

Tightening torque
19—25 N·m {2.0—2.5 kgf·m, 15—18 ft·lbf}


bfw2za00000080

1	O-ring (outer diameter approx. 15.6 mm {0.614 in}, thickness approx. 2.4 mm {0.094 in})
2	O-ring (outer diameter approx. 73.3 mm {2.89 in}, thickness approx. 3.0 mm {0.12 in})
3	Converter housing
4	25 bolts * (M8×1.25 bolt, length to approx. 28 mm {1.1 in})


38. Remove the SSTs from the transaxle using the following procedure:

Caution
- **When removing the transaxle from the SST (engine stand) using chain hoists, be careful not to allow the transaxle (oil cooler in particular) to contact the SST (engine stand). If the transaxle contacts the SST, check the areas that made contact and replace damaged parts with new ones.**

(1) Assemble the SSTs using part number: 9YA02 1015, or M10×1.5 bolts, length to 35 mm {1.4 in}.

A : Part number: 9YA02 1015, or M10×1.5 bolt, length to 35 mm {1.4 in}

Tightening torque
38—52 N·m {3.9—5.3 kgf·m, 29—38 ft·lbf}




bfw2za00000344

(2) Using chain hoists, remove the SST (engine stand) from the transaxle.

Caution
- **When removing the transaxle from the SST (engine stand) using chain hoists, be careful not to allow the transaxle (oil cooler in particular) to contact the SST (engine stand). If the transaxle contacts the SST, check the areas that made contact and replace damaged parts with new ones.**


A : Part number: 9YA02 A220, or M12×1.75 bolt, length to 40 mm {1.6 in}



bfw2za00000315

(3) Remove the SSTs.


A : Part number: 9YA02 1015, or M10×1.5 bolt, length to 35 mm {1.4 in}



bfw2za00000345

(4) Disassemble the SST.

A : Part number: 9YA02 1440, or M14×1.5 bolt, length to 100 mm {3.94 in}




bfw2za00000346

39. Assemble the torque converter using the following procedure:


(1) Apply ATF (ATF FZ) to the end of the starter shaft of the oil pump shown in the figure.

Caution

- **Accurately perform to protect the torque converter internal parts.**


bfw2za00000347

(2) Assemble the torque converter so that the two surfaces of the notch on the end of the torque converter engage the inner rotor of the oil pump.




bfw2za00000348

(3) To verify that the torque converter is securely assembled, measure the distance shown in the figure.

Note
- Recommended measuring instrument: Depth gauge, straight edge ruler

A : Converter housing end (alignment surface with engine)
B : Torque converter stud bolt seat



azzjjw00001418

Specification
17.35 mm {0.683 in} or more


- If not within the specification, remove the torque converter and reassemble.

Note
- Measurement method

1) Set two straight edge rulers along the alignment surface of the converter housing with the engine as shown in the figure.
2) Measure the positions (2 locations) shown in the figure using a depth gauge and calculate the average value.

A : Straight edge ruler


3) Subtract the thickness of the straight edge ruler from the average value.



bfw2za00000349

40. Assemble and tighten the stud bolts.


Tightening torque
15—25 N·m {1.6—2.5 kgf·m, 12—18 ft·lbf}



azzjjw00000341

41. Assemble the electric AT oil pump using the following procedure (only vehicles with i-stop):

Caution
- **Do not drop or apply an impact to the electric AT oil pump. Replace the electric AT oil pump with a new one if it was dropped or received an impact.**
- **Do not disassemble the electric AT oil pump. Replace the electric AT oil pump if it has been disassembled.**
- **To prevent a malfunction, be careful not to allow sealant or foreign matter to penetrate the electric AT oil pump and the interior of the transaxle.**
- **Be careful not to scratch or damage the aligning surfaces of the electric AT oil pump and end cover and the O-ring assembly area so as not to cause ATF leakage.**




bfw2za00000350

(1) Assemble new O-rings using the following procedure:

Caution
- **If an O-ring is reused it could cause ATF leakage, therefore use a new O-ring.**

Note
- O-ring size: Outer diameter approx. 15.6 mm {0.614 in}, thickness approx. 2.4 mm {0.094 in}


1) Apply ATF (ATF FZ) to the new O-rings.
2) Assemble the new O-rings.



bfw2za00000351

(2) Remove any remaining old sealant on the contact surfaces of the end cover and electric AT oil pump, and clean degrease the contact surfaces.


Caution
- **When degreasing and if degreaser is used, use a rag saturated with degreaser and be careful not to allow degreaser to penetrate the oil passage.**
  In addition, after degreasing, visually verify that there is no foreign matter (such as old sealant, cloth fibers) which has penetrated the oil passage.


azzjjw00001460

(3) Apply sealant (silicone sealant TB1217E or equivalent) to the electric AT oil pump.


Caution
- **If sealant is applied excessively or applied to a part other than the indicated part, the O-ring could deform and the sealant could penetrate the oil passage. Apply an appropriate amount of sealant to the indicated part.**

Note
- Sealant application amount (bead thickness): φ 0.5—1.5 mm {0.02—0.05 in}



bfw2za00000352

(4) Assemble the electric AT oil pump before the applied sealant starts to harden.



azzjjw00001461

(5) Assemble and tighten the bolts shown in the figure.

Note
- Bolt size: M8×1.25 bolt, length to approx. 25 mm {0.98 in}

Tightening torque
19—25 N·m {2.0—2.5 kgf·m, 15—18 ft·lbf}

1	O-ring (outer diameter approx. 15.6 mm {0.614 in}, thickness approx. 2.4 mm {0.094 in})
2	Electric AT oil pump
3	3 bolts (M8×1.25 bolt, length to approx. 25 mm {0.98 in})


azzjjw00001462