
RING GEAR AND DIFFERENTIAL DISASSEMBLY [FW6A-EL/FW6AX-EL]

id0517006611z3

Structural View



bfw2za00000556

1	Taper roller bearing (transaxle case side)
2	Taper roller bearing (converter housing side)
3	12 bolts
4	Ring gear
5	Roll pin
6	Pinion shaft

7	Pinion gear
8	Thrust washer
9	Side gear
10	Thrust washer
11	Differential gear case

Disassembly Procedure

1. Perform the following inspection:

Caution

- **If there is no malfunction based on the results of the inspection, it not necessary to disassemble the ring gear and differential.**


- Visual inspection of parts (See VISUAL INSPECTION OF PARTS [FW6A-EL/FW6AX-EL])
- Ring gear and differential inspection (See RING GEAR AND DIFFERENTIAL INSPECTION [FW6A-EL/FW6AX-EL])

- If there is a malfunction, disassemble the ring gear and differential and replace the malfunctioning part with a new part.

2. Remove the taper roller bearing (transaxle case side) using the following procedure:
   (1) Secure the ring gear and differential in a vise.

Caution
- **Insert a protective plate between the vise and the part so as not to damage the part.**


A : Vise




bfw2za00000557

   (2) Remove the taper roller bearing (transaxle case side) using the SST.

A : Vise




azzjjw00000952



bfw2za00000558

   (3) Remove the ring gear and differential from the vise.

A : Vise




azzjjw00001255

3. Remove the taper roller bearing (converter housing side) using the following procedure:
   (1) Secure the ring gear and differential in a vise.

Caution
- **Insert a protective plate between the vise and the part so as not to damage the part.**


A : Vise




azzjjw00001256

(2) Remove the taper roller bearing (converter housing side) using the SST.

A : Vise




bfw2za00000559



bfw2za00000560


(3) Remove the ring gear and differential from the vise.

A : Vise



azzjjw00000958

4. Remove the ring gear using the following procedure:




azzjjw00000959

(1) Secure the ring gear and differential in a vise.

Caution
- **Insert a protective plate between the vise and the part so as not to damage the part.**

A : Vise




azzjjw00000960

(2) Loosen the bolts shown in the figure.


Caution
- **Only loosen the bolts, do not remove them, otherwise the ring gear and differential will fall off.**

Note
- Change the securing position of the ring gear and differential with the vise and loosen all of the bolts shown in the figure.


azzjjw00000961


(3) Remove the ring gear and differential from the vise.

A : Vise




azzjjw00000958


(4) Remove the bolts shown in the figure.


azzjjw00000961

(5) Lightly tap the ring gear with a plastic hammer and remove the ring gear.



bfw2za00000561




azzjjw00000963


1	12 bolts
2	Ring gear

5. Remove the roll pin shown in the figure using a pin punch.

Note
- Use a pin punch with an end outer diameter of 3 mm {0.119 in} or more, and within 4 mm {0.157 in}, and an end length of 50 mm {2.0 in} or more.




azzjjw00001487




bfw2za00001208

6. Remove the pinion shaft.




azzjjw00001489

7. Remove the pinion gears using the following procedure:
   (1) Rotate the pinion gears as shown in the figure.




azzjjw00001490

   (2) Remove the pinion gears.




azzjjw00001491

8. Remove the thrust washers from the pinion gears.




azzjjw00001492

9. Remove the side gears.



azzjjw00001493

10. Remove the thrust washers from the side gears.
11. Clean the disassembled parts. (See AUTOMATIC TRANSAXLE CLEANING.)



azzjjw00001494