
REAR PLANETARY GEAR INSPECTION

id051700662100

Radial Needle Bearing Inspection (In Pinion Gear)

1. Place the rear planetary gear with the front internal gear side pointing upward on a workbench.




azzjjw00001265

2. Rotate the pinion gears by hand and verify that there is no malfunction in the radial needle bearing in the pinion gear (rotation sticking).

Caution
- **Verify for all the pinion gears.**


- If there is a malfunction, disassemble the rear planetary gear and replace the rear planetary carrier with a new one.
  (See REAR PLANETARY GEAR DISASSEMBLY.)
  (See REAR PLANETARY GEAR ASSEMBLY.)



azzjjw00001278


Thrust Needle Bearing Inspection

1. Place the rear planetary gear with the front internal gear side pointing upward on a workbench.




azzjjw00001265

2. Assemble the rear sun gear to the rear planetary gear.




azzjjw00001267


cardiagn.com


bfw2za00000601

3. With a load applied by hand to the rear sun gear, rotate the rear sun gear and verify that there is no malfunction in the thrust needle bearing (rotation sticking).
   - If there is a malfunction, disassemble the rear planetary gear and replace the rear planetary carrier with a new one.
     (See REAR PLANETARY GEAR DISASSEMBLY.)
     (See REAR PLANETARY GEAR ASSEMBLY.)


bfw2za00000602

4. Remove the rear sun gear.


azzjjw00001270


Pinion Washer Inspection
Pinion washer visual inspection

1. Visually verify that all of the following washers are between the pinion gear and planetary carrier for one pinion gear.

Caution
- **Verify for all the pinion gears.**

— Copper washer (outer side): 2
— Iron washer (inner side): 2

A : Copper washer (outer side)
B : Iron washer (inner side)




bfw2za00000603

- Even if one of the washers is damaged, disassemble the rear planetary gear and replace the rear planetary carrier with a new one.
  (See REAR PLANETARY GEAR DISASSEMBLY.)
  (See REAR PLANETARY GEAR ASSEMBLY.)

cardiagn.com

Pinion washer wear inspection

1. Place the rear planetary gear with the front internal gear side pointing downward on a workbench.



azzjjw00001271


2. Measure the gap between the pinion washer and planetary carrier.

Caution
- **Measure for all the pinion gears.**

Note
- Recommended measuring instrument: Thickness gauge

Maximum:
0.879 mm {0.0346 in}

- If it is more than the maximum specification, disassemble the rear planetary gear and replace the rear planetary carrier with a new one.
  (See REAR PLANETARY GEAR DISASSEMBLY.)
  (See REAR PLANETARY GEAR ASSEMBLY.)



bfw2za00000604

cardiagn.com