
REDUCTION PLANETARY GEAR INSPECTION

id051700662200

Radial Needle Bearing Inspection (In Pinion Gear)

1. Place the reduction planetary gear with the rear internal gear side pointing downward on a workbench.




azzjjw00001273

2. Rotate the pinion gears by hand and verify that there is no malfunction in the radial needle bearing in the pinion gear (rotation sticking).

Caution
- **Verify for all the pinion gears.**

- If there is a malfunction, disassemble the reduction planetary gear and replace the reduction planetary carrier with a new one.
  (See REDUCTION PLANETARY GEAR DISASSEMBLY.)
  (See REDUCTION PLANETARY GEAR ASSEMBLY.)



azzjjw00001274

Pinion Washer Inspection

Pinion washer visual inspection


1. Visually verify that all of the following washers are between the pinion gear and planetary carrier for one pinion gear.

Caution
- **Verify for all the pinion gears.**

— Copper washer: 2

A : Copper washer

- Even if one of the washers are damaged, disassemble the reduction planetary gear and replace the reduction planetary carrier with a new one.
  (See REDUCTION PLANETARY GEAR DISASSEMBLY.)
  (See REDUCTION PLANETARY GEAR ASSEMBLY.)




azzjjw00001526

cardiagn.com

Pinion washer wear inspection

1. Place the reduction planetary gear with the rear internal gear side pointing downward on a workbench.



azzjjw00001273


2. Measure the gap between the pinion washer and planetary carrier.

Caution
- **Measure for all the pinion gears.**

Note
- Recommended measuring instrument: Thickness gauge

Maximum:
0.820 mm {0.0322 in}

- If it is more than the maximum specification, disassemble the reduction planetary gear and replace the reduction planetary carrier with a new one.
  (See REDUCTION PLANETARY GEAR DISASSEMBLY.)
  (See REDUCTION PLANETARY GEAR ASSEMBLY.)



azzjjw00001527


Bush Inner Diameter Inspection

1. Measure the inner diameter of the bush shown in the figure.

Note
- When measuring, measure near the center of the bush avoiding the oil groove, and then calculate the average value of the X and Y directions as shown in the figure.
- Recommended measuring instrument: Cylinder gauge or caliper gauge

Maximum:
35.095 mm {1.3816 in}

- If it is more than the maximum specification, disassemble the reduction planetary gear and replace the reduction planetary carrier with a new one.
  (See REDUCTION PLANETARY GEAR DISASSEMBLY.)
  (See REDUCTION PLANETARY GEAR ASSEMBLY.)



azzjjw00001276

cardiagn.com