
SECONDARY GEAR AND OUTPUT GEAR INSPECTION

id051700662300

Taper Roller Bearing Inspection


1. Place the secondary gear and output gear with the output gear side pointing upward on a workbench.




azzjjw00001279

2. Assemble the bearing race to the secondary gear and output gear.

Note
- Bearing race size: Outer diameter approx. 75 mm {3.0 in}




azzjjw00001280



azzjjw00001281


3. With a load applied by hand to the bearing race, rotate the bearing race and verify that there is no malfunction in the taper roller bearing (rotation sticking).
   - If there is a malfunction, disassemble the secondary gear and output gear and replace the taper roller bearing with a new one.
     (See SECONDARY GEAR AND OUTPUT GEAR DISASSEMBLY.)
     (See SECONDARY GEAR AND OUTPUT GEAR ASSEMBLY.)



azzjjw00001282


cardiagn.com

4. Remove the bearing race.



azzjjw00001283


5. Place the secondary gear and output gear with the output gear side pointing downward on a workbench.




azzjjw00001284

6. Assemble the bearing race to the secondary gear and output gear.

Note
- Bearing race size: Outer diameter approx. 70 mm {2.8 in}




azzjjw00001285



bfw2za00000605


cardiagn.com

7. With a load applied by hand to the bearing race, rotate the bearing race and verify that there is no malfunction in the taper roller bearing (rotation sticking).
   - If there is a malfunction, disassemble the secondary gear and output gear and replace the taper roller bearing with a new one.
     (See SECONDARY GEAR AND OUTPUT GEAR DISASSEMBLY.)
     (See SECONDARY GEAR AND OUTPUT GEAR ASSEMBLY.)



bfw2za00000606

8. Remove the bearing race.



azzjjw00001288

cardiagn.com