LOW CLUTCH HUB INSPECTION

id051700663100

Bush Inner Diameter Inspection


1. Measure the inner diameter of bush in two locations shown in the figure.

Note

- When measuring, measure near the center of the bush avoiding the oil groove, and then calculate the average value of the X and Y directions as shown in the figure.
- Recommended measuring instrument: Cylinder gauge or caliper gauge

Maximum:
31.270 mm {1.2311 in}

- If it is more than the maximum specification, replace the low clutch hub with a new one.



bfw2za00000611