TORQUE CONVERTER CLEANING

id051700661500


Cleaning Outside of Torque Converter

1. Plug to the position shown in the figure with packing tape.

Caution

- **If foreign matter penetrates the torque converter, it could cause an operation malfunction. Therefore, when cleaning the outside of the torque converter, plug the position shown in the figure with packing tape.**

A : Plug (packing tape)



azzjjw00001502


2. Wipe off foreign matter on the exterior of the torque converter using a cloth.Depending on the condition, clean using detergent and dry using compressed air.

Warning

- **Always wear protective eye wear when using compressed air. Otherwise, degreaser or dirt particles blown off by the compressed air could get into the eyes.**

3. Throw away the used packing tape used as the plug.


A : Plug (packing tape)



azzjjw00001503

Torque Converter Flushing

1. Prepare a clean oil receptacle.




azzjjw00001062


2. Add new ATF (ATF FZ) to the torque converter from the position shown in the figure.

Note

- Because the ATF in the torque converter needs to be well stirred, when adding ATF do not completely fill the torque converter. Fill only about halfway.


azzjjw00001063


3. Shake the torque converter to stir the ATF in the torque converter.


azzjjw00001064

4. Drain the ATF in the torque converter into the clean oil receptacle.

Note
- While shaking the torque converter, drain as much of the ATF in the torque converter as possible.

5. Verify that none of the following foreign matter is mixed in with the ATF drained from the torque converter:
   - Large metal fragments of Φ0.5 mm {0.02 in} or more that cannot pass through the oil strainer
   - Fibrous clutch or brake facing
6. Dispose of the ATF in the oil receptacle and clean the oil receptacle.
7. Perform Steps 2 — 6 three times.
   - If metal fragments and facing material continue to appear in the drained ATF from the torque converter after it is flushed repeatedly, replace the torque converter with a new one.


azzjjw00001065