OIL COOLER CLEANING

id051700661600


Cleaning Outside of Oil Cooler

1. Plug the positions shown in the figure with packing tape.

Caution

- **If foreign matter penetrates the oil cooler, it could cause an operation malfunction. Therefore, when cleaning the outside of the oil cooler, plug the positions shown in the figure with packing tape.**

A : Plugs (packing tape)



azzjjw00001504


2. Wipe off foreign matter on teh exterior of the torque converter using a cloth. Depending on the condition, clean using detergent and dry using compressed air.

Warning

- **Always wear protective eye wear when using compressed air. Otherwise, degreaser or dirt particles blown off by the compressed air could get into the eyes.**

3. Throw away the used packing tape used as the plugs.

A : Plugs (packing tape)



azzjjw00001505


Oil Cooler Flushing (Water Passage)

1. Plug the positions (oil passage) shown in the figure with packing tape.

Caution


- **If engine coolant or water penetrates the oil cooler (in oil passage), it could cause an operation malfunction. Therefore, when flushing the oil cooler (water passage), plug the positions (oil passage) shown in the figure with packing tape.**

A : Plugs (packing tape)




azzjjw00001506

2. Prepare a clean oil receptacle.



azzjjw00001066

3. Add water to the oil cooler from the water passage shown in the figure.



azzjjw00001507


4. Blow compressed air into the water passage shown in the figure and drain the engine coolant and water in the oil cooler.

Warning
- **Always wear protective eye wear when using the air compressor. Otherwise, engine coolant, water, or dirt particles blown off by the air compressor could get into the eyes.**

Caution
- **Perform the work at a position where the engine coolant and water in the oil cooler can be drained into a clean oil receptacle.**
- **To prevent damage to parts, always use an air compressor which is adjusted to the indicated pressure.**

Compressed air pressure

150—200 kPa {1.53—2.03 kgf/cm^2, 21.8—29.0 psi}




azzjjw00001508

5. Verify that none of the following foreign matter is mixed in with the engine coolant and water drained from the oil cooler.
   - Rust or water stain due to deterioration of engine coolant
   - Engine oil
   - Fragments of cooling system parts (plastic, metal, or rubber fragments)
6. Dispose of the engine coolant and water in the oil receptacle and clean the oil receptacle.
7. Perform Steps 3 — 6 three times.
   - If foreign matter remains even after the oil cooler is flushed repeatedly, replace the oil cooler with a new one and inspect the cooling system part.

Note
- For the cooling system part inspection, verify the Workshop Manual.

8. Throw away the used packing tape used as the plugs.

A : Plugs (packing tape)



azzjjw00001509


Oil Cooler Flushing (Oil Passage)

1. Plug the positions (water passage) shown in the figure with packing tape.

Caution


- **If ATF penetrates the oil cooler (in water passage), it could cause an operation malfunction. Therefore, when flushing the oil cooler (oil passage), plug the positions (water passage) shown in the figure with packing tape.**

A : Plugs (packing tape)




azzjjw00001510

2. Prepare a clean oil receptacle.


azzjjw00001066

3. Add new ATF (ATF FZ) to the oil cooler from the oil passage shown in the figure.


azzjjw00001511


4. Blow compressed air into the oil passage shown in the figure and drain the ATF in the oil cooler.

Warning

- **Always wear protective eye wear when using the air compressor. Otherwise, ATF or dirt particles blown off by the air compressor could get into the eyes.**


Caution
- **Perform the work at a position where the ATF in the oil cooler can be drained into a clean oil receptacle.**
- **To prevent damage to parts, always use an air compressor which is adjusted to the indicated pressure.**

Compressed air pressure
491—882 kPa {5.01—8.99 kgf/cm^2, 71.3—127.0 psi}


azzjjw00001512

5. Verify that none of the following foreign matter is mixed in with the ATF drained from the oil cooler.
   - Large metal fragments of Φ0.5 mm {0.02 in} or more that cannot pass through the oil strainer
   - Fibrous clutch or brake facing
6. Dispose of the ATF in the oil receptacle and clean the oil receptacle.
7. Perform Steps 3 — 6 three times.
   - If foreign matter such as metal fragments or facing remain even after the oil cooler is flushed repeatedly, replace the oil cooler with a new one.
8. Throw away the used packing tape used as the plugs.

A : Plugs (packing tape)



azzjjw00001513