





G16		G18									



Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.







: FRONT HARNESS
: REAR HARNESS