HOW TO USE THIS MANUAL

id000000800100

Range of Topics

No.	TROUBLESHOOTING ITEM	DESCRIPTION	Page
1	Melting of main or other fuses		
	MIL comes on		(See 01-03-7 NO.2 MIL COMES ON) (See 01-03-8 NO. 3 WILL NOT CRANK)
5	Engine stalls.	After start/at idle	