DTC P2226:00 [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0102q1159300

Note
- To determine the malfunctioning part, proceed with the diagnostics from "Function Inspection Using M-MDS".

Details On DTCs

DESCRIPTION	**BARO sensor range/performance problem**	
DETECTION CONDITION	Determination conditions	• Communication error between BARO sensor and PCM • Non-volatile memory error in BARO sensor
	Preconditions	• Battery voltage: **10.5—16 V** *1 *1: Value can be verified by displaying PIDs using M-MDS
	Malfunction determination period	• **5 s** period
	Drive cycle	• 1
	Self test type	• CMDTC self test, KOEO self test, KOER self test
	Sensor used	• BARO sensor (built-into PCM)
FAIL-SAFE FUNCTION	• Fixes the barometric pressure for the engine control at **101.32 kPa {1.0332 kgf/cm^2, 14.695 psi}**.	
VEHICLE STATUS WHEN DTCs ARE OUTPUT	• Not applicable	
POSSIBLE CAUSE	• BARO sensor (built-into PCM) malfunction • PCM malfunction	

System Wiring Diagram
- Not applicable

Function Explanation (DTC Detection Outline)
- If there is a communication error between the BARO sensor and the CPU or a malfunction in the non-volatile memory inside the BARO sensor, the PCM stores a DTC.

Repeatability Verification Procedure
1. Not applicable

PID Item/Simulation Item Used In Diagnosis
- Not applicable

Function Inspection Using M-MDS

STEP	INSPECTION	RESULTS	ACTION
1	**PURPOSE: VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	**PURPOSE: RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture function of the PC. • Record the snapshot data on the repair order.	—	Go to the troubleshooting procedure to perform the procedure from Step 1.

Troubleshooting Diagnostic Procedure
Intention of troubleshooting procedure
- Step 1
  - — Perform a unit inspection of the BARO sensor.

- Step 2—3
  — Verify that the primary malfunction is resolved and there are no other malfunctions.

STEP	INSPECTION	RESULTS	ACTION
1	**PURPOSE: DETERMINE INTEGRITY OF BARO SENSOR** • Inspect the BARO sensor. (See BAROMETRIC PRESSURE (BARO) SENSOR INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) • Is there any malfunction?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
		No	Go to the next step.
2	**PURPOSE: PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS PCM** • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) • Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) • Is the same DTC present?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
		No	Go to the next step.
3	**PURPOSE: VERIFY IF THERE IS ANY OTHER MALFUNCTION** • Is any other DTC or pending code stored?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
		No	DTC troubleshooting completed.