## DTC P0610:00 [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0102q1706000

| DTC P0610:00 | PCM vehicle configuration error |
|---|---|
| DETECTION CONDITION | • PCM data configuration error.<br>**Diagnostic support note**<br>• This is a continuous monitor (CCM).<br>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.<br>• FREEZE FRAME DATA/Snapshot data is available.<br>• DTC is stored in the PCM memory. |
| FAIL-SAFE FUNCTION | Not applicable |
| POSSIBLE CAUSE | • Configuration procedure has not been completed<br>• PCM connector or terminals malfunction<br>• PCM malfunction |
| SYSTEM WIRING DIAGRAM | Not applicable |

### Diagnostic Procedure

| STEP | INSPECTION | | ACTION |
|---|---|---|---|
| 1 | **VERIFY FREEZE FRAME DATA/SNAPSHOT DATA HAS BEEN RECORDED**<br>• Has the FREEZE FRAME DATA/snapshot data been recorded? | Yes | Go to the next step. |
| | | No | Record the FREEZE FRAME DATA/snapshot data on the repair order, then go to the next step. |
| 2 | **VERIFY RELATED SERVICE INFORMATION AVAILABILITY**<br>• Verify related Service Information availability.<br>• Is any related Service Information available? | Yes | Perform repair or diagnosis according to the available Service Information.<br>• If the vehicle is not repaired, go to the next step. |
| | | No | Go to the next step. |
| 3 | **PERFORM PCM CONFIGURATION (USING READ/WRITE FUNCTION)**<br>• Perform the PCM configuration (using read/write function).<br>(See PCM CONFIGURATION (USING READ/WRITE FUNCTION) [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>• Clear the DTC from the PCM memory using the M-MDS.<br>(See AFTER REPAIR PROCEDURE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>• Perform the KOEO or KOER self test.<br>(See KOEO/KOER SELF TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>• Is the same DTC present? | Yes | Go to the next step. |
| | | No | Go to Step 6. |
| 4 | **INSPECT PCM CONNECTOR CONDITION**<br>• Switch the ignition off.<br>• Disconnect the PCM connector.<br>• Inspect for poor connection (such as damaged/pulled-out pins, corrosion).<br>• Is there any malfunction? | Yes | Repair or replace the connector and/or terminals, then go to the next step. |
| | | No | Perform the PCM configuration (using read/write function) again.<br>(See PCM CONFIGURATION (USING READ/WRITE FUNCTION) [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>• If the malfunction recurs, perform the PCM configuration (using as-built data).<br>(See PCM CONFIGURATION (USING AS-BUILT DATA) [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>Go to the next step. |

| STEP | INSPECTION | | ACTION |
|---|---|---|---|
| 5 | **VERIFY DTC TROUBLESHOOTING COMPLETED**<br>• Always reconnect all disconnected connectors.<br>• Clear the DTC from the PCM memory using the M-MDS.<br>(See AFTER REPAIR PROCEDURE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>• Perform the KOEO or KOER self test.<br>(See KOEO/KOER SELF TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>• Is the same DTC present? | Yes | Replace the PCM, then go to the next step.<br>(See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) |
| | | No | Go to the next step. |
| 6 | **VERIFY AFTER REPAIR PROCEDURE**<br>• Perform the “AFTER REPAIR PROCEDURE”.<br>(See AFTER REPAIR PROCEDURE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)<br>• Are any DTCs present? | Yes | Go to the applicable DTC inspection.<br>(See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) |
| | | No | DTC troubleshooting completed. |