## AFTER REPAIR PROCEDURE [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0102q1801100

1. Switch the ignition off.
2. Connect the M-MDS to the DLC-2.
3. Switch the ignition ON (engine off).
4. Verify the DTC according to the directions on the M-MDS screen.
   - Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition off for **30 s or more**.

**Caution**
- **Always switch the ignition off after clearing the DTC.**
- **If the engine is accidentally started, disconnect the negative battery cable and reconnect it. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)**

6. Switch the ignition ON (engine on).
7. Verify all accessory loads are off.
8. Start the engine and maintain the engine speed at **2,800—3,200 rpm** until the cooling fan starts running (for A/F sensor and HO2S activation).
9. When the cooling fan starts running, idle the engine.
10. Maintain idle for **30 s or more** after the cooling fan has stopped (for fuel learning).
11. Perform the DTC inspection again and verify that no DTCs are stored. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
12. Switch the ignition off.
13. Disconnect the M-MDS to the DLC-2.