DTC P0219:00 [SKYACTIV-D 1.5]

id0102q2148300

DTC P0219:00	Engine overspeed condition
DETECTION CONDITION	• PCM detects that the engine speed is **5,670 rpm or more**. **Diagnostic support note** • This is an intermittent monitor (other). • The check engine light does not illuminate. • FREEZE FRAME DATA/Snapshot data is not available. • DTC is not stored in the PCM memory.
FAIL-SAFE FUNCTION	Not applicable
POSSIBLE CAUSE	• ATX system malfunction (ATX) — Excessive rotation due to improper gear lock • Malfunction caused by the following driving operations: — Excessive rotation due to improper shift operation — Deceleration using improper gear, and descending slope • Mechanical (engine) malfunction — Fuel injector malfunction • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the PENDING CODE/DTC P0336:00 or P0337:00 also present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC P0336:00 [SKYACTIV-D 1.5].) (See DTC P0337:00 [SKYACTIV-D 1.5].)
		No	Go to the next step.
3	**VERIFY DTC RELATED FUEL SYSTEM PART** • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is a DTC related to a fuel system part stored?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	ATX: • Go to the next step. MTX: • Go to Step 5.
4	**VERIFY ATX RELATED DTC** • Retrieve TCM DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (EW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
		No	Go to the next step.
5	**INSPECT EFFECT OF VEHICLE CONDITION FOR MALFUNCTION** • Verify how the customer drives the vehicle by asking the customer the following: — Improper shift operation — Deceleration using improper gear, and descending slope • Is the use situation as indicated above?	Yes	Explain to the customer that the vehicle is normal. (malfunction due to customer's improper driving operation) If there is a concern with customer's driving, provide the customer some pertinent advice (such as gear selection, how to use manual mode).
		No	Go to the next step.
6	**INSPECT FUEL INJECTOR OPERATION** • Perform the Fuel Injector Operation Inspection. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
7	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Start the engine and warm it up completely. • Drive the vehicle. • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
8	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.