DTC P1200:00 [SKYACTIV-D 1.5]

id0102q2148900

DTC P1200:00	Fuel injection amount learning not completed
DETECTION CONDITION	• Fuel injector injection amount correction is not completed correctly. **Diagnostic support note** • This is an intermittent monitor (other). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA is available. • Snapshot data is not available. • DTC is not stored in the PCM memory.
FAIL-SAFE FUNCTION	• Not applicable
POSSIBLE CAUSE	• Loose connection temporary between DLC-2 and M-MDS while injection amount correction. • Fuel injector injection amount correction procedure has not been completed. • Fuel injector malfunction • Mechanical (engine) malfunction — Improper engine compression • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA on the repair order.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
4	**INSPECT DLC-2 CONNECTION CONDITION** • Switch the ignition off. • Inspect the connection between the DLC-2 and M-MDS, and inspect the terminals for damage, deformation, corrosion, or disconnection. • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 9.
		No	Go to the next step.
5	**INSPECT FUEL INJECTOR** • Inspect the fuel injector. (See FUEL INJECTOR INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Replace the fuel injector, then go to Step 9. (See FUEL INJECTOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
6	**INSPECT ENGINE COMPRESSION** • Inspect the engine compression. (See COMPRESSION INSPECTION [SKYACTIV-D 1.5].) • Are compression pressures within specification? **Specification:** • Compression — Standard: **2,150—2,350 kPa {21.93—23.96 kgf/cm^2, 311.9—340.8 psi} (200 rpm)** — Minimum: **1,800 kPa {18.35 kgf/cm^2, 261.1 psi} (200 rpm)** — Maximum difference between cylinders: **150 kPa {1.53 kgf/cm^2, 21.8 psi} (200 rpm)**	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results, then go to Step 9.
7	**PERFORM FUEL INJECTOR INJECTION AMOUNT CORRECTION** • Perform the “FUEL INJECTOR INJECTION AMOUNT CORRECTION”. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 1.5].) • Start the engine. • Verify the glow indicator light. • Does the glow indicator light illuminate?	Yes	Re-perform the PCM fuel injection amount adjustment. (Perform the “FUEL INJECTOR DATA RESET” and “FUEL INJECTOR CODE PROGRAM” using the M-MDS.) (See FUEL INJECTOR DATA RESET [SKYACTIV-D 1.5].) (See FUEL INJECTOR CODE PROGRAM [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.
8	**VERIFY DTC** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-D 1.5].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If a malfunction occurs, change the learning method (use/do not use M-MDS), and re-implement the “FUEL INJECTOR INJECTION AMOUNT CORRECTION”. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to Step 10.
9	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-D 1.5].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.
10	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.