DTC P1329:00 [SKYACTIV-D 1.5]

id0102q2149200

DTC P1329:00	Common rail pressure higher than desired (engine running)
DETECTION CONDITION	• When the following conditions are met, the common rail fuel pressure value **exceeds 250 MPa {2,549 kgf/cm^2, 36,260 psi}** or the fuel pressure value exceeds the value calculated by the PCM based on the engine speed for a continuous **1 s**. **MONITORING CONDITIONS** — Battery voltage: **8 V or more** — **0.5 s** have elapsed after the ignition was switched ON (engine on) — The following DTCs are not detected: • Fuel pressure sensor: P0191:00, P0192:00, P0193:00 • When the following conditions are met, the common rail fuel pressure value **exceeds 217 MPa {2,213 kgf/cm^2, 31,473 psi}** or the fuel pressure value exceeds the value calculated by the PCM based on the engine speed for a continuous **60 s**. **MONITORING CONDITIONS** — Battery voltage: **8 V or more** — **0.5 s** have elapsed after the ignition was switched ON (engine on) — The following DTCs are not detected: • Fuel pressure sensor: P0191:00, P0192:00, P0193:00 **Diagnostic support note** • This is an intermittent monitor (fuel system). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• Limits the engine torque or the upper limit of the engine speed.
POSSIBLE CAUSE	• Fuel pressure relief valve malfunction • Fuel pressure sensor malfunction • Suction control valve malfunction • Fuel pipe perforation or breakage (improper connection) • Fuel filter clogged (The PCM corrects the fuel pressure in the direction of increase via feedback control in response to a fuel pressure decrease due to temporary clogging. If the clogging is cleared, a DTC is detected because fuel pressure increases to the threshold or more.) • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**RECORD FREEZE FRAME DATA/SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (fuel system related) on the repair order.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
3	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
4	**INSPECT FUEL PRESSURE RELIEF VALVE** • Inspect the fuel pressure relief valve. (See FUEL PRESSURE RELIEF VALVE INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Replace the common rail, then go to Step 9. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
5	**INSPECT FUEL PRESSURE SENSOR** • Inspect the fuel pressure sensor. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Replace the common rail, then go to Step 9. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
6	**INSPECT SUCTION CONTROL VALVE** • Inspect the suction control valve. (See SUCTION CONTROL VALVE INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Replace the suction control valve, then go to Step 9. (See SUCTION CONTROL VALVE REMOVAL/ INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
7	**INSPECT FUEL PIPE** • Inspect the fuel pipe installation condition. (See FUEL SYSTEM LOCATION INDEX [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Install the fuel pipe properly, then go to Step 9.
		No	Go to the next step.
8	**INSPECT FUEL FILTER** • Inspect the fuel filter for clogging. (See FUEL FILTER INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to the next step. (See FUEL FILTER REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
9	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Start the engine and warm it up completely. **Caution** **• While performing this step, always operate the vehicle in a safe and lawful manner.** **• When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later.** • Drive the vehicle under the FREEZE FRAME DATA/snapshot data condition. • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.
10	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.