DTC P1676:00 [SKYACTIV-D 1.5]

id0102q2149900

DTC P1676:00	Fuel injector code mistakenly programmed
DETECTION CONDITION	• The fuel injector identification number is mistakenly programmed into the PCM for a continuous 1 s when the following condition is met. **MONITORING CONDITIONS** — Ignition switched ON (engine off or on) **Diagnostic support note** • This is an intermittent monitor (fuel system). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• Limits the engine torque or the upper limit of the engine speed. • Inhibits the auto DPF regeneration control. • Fully open the intake shutter valve. • Inhibits the compulsory DPF regeneration control. • Inhibits the EGR control. • PCM restricts engine-transaxle integration control. (ATX) • Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	• Fuel injector code program is not performed correctly. • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**RECORD FREEZE FRAME DATA/SNAPSHOT DATA AND DIAGNOSTIC MONITORING TEST RESULTS TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data and DIAGNOSTIC MONITORING TEST RESULTS (fuel system related) on the repair order.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**PERFORM FUEL INJECTOR CODE PROGRAM** • Perform the “FUEL INJECTOR CODE PROGRAM”. (See FUEL INJECTOR CODE PROGRAM [SKYACTIV-D 1.5].) • Is the fuel injector code programmed correctly?	Yes	Go to the next step.
		No	Perform the “FUEL INJECTOR DATA RESET”. (See FUEL INJECTOR DATA RESET [SKYACTIV-D 1.5].) Perform the “FUEL INJECTOR CODE PROGRAM” again. (See FUEL INJECTOR CODE PROGRAM [SKYACTIV-D 1.5].) Go to the next step.
4	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
5	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.