DTC P167B:00 [SKYACTIV-D 1.5]

id0102q2150000

DTC P167B: 00	**Fuel injection amount learning not completed in fuel injection system**
DETECTION CONDITION	• Fuel injector injection amount correction is not completed. **Diagnostic support note** • This is an intermittent monitor (other). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA is available. • Snapshot data is not available. • DTC is not stored in the PCM memory.
FAIL-SAFE FUNCTION	• Not applicable
POSSIBLE CAUSE	• Fuel injector injection amount correction is not completed. • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA on the repair order.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
4	**PERFORM FUEL INJECTOR INJECTION AMOUNT CORRECTION** • Perform the “FUEL INJECTOR INJECTION AMOUNT CORRECTION”. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 1.5].) • Start the engine. • Verify the glow indicator light. • Does the glow indicator light illuminate?	Yes	Re-perform the PCM fuel injection amount adjustment. (Perform the “FUEL INJECTOR DATA RESET” and “FUEL INJECTOR CODE PROGRAM” using the M-MDS.) (See FUEL INJECTOR DATA RESET [SKYACTIV-D 1.5].) (See FUEL INJECTOR CODE PROGRAM [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.
5	**VERIFY DTC** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-D 1.5].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If a malfunction occurs, change the learning method (use/do not use M-MDS), and re-implement the “FUEL INJECTOR INJECTION AMOUNT CORRECTION”. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to Step 7.

STEP	INSPECTION		ACTION
6	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-D 1.5].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.
7	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.