## DTC P2228:00 [SKYACTIV-D 1.5]

id0102q2153200

| DTC P2228:00 | BARO sensor circuit low input |
|---|---|
| DETECTION CONDITION | • The PCM monitors input voltage from the BARO sensor. If the input voltage is **below 1.17 V** for **5 s**, the PCM determines that the BARO sensor circuit has a malfunction.<br>**MONITORING CONDITIONS**<br>— Battery voltage: **8—20 V**<br>— **0.5 s** have elapsed after the ignition was switched ON (engine off or on)<br>**Diagnostic support note**<br>• This is a continuous monitor (CCM).<br>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.<br>• FREEZE FRAME DATA/Snapshot data is available.<br>• DTC is stored in the PCM memory. |
| FAIL-SAFE FUNCTION | • Limits the engine torque or the upper limit of the engine speed.<br>• Inhibits the auto DPF regeneration control.<br>• Inhibits the compulsory DPF regeneration control.<br>• Inhibits the EGR control.<br>• PCM restricts engine-transaxle integration control. (ATX)<br>• Inhibits engine-stop by operating the i-stop function. |
| POSSIBLE CAUSE | • BARO sensor (built-into PCM) malfunction<br>• PCM malfunction |
| SYSTEM WIRING DIAGRAM | Not applicable |

### Diagnostic Procedure

| STEP | INSPECTION | | ACTION |
|---|---|---|---|
| 1 | **RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION**<br><br>**Note**<br>• Recording can be facilitated using the screen capture function of the PC.<br><br>• Record the FREEZE FRAME DATA/snapshot data on the repair order. | — | Go to the next step. |
| 2 | **VERIFY RELATED SERVICE INFORMATION AVAILABILITY**<br>• Verify related Service Information availability.<br>• Is any related Service Information available? | Yes | Perform repair or diagnosis according to the available Service Information.<br>• If the vehicle is not repaired, go to the next step. |
| | | No | Go to the next step. |
| 3 | **INSPECT BARO SENSOR**<br>• Inspect the BARO sensor.<br>(See BAROMETRIC PRESSURE (BARO) SENSOR INSPECTION [SKYACTIV-D 1.5].)<br>• Is there any malfunction? | Yes | Replace the PCM, then go to the next step.<br>(See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) |
| | | No | Go to the next step. |
| 4 | **VERIFY DTC TROUBLESHOOTING COMPLETED**<br>• Clear the DTC from the PCM memory using the M-MDS.<br>(See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].)<br>• Perform the KOEO or KOER self test.<br>(See KOEO/KOER SELF TEST [SKYACTIV-D 1.5].)<br>• Is the same DTC present? | Yes | Replace the PCM, then go to the next step.<br>(See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) |
| | | No | Go to the next step. |
| 5 | **VERIFY AFTER REPAIR PROCEDURE**<br>• Perform the “AFTER REPAIR PROCEDURE”.<br>(See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].)<br>• Are any DTCs present? | Yes | Go to the applicable DTC inspection.<br>(See DTC TABLE [SKYACTIV-D 1.5].) |
| | | No | DTC troubleshooting completed. |