DTC P2463:00 [SKYACTIV-D 1.5]

id0102q2154200

DTC P2463:00	Diesel particulate filter excess accumulation (large)
DETECTION CONDITION	• PCM detects that the soot accumulation amount **above 13 g/l {0.8 lb/ft^3}**. **Diagnostic support note** • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• PCM restricts engine torque. • Inhibits the auto DPF regeneration control. • Inhibits the EGR control. • Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	• Pipe between exhaust gas pressure sensor No.2 and catalytic converter (diesel particulate filter) restriction and/or damaged • Diesel particulate filter restriction and/or damaged • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data on the repair order.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the PENDING CODE/DTC P242F:00 also present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC P242F:00 [SKYACTIV-D 1.5].)
		No	Go to the next step.
4	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Has any DTC other than P2458:00 or P2463:00 been stored?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].) **Note** • When a DTC other than DTC P2458:00 or P2463:00 is stored, compulsory DPF regeneration may be restricted by the PCM control. Perform applicable DTC troubleshooting, and then perform compulsory DPF regeneration.
		No	Go to the next step.

Cardiagn.com

STEP	INSPECTION		ACTION
5	**INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 RELATED PIPE** • Visually inspect the exhaust gas pressure sensor No.2 related pipe for restriction and damaged. (See EXHAUST GAS PRESSURE SENSOR INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 7.
		No	Perform the “FUEL INJECTOR INJECTION AMOUNT CORRECTION” then perform the “COMPULSORY DIESEL PARTICULATE FILTER REGENERATION”. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 1.5].) (See COMPULSORY DIESEL PARTICULATE FILTER REGENERATION [SKYACTIV-D 1.5].) Go to the next step.
6	**VERIFY DTC** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-D 1.5].) • Start the engine and warm it up completely. **Caution** **• While performing this step, always operate the vehicle in a safe and lawful manner.** **• When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later.** • Drive the vehicle under the FREEZE FRAME DATA/snapshot data condition. • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Diesel particulate filter restriction and/or damaged can be considered the cause. • Replace the catalytic converter (diesel particulate filter), then go to the next step. (See EXHAUST SYSTEM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to Step 8.
7	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-D 1.5].) • Start the engine and warm it up completely. **Caution** **• While performing this step, always operate the vehicle in a safe and lawful manner.** **• When the M-MDS is used to observe monitor system status while driving, be sure to have another technician with you, or record the data in the M-MDS using the PID/DATA MONITOR AND RECORD capturing function and inspect later.** • Drive the vehicle under the FREEZE FRAME DATA/snapshot data condition. • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.

cardiagn.com

STEP	INSPECTION		ACTION
8	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Referring to each adjustment procedure, perform fuel injector injection amount correction and then the diesel particulate filter data reset. (See FUEL INJECTOR INJECTION AMOUNT CORRECTION [SKYACTIV-D 1.5].) (See DIESEL PARTICULATE FILTER DATA RESET [SKYACTIV-D 1.5].) DTC troubleshooting completed.

cardiagn.com