
DTC P0342:00 [SKYACTIV-D 1.5]

id0102q2155000

DTC P0342:00	CMP sensor circuit problem
DETECTION CONDITION	• CMP sensor signal is not input **5 times** while the camshaft rotates **11 times** with the following conditions met. **MONITORING CONDITIONS** — Battery voltage: **8 V or more** — **0.5 s** have elapsed after the ignition was switched ON (engine on) **Diagnostic support note** • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• Not applicable
POSSIBLE CAUSE	• CMP sensor connector or terminals malfunction • Short to ground in wiring harness between the following terminals: — CMP sensor terminal C—PCM terminal 1K — CMP sensor terminal A—PCM terminal 1A • PCM connector or terminals malfunction • Short to power supply in wiring harness between CMP sensor terminal A and PCM terminal 1A • CMP sensor circuits are shorted to each other • Open circuit in wiring harness between the following terminals: — CMP sensor terminal C—PCM terminal 1K — CMP sensor terminal A—PCM terminal 1A — CMP sensor terminal B—PCM terminal 1B • CMP sensor malfunction — CMP sensor is dirty — CMP sensor pulse wheel malfunction — Damage to the detection area of the CMP sensor • CKP sensor connector or terminals malfunction • CKP sensor malfunction • Loose timing chain or improper valve timing • PCM malfunction

DTC P0342:00	CMP sensor circuit problem



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS AT TIME OF DTC DETECTION TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture function of the PC. • Record the FREEZE FRAME DATA/snapshot data on the repair order.	—	Go to the next step.
2	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
4	**INSPECT CMP SENSOR CONNECTOR CONDITION** • Switch the ignition off. • Disconnect the CMP sensor connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
5	**INSPECT CMP SENSOR CIRCUIT FOR SHORT TO GROUND** • Verify that the CMP sensor connector is disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: — CMP sensor terminal C — CMP sensor terminal A • Is there continuity?	Yes	If the short to ground circuit could be detected in the wiring harness: • Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: — CMP sensor terminal C—PCM terminal 1K — CMP sensor terminal A—PCM terminal 1A **If there is a common connector:** — Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to ground. — Repair or replace the malfunctioning part. **If there is no common connector:** — Repair or replace the wiring harness which has a short to ground. If the short to ground circuit could not be detected in the wiring harness: • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to Step 14.
		No	Go to the next step.
6	**INSPECT PCM CONNECTOR CONDITION** • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
7	**INSPECT CMP SENSOR SIGNAL CIRCUIT FOR SHORT TO POWER SUPPLY** • Verify that the CMP sensor and PCM connectors are disconnected. • Switch the ignition ON (engine off). **Note** • Another DTC may be stored by the PCM detecting an open circuit. • Measure the voltage at the CMP sensor terminal A (wiring harness-side). • Is the voltage **0 V**?	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between CMP sensor terminal A and PCM terminal 1A. **If there is a common connector:** • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to power supply. • Repair or replace the malfunctioning part. **If there is no common connector:** • Repair or replace the wiring harness which has a short to power supply. Go to Step 14.

STEP	INSPECTION		ACTION
8	**INSPECT CMP SENSOR CIRCUITS FOR SHORT TO EACH OTHER** • Verify that the CMP sensor and PCM connectors are disconnected. • Switch the ignition off. • Inspect for continuity between CMP sensor terminals C, A and B (wiring harness-side). • Is there continuity?	Yes	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: • CMP sensor terminal C—PCM terminal 1K • CMP sensor terminal A—PCM terminal 1A • CMP sensor terminal B—PCM terminal 1B **If there is a common connector:** • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for a short to each other. • Repair or replace the malfunctioning part. **If there is no common connector:** • Repair or replace the wiring harness which has a short to each other. Go to Step 14.
		No	Go to the next step.
9	**INSPECT CMP SENSOR CIRCUIT FOR OPEN CIRCUIT** • Verify that the CMP sensor and PCM connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side): — CMP sensor terminal C—PCM terminal 1K — CMP sensor terminal A—PCM terminal 1A — CMP sensor terminal B—PCM terminal 1B • Is there continuity?	Yes	Go to the next step.
		No	Refer to the wiring diagram and verify whether or not there is a common connector between the following terminals: • CMP sensor terminal C—PCM terminal 1K • CMP sensor terminal A—PCM terminal 1A • CMP sensor terminal B—PCM terminal 1B **If there is a common connector:** • Determine the malfunctioning part by inspecting the common connector and the terminal for corrosion, damage, or pin disconnection, and the common wiring harness for an open circuit. • Repair or replace the malfunctioning part. **If there is no common connector:** • Repair or replace the wiring harness which has an open circuit. Go to Step 14.
10	**INSPECT CMP SENSOR** • Inspect the CMP sensor. (See CAMSHAFT POSITION (CMP) SENSOR INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Replace the CMP sensor, then go to Step 14. (See CAMSHAFT POSITION (CMP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
11	**INSPECT CKP SENSOR CONNECTOR CONDITION** • Switch the ignition off. • Disconnect the CKP sensor connector. • Inspect for poor connection (such as damaged/pulled-out pins, corrosion). • Is there any malfunction?	Yes	Repair or replace the connector and/or terminals, then go to Step 14.
		No	Go to the next step.
12	**INSPECT CKP SENSOR** • Inspect the CKP sensor. (See CRANKSHAFT POSITION (CKP) SENSOR INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Replace the CKP sensor, then go to Step 14. (See CRANKSHAFT POSITION (CKP) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
13	**VERIFY ASSEMBLY CONDITION OF TIMING CHAIN** • Verify the condition of the timing chain assembly (valve timing, looseness, jumping). (See TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) • Is there any malfunction?	Yes	Repair or replace the malfunctioning part. Assemble the timing chain using the correct timing, then go to the next step. (See TIMING CHAIN REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
14	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Start the engine and race it. • Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.
15	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.