DTC P0313:00 [SKYACTIV-D 1.5]

id0102q2156500

DTC P0313:00	**Misfire detected with low fuel**
DETECTION CONDITION	• "Injection amount cumulative value after lowering point E", which is calculated by the PCM, exceeds the threshold value (larger than DTC P115A:00). **Diagnostic support note** • This is an intermittent monitor (other). • The check engine light does not illuminate. • FREEZE FRAME DATA/Snapshot data is not available. • DTC is not stored in the PCM memory.
FAIL-SAFE FUNCTION	• PCM restricts engine torque. • Inhibits the auto DPF regeneration control. • Inhibits the compulsory DPF regeneration control. • Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	• Fuel runout • Fuel gauge (integrated in instrument cluster) malfunction • Fuel gauge sender unit malfunction • PCM malfunction
SYSTEM WIRING DIAGRAM	Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**VERIFY RELATED SERVICE INFORMATION AVAILABILITY** • Verify related Service Information availability. • Is any related Service Information available?	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
2	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the PENDING CODE/DTC P115B:00 also present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC P115B:00 [SKYACTIV-D 1.5].)
		No	Go to the next step.
3	**INSPECT WHETHER MALFUNCTION IS FUEL RUNOUT OR OTHER** • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Switch the ignition off. • Refill the fuel **above 9 L {2 US gal, 2 Imp gal}**. • Start the engine and warm it up completely. • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the DTC P115A:00 or P0313:00 present? **Note** • If the refueling amount is low, the PCM stored DTC P115A:00 or P0313:00 continues.	Yes	Go to the next step.
		No	Any other PENDING CODEs and/or DTCs are present: • Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].) Any other PENDING CODEs and/or DTCs are not present: • The cause of this DTC is low fuel level. — DTC troubleshooting completed.

STEP	INSPECTION		ACTION
4	**REINSPECT WHETHER MALFUNCTION IS FUEL RUNOUT OR OTHER** • Switch the ignition off. • Refill the fuel till fuel level is **above 9 L {2 US gal, 2 Imp gal}**. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Switch the ignition off. • Refill the fuel **above 9 L {2 US gal, 2 Imp gal}**. • Start the engine and warm it up completely. • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the DTC P115A:00 or P0313:00 present?	Yes	Inspect the fuel gauge. (See INSTRUMENT CLUSTER INSPECTION.) • Repair or replace the malfunctioning part according to the inspection results, then go to the next step. (See INSTRUMENT CLUSTER REMOVAL/ INSTALLATION.)
		No	Any other PENDING CODEs and/or DTCs are present: • Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].) Any other PENDING CODEs and/or DTCs are not present: • The cause of this DTC is low fuel level. — DTC troubleshooting completed.
5	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Replace the PCM, then go to the next step. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.
6	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.